
一文搞懂 Linux 网络 Phy 驱动

原创 BSP实战 人人极客社区 2023-11-02 08:08 发表于江苏





人人极客社区

工程师们自己的Linux底层技术社区,分享体系架构、内核、网络、安全和驱动。 302篇原创内容

公众号

- 概述
- 数据结构
 - phy_device
 - phy_driver
 - mii_bus
 - net_device
- phy 设备的注册
- phy 驱动的注册
 - genphy_driver 通用驱动
 - NXP TJA 专有驱动
- 网卡 fec 和 Phy 的协作
 - 自协商配置
 - link 状态读取
 - link 状态通知

Linux BSP实战课 (网络篇) : 数据包的发送过程


Linux BSP实战课(网络篇): 数据包的接收过程

WILL 8201F/FL/FN-VB MILI/RMII MAC


上图来自 瑞昱半导体 (RealTek) 的 RTL8201F 系列网卡 PHY 芯片手册。按OSI 7层网络模型划分,网卡PHY 芯片(图中的RTL8201F)位于物理层,对应的软件层就是本文讨论的 PHY 驱动层;而 MAC 位于 数据链路层,也是通常软件上所说的网卡驱动层,它不是本文的重点,不做展开。另外,可通过 MDIO 接口对 PHY 芯片进行配置(如PHY芯片寄存器读写),而 PHY 和 MAC 通过 MII/RMII 进行数据传输。

PHY芯片通过MII/GMII/RMII/SGMII/XGMII等多种媒体独立接口(介质无关接口)与数据链路层的MAC芯片相连,并通过MDIO接口实现对PHY 状态的监控、配置和管理。

PHY与MAC整体的连接框图:



每个 phy 芯片会创建一个 struct phy_device 类型的设备,对应的有 struct phy_driver 类型的驱动,这两者实际上是挂载在 mdio_bus_type 总线上的,mac 会被注册成 struct net_device。



phy_device

```
struct phy_device {
struct phy_driver *drv; // PHY设备驱动
struct mii_bus *bus; // 对应的MII总线
struct device dev; // 设备文件
u32 phy_id; // PHY ID

struct phy_c45_device_ids c45_ids;
bool is_c45;
```

phy_driver

```
struct phy_driver {

struct mdio_driver_common mdiodrv;

u32 phy_id;

char *name;

u32 phy_id_mask;

u32 features;

u32 flags;

const void *driver_data;

int (*soft_reset)(struct phy_device *phydev);

int (*config_init)(struct phy_device *phydev);

int (*probe)(struct phy_device *phydev);

int (*probe)(struct phy_device *phydev);

int (*resume)(struct phy_device *phydev);

int (*resume)(struct phy_device *phydev);

int (*aneg_done)(struct phy_device *phydev);

int (*aneg_done)(struct phy_device *phydev);

int (*ack_interrupt)(struct phy_device *phydev);

int (*config_intr)(struct phy_device *phydev);

int (*config_intr)(struct phy_device *phydev);

int (*ack_interrupt)(struct phy_device *phydev);

int (*did_interrupt)(struct phy_device *phydev);

int (*finatch_phy_device)(struct phy_device *phydev);

int (*match_phy_device)(struct phy_device *phydev);

int (*ts_info)(struct phy_device *phydev, struct ifreq *ifr);

bool (*rxtstamp)(struct phy_device *dev, struct sk_buff *skb, int type);

void (*txtstamp)(struct phy_device *dev, struct sk_buff *skb, int type);

int (*set_wol)(struct phy_device *dev, struct sk_buff *skb, int type);

int (*get_wol)(struct phy_device *dev, struct ethtool_wolinfo *wol);

void (*link_change_notify)(struct phy_device *dev);

int (*read_mmd)(struct phy_device *dev, int devnum, u16 regnum);
```

mii_bus

net_device

```
unsigned int promiscuity; /* 网络设备接口的混杂模式 */
unsigned int allmulti; /* 网络设备接口的全组播模式 */
struct netdev_hw_addr_list uc; /* 辅助单播MAC地址列表 */
struct netdev_hw_addr_list mc; /* 主mac地址列表 */
struct netdev_hw_addr_list dev_addrs; /* hw设备地址列表 */
unsigned char broadcast[MAX_ADDR_LEN]; /* hw/i-播地址 */
struct netdev_rx_queue *_rx; /* 网络设备接口的数据包接收队列 */
struct netdev_queue *_tx /* 网络设备接口的数据包发送队列 */
unsigned int num_tx_queues; /* 7X队列数 */
unsigned int real_num_tx_queues; /* 当前设备活动的TX队列数 */
unsigned long tx_queue_len; /* 每个队列允许的最大帧 */
unsigned long state; /* 网络设备接口的状态 */
struct net_device_stats stats; /* 网络设备接口的统计情况 */
possible_net_t nd_net; /* 用于执行网络设备所在的命名空间 */
};
```

phy设备的注册

以网卡 Fec 为例,网卡驱动在初始化 fec_probe() 时遍历 dts 的定义,创建相应 struct phy_device 类型的设备,主要步骤为:

- 1. 注册网络设备 net device
- 2. 申请队列和 DMA
- 3. 申请 MDIO 总线
- 4. 创建并注册 Phy 设备

```
. . .
     -> fec_enet_get_queue_num(pdev, &num_tx_qs, &num_rx_qs); // 从设备树获取fsl,num-tx-queue
    -> of_parse_phandle(np, "phy-handle", 0)
    -> fec enet mii init(pdev);
            -> mdiobus register(mdio)
               -> bus->dev.groups = NULL;
               -> device register(&bus->dev);
```

```
-> phydev = get_phy_device(bus, addr);
         ->err = phy_device_register(phydev);
         -> of_mdiobus_register_phy(mdio, child, addr) } // 创建并注册PHY设备
            -> is_c45 = of_device_is_compatible(child, "ethernet-phy-ieee802.3-c45") //
         -> get_phy_id(bus, addr, &phy_id, is_c45, &c45_ids);//通过mdio得到PHY的ID
                      -> dev = kzalloc(sizeof(*dev), GFP KERNEL);
                         dev->dev.release = phy device release;
                         dev->speed = 0:
                         dev->asym pause = 0;
                          dev->addr = addr;
                         -> INIT_WORK(&dev->phy_queue, phy_change); // 曲phy_inter
                          -> request_module(MDIO_MODULE_PREFIX MDIO_ID_FMT, MDIO_ID_AR
                      -> of_node_get(child); //将OF节点与设备结构相关联
                       -> phy->dev.of node = child;
                          -> phydev->bus->phy_map[phydev->addr] = phydev; //添加PHY到
                          -> device_add(&phydev->dev);
------一般来说只要设备树种指定了PHY设备的"reg"属性,后面的流程可以自动忽略 -------
```

内核中有 genphy_driver 通用驱动,以及专有驱动(这里以 NXP TJA 驱动为例),分别如下:

```
static struct phy_driver genphy_driver = {
    .phy_id = 0xffffffff,
    .phy_id_mask = 0xffffffff,
    .name = "Generic PHY",
    .get_features = genphy_read_abilities,
    .suspend = genphy_suspend,
    .resume = genphy_resume,
    .set_loopback = genphy_loopback,
};

static struct phy_driver tjallxx_driver[] = {
    {
        PHY_ID_MATCH_MODEL(PHY_ID_TJA1100),
        .name = "NXP TJA1100",
        .features = PHY_BASIC_T1_FEATURES,
        .probe = tjallxx_probe,
        .soft_reset = tjallxx_config_aneg,
        .config_aneg = tjallxx_config_init,
        .read_status = tjallxx_read_status,
        .get_sqi = tjallxx_get_sqi,
        .get_sqi = tjallxx_get_sqi,
        .get_sqi = max = tjallxx_get_sqi_max,
        .suspend = genphy_suspend,
```

genphy_driver 的 struct phy_driver 的注册过程如下:

module_phy_driver(tja11xx_driver);

.get_sset_count = tja11xx_get_sset_count,

```
phy_init
phy_driver_register()
driver_register(&new_driver->mdiodrv.driver)
bus_add_driver(drv)
driver_attach(drv)
bus_for_each_dev(drv->bus, NULL, drv, __driver_attach)
while ((dev = next_device(&i)) && !error)

/* 循环到注册的 PHY 设备时 */
fn(dev, data) = __driver_attach()

/* 匹配设备和驱动 */
driver_match_device(drv, dev)
mdio_bus_match(dev, drv)
phy_bus_match(dev, drv)

/* 按 phy_id & phy_id_mask 匹配 */
return (phydrv->phy_id & phydrv->phy_id_mask) == (phyde

/* 匹配到设备和驱动, 加载驱动 */
driver_probe_device(drv, dev)
really_probe(dev, drv)
dev->driver = drv; /* 绑定设备的驱动 */
drv->probe(dev) = phy_probe
```

其中一个关键点是 mdio driver 的 probe 函数是一个通用函数 phy_probe:

```
static int phy_probe(struct device *dev)
{
    struct phy_device *phydev = to_phy_device(dev);  // 获取PHY设备
    struct device_driver *drv = phydev->mdio.dev.driver;
    struct phy_driver *phydrv = to_phy_driver(drv);  // 获取PHY驱动
    int err = 0;
```

```
if (!phy_drv_supports_irq(phydrv) && phy_interrupt_is_valid(phydev)) // 设置中断方式
      goto out;
   err = genphy_read_abilities(phydev); //读取状态寄存器来确定 phy 芯片的能力
if (!linkmode_test_bit(ETHTOOL_LINK_MODE_Autoneg_BIT,
   phydev->is_gigabit_capable = 1;
if (linkmode_test_bit(ETHTOOL_LINK_MODE_1000baseT_Full_BIT,
   phydev->is_gigabit_capable = 1;
```

其中通用 phy 驱动会调用函数 genphy_read_abilities 来读取状态寄存器来确定 phy 芯片的能力:

```
genphy_read_abilities()
`-| {
```

```
| val = phy_read(phydev, MII_BMSR); // 读取 mdio 0x01 寄存器来确定 phy 的 10/100M 能力
| linkmode_mod_bit(ETHTOOL_LINK_MODE_Autoneg_BIT, phydev->supported, val & BMSR_ANEGCAPABLE
| linkmode_mod_bit(ETHTOOL_LINK_MODE_100baseT_Full_BIT, phydev->supported, val & BMSR_100FU
| linkmode_mod_bit(ETHTOOL_LINK_MODE_100baseT_Half_BIT, phydev->supported, val & BMSR_10FULL
| linkmode_mod_bit(ETHTOOL_LINK_MODE_10baseT_Full_BIT, phydev->supported, val & BMSR_10FULL
| linkmode_mod_bit(ETHTOOL_LINK_MODE_10baseT_Half_BIT, phydev->supported, val & BMSR_10HALF
| if (val & BMSR_ESTATEN) {
| val = phy_read(phydev, MII_ESTATUS); // 读取 mdio 0x0f 寄存器来确定 phy 的 1000M 能力
| linkmode_mod_bit(ETHTOOL_LINK_MODE_1000baseT_Full_BIT, phydev->supported, val & ESTATUS_1
| linkmode_mod_bit(ETHTOOL_LINK_MODE_1000baseT_Half_BIT, phydev->supported, val & ESTATUS_1
| linkmode_mod_bit(ETHTOOL_LINK_MODE_1000baseT_Full_BIT, phydev->supported, val & ESTATUS_1
| }
| }
| }
```

NXP TJA 专有驱动

NXP TJA 驱动的 struct phy_driver 的注册过程如下:

根据上面的分析,由于存在 phydev->drv->probe,所以会调用其注册的函数 tja11xx_probe。

网卡 fec 和 Phy 的协作

在 linux 内核中,以太网 mac 会被注册成 struct net_device,phy 芯片会被注册成 struct phy_device。 phy_device 的状态怎么传递给 net_device,让其在 link 状态变化时做出对应的配置 改变,这个任务就落在上述的 struct phylink 中介身上。

下面就以 fec 网口驱动为例,展示一下网卡 fec 和 phy 的协作过程。整个 phy 驱动的主要调用流程如下图所示:

一个 phy 驱动的原理其实是非常简单的,一般流程如下:

- 1. 用轮询/中断的方式通过 mdio 总线读取 phy 芯片的状态。
- 2. 在 phy link 状态变化的情况下,正确配置 mac 的状态。(例如:根据 phy 自协商的速率 10/100/1000M 把 mac 配置成对应速率)

phy 芯片状态在 phy 设备注册的时候已经体现,这里详细讲下如何在 phy link 状态变化的情况下,正确配置 mac 的状态。

```
...
  case PHY RUNNING:
 if (needs aneg)
  err = phy_start_aneg(phydev);
  phydev_dbg(phydev, "PHY state change %s -> %s\n",
  if (phydev->drv && phydev->drv->link_change_notify)
```

具体启动 phy 自协商的代码流程如下:

link 状态读取

phy link 状态读取的代码流程如下:

link 状态通知

phy 的 link 状态变化怎么通知给 netdev,并且让 mac 做出相应的配置改变,这个是通过一个中介 phylink 来实现的。

```
phy_link_up()/phy_link_down()
    '-| phydev->phy_link_change(phydev, true/false);
```

