Quickstart Guide



E-Smart Screen (ESS)

Display Your Vision Whenever, Wherever!

EwrTech Team- v0.1 (beta)




Table of Contents

Section 1: Introductio	<u>n</u>	001
Access - Login In Login to ESS (htt	<u>fo</u> ps)	002 003
Section 2: Content Ty	pes (Slides)	007
Web Page Slideshow QR - Text Audio Video Image		007 008 008 009 010 011
<u>Time (Scheduler)</u>		011
Section 3: Settings VPN and Remote Access Change Your Password & 2FA Set Monitor Resolution & Position Power Saving - Suspend System Connect to your Wifi		012 012 013 013 014 014
Section 4: Join ESS To	A New Wifi Network	016
Apps (Additional Appli	cations)	018

Section 1: Introduction

What's ESS?

ESS allows you to display any type of content (images, videos, web pages, slideshows, audio files, and more) on your screen or TV based on a schedule you create. You can schedule the contents to run on a specific date and select days of the week to run it. The scheduler is highly flexible, you can schedule a slide to display throughout a period of time, a single time, recur daily, hourly, or even run every second.

Some advanced features:

- Watch regualr TV channel or listen to your favorite radio
- Simple text to speech (natural voice)
- Can schedule voice reminders to tell you the current time, weather, or even tell a joke
- Create QR and add them on top of your image
- Dual monitor support, schedules slides for each monitor separately
- Advanced networking features, can serve as secure Hotspot or a VPN
- Run as a regular Linux server, easily access SSH through web browser

You can consider ESS as an **advanced digital signage with a lot more features and capabilties**. In addition, you can add extra **EWR Applications** and use them as Add-ons to run along side the ESS. The ESS Bundle version includes:

- E-Pad (PC Mode)
- E-Share (Screen Sharing)


The core features don't require internet connection and we support both x86-64 and arm64 cpu architecture.

Access - Login Info


There are multipe ways to access the ESS system, via Ethernet, USB, and the Wifi or the Hotspot if your ESS device supports the Access-Point Mode.

The device turns to a hotspot when it's not connected to any Wifi / Access Points, this way you always have an option to connect to it.

To connect to the device directly, search for the default ESS hotspot SSID.



Once you connect to the ESS device via hotspot, you can then join the ESS device to your own Wifi:



Steps:

- 1- Connect your monitor or TV to the ESS device
- 2- Turn on your monitor and set the output source accordingly
- 3- Connect the power adapter to the ESS device. If the device is set to **auto-power**, it will turn on automatially as soon as you plug into the power source. Otherwise, press the power button to turn it on
- 4- Once the device is turnned on, wait 5 to 10 minutes for the initial configuration
- 5- By default, the device is set to the Hotspot mode for easy access. Connect to it directly just like when you connect to a regular Access Point / Wifi Router
- 6- Use your laptop or phone to connect to the ESS device, scan the Hotspot:


Default Hotspot SSID : myHotspot00 # Default Wifi Password: myHSPass_99

Once you are connected to the **myHotspot00**, you can now access the ESS system using your web browser Note: the ESS device's wifi card must support the Access-Point mode, otherwise you can't connect to the hotspot.

Login to ESS (https)

A- After you are connected to the ESS default hotspot, open your browser and type the default ESS IP Address: https://10.42.0.1:9001 (must type https://)


You will get a security warning, similar to this: (depending on your browser)




You will see this because ESS uses a "Self Signed Certificate" so you can use the system on your private network. This is safe, Cisco and Google use Self Signed Certs for systems that requrie to work without a FQDN. To learn more, see the official page: https://en.wikipedia.org/wiki/Self-signed_certificate

- Click on "Advanced" (some Web Browser may have a button saying Continue, or similar)

- Look for the ESS IP address.




- Click on "Proceed to 10.42.0.1 (unsafe)"




- We need to pass the **2FA**. You must install a **2-Step Authentication App** on your phone. There are many, and we recommend the **Google Authenticator**. You can find it in the App Store and Google Play store.



B- After you install Google Authenticator, open it and scan the QR Code below:









2FA

Enter TOTP	The code changes every 30 seconds
Verify	


If you have any issues connecting to the device or logging in, please see: Section 4.

Section 2: Content Types (Slides)

Almost anything you can display on your regular PC screen or an audio file or link you can play is considered a contnet for ESS.

For example, you can upload an image from your computer or phone to schedule and display it on either the first or the second monitor, display a public web page, play and radio or a YouTube link, create a QR code, watch TV, set time reminders, and more. Here's a list of contents:


After you login, click on the plus sign to add a new slide. Then select the content type:



- Web Page

Allows you to schedule and display a publicly or locally available link using any standard protocl, and optionally set a refresh time.


The Web Page slide's minimum time is 5 minutes and the refresh minimum is 15.



- Slideshow

You can combine photos and videos to create a slideshow and run it based on the schedule you create.


Monitor 1 - Configure Slideshow Slide:



- QR - Text


Allows you to generate a QR code / link and add it on top of your photos, then display it based on the schedule you create. You can also display text.

Add QR slide



Add QR slide

Monitor 1 - Configure QR Slide:



- Audio

You can schedule to an audio file, listen to the radio or podcast, or use the **Text-to-Speech** feature with commonly used keywords such as **TIME**, **WEATHER**, and **DATE**.

We provide some example links for popular radio channels. You can also find free channels online.

You can type a sentence and it will convert it to natural sound speech, and use common keywords with your sentence. Example:

It is TIME and the weather is WEATHER

Time and WEATHER are both keywords.

Monitor 1 - Configure Audio Slide: Start Date: Start Time: mm/dd/yyyy --:-- --(1) End Date: End Time: mm/dd/yyyy --:-- --(1) Week Days: I W <u>Th</u> E Sa Text to speech Live Audio Loop Upload Audio (mp3 | <= 6MB) Choose File No file chosen Name: Slide name defined by user Go Back Save

Start Date: Start Time: mm/dd/yyyy --:-- --(1) End Date: End Time: mm/dd/yyyy (1) Week Days: <u>T</u> <u>W</u> <u>Th</u> Text to speech Live Audio Loop Time Gap (Seconds): 1 0 Text Example - Keywords Name: Slide name defined by user

Save

Monitor 1 - Configure Audio Slide:


Go Back

- Video

Allows you to schedule and play a TV channel, upload your own vidoe files, use YouTube, IP Camera, live streams, and more.


We provide some TV channels examples in the slide. You can search online for IP TV links.

Monitor 1 - Configure Video Slide:



If you try to add two video slides to run on the same monitor / Display, and set the time for both slides to run at the sametime or overlap each other, the system will require you to change the time of the sldies to prevent playing two videos on the same monitor at the sametime.

Monitor 1 - Configure Video Slide:



- Image

Schedule and display any mage format, jpg, png etc.. For example, a resturant can display breakfast menu from 7AM to 11PM, and display the lunch menu from 11AM to 3PM.

Monitor 1 - Configure Image Slide: Start Date: Start Time: mm/dd/yyyy 0 End Date: End Time: mm/dd/yyyy --:--0 Week Days: T W Th <u>S</u> F Sa Upload Image (png,jpg | <= 6MB) Choose File No file chosen Priority 1 Vertical Optional Text: Name: Slide name defined by user Go Back Save

Time (Scheduler)

When you add a new slide, you will see three options for the **Time**. You can select the one that best suits your scheduling needs.

Daily:

This is commonly used and works for most cases. You can start and end the slide at specific times and dates, and also select the days of the week.


Hourly:

Schedule the slide to run at a specific **Minute** of the hour, and start and end at a specific date.

Period:

This is suitable to run a slide through out a long period of time without stopping it. If you want to run a slide for more than 24 hours continuously, this may be the most suitable scheduling type.

Add a new slide



Section 3: Settings

You can change the display resolution, set a standby time, configure the VPN remote access, and much more under the settings menu.

Click on the gear icon



located on the top right corner:

Most of the settings are self explanatory. Some features need additional clearification: General
Network
User
Display
System
Emergency
Support
Upgrade
About
Facory Reset

Display
Disp

VPN and Remote Access

We support all major VPNs, both the software and hardware based. We recommend the highly secure and scalable VPN called **ZeroTier**, but other options that we provide are just as good. It all depends on your specific needs.

With a click of a button, you can install and configure the VPN to have secure remote access to your device, and all your network!




Change Your Password & 2FA

ESS has three different users. You may only see two in the menu "User Settings".

You can change the password for each user separately.

You must change your password and 2FA for better security. Do not run the system with the default username and password.



Set Monitor Resolution & Position

You can configure dual monitors, change a monitor to vertical, and more. Go to the Setting Menu, click on Display

Click on the button **Resolution** and select the pre-configure profile settings.

The default profile works for most monitors.

You will see the changes in the monitors when you select different profiles. Once you select the most suitable profile for your monitors, you must click on the blue button:

Save Config



Power Saving - Suspend System

You can schedule the ESS device to suspend based on the schedule you can create.

You can save energy and your hardware and monitors may last longer when not in used, when they don't need to be.




Connect to your Wifi

By default, the ESS creates a hotspot for you to connect to it directly. Once you are connected, you can then connect to another Wifi, and when the Wifi you have connected to is no longer available, it will fall back to the hotspot so you don't lose access.

For more details, see Section 4.

Go to the **Setting Menu**, click on **Network** then click on the button: **Set Wifi**





Apps (Additional Applications)

EwrTech has many products, a couple of them are bundled with the standard ESS version (this version), the **E-Share** and **E-Pad**.


E-Share:

Allows you to easily share your screen with the monitors connected to the ESS device, or send invite links for sharing your screen with others. You can also use a webcam and stream a video file directly from your phone.

E-Pad:

This simply turns the system into a standard PC that you can use as a web browser, or do anything else you can do when using a Linux Desktop PC. You can use your phone or any other device as a virtual keyboard and mouse to interact with the system.


For more information, please check the user manuals for the specific product you are interested in.



Section 4: Join ESS To A New Wifi Network


The ESS device can be connected to a Wifi as a regular device, or you can turn it to a Hotspot to connect to it directly.

You can't access ESS if you are not on the same network. In this example, the ESS IP address is: 10.42.0.1



The Wifi card in your ESS device must **support Access-Point Mode**, otherwise you may not see the hotspot name or be able to connect to it.

A Wifi device (Router / Access-Point) assigns a unique ip address to each device. When you turn the ESS to Hotspot, it changes to a router. It takes a few minutes for changes to apply.



1 - Once you are connect to the ESS device, open your browser and type:

https://<ESS IP ADDRESS>:9001

Example:

https://10.42.0.1:9001

If the ESS device is joined to your own Wifi router, it will obtain a new IP address from the router.

Note: when connecting or disconnecting to a network, it takes a few minutes for the changes to take effect.



2- You will get disconnected once you click on the button "Connect" because the ESS device will be joined to a new network:


My-Wifi-BlueSkye and thus will have a new IP address.

You will need to find the new IP address the ESS device has obtained.

To access the ESS again, connect your laptop or phone to the same Wifi (My-Wifi-BlueSkye) and find the new IP address assigned to the ESS system.



Note: if it fails to join the new network (My-Wifi-BlueSkye), it will fall back to the current network.



4- As you can see, the ESS system has joined a new network, and has a new IP address (192.168.1.25).

You will get an error if you are still trying to access the old ESS IP address.


You have to connect to the same Wifi and find the new ESS IP address to access it again.



5- Once you are on the same network, find the new IP address assinged to the ESS device.

The new IP will be displayed on the monitor and stay for 1 minute.


Another way to find the IP, use PING command: ping -4 essbox00 in the command-line.



If you still can't find the IP of the ESS device, there are many other ways you can try. That's beyond the scope of this quickguide. You may consult with your IT, or contact us.

6- Finally, go to your browser and type the new IP address of the ESS:

https://192.168.1.25:9001



Thank you!

Note:

ESS software is still in the development stage. This a basic help document and will change in the future.

We provide other methods to access the system: USB, Ethernet, and VPN. If you encounter any issue or need help please feel free to contact us:

https://www.ewrtech.com/

Toll Free: +1 (833) 830-0330

© EwrTech LLC - USA - ESS v0.1