

© Copyright EZTech Ltd. 2018 all rights reserved www.eztech.ind.br

#### **AUTOMATIC**

#### **SIMULATOR**

**MANUAL** 



© Copyright EZTech Ltd. 2018 all rights reserved www.eztech.ind.br

#### Summary


| Download the installation package | 4 |
|-----------------------------------|---|
| Installing the EZTech package     | 4 |
| Failed to connect                 | 5 |
| License Key                       | 5 |
| Task Manager EZServer             | 6 |
| EZConfig Key                      | 6 |
| Grades and Tanks                  | 7 |
| Delivery Position and Hoses       | 7 |
| Pump Type EZSoftSim               | 8 |
| EZMonitor                         | 8 |



© Copyright EZTech Ltd. 2018 all rights reserved www.eztech.ind.br

1: Download the installation **EZForecourt USB** package. Link:

Download EZForecourtPlus 25b07R




Download the installation package



© Copyright EZTech Ltd. 2018 all rights reserved www.eztech.ind.br

2: Install the **EZForecourt USB** package that can be downloaded from the EZTech. **Choose the full installation** option.




Installing the EZTech package



© Copyright EZTech Ltd. 2018 all rights reserved www.eztech.ind.br

3: A message "Failed to Connect" will appear at the end of the installation for not having recognized a physical USB EZForecourt connected to your computer, ignore the message and move on.




Failed to connect



© Copyright EZTech Ltd. 2018 all rights reserved www.eztech.ind.br

4: A generic license key will be generated for the operation of the service. Click "Write" and then click "Exit".




License Key



© Copyright EZTech Ltd. 2018 all rights reserved www.eztech.ind.br

5: The EZServer Service should now be running, check the Task Manager.




Task Manager EZServer



© Copyright EZTech Ltd. 2018 all rights reserved www.eztech.ind.br

6: Run the EZConfig.exe application in [C: \ EZForecourt], the password is the coseno, the 3 digits after the comma generated from the key shown when running the application.




EZConfig Key



© Copyright EZTech Ltd. 2018 all rights reserved www.eztech.ind.br

7: Create grades and set prices for them, then build tanks and refer to the grades created.




**Grades and Tanks** 



© Copyright EZTech Ltd. 2018 all rights reserved <u>www.eztech.ind.br</u>

8: Create Delivery Positions and their respective Hoses.




**Delivery Position and Hoses** 



© Copyright EZTech Ltd. 2018 all rights reserved www.eztech.ind.br

9: Change the Pump Positions of Delivery Positions created for EZSoftSim.




Pump Type EZSoftSim



© Copyright EZTech Ltd. 2018 all rights reserved www.eztech.ind.br

10: Open the EZMonitor.exe application in [C: \ EZForecourt \ EZMonitor], the generated deliveries can be monitored there. Now, just test the supply of these deliveries with your Management System.



**EZMonitor**