ETC Keyboard Shortcuts

Element Classic

Hotkeys

To enable Eos functions on macOS Function keys:

- Open Systems Preferences
- Go into the Keyboard section
- Enable the "Use all F1, F2,etc... keys as standard function keys" setting.



Note: *Some international keyboards require "Use Shift Key as Eos Shift" to be disabled in the General section of the ECU Settings. Use Z as shift to access shortcut functions in these cases.*

Console Function	PC Keyboard Shortcut
Shortcut List	Alt /
	?
0	0
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
. (decimal)	. (decimal)
- (minus)	- (minus)
+ (plus)	=
	+
+%	Shift =
	Control Alt =
-%	Shift -
	Control Alt -
/	/
A3D Camera Up	Up Arrow
A3D Camera Up (Edit Mode)	W
A3D Camera Forwards	Shift Up Arrow
A3D Camera Forwards (Edit Mode)	Shift W
A3D Camera Left	Left Arrow
A3D Camera Left (Edit Mode)	A
A3D Camera Down	Down Arrow
A3D Camera Down (Edit Mode)	S
A3D Camera Backwards	Shift Down Arrow
A3D Camera Backwards (Edit Mode)	Shift S

Corporate Headquarters Middleton, WI, USA +1 608 831 4116 **London, UK** +44 (0)20 8896 1000
Holzkirchen, DE +49 (80 24) 47 00-0 **Rome, IT** +39 (06) 32 111 683 **Hong Kong** +852 2799 1220 **Paris, FR** +33 1 4243 3535
Web etcconnect.com **Support** support.etcconnect.com **Contact** etcconnect.com/contactETC
© 2020 ETC, Inc. Trademark and patent info: etcconnect.com/ip
Product information and specifications subject to change. ETC intends this document to be provided in its entirety.
4330M1320-3.0.0 Rev A Released 2020-08

ETC Keyboard Shortcuts
Eos Family v3.0.0

A3D Camera Right	Right Arrow
A3D Camera Right (Edit Mode)	D
About	Y
Address / Dimmer	Alt A
All NPs	Control N
At	A
	@
	*
Back (ECU)	Escape
Beam Filter	Control B
Beam Palette	Alt B
Blind	F2
	Control 2
Block	B
Capture	Control Alt P
Clear	Backspace
Clear Command Line	Shift Backspace
	Control Alt Backspace
Clear Label	Control Backspace
Color Filter	Control C
Color Palette	Alt C
Color Path	Control Alt W
Copy To	C
Cue	Q
Cue Only / Track	X
Data	Control D
Data Mode	Control Shift D
Delay	D
Delete	Delete
Delete (macOS)	Fn Delete
Displays	F9
	Control 9
Effect	Alt E
Enter	Enter
Escape	Escape
Expand	F5
	Control 5
FlexiChannel	F3
	Control 3
Focus Filter	Control F
Focus Palette	Alt F
Follow	Shift D
	Control Alt D
Format	F4

ETC Keyboard Shortcuts
Eos Family v3.0.0

	Control 4
(Scroller) Frame	Control Alt C
Full	F
Go	Spacebar
Go To Cue	Control G
Go To Cue Zero	Control Alt G
Group	G
Help	Alt /
Home	Home
	Control H
Home (macOS)	Fn Left Arrow
Intensity Filter	Control I
Intensity Palette	Alt I
Label / Note	L
Last	Page Up
	Control ,
Last (macOS)	Fn Up Arrow
Learn	Alt L
Level	Control V
Live	F1
	Control 1
Load	Control Alt L
Macro	M
Macro 801*	Control Alt 1
Macro 802*	Control Alt 2
Macro 803*	Control Alt 3
Macro 804*	Control Alt 4
Macro 805*	Control Alt 5
Macro 806*	Control Alt 6
Macro 807*	Control Alt 7
Macro 808*	Control Alt 8
Macro 809*	Control Alt 9
Macro 810*	Control Alt 0
Magic Sheet	Alt M
Manual Override	Control Alt M
	Control Alt N
Mirror Start	Alt F1
Mirror Stop	Alt F2
ML Controls	F7
	Control 7
More Softkeys (More SK)	Alt 7
Next	Page Down
	Control .
Next (macOS)	Fn Down Arrow

ETC Keyboard Shortcuts
Eos Family v3.0.0

Off	Control Alt O
Offset	Control O
Out	O
Page Left	Left Arrow
Page Right	Right Arrow
Page Up	Up Arrow
Page Down	Down Arrow
Parameters (Display)	Control D
Park	Alt K
Part	P
Patch	;
Rate	Control Alt R
Recall From	E
Record	R
RecordOnly	Control R
Release	Control Alt S
Rem Dim	H
Scroll Lock	Control 6
Select	Control Enter
Select (ECU)	Return
Select Active	Control A
Select Last	Control L
Select Manual	Control M
Setup	Alt S
Shift	Z
Snapshot	Control S
Sneak	N
Softkey 1	Alt 1
Softkey 2	Alt 2
Softkey 3	Alt 3
Softkey 4	Alt 4
Softkey 5	Alt 5
Softkey 6	Alt 6
Spacebar Disable	Alt G
Staging Mode	F6
Stop / Back	Control Spacebar
	Control Alt Q
Stop Effect	Control Alt E
	Control Alt K
Submaster	S
Tab	Tab
Time	I
Time (Displays)	Control Alt I
Timing Disable	Control Alt T

Toggle Hotkeys	F8
	Control 8
Thru	T
Undo	Control X
Update	U
Virtual Keyboard	Control K
Workspace	] or [

*Some Shortcut Key combinations are not available on all physical keyboard layouts.

^Alternatively use Encoder Display + category to change the encoder pages.