

# IDENTIFICATION

## 1960-64 Chevrolet Serial Identification Number

The serial identification number is located on a plate attached to the door frame.

**1 C 15 4 F 103455**

**Model Year** \_\_\_\_\_  
0 = 1960      2 = 1962      4 = 1964  
1 = 1961      3 = 1963

**Chassis Designation** \_\_\_\_\_  
C = 2WD      K = 4WD

**Series** \_\_\_\_\_  
14 = 1/2 ton Shortbed 115" Wheelbase  
15 = 1/2 ton Longbed 127" Wheelbase  
25 = 3/4 ton Longbed 127" Wheelbase

**Truck Type** \_\_\_\_\_  
4 = Pickup

**Assembly Plant** \_\_\_\_\_  
A = Atlanta      J = Janesville      P = Pontiac      Z = Fremont  
B = Baltimore      K = Kansas City      S = St. Louis      1 = Oshawa  
F = Flint      N = Norwood      T = Tarrytown

**Vehicle Number** \_\_\_\_\_  
3,455<sup>th</sup> unit built

**Each year begins with serial number 100,001**

## 1965-66 Chevrolet Serial Identification Number

**C 14 4 6 S 107722**

**Chassis Designation** \_\_\_\_\_  
C = 2WD      K = 4WD

**Series** \_\_\_\_\_  
14 = 1/2 ton Shortbed 115" Wheelbase  
15 = 1/2 ton Longbed 127" Wheelbase  
25 = 3/4 ton Longbed 127" Wheelbase

**Truck Type** \_\_\_\_\_  
4 = Pickup

**Model Year** \_\_\_\_\_  
5 = 1965      6 = 1966

**Assembly Plant** \_\_\_\_\_  
A = Atlanta      J = Janesville      P = Pontiac      Z = Fremont  
B = Baltimore      K = Kansas City      S = St. Louis      1 = Oshawa  
F = Flint      N = Norwood      T = Tarrytown

**Vehicle Number** \_\_\_\_\_  
7,722<sup>nd</sup> unit built

**Each year begins with serial number 100,001**

## 1960-66 Chevrolet Model Identification

**C 2 5 04**

**Chassis Type** \_\_\_\_\_  
C = 2WD      K = 4WD

**GVW Classification** \_\_\_\_\_  
1 = 5,000lb      2 = 7,500lb

**Wheelbase** \_\_\_\_\_  
4 = 115" Wheelbase      5 = 127" Wheelbase

**Cab and Bed Type** \_\_\_\_\_  
04 = Stepside Pickup      34 = Fleetside Pickup

## 1960-66 GMC Serial Identification Number

**K 15 02 P N 2611 A**

**Chassis Designation** \_\_\_\_\_  
Blank = 2WD      I = In-Line 6 cylinder engine  
K = 4WD

**Series** \_\_\_\_\_  
10 = 1/2 ton      15 = 3/4 ton

**Wheelbase** \_\_\_\_\_  
01 = 115" Wheelbase      02 = 127" Wheelbase

**Assembly Plant** \_\_\_\_\_  
P = Pontiac      H = Oakland  
C = Oakland      Z = Fremont

**Model Code** \_\_\_\_\_  
N = 1960-61\*      F = 1964-66\*  
J = 1962      D = 1966 (In-Line 6 cylinder models only)  
G = 1963      \*See chart for specific model years by vehicle number.

**Vehicle Number** \_\_\_\_\_  
2611 = 611<sup>th</sup> 3/4 4WD truck built at Pontiac plant in 1961.

**GVW Rating** \_\_\_\_\_  
A = 5,000lbs      B = 7,000lbs

## GMC Model Year ID for N and F Model Trucks

| Pontiac Assembly Plant |             |                                                           |             |
|------------------------|-------------|-----------------------------------------------------------|-------------|
| 2WD 1/2 ton            | 4WD 1/2 ton | 2WD 3/4 ton                                               | 4WD 3/4 ton |
| 1960 N1001-N26000      | N1001-N2000 | N1001-N6000                                               | N1001-N2000 |
| 1961 N26001-on         | N2001-on    | N6001-on                                                  | N2001-on    |
| 1964 F1001-F20000      | F1001-F2000 | F1001-F10000 (w/o in-line 6)<br>F1001-F3000 (w/in-line 6) | F1001-F2000 |
| 1965 F20001-F40000     | F2001-F3000 | F10001-F20000 (w/o in-line 6)<br>F3001-on (w/in-line 6)   | F2001-F3000 |
| 1966 F40001-on         | F3001-on    | F20001-on                                                 | F3001-on    |

| Oakland or Fremont Assembly Plants                            |             |                                                          |             |
|---------------------------------------------------------------|-------------|----------------------------------------------------------|-------------|
| 2WD 1/2 ton                                                   | 4WD 1/2 ton | 2WD 3/4 ton                                              | 4WD 3/4 ton |
| 1960 N1001-N10000                                             | N1001-N2500 | N1001-N2500                                              | N1001-N2500 |
| 1961 N10001-on                                                | N2501-on    | N2501-on                                                 | N2501-on    |
| 1964 F1001-F7000 (w/o in-line 6)<br>F1001-F4000 (w/in-line 6) | F1001-F2000 | F1001-F5000 (w/o in-line 6)<br>F1001-F2000 (w/in-line 6) | F1001-F2000 |
| 1965 F7001-F12000 (w/o in-line 6)<br>F4001-on (w/in-line 6)   | F2001-F3000 | F5001-F10000 (w/o in-line 6)<br>F2001-on (w/in-line 6)   | F2001-F3000 |
| 1966 F12001-on                                                | F3001-on    | F10001-on                                                | F3001-on    |

## Truck Series Identification

The easiest way to tell if your truck is a 10 or 20 series truck is to look at the bolt patterns on your wheels. Trucks with 5 or 6 bolt patterns are 10 series, trucks with 8 bolt patterns are 20 series trucks.

## Shortbed / Longbed Identification

|          | Bed Length | Wheelbase (in) |
|----------|------------|----------------|
| Shortbed | 78"        | 115"           |
| Longbed  | 98"        | 127"           |