

Negative of the LM393 should be to GND. Cut the trace to -12V and short C8 to GND with a 0 Ohm.



