B2BConnector

File: B2BConnector.kicad_sch

MainPower

File: MainPower.kicad_sch

Connectors

File: Connectors.kicad_sch

M.2

File: M2.kicad_sch

External INS

File: vectornav.kicad_sch

USB3

File: USB3.kicad_sch

IMPORTANT: FOR USE WITH EchoPilot AI REV 1 OR NEWER

J1 Conn_01x01 — 1 — GND

J2 Conn_01x01 — GND

J3 Conn_01x01 — GND

J4 Conn_01x01 — GND

FID1 Fiducial

FID2 Fiducial

FID3 Fiducial

FID4 Fiducial

FID5 Fiducial

FID6 Fiducial

Echo MAV, LLC

Sheet: /

File: pixc4-jetson-universal-carrier.kicad_sch

Title: EchoPilot Carrier

Size: B	Date: 2021-03-23	**Rev: 1**
KiCad E.D.A. kicad 7.0.6-rc1-29-g152dc56df4		Id: 1/7

TP1
TestPoint
GND

STATUS LEDS
+5V
+5V_FMU
+5V_PROT
D4 LED_G
D5 LED_G
D7 LED_G
R16 1.0K
R17 1.0K
R25 1.0K
GND

PLANE STITCHING CAPS
+5V
+5V_FMU
C41 0.1uF
C42 0.1uF
C62 0.1uF
C71 0.1uF
C72 0.1uF
C90 0.1uF
C91 0.1uF
C92 0.1uF
+1V1
+3.3V

MAIN SYSTEM 5.1V, 5A
+BATT
C8 2.2uF 100V
C11 2.2uF 100V
C13 2.2uF 100V
U4
TPS54561QDPRRQ1
VIN
EN
RT/CLK
SS/TR
COMP
PWRGD
BOOT
SW
FB
EXP
GND
243K R9
C15 10nF
C21 0.1uF
L2 ASPIAIG-F1040-7R3M-I
D3 PDS760-13
R7 16.9K
C17 4.7nF
C19 47pF
R14 54.9K
R15 10.2K

Jetson Power
+5V
C23 47uF 10V
C25 47uF 10V
C27 47uF 10V

POWER IN
J27
XT30PW-M
XT30 IN
PWR_IN
D1 TVS
R5 750m
C9 10uF 100V

REVERSE POLARITY PROTECTION
SQJ463EP-T1_GE3
Q2
+BATT
D_Zener
D6 12V
R18 10K

FMU SYSTEM 5.4V, 5A
+BATT
C7 2.2uF 100V
C10 2.2uF 100V
C12 2.2uF 100V
U3
TPS54561QDPRRQ1
243K R8
C14 10nF
C20 0.1uF
L1 ASPIAIG-F1040-7R3M-I
D2 PDS760-13
R6 16.9K
C16 4.7nF
C18 47pF
R10 57.6K
R12 10.2K

FMU Power
+5V_FMU
C22 47uF 10V
C24 47uF 10V
C26 47uF 10V

CURRENT LIMITED 5V OUT
USED FOR SPARE, IRIDIUM
+5V
U6
TPS2561
IN
EN1
EN2
PAD
GND
OUT1
FAULT1
OUT2
FAULT2
ILM
0.1uF C35
+5V_PROT
+5V_PROT_INS
J11
Conn_01x02
C93 47uF 10V
C94 47uF 10V
R24 37.4K 1%
1.5A LIMIT
CURRENT LIMITED 5V OUT
USED FOR INS/RS-232

USB HUB POWER
U5
LTC3622IDE-2-PBF
VIN1
VIN2
RUN1
RUN2
SW1
FB1
INTVCC
MODE/SYNC
PHASE
ILIM
SW2
FB2
GND
PGOOD1
PGOOD2
+5V
C30 10uF
PGOOD2
C49 1.0uF
INTVCC
+3.3V
L6 1.2uH
C32 22uF
C31 22pF
R11 619K
R13 137K
R38 10K
L5 1.2uH
R20 619K
R21 732K
C34 22pF
+1V1
C33 22uF

3.3V AND 1.1V POWER
RUN/PGOOD LOGIC ENSURES 1.1V SUPPLY IS STABLE FIRST, AS REQUIRED BY USB HUB

Echo MAV, LLC
Sheet: /MainPower/
File: MainPower.kicad_sch
Title: EchoPilot Carrier
Size: B | Date: 2021-03-23 | Rev: 1
KiCad E.D.A. kicad 7.0.6-rc1-29-g152dc56df4 | Id: 2/7


ETHERNET MAGNETICS
U1
HX0068ANLT
ETH_RADIO_RX_P
ETH_RADIO_RX_N
ETH_RADIO_TX_P
ETH_RADIO_TX_N
RD+
RD−
TD+
TD−
RDCT
TDCT
RX+
RX−
TX+
TX−
RXCT
TXCT
ETH_RADIO_RX_POSTMAG_P
ETH_RADIO_RX_POSTMAG_N
ETH_RADIO_TX_POSTMAG_P
ETH_RADIO_TX_POSTMAG_N
R3
75
C1
0.1uF
C3
0.1uF
C5
1000pF
GND
U2
HX0068ANLT
ETH_SPARE_RX_P
ETH_SPARE_RX_N
ETH_SPARE_TX_P
ETH_SPARE_TX_N
ETH_SPARE_RX_POSTMAG_P
ETH_SPARE_RX_POSTMAG_N
ETH_SPARE_TX_POSTMAG_P
ETH_SPARE_TX_POSTMAG_N
R4
75
C2
0.1uF
C4
0.1uF
C6
1000pF
JETSON CONNECTIONS
MIPI CAM 1
J8
1-84952-5
CAM0_D0_N
CAM0_D0_P
CAM0_D1_N
CAM0_D1_P
CAM0_C_N
CAM0_C_P
CAM0_GPIO
CAM0_MCLK
CAM0_SCL0
CAM0_SDA0
3V3_SYS
C28
0.1uF
ETH 2
J9
Conn_01x04
ETH 1
J15
Conn_01x04
JETSON GPIO
J33
Conn_01x04
GPIO02
GPIO10
GPIO12
MIPI CAM 2
J14
1-84952-5
CAM1_D0_N
CAM1_D0_P
CAM1_D1_N
CAM1_D1_P
CAM1_C_N
CAM1_C_P
CAM1_GPIO
CAM1_MCLK
CAM1_SCL0
CAM1_SDA0
C29
0.1uF
JETSON CAN1
J7
Conn_01x04
JETSON_CAN+
JETSON_CAN−
+5V_PROT
JETSON I2C
J34
Conn_01x04
XAVIER_I2C1_SCL
XAVIER_I2C1_SDA
IRIDIUM 9603 ROCKBLOCK COMPATIBLE
0532617010
J10
IRID_RX_OUT_3.3
IRID_NA_3.3
IRID_RING_3.3
IRID_TX_IN_3.3
IRID_ON_OFF_3.3
USB 2.0 PORTS
J21
Conn_01x04
J22
Conn_01x04
J23
Conn_01x04
PORT_VBUS_2
USB2−
USB2+
PORT_VBUS_3
USB3−
USB3+
PORT_VBUS_4
USB4−
USB4+
MAX 2A DUE TO TRACE WIDTH AND RP DIODE
ONLY REVERSE POLARITY PROTECTED!!
+BATT
B260S1F-7
D9
SPARE BATTERY POWER OUT
J12
Conn_01x04
+5V_FMU
PIEZO BUZZER SUPPORT
U9
LT3469
C46
1.0uF
L3
47uH
VIN
SW
+IN
−IN
VCC
FB
GND
OUT
453K
R30
6.5K
R31
C48
0.47uF
BUZZER_1
R27
9.09K
BUZZER_OUT
R28
10K
R29
100K
C47
5600pF
FMU CONNECTIONS
+VDD_5V_PERIPH
R47, R51, R53 AND R52 CAN BE USED FOR
RESISTOR DIVIDER AS NEEDED TO SCALE INPUTS
V/I SENSE
AND ANALOG IN
J13
Conn_01x08
NOTE: ANALOG INPUT UP TO 3.3V
BATT_VOLTAGE_SENS_PROT
BATT_CURRENT_SENS_PROT
BATT2_VOLTAGE_SENS_PROT
BATT2_CURRENT_SENS_PROT
SPARE1_ADC1
SPARE2_ADC1
R47
R51
DNI
R52
DNI
R53
NOTE: FMU CHANNELS 1-4 ARE DSHOT COMPATIBLE
+VDD_SERVO IS ONLY
FOR THE FMU TO MONITOR
THIS VOLTAGE. NOT TO POWER SERVO!
+VDD_SERVO
D10
D_Schottky
D11
IO−CH1−PROT
IO−CH2−PROT
IO−CH3−PROT
IO−CH4−PROT
IO−CH5−PROT
IO−CH6−PROT
IO−CH7−PROT
IO−CH8−PROT
FMU−CH1−PROT
FMU−CH2−PROT
FMU−CH3−PROT
FMU−CH4−PROT
TO PWM BREAKOUT BOARD
J28
Conn_01x14
+VDD_5V_RADIO
RADIO IN
RC_INPUT
J16
Conn_01x03
TELEM1
J18
Conn_01x06
TELEM1_TX
TELEM1_RX
TELEM1_CTS
TELEM1_RTS
FMU I2C_2
J25
Conn_01x04
FMU_I2C_2_SCL
FMU_I2C_2_SDA
FMU CAN2
J17
Conn_01x04
CAN_2+
CAN_2−
S.BUS OUT/RSSI IN
J26
Conn_01x03
S.BUS_OUT
FMU CAN1
J19
Conn_01x04
CAN_1+
CAN_1−
GPS/COMPASS/SAFETY
J20
Conn_01x10
GPS1_TX
GPS1_RX
FMU_I2C_1_SCL
FMU_I2C_1_SDA
SAFETY_SWITCH_IN
SAFETY_SWITCH_LED_OUT
R19
100
SAFETY_VDD
BUZZER_OUT
Echo MAV, LLC
Sheet: /Connectors/
File: Connectors.kicad_sch
Title: EchoPilot Carrier
Size: B
Date: 2023-03-05
Rev: 1
KiCad E.D.A. kicad 7.0.6-rc1-29-g152dc56df4
Id: 3/7

JETSON

J5A
FX23L-80P-0.5SV10

1	JETSON_CAN+	
2	JETSON_CAN-	
3	GND	
4	CAM0_SDA0	
5	CAM0_SCL0	
6	CAM0_MCLK	
7	CAM0_GPIO	
8	GND	
9	CAM0_D1_P	
10	CAM0_D1_N	
11	GND	
12	CAM0_C_P	
13	CAM0_C_N	
14	GND	
15	CAM0_D0_P	
16	CAM0_D0_N	
17	GND	
18	CAM1_SDA0	
19	CAM1_SCL0	
20	CAM1_MCLK	
21	CAM1_GPIO	
22	GND	
23	CAM1_D1_P	
24	CAM1_D1_N	
25	GND	
26	CAM1_C_P	
27	CAM1_C_N	
28	GND	
29	CAM1_D0_P	
30	CAM1_D0_N	
31	GND	
32	I2S0_DOUT	
33	I2S0_DIN	
34	I2S0_FS	
35	I2S0_SCLK	
36	AUDIO_MCLK	
37	GPIO12	
38	GPIO10	
39	GND	
40	IRID_RX_OUT_3.3	

J5B
FX23L-80P-0.5SV10

41	ETH_SPARE_TX_N	
42	ETH_SPARE_TX_P	
43	ETH_SPARE_RX_N	
44	ETH_SPARE_RX_P	
45	GND	
46	ETH_RADIO_RX_P	
47	ETH_RADIO_RX_N	
48	ETH_RADIO_TX_P	
49	ETH_RADIO_TX_N	
50	GND	
51	USBSS_RX_P	
52	USBSS_RX_N	
53	GND	
54	USBSS_TX_P	
55	USBSS_TX_N	
56	GND	
57	PORT_VBUS_JETSON	
58	JETSON_USB1_D_P	
59	JETSON_USB1_D_N	
60	GND	
61	PORT_VBUS_4	
62	USB4+	
63	USB4-	
64	GND	
65	PORT_VBUS_3	
66	USB3+	
67	USB3-	
68	GND	
69	PORT_VBUS_2	
70	USB2+	
71	USB2-	
72	GND	
73	IRID_NA_3.3	
74	IRID_RING_3.3	
75	IRID_TX_IN_3.3	
76	IRID_ON_OFF_3.3	
77	XAVIER_I2C1_SDA	
78	XAVIER_I2C1_SCL	
79	GPIO02	
80	F1 1A → 3V3_SYS	

ADD MAGNETICS TO CARRIER BOARD

J5C
FX23L-80P-0.5SV10

P1	+5V	
P2		
P3	GND	
P4		
MNT_1	GND	
MNT_2		

FMU

J6A
FX23L-80P-0.5SV10

1	FMU-CH6-PROT	
2	FMU-CH5-PROT	
3	FMU-CH4-PROT	
4	FMU-CH3-PROT	
5	FMU-CH2-PROT	
6	FMU-CH1-PROT	
7	IO-CH1-PROT	
8	IO-CH2-PROT	
9	IO-CH3-PROT	
10	IO-CH4-PROT	
11	IO-CH5-PROT	
12	IO-CH6-PROT	
13	IO-CH7-PROT	
14	IO-CH8-PROT	
15	GND	
16	+VDD_5V_PERIPH	
17	FMU_I2C_2_SCL	
18	FMU_I2C_2_SDA	
19	GND	
20	CAN_2+	
21	CAN_2-	
22	GND	
23	CAN_1+	
24	CAN_1-	
25	GND	
26	TELEM1_RTS	
27	TELEM1_CTS	
28	TELEM1_RX	
29	TELEM1_TX	
30	GND	
31	BATT_CURRENT_SENS_PROT	
32	BATT_VOLTAGE_SENS_PROT	
33	+VDD_SERVO	
34	GND	
35	ONLY USED TO SENSE VSERVO VOLTAGE	
36	GND	
37		
38		
39		
40		

RC IN

FMU POWER

J6B
FX23L-80P-0.5SV10

41	+VDD_5V_PERIPH	
42	SPI5_SCK_EXTERNAL1	
43	SPI5_MISO_EXTERNAL1	
44	SPI5_MOSI_EXTERNAL1	
45	SPI5_CS1_EXTERNAL1	
46	SPI5_CS2_EXTERNAL1	
47	GND	
48		
49	GPS1_TX	
50	GPS1_RX	
51	FMU_I2C_1_SCL	
52	FMU_I2C_1_SDA	
53	GND	
54	SAFETY_SWITCH_IN	
55	SAFETY_SWITCH_LED_OUT	
56	SAFETY_VDD	
57	BUZZER_1	
58	GND	
59	+VDD_5V_RADIO	
60	RC_INPUT	
61	GND	
62	+5V_FMU	
63		
64		
65		
66		
67		
68		
69	GND	
70	VDD_POWERA_VALID	
71	VDD_POWERB_VALID	
72	S.BUS_OUT	
73	UART4_TX	
74	UART4_RX	
75	GND	
76	BATT2_CURRENT_SENS_PROT	
77	BATT2_VOLTAGE_SENS_PROT	
78	SPARE1_ADC1	
79	SPARE2_ADC1	
80		

OPTIONAL SPI EXTERNAL SENSOR

EXT GPS/COMPASS

NO B POWER SOURCE ON THIS BOARD, THE FMU WILL PULL THIS UP

J6C
FX23L-80P-0.5SV10

P1	+5V	
P2		
P3	GND	
P4		
MNT_1	GND	
MNT_2		

+5V_FMU

R2
220

VDD_POWERA_VALID

Q1
Q_NMOS_GSD

R1
10K

GND

Echo MAV, LLC

Sheet: /B2BConnector/
File: B2BConnector.kicad_sch

Title: EchoPilot Carrier

Size: B	Date: 2021-03-23	**Rev: 1**
KiCad E.D.A. kicad 7.0.6-rc1-29-g152dc56df4		Id: 4/7

PER R1, ONLY EXTERNAL INS ARE SUPPORTED VIA J32. E.G. VECTORNAV VN-100, 200, 300, 110, 210, 310
CUSTOM CABLE SOLUTIONS WILL BE REQUIRED





Echo MAV, LLC
Sheet: /External INS/
File: vectornav.kicad_sch

Title: EchoPilot Carrier

Size: A4	Date: 2023-06-25	**Rev: 1**
KiCad E.D.A. kicad 7.0.6-rc1-29-g152dc56df4		Id: 5/7


USB 3.2 HUB, INPUT FROM JETSON
OUTPUT 1 TO M.2 (5G MODEM)
OUTPUT 2/3 TO 10 PIN CONNECTORS
TUSB8042AIRGCR
IC1
U8
Crystal
U10
TPS2561
U11
TPS25221
FB3
FB1
FerriteBead
1A LIMIT
J24
J29
Conn_01x10
BYPASS CAPS
Echo MAV, LLC
Sheet: /USB3/
File: USB3.kicad_sch
Title: EchoPilot Carrier
Size: A4
Date:
Rev: 1
KiCad E.D.A. kicad 7.0.6-rc1-29-g152dc56df4
Id: 6/7


DESIGNED FOR SIERRA WIRELESS 5G MODULES
KEY B
J30
SM3ZS067U310ABR1200
+3.3V_MODEM
U13
RCLAMP0504PATCT
+SIM_VCC
SIM ESD
SIM_DATA
SIM_RESET
SIM_CLK
SIM_DETECT
NANO SIM CARD HOLDER
J31
G85D1171012HHR
MODEM FED BY FMU POWER SUPPLY TO DISTRIBUTE LOAD BETWEEN THE TWO SUPPLIES
5G MODEM MAY CONSUME UP TO 3A
MODEM SUPPLY
U12
MAX20074
+5V_FMU
GND if no SIM
Floating if SIM
1.8V TO ENABLE USB
WWAN ACTIVITY
SP1
SM3ZS067U310-NUT1
USE M2 X 0.4MM X 3MM WAFER HEAD SCREW
PCIE_DIS
VBUS_CELL
USB_CELL_SSTX+
USB_CELL_SSTX-
USB_CELL_SSRX+
USB_CELL_SSRX-
USB_CELL_D+
USB_CELL_D-
PERST
CLKREQ
PEWAKE
PETp0/SATA-A+
PETn0/SATA-A-
PERp0/SATA-B-
PERn0/SATA-B+
PETp1/USB3.0-Tx+/SSIC-TxP
PETn1/USB3.0-Tx-/SSIC-TxN
PERp1/USB3.0-Rx+/SSIC-RxP
PERn1/USB3.0-Rx-/SSIC-RxN
USB_D+
USB_D-
UIM-PWR
UIM-DATA
UIM-CLK
UIM-RESET
DEVSLP
FULL_CARD_POWER_OFF
RESET
REFCLKp
REFCLKn
CONFIG_0
CONFIG_1
CONFIG_2
CONFIG_3
ANTCTL0
ANTCTL1
ANTCTL2
ANTCTL3
W_DISABLE1
GPIO_0
GPIO_1
GPIO_2
GPIO_3
GPIO_4
GPIO_5
GPIO_6
GPIO_7
GPIO_8
GPIO_9/DAS/DSS/LED1
GPIO_10
GPIO_11
DPR
SUSCLK
COEX1
COEX2
COEX3
3.3V
SH
GND
R44 8.25K
R45 10K
R43 1.0K
R42 80.6K
R46 10
R48 56.2K
R49 10K
R50 787
C80 0.1uF
C81 0.1uF
C82 0.1uF
C83 22uF
C84 4.7uF
C85 0.1uF
C86 1.0uF
C87 4.7uF
C88 10pF
C89 22uF
L4 1uH
D12 LED
D13 LED_G
Echo MAV, LLC
Sheet: /M.2/
File: M2.kicad_sch
Title: EchoPilot Carrier
Size: A4
Date:
Rev: 1
KiCad E.D.A. kicad 7.0.6-rc1-29-g152dc56df4
Id: 7/7