


Can't see the video? <u>View on YouTube</u> →

# **Fast PWM Circuit Diagram**

The circuit diagram shows LEDs connected to PB2 (OC0A PWM channel from TC0) and PD5 (OC0B PWM channel from TC0).



Circuit Diagram for the Dual Channel Fast PWM Example

# **Fast PWM Software**

The C source code controlling two PWM channels from timer/counter0 in fast PWM mode is shown here.

// TCO fast PWM.c

```
#define F_CPU 1000000UL
#include <avr/io.h>
#include <util/delay.h>
int main(void)
{
                                             // 8-bit PWM value
// 8-bit PWM value
    unsigned char PWM val1 = 0;
    unsigned char PWM val2 = 255;
    unsigned char up \overline{d}n = 0;
                                              // up down count flag
             |= (1 << PB2);
                                                   // PWM output on PB2 - OC0A
    DDRR
            = (1 << PD5);
                                                   // PWM output on PD5 - OC0B
    // fast PWM mode
    TCCR0A = (1 << COM0A1) | (1 << COM0B1) | (1 << WGM01) | (1 << WGM00);
    TCCR0B = (1 \ll CS01);
                                // clock source = CLK/8, start PWM
    while(1)
    {
         if ((PWM_val1 == 255) || (PWM_val1 == 0)) {
             up d\overline{n} ^= 0x01;
                                     // toggle count direction flag
          delay_ms(5);
         OCROB = PWM_val1;
OCROB = PWM_val2;
                                     // write new PWM value
         if (up_dn) {
                                     // increment or decrement PWM value
         PWM_val1++;
         PWM val2--;
    else {
         PWM val1--;
         PWM_val2++;
    }
}
```

This example is very similar to the code used in the second example of the previous part of this tutorial, except an extra output (second PWM channel) is enabled on PD5. The PWM is now initialized into fast PWM mode and the second PWM channel is enabled.

When the value continuously written to one PWM channel is incremented to brighten the attached LED, the value written to the other channel is decremented to dim the attached LED.

### **Project Source Code**

The above code can be copied and pasted into your own project, or download the Atmel Studio project for this example here:

TC0 fast PWM.zip (15.6kB)



#### ← Go back to Part 11Go to Part 13 →

To comment on this article or ask questions, go to the <u>blog entry for this article</u>. Use the comment box at the bottom of the blog entry.



## **Beginners**

• About Electronics