

K1 represents suspension stiffness where c1 represents damping coefficient. Where K1 is kept constant we can see less displacement/oscillation of the system as damping coefficient is increased.