38 VF139 - Airbag Warning Management (VF139_V1_PJ3U)

Document Code: VF139_V1_PJ3U | Components: IPC, ORC (Airbag ECU), BCM

38.12 Indication Management

IND_ROW | AIR BAG FAIL.V1 | When FailPresent == 1 or AirBagLampReq == ON | Yes - Airbag failure, see hand
IND_ROW | AIR BAG TEMPORARY CALIBRATION.V1 | When ORC is in Plant Mode / Temporary Calibration active | Y
IND_ROW | AIR BAG RECOVERY.V1 | When CAN node ORC_FD_1 is in timeout > tREC | Yes - Check Airbag System |
IND_ROW | PASSENGER AIR BAG OFF.V1 | When PassengerAirBagStatus == DISABLED | Yes - Passenger Airbag Deac

38.14.1 Configuration Parameters Table

ID | Parameter Name | First Trial Value | Range Value | Resolution | Unit | Component | Implementation | XCP | Impact | Description
PAR_ROW | PAR_139_01 | tREC | 2,5 | 0,1÷5 | 0,1 | s | IPC | SUPPLIER EOL_2 | NO | Diagnosis | Time-out of the signa
PAR_ROW | PAR_139_02 | T_AIRBAG_STARTUP_CHK | 4,0 | 2,0÷6,0 | 0,5 | s | IPC | SUPPLIER EOL_2 | NO | HMI | Duration
PAR_ROW | PAR_139_03 | CFG_PAB_PRESENT | 1 | 0÷1 | 1 | - | IPC | PROXI | NO | Vehicle Configuration | Enables Passe
PAR_ROW | PAR_139_04 | T_ORC_CRASH_LATCH | 50 | 10÷200 | 10 | ms | ORC | SUPPLIER EOL | YES | Safety | Crash deploy