User Manual of JDY-25M iBeacon Probe

Configure to iBeacon probe mode, please send the following instructions.

Step 1 is to configure to iBeacon probe mode: AT+ROLE4

Step 2 is to send reset instruction to restart the module: AT+RESET

The module will automatically search for the surrounding iBeacon broadcast signals in the following format:

IBEACON probe mode output data format is as follows:

54 58 44 ea d8 f1 b5 a2 52 fd a5 06 93 a4 e2 4f b1 af cf c6 eb 07 64 78 25 00 0a 00 07 0d 0a

TX MAC RSSI iBeacon UUID Major Minor
End