Instruc Assignment Project Exam Help tation 2

https://eduassistpro.github.io/

Add WeChat edu_assist_pro

Review

- MIPS defines instructions to be same size as data (one word) so that they can use the same memory (can use lw and sw) Assignment Project Exam Help
- Machine Language
 - 32 bits representing https://eduassistpro.github.io/

R	opcode	rs Add	WeCha	t edu_ass	hamt	funct
I	opcode	rs	rt	immediate		te

 Computer actually stores programs as a series of these machine instructions

Outline

- Branch instruction encoding
- Jump instructions Assignment Project Exam Help
- Disassembly

https://eduassistpro.github.io/

Pseudoinstructions
 — Add WeChat edu_assist_pro
 "True" Assembly Language (TAL
 "MIPS" Assembly Language (MAL)

Branches: PC-Relative Addressing (1/5)



- Use I-Format
- opcode specifies be equets to sabride lp
- Rs and Rt sphttps://eduassistpro.github.log
- What can immediate sp edu_assist_pro
 - Immediate is only 16 bits
 - PC is 32-bit pointer to memory
 - Immediate cannot specify entire address to which we want to branch

Branches: PC-Relative Addressing (2/5)

- How do we usually use branches?
 - Answer: if-else, while, for
 Assignment Project Exam Help

 Loops are generally
 - 0 instructions
 - Function calls and u https://eduassistpro.githubeiq/sing jump instructions (j and jal) wetchat edu_assist_pro
- Conclusion: Though we may want to branch to anywhere in memory, a single branch will generally change the PC by a very small amount

5

Branches: PC-Relative Addressing (3/5)

- Solution: PC-Relative Addressing
- Let the 16-bit immediate field be a signed two's Assignment Project Exam Help complement integer PC if we take the branch.

 https://eduassistpro.github.io/
- Now we can branch the work edu_assist pto which should be enough to cover any loop.
- Any ideas to further optimize this?

Branches: PC-Relative Addressing (4/5)

- Note: Instructions are words, so they're word aligned

 - The number of byteshttps://eduassistpro.github.jobe a multiple of 4
 - Thus, specify the immediate edu_assist_pro
- We can branch $+/- 2^{15}$ words from the PC (or $+/- 2^{17}$ bytes)
- Thus, we can handle loops 4 times as large as a byte offset

Branches: PC-Relative Addressing (5/5)

- Branch Calculation:
 - If we don't take the branch:

PC+4 = byte address o

If we do take the bran https://eduassistpro.github.io/

- Observations
 - Immediate field specifies the number of words to jump, which is simply the number of instructions to jump
 - Immediate field can be positive or negative.
 - Due to hardware, add immediate to (PC+4), not to PC;
 - This will be clearer why later in course

McGill COMP273 8

Branch Example (1/3)

MIPS Code:

```
Loop: beq $9 $0 <u>End</u>
add $As$ign$nent Project Exam Help
addi $9 $
j Loop https://eduassistpro.github.io/
Add WeChat edu_assist_pro
```

Branch is I-Format:

```
opcode = 4 (look up in table)
rs = 9 (first operand)
rt = 0 (second operand)
immediate = ???
```




Branch Example (2/3)

MIPS Code:

```
Loop: beq $9 $0 <u>End</u>
add $8.$ign$1.0nt Project Exam Help
addi $9 $
j Loop https://eduassistpro.github.io/
Add WeChat edu_assist_pro
```

- Immediate Field:
 - Number of instructions to add to (or subtract from) the PC, starting at the instruction following the branch.
 - In beq case, immediate = 3

Branch Example (3/3)



Questions on PC-addressing

- Does the value in branch field change if we move the code?
- What do we do if its. > 2¹⁵ instructions? Help
- Since its limited to + oesn't this generate lots of extra MIPS in https://eduassistpro.github.io/

Add WeChat edu_assist_pro



J-Format Instructions (1/5)

- For general jumps (j jump to anywhere in memory.

 https://eduassistpro.github.io/
- Ideally, we could specify a specif
- Unfortunately, we can't fit both a 6-bit opcode and a 32-bit address into a single 32-bit word, so we compromise.

J-Format Instructions (2/5)

6 bits 26 bits

Jopcode target address

- Define "field"

 Assignment Project Exam Help
 - As usual, ea https://eduassistpro.github.io/
- Key ConceptsAdd WeChat edu_assist_pro
 - Keep opcode field identical to R-format and I-format for consistency.
 - Combine all other fields to make room for large target address.

J-Format Instructions (3/5)

- For now, we can specify 26 bits of the 32-bit bit address.
- Optimization: Assignment Project Exam Help
 - Note that, just like w ill only jump to word aligned addresses, s https://eduassistpro.githubi (հի binary).
 - So let's just take this And the Monte that edu_assist specify them.

J-Format Instructions (4/5)

- So, we can specify 28 bits of the 32-bit address.
- Where do we get the other 4 bits? Exam Help
 - Always take the 4 hi
 - Technically, it mean it's adequate 99.9994 to that edu_assistrograms aren't that long
 - If we absolutely need to specify a 32-bit address, we can always put it in a register and use the jr instruction

J-Format Instructions (5/5)

Summary, with II meaning concatenation

```
Assignment Project Exam Help

New PC = PC[3 ss (26 bits) II 00 https://eduassistpro.github.io/

4 bits II 200 et al. assistances
```

Understand where each part came from!

Outline

- Branch instruction encoding
- Jump instructions Assignment Project Exam Help
- Disassembly

https://eduassistpro.github.io/

Decoding Machine Language

- How do we convert 1s and 0s to C code?
 - Machine language \rightarrow assembly \rightarrow C
- For each 32 bits: Assignment Project Exam Help
 - Look at opcode: 0 m https://eduassistpro.githe.thnio/ J-Format, otherwise I-Format
 Add WeChat edu_assist_pro

 - Instruction type determines which

 t

 - Write out MIPS assembly code, converting each field to name, register number/name, or decimal/hex number
 - Logically convert this MIPS code into valid C code. Always possible? Unique?

Decoding Example (1/7)

00001025 0005402A 11000003 **Assignment Project Exam Help**

https://eduassistpro.github.io/

- Six machine take Wagehat edu_assist_ipropex
- Let the first instruction be at address 419430410 (0x0040000).
- Next step: convert to binary

Decoding Example (2/7)

- The machine and was edu_assists of binary
- Next step: identify opcode and format

Format Decoding Example (3/7)

- Opcode (first dbits) Chat edu_assist_the format
- 0 means R-Format, 2 or 3 means J-Format, otherwise I-Format
- Next step: separation of fields

Format Decoding Example (3/7)

• Fields separated Waschat edu_assist/opcode

Format Decoding Example (4/7)

0	0	0	2	0	37		
0	0	5	8	0	42		
4	8	0	3				
0 A	ssignn	nenţ Pr	ojęct I	Exam l	$Help_2$		
8		// 1	. ,				
2	https://eduassistpro.github.io/						
	0 0 4 0 A 8 2	8	8	8	0 0 0 2 0 0 0 5 8 0 4 8 0 3 0 Assignment Project Exam 8 https://eduassistpro.git		

- Convert binaryd Wchatedu_assist_pro
- Next step: translate ("disassemble") to MIPS assembly instructions

Decoding Example (5/7)

```
0 \times 00400000 or $2, $0, $0 0 \times 00400004 slt $8, $0, $5 0 \times 00400008 beq $8, $0, 3 Assignment Project Exam Help, $4 0 \times 0 https://eduassistpro.github.jo/
```

- MIPS Assembly, With the edu_assistations
- For a Better solution, translate to more meaningful instructions
 - Need to fix the branch and jump and add labels

McGill COMP273 25

Decoding Example (6/7)

```
or $v0, $0, $0

LOOP: slt $t0, $0, $a1

beq $t0, $0, EXIT

Assignment Project Exam Helpv0, $a0

https://eduassistpro.github.io/

EXIAdd WeChat edu_assist_pro
```

- Next step: translate to C code
 - Many options

Decoding Example (7/7)

C code: \$v0: product Assignment Project Exam Help \$a0: multiplicand – Mapping: \$a1: mhttps://eduassistpro.github.io/ product = 0; while (multiplier > 0) { product += multiplicand; multiplier -= 1;

Assignment Project Exam Help NS https://eduassistpro.github.io/
Add WeChat edu_assist_pro

Outline

- Branch instruction encoding
- Jump instructions Assignment Project Exam Help
- Disassembly

https://eduassistpro.github.io/

Pseudoinstructions

 "True" Assembly Language (TAL
 (MAL)

Recall Load Upper Immediate (LUI)

• So how does lui help us?

- Now each I-format instruction has only a 16-bit immediate.
- Assembler can do this automatically!
 - If number too big, then just automatically replace addi with lui, ori, add

True Assembly Language

- Pseudoinstruction: A MIPS instruction that doesn't turn directly into a machine language instruction.

 Assignment Project Exam Help

 What happens with

 ?
- - https://eduassistpro.github.io/ everal real" MIPS They're broken up b instructions. Add WeChat edu_assist_pro
 - But what is a "real" MIPS instruction? Answer in a few slides
- First some examples

31

Example Pseudoinstructions

Register Move

```
move reg2, reg1
  Expands to: Assignment Project Exam Help
  add reg2, $ze
                    https://eduassistpro.github.io/

    Load Immediate

         reg, valueAdd WeChat edu_assist_pro
  If value fits in 16 bits:
  addi req, $zero, value
  else:
  lui
         reg, upper 16 bits of value
         req, req, lower 16 bits
  ori
```

True Assembly Language

• Problem:

- When breaking up a pseudoinstruction, the assembler may need to use an extra registerignment Project Exam Help
- If it uses any regular https://eduassistpro.github.io/
 put into it.

Add WeChat edu_assist_pro

• Solution:

- Reserve a register (\$1, called \$at for "assembler temporary") that the assembler will use when breaking up pseudo-instructions.
- Since the assembler may use this at any time, it's not safe to code with it.

cGill COMP273 33

Example Pseudoinstructions

Rotate Right Instruction

```
ror reg, value

Expands to:

$\frac{\text{Signment Project Exam Help}}{0}$

$\frac{\text{san https://eduassistpro.github.io}}{0}$

$\frac{\text{san https://eduassistpro.github.io}}{0}$

$\frac{\text{san https://eduassistpro.github.io}}{0}$

$\frac{\text{san https://eduassistpro.github.io}}{0}$

$\frac{\text{san https://eduassistpro.github.io}}{0}$

$\frac{\text{reg reg 3}}{\text{Add WeChat edu_assist_pro}}$

or reg, \text{reg, \text{$\text{yend}}}$
```

No operation instruction

```
nop

Expands to instruction = \mathbf{0}_{ten}
sll $0, $0, 0
```

Example Pseudoinstructions

Wrong operation for operand

```
If value fits in 16 bits:

addiu reg, reg, value # should be addiu

Assignment Project Exam Help

addiu reg, reg, https://eduassistpro.github.io/

else:

Add WeChat edu_assist_pro

lui $at, upper 16 bits of

ori $at, $zero, lower 16 bits of value

addu reg, reg, $at
```

McGill COMP273 35

True Assembly Language

- MAL (MIPS Assembly Language): the set of instructions that a programmer may use to code in MIPS; this includes Assignment Project Exam Help pseudoinstructions
- TAL (True Assembly https://eduassistpro.github.touctions that can actually get translate. dout we chiat edu_assist_enanguage instruction (32-bit binary string)
- A program must be converted from MAL into TAL before it can be translated into 1s and 0s.

Questions on Pseudoinstructions

- How does MIPS assembler recognize pseudoinstrucitons?
 - It looks for officially defined pseudo-instructions, such as ror and Assignment Project Exam Help
 - It looks for special c https://eduassistpro.githulmicorrect for the operation and tries to handle it great edu_assist_pro

Question

- Which lines below are pseudo-instructions (MIPS Assembly Language); that is, not TAL?
 - 1. addi \$t0, \$t1, 400 Assignment Project Exam Help
 - 2. beq \$s0, 10, Exit https://eduassistpro.github.io/
 - 3. sub \$t0, \$t1, 1 Add WeChat edu_assisy_pro
 - B. 2 only
 - C. 3 only
 - D. 1 and 2
 - E. 2 and 3
 - F. All of the above

38

McGill COMP273

Question

 Which lines below are pseudo-instructions (MIPS Assembly Language); that is, not TAL?

- 1. addi \$t0, \$t1, 400 | 40,000 > +32,767 thus need lui, ori
- 2. beq \$s0, 10, Exit https://eduassistpro.github.io/
- 3. sub \$t0, \$t1, 1 Add WeChat edu_assis*_pro

sub: both must be registers; even if it was subi, there is no subi in TAL; generates addi \$t0,\$t1, -1

- B. 2 only
- C. 3 only
- D. 1 and 2
- E. 2 and 3
- F. All of the above

McGill COMP273

Summary

R	opcode	rs	rt	rd	shamt	funct
I	opcode	rs	rt	immediate		
J	opcode	Assignment Project Examples				

- Machine Lang
 32 bits repre

 https://eduassistpro.github.io/

 n
- Branches use PC-relative ad edu_assist_pro
 Jumps use absolute addressing
- Disassembly is easy: starts by decoding opcode field
- Assembler expands real instruction set (TAL) with pseudoinstructions (MAL)

Summary

• To understand the MIPS architecture and be sure to get best performance, it is best to study the True Assembly Language instructions.

Assignment Project Exam Help

https://eduassistpro.github.io/

Add WeChat edu_assist_pro

Organization of an Assembly Program

Assembly Program

- Just plain text file with data declarations, program code
- Suffix .asm for MARS simulator (suffix .s in some other simulators)
- Contains dassignments Parojection de Section
- Data Declaratio
 - https://eduassistpro.github.io/

 Placed in sectio
 - Declares variable not the district edu_assist a posted in main memory (RAM)

Code

- Placed in section of text identified with assembler directive .text
- Contains program code (instructions)
- Starting point for code execution given label main:
- Ending point of main code should use exit system call (more later...)

Template for a MIPS program

Data Declarations

Format for declarations:

```
name: .storage type value(s)

Assignment Project Exam Help

Optional label identi

v color
```

- Storage type directi https://eduassistpro.gjtbผู่อย่อ/
- Create storage for variable of Chet edu_assistipen name, specified value
- Value(s) gives initial value(s), except for storage type .space, when the value gives number of bytes to be allocated

Data Declaration Examples

```
.word 3
var1:
                         # integer variable with initial value 3
array1: .byte 'a','b' # 2-element character array,
                         # with elements initialized to a and b
               Assignment Project Exam Help
array2: .space 40
                                             tive bytes,
                    https://eduassistpro.gializedo/character
                    # array, or t integer array;
Add# We mhat edu_assistateronich!
str1: .asciiz "hi!" # null terminated string 68 69 21 00
w1: .word 0x00216968 # same as str1 for little endian
w2: .word 0x68692100 # same as strl for big endian
myStructure:
                         # structure with a float and string pointer
       1.5
.float
.word
        str1
```

Little Endian vs Big Endian How are words stored in Memory?

- Little endian Stores the Least significant byte at the lowestraddress Example Helpel Pentium Processors. https://eduassistpro.github.io/
- **Big endian** Stores the Add WeChat edu_assist_pro byte at the **lowest addr** ple: Sun/SPARC, IBM/RISC 6000.

System Calls and I/O (MARS Simulator)

Service	Code	Arguments	Result
print integer	1	\$a0 = value	(none)
print float	2	\$f12 = float value	(none)
print double	Ass	signmentePreject Exam Help	(none)
print string	4	ring	(none)
read integer	5	https://eduassistpro.github	\$v0 = value read
read float	6	(nArd)d WeChat edu_assist_p	0\$€ = value read
read double	7	(none)	\$f0 = value read
read string	8	\$a0 = address where string to be stored \$a1 = number of characters to read + 1	(none)
memory allocation	9	\$a0 = number of bytes of storage desired	\$v0 = address of block
exit (end program)	10	(none)	(none)

Hello World Example

```
string1: .asciiz "Hello World.\n"

Assignment Project Exam Help
.text

main: li $v0, 4 https://eduassistpro.glihoub.lo/fint into $v0
la $a0, s https://eduassistpro.glihoub.lo/fint into $a0
syscall
li $v0, 10Add Welchat edu_assisthepro into $v0
syscall # call operating system to exit
```

LA and LI pseudoinstructions do the same job.
Using LA instead of LI lets us show that we are loading an address.

We should probably skip the rest of this stuff...

Assignment Project Exam Help

https://eduassistpro.github.io/

Add WeChat edu_assist_pro

Examples using Pointers

- The following slides are more practice on the differences between a pointer and a value, and showing how to use Assignment Project Exam Help pointers
- Example uses of poi https://eduassistpro.github.io/
 - Arrays of primitive typed (Wg. Chat edu_assist_pro
 - Pointers to data structures

Assembly Code to Implement Pointers

Dereferencing ⇒ data transfer in assembly

Assembly Code to Implement Pointers

Let c be an int, have value 100, be at memory address 0x10000000. Let p be in \$a0, x in \$s0

p = &c; /* p gets 0 Assignment Project Exam Help

Practice with Arrays

Implement a bubble sort function

```
void bubblesort( int* A, int length ) {
  boolean swapped;
 int n = lengassignment Project Exam Help
  do {
   swapped = fals
for ( int i = https://eduassistpro.github.io/
     if ( A[i] > A[i+1] ) {
       swap(A, i Add WeChat edu_assist_pro
       swapped = true;
                           Void swap( int* A, int i, int j ) {
   n = n - 1;
                             int tmp = A[i];
  } while ( swapped );
                             A[i] = A[j];
                             A[j] = tmp;
```

Pointers to Structures

```
value
    C Example
    linked list:
struct nasignment Projectalus Heyalue
     struct https://eduassistpro.github.io/
     int value;
Add WeChat edu_assist_pro
If p is a pointer to a node, declared with
struct node *p, then:
(*p).value or p->value for "value" field,
(*p) .next or p->next for pointer to next node
```

Linked-list in C

```
main (void) {
  struct node *head, *temp, *ptr;
  int sum;
  /* create the nodes*/
  head = (struct node *) malloc(sizeof(struct node));
head->value Assemment Project Exam Help
  head->next = 0;
  temp = (struct https://eduassistpro.giththuco/node));
  temp->next = he
  temp->value = 42;
Add WeChat edu_assist_pro
  head = temp;
  /* add up the values */
  ptr = head; sum = 0;
  while (ptr != 0) {
    sum += ptr->value;
    ptr = ptr->next;
```

Linked-list in MIPS Assember (1/2)

```
# head:s0, temp:s1, ptr:s2, sum:s3
 # create the nodes
      li $a0,8# sizeof(node)
      jal malloc # the call
      moveAssignment Pr#jentalexametselpesult
In MARS we would use
      li
           $t
           $thttps://eduassistpro.githebue/= 23
$z ext = NULL
      SW
      SW
     Add WeChat edu_assist_pro $a0,8
      jal
          malloc
     move $s1,$v0 # temp = malloc
      sw $s0,0($s1) # temp->next = head
      li $t0,42
          $t0,4($s1) # temp->value = 42
      SW
      move $s0,$s1 # head = temp
```

Linked-list in MIPS Assember (2/2)

```
# head:s0, temp:s1, ptr:s2, sum:s3
       #Assignment Peroject Jessam Help
                              ptr = head
       move
       move https://eduassistpro.github.io/0
loop: beq $$2 $zero
lw $t0,4($$2 et value
       addu $s3,$s3,$t0 # compute new sum
       lw $$3,0($$2) # ptr = ptr->next
                         # repeat
            loop
exit:
```

Review and More Information

- Textbook
 - 2.5 Representing Instructions in the computer Assignment Project Exam Help
 2.10 Addressing for

 - 2.12 Translating and https://eduassistpro.github.io/
 - Just the section on the Assemble length iedu_assist_psecodoinstructions (pg 124, 125, 5th edition)

McGill COMP273 58