

BL702/704/706

参考手册


版本: 1.1

版权 @ 2021

www.bouffalolab.com

Contents

1	系统	统和存储	皆器概述	22
	1.1	简介		22
	1.2	主要特	時征	22
	1.3	功能推	描述	22
2	复	位和时钟	þ	26
	2.1	简介		26
	2.2	复位源	原	26
	2.3	时钟源	原	27
3	GL	.B		29
	3.1	简介		29
	3.2	功能指	描述	29
		3.2.1	时钟管理	29
		3.2.2	复位管理	29
		3.2.3	总线管理	31
		3.2.4	内存管理	31
		3.2.5	GPIO 概述	31
		3.2.6	GPIO 主要特点	31
		3.2.7	GPIO 功能描述	31
		3.2.8	GPIO 功能设定	32
		3.2.9	GPIO 输出设置	37
		3.2.10	GPIO 输入设置	37
		3.2.11	GPIO 可选功能设置	37
		3.2.12	GPIO 中断设置	37
	3.3	寄存器	器描述	38
		3.3.1	clk_cfg0	40
		3.3.2	clk cfq1	41





3.3.3	clk_cfg2	42
3.3.4	clk_cfg3	42
3.3.5	swrst_cfg0	43
3.3.6	swrst_cfg1	44
3.3.7	swrst_cfg2	45
3.3.8	cgen_cfg0	46
3.3.9	cgen_cfg1	46
3.3.10	bmx_cfg1	47
3.3.11	bmx_cfg2	47
3.3.12	bmx_err_addr	48
3.3.13	seam_misc	48
3.3.14	CPU_CLK_CFG	49
3.3.15	GPADC_32M_SRC_CTRL	49
3.3.16	DIG32K_WAKEUP_CTRL	50
3.3.17	UART_SIG_SEL_0	50
3.3.18	GPIO_CFGCTL0	53
3.3.19	GPIO_CFGCTL1	54
3.3.20	GPIO_CFGCTL2	55
3.3.21	GPIO_CFGCTL3	56
3.3.22	GPIO_CFGCTL4	57
3.3.23	GPIO_CFGCTL5	58
3.3.24	GPIO_CFGCTL6	59
3.3.25	GPIO_CFGCTL7	60
3.3.26	GPIO_CFGCTL8	61
3.3.27	GPIO_CFGCTL9	62
3.3.28	=	63
3.3.29	GPIO_CFGCTL11	64
3.3.30	GPIO_CFGCTL12	65
3.3.31	GPIO_CFGCTL13	66
3.3.32	GPIO_CFGCTL14	67
3.3.33	GPIO_CFGCTL15	68
3.3.34	GPIO_CFGCTL16	69
3.3.35	GPIO_CFGCTL17	69
3.3.36	GPIO_CFGCTL18	70
3.3.37	GPIO_CFGCTL30	71
3.3.38	GPIO_CFGCTL32	72
3.3.39	GPIO_CFGCTL34	74
3.3.40	GPIO_CFGCTL35	76
3.3.41	GPIO_INT_MASK1	77



	3.3.42	GPIO_INT_STAT1	77
	3.3.43	GPIO_INT_CLR1	77
	3.3.44	GPIO_INT_MODE_SET1	78
	3.3.45	GPIO_INT_MODE_SET2	78
	3.3.46	GPIO_INT_MODE_SET3	79
	3.3.47	GPIO_INT_MODE_SET4	80
	3.3.48	GPIO_INT2_MASK1	81
	3.3.49	GPIO_INT2_STAT1	82
	3.3.50	GPIO_INT2_CLR1	82
	3.3.51	GPIO_INT2_MODE_SET1	82
	3.3.52	GPIO_INT2_MODE_SET2	83
	3.3.53	GPIO_INT2_MODE_SET3	84
	3.3.54	GPIO_INT2_MODE_SET4	85
	3.3.55	led_driver	86
	3.3.56	usb_xcvr	87
	3.3.57	usb_xcvr_config	88
	3.3.58	gpdac_ctrl	89
	3.3.59	gpdac_actrl	90
	3.3.60	gpdac_bctrl	90
	3.3.61	gpdac_data	91
1 A[OC		92
4.1	简介		92
4.2	主要特	侍点	92
4.3	功能抗	描述	93
	4.3.1	ADC 引脚和内部信号	93
	4.3.2	ADC 通道	94
	4.3.3	ADC 时钟	95
	4.3.4	ADC 转换模式	96
	4.3.5	ADC 结果	96
	4.3.6	ADC 异常中断	97
	4.3.7	ADC FIFO 与阈值中断	97
	4.3.8	ADC 设置流程	98
	4.3.9	VBAT 测量	98
	4.3.10	TSEN 测量	99
4.4	寄存器	器描述	99
	4.4.1	gpadc_config	100
	4.4.2	gpadc_dma_rdata	101
	4.4.3	gpadc_reg_cmd	101
	4.4.4	gpadc_reg_config1	104



	4.4.5	gpadc_reg_config2	106
	4.4.6	gpadc_reg_scn_pos1	108
	4.4.7	gpadc_reg_scn_pos2	108
	4.4.8	gpadc_reg_scn_neg1	109
	4.4.9	gpadc_reg_scn_neg2	109
	4.4.10	gpadc_reg_status	110
	4.4.11	gpadc_reg_isr	110
	4.4.12	gpadc_reg_raw_result	111
	4.4.13	gpadc_reg_define	111
5 D	AC		112
5.1	简介		112
5.2	主要朱	寺点	112
5.3	功能指	描述	112
5.4	寄存器	器描述	114
	5.4.1	gpdac config	114
	5.4.2	gpdac dma config	115
	5.4.3	gpdac dma wdata	116
	5.4.4	gpdac_ctrl	116
	5.4.5	gpdac_actrl	117
	5.4.6	gpdac bctrl	117
	5.4.7	gpdac data	118
6 D	MA	· · · · · · · · · · · · · · · · · · ·	119
6.1			119
6.2		· 导征	119
6.3		描述	120
	6.3.1	工作原理	120
	6.3.2	DMA 通道配置	121
	6.3.3	外设支持	121
	6.3.4	链表模式	122
	6.3.5	DMA 中断	123
6.4	- 传输模	莫式	123
	6.4.1	内存到内存	123
	6.4.2	内存到外设	123
	6.4.3	外设到内存	124
	6.4.4	外设到外设	124
6.5		器描述	124
٥.٠	6.5.1	DMA IntStatus	126
	6.5.2	DMA_IntTCStatus	127
	6.5.3	DMA IntTCClear	127



6.5.4	DMA_IntErrorStatus
6.5.5	DMA_IntErrClr
6.5.6	DMA_RawIntTCStatus
6.5.7	DMA_RawIntErrorStatus
6.5.8	DMA_EnbldChns
6.5.9	DMA_SoftBReq
6.5.10	DMA_SoftSReq
6.5.11	DMA_SoftLBReq
6.5.12	DMA_SoftLSReq
6.5.13	DMA_Config
6.5.14	DMA_Sync
6.5.15	DMA_C0SrcAddr
6.5.16	DMA_C0DstAddr
6.5.17	DMA_C0LLI
6.5.18	DMA_C0Control
6.5.19	DMA_C0Config
6.5.20	DMA_C1SrcAddr
6.5.21	DMA_C1DstAddr
6.5.22	DMA_C1LLI
6.5.23	DMA_C1Control
6.5.24	DMA_C1Config
6.5.25	DMA_C2SrcAddr
6.5.26	DMA_C2DstAddr
6.5.27	DMA_C2LLI
6.5.28	DMA_C2Control
6.5.29	DMA_C2Config
6.5.30	DMA_C3SrcAddr
6.5.31	DMA_C3DstAddr
6.5.32	DMA_C3LLI
6.5.33	DMA_C3Control
6.5.34	DMA_C3Config
6.5.35	DMA_C4SrcAddr
6.5.36	DMA_C4DstAddr
6.5.37	DMA_C4LLI
6.5.38	DMA_C4Control
6.5.39	DMA_C4Config
6.5.40	DMA_C5SrcAddr
6.5.41	
6.5.42	



6.5.43	DMA_C5Control	148
6.5.44	DMA_C5Config	149
6.5.45	DMA_C6SrcAddr	150
6.5.46	DMA_C6DstAddr	150
6.5.47	DMA_C6LLI	150
6.5.48	DMA_C6Control	151
6.5.49	DMA_C6Config	152
6.5.50	DMA_C7SrcAddr	153
6.5.51	DMA_C7DstAddr	153
6.5.52	DMA_C7LLI	153
6.5.53	DMA_C7Control	154
6.5.54	DMA_C7Config	155
7 L1C		156
7.1 简介		156
7.2 主要特	特征	157
7.3 功能	描述	157
7.3.1	TCM 与 Cache RAM 资源相互变换......................	157
7.3.2	缓存 (Cache)	157
7.4 寄存	器描述	158
7.4.1	I1c_config	159
7.4.2	hit_cnt_lsb	159
7.4.3	hit_cnt_msb	159
7.4.4	miss_cnt	160
8 IR		161
8.1 简介		161
8.2 主要特	特征	161
8.3 功能	描述	161
8.3.1	固定协议接收	161
8.3.2	脉冲宽度接收	163
8.3.3	普通发送模式	163
8.3.4	脉冲宽度发送	163
8.3.5	载波调制	163
8.3.6	IR 中断	164
8.4 寄存	器描述	164
8.4.1	irtx_config....................................	165
8.4.2	irtx_int_sts	166
8.4.3	 irtx_data_word0	166
8.4.4	 irtx_data_word1...............................	167
8.4.5	irtx pulse width	167



	8.4.6	irtx_pw	37
	8.4.7	irtx_swm_pw_0	38
	8.4.8	irtx_swm_pw_1	38
	8.4.9	irtx_swm_pw_2	39
	8.4.10	irtx_swm_pw_3	39
	8.4.11	irtx_swm_pw_4	70
	8.4.12	irtx_swm_pw_5	70
	8.4.13	irtx_swm_pw_6	70
	8.4.14	irtx_swm_pw_7	71
	8.4.15	irrx_config	71
	8.4.16	irrx_int_sts	72
	8.4.17	irrx_pw_config	73
	8.4.18	irrx_data_count	73
	8.4.19	irrx_data_word0	73
	8.4.20	irrx_data_word1	74
	8.4.21	irrx_swm_fifo_config_0	74
	8.4.22	irrx_swm_fifo_rdata	75
9 SI	PI		76
9.1	简介		76
9.2	主要特	寺征	76
9.3	功能指	苗述	77
	9.3.1	时钟控制	77
	9.3.2	主设备持续传输模式	77
	9.3.3	接收过滤功能	77
	9.3.4	接收去差错功能	78
	9.3.5	从模式超时机制	78
	9.3.6	I/O 传输模式	78
	9.3.7	DMA 传输模式	78
	9.3.8	SPI 中断	79
9.4	寄存器	暑描述	79
	9.4.1	spi_config	30
	9.4.2	spi_int_sts	31
	9.4.3	spi_bus_busy	32
	9.4.4	spi_prd_0	33
	9.4.5	spi_prd_1	33
	9.4.6	spi_rxd_ignr	33
	9.4.7	spi_sto_value	34
	9.4.8	spi_fifo_config_0	34
	9.4.9	spi_fifo_config_1	35



9.4.10	spi_fifo_wdata	. 185
9.4.11	spi_fifo_rdata	. 186
10 UART .		. 187
10.1 简介	•	. 187
10.2 主要特	特征	. 187
10.3 功能扩	描述	. 188
10.3.1	数据格式描述	. 188
10.3.2	基本架构图	. 188
10.3.3	时钟源	. 188
10.3.4	波特率设定	. 189
10.3.5	发送器	. 189
10.3.6	接收器	. 190
10.3.7	自动波特率检测	. 190
10.3.8	硬件流控	. 191
10.3.9	LIN 传输模式	. 191
10.3.10	D DMA 传输模式	. 191
10.3.11	I UART 中断	. 191
10.4 寄存器	器描述	. 192
10.4.1	utx_config	. 193
10.4.2	urx_config	. 194
10.4.3	uart_bit_prd	. 195
10.4.4	data_config	. 195
10.4.5	utx_ir_position	. 195
10.4.6	urx_ir_position	. 196
10.4.7	urx_rto_timer	. 196
10.4.8	uart_sw_mode	. 197
10.4.9	uart_int_sts	. 197
10.4.10) uart_int_mask 198
10.4.11	l uart_int_clear	. 199
10.4.12	 2 uart_int_en	. 199
10.4.13	B uart_status	. 200
10.4.14		. 200
	 5_uart_fifo_config_0..............................	
	G G_uart_fifo_config_1	
	 3 uart_fifo_rdata	
11 2 主要组		203



11.3 功	能描述
11.3.	1 起始和停止条件
11.3.2	2 数据传输格式
11.3.	3 仲裁
11.4 120	C 时钟设定
11.5 120	C配置流程
11.5.	1 配置项
11.5.2	2 读写标志位
11.5.	3 从设备地址
11.5.4	4 从设备寄存器地址
11.5.	5 从设备寄存器地址长度
11.5.0	6 数据 20
11.5.	7 数据长度 20
11.5.8	3 使能信号 20
11.6 FIF	FO 管理
11.7 搭	配使用 DMA
11.7.	1 DMA 发送流程 20
11.7.	2 DMA 接收流程 20
11.8 中国	新
11.9 寄	存器描述
11.9.	1 i2c_config
11.9.2	2 i2c_int_sts
11.9.3	3 i2c_sub_addr
11.9.4	4 i2c_bus_busy
11.9.	5 i2c_prd_start
11.9.0	6 i2c_prd_stop
11.9.	7 i2c_prd_data
11.9.8	3 i2c_fifo_config_0
11.9.9	9 i2c_fifo_config_1
11.9.	10 i2c_fifo_wdata
11.9.	11 i2c_fifo_rdata
12 PWM .	
12.1 简:	介
12.2 主	要特征
12.3 功	能描述
12.3.	1 时钟与分频器
12.3.	2 脉冲产生原理
12.3.	3 PWM 中断



12.4 寄存器	器描述	220
12.4.1	pwm_int_config	222
12.4.2	pwm0_clkdiv	222
12.4.3	pwm0_thre1	222
12.4.4	pwm0_thre2	223
12.4.5	pwm0_period	223
12.4.6	pwm0_config	224
12.4.7	pwm0_interrupt	224
12.4.8	pwm1_clkdiv	225
12.4.9	pwm1_thre1	225
12.4.10	pwm1_thre2	225
12.4.11	pwm1_period	226
12.4.12	pwm1_config	226
12.4.13	pwm1_interrupt	227
12.4.14	pwm2_clkdiv	227
12.4.15	pwm2_thre1	228
12.4.16	pwm2_thre2	228
12.4.17	pwm2_period	228
12.4.18	pwm2_config	229
12.4.19	pwm2_interrupt	229
12.4.20	pwm3_clkdiv	230
12.4.21	pwm3_thre1	230
12.4.22	pwm3_thre2	231
12.4.23	pwm3_period	231
12.4.24	pwm3_config	231
12.4.25	pwm3_interrupt	232
12.4.26	pwm4_clkdiv	232
12.4.27	pwm4_thre1	233
12.4.28	pwm4_thre2	233
12.4.29	pwm4_period	234
12.4.30	pwm4_config	234
12.4.31	pwm4_interrupt	235
13 TIMER		236
13.1 简介		236
13.2 主要特	寺征	237
13.3 功能排	苗述	237
13.3.1	8-bit 分频器	237
13.3.2	通用定时器工作原理	238
13.3.3	看门狗定时器工作原理	239



13	3.3.4	报警设定 .																		239
13	3.3.5	看门狗报警																		239
13.4	寄存器	・ ・ ・ ・ ・ ・ ・ ・ ・ ・ ・ ・ ・ ・ ・ ・ ・ ・ ・																		240
13	3.4.1	TCCR																		242
13	3.4.2	TMR2_0 .																		242
13	3.4.3	TMR2_1 .																		243
13	3.4.4	TMR2_2 .																		243
13	3.4.5	TMR3_0 .																		243
13	3.4.6	TMR3_1 .																		244
13	3.4.7	TMR3_2 .																		244
13	3.4.8	TCR2																		244
13	3.4.9	TCR3																		245
13	3.4.10	TMSR2																		245
13	3.4.11	TMSR3																		246
13	3.4.12	TIER2																		246
13	3.4.13	TIER3																		247
13	3.4.14	TPLVR2 .																		247
13	3.4.15	TPLVR3 .																		247
13	3.4.16	TPLCR2 .																		248
13	3.4.17	TPLCR3 .																		248
13	3.4.18	WMER																		249
13	3.4.19	WMR																		249
13	3.4.20	WVR																		249
13	3.4.21	WSR																		250
13	3.4.22	TICR2																		250
13	3.4.23	TICR3																		251
13	3.4.24	WICR																		251
13	3.4.25	TCER																		252
13	3.4.26	TCMR																		252
13	3.4.27	TILR2																		253
13	3.4.28	TILR3																		253
13	3.4.29	WCR																		254
13	3.4.30	WFAR																		254
13	3.4.31	WSAR																		255
13	3.4.32	TCVWR2 .																		255
13	3.4.33	TCVWR3 .																		255
13	3.4.34	TCVSYN2																		256
13	3.4.35	TCVSYN3																		256
13	3.4.36	TCDR																		256



14 QDE	C		 	 	 	 	 		257
14.1	简介		 	 	 	 	 	 •	257
14.2	主要特	征	 	 	 	 	 		257
14.3	功能描	述	 	 	 	 	 		258
14.4	寄存器	¦描述	 	 	 	 	 	 •	259
14	.4.1	qdec0_ctrl0	 	 	 	 	 		259
14	.4.2	qdec0_ctrl1	 	 	 	 	 		260
14	.4.3	qdec0_value	 	 	 	 	 		261
14	.4.4	qdec0_int_en	 	 	 	 	 	 •	262
14	.4.5	qdec0_int_sts	 	 	 	 	 		262
14	.4.6	qdec0_int_clr	 	 	 	 	 		263
14	.4.7	qdec1_ctrl0	 	 	 	 	 		263
14	.4.8	qdec1_ctrl1	 	 	 	 	 		264
14	.4.9	qdec1_value	 	 	 	 	 		265
14	.4.10	qdec1_int_en	 	 	 	 	 		265
14	.4.11	qdec1_int_sts	 	 	 	 	 		266
14	.4.12	qdec1_int_clr	 	 	 	 	 		266
14	.4.13	qdec2_ctrl0	 	 	 	 	 	 •	267
14	.4.14	qdec2_ctrl1	 	 	 	 	 	 •	268
14	.4.15	qdec2_value	 	 	 	 	 	 •	268
14	.4.16	qdec2_int_en	 	 	 	 	 	 •	269
14	.4.17	qdec2_int_sts	 	 	 	 	 	 •	269
14	.4.18	qdec2_int_clr	 	 	 	 	 		270
15 KeyS	can .		 	 	 	 	 		271
15.1	简介		 	 	 	 	 		271
15.2	主要特	征	 	 	 	 	 		271
15.3	功能描	述	 	 	 	 	 		271
15	.3.1	可配置的行列数	 	 	 	 	 	 •	271
15	.3.2	GPIO 选择	 	 	 	 	 	 •	271
15	.3.3	键值	 	 	 	 	 	 •	272
15	.3.4	中断	 	 	 	 	 	 •	272
15.4	寄存器	描述	 	 	 	 	 	 •	272
15	.4.1	ks_ctrl	 	 	 	 	 	 •	272
15	.4.2	ks_int_en	 	 	 	 	 	 •	273
15	.4.3	ks_int_sts	 	 	 	 	 	 •	273
15	.4.4	keycode_clr	 	 	 	 	 		274
15	.4.5	keycode_value	 	 	 	 	 	 •	274
16 I2S .			 	 	 	 	 		275
16.1	简介				 	 	 		275



16.2 主要特	特征	. 275
16.3 功能	描述	. 275
16.4 寄存	器描述	. 276
16.4.1	i2s_config	. 276
16.4.2	i2s_int_sts	. 278
16.4.3	i2s_bclk_config	. 279
16.4.4	i2s_fifo_config_0	. 279
16.4.5	i2s_fifo_config_1	. 280
16.4.6	i2s_fifo_wdata	. 281
16.4.7	i2s_fifo_rdata	. 281
16.4.8	i2s_io_config	. 281
17 Emac .		. 283
17.1 简介		. 283
17.2 主要特	特征	. 283
17.3 功能	描述	. 284
17.4 时钟		. 286
17.5 收发约	缓冲描述符 (BD, Buffer Descriptor)........................	. 286
17.6 PHY	′交互	. 286
17.7 编程》	流程	. 287
17.7.1	PHY 初始化	. 287
17.7.2	发送数据帧	. 287
17.7.3	接收数据帧	. 288
17.8 寄存	器描述	. 288
17.8.1	MODE	. 289
17.8.2	INT_SOURCE	. 291
17.8.3	INT_MASK	. 292
17.8.4	IPGT	
17.8.5	PACKETLEN	. 293
17.8.6	COLLCONFIG	. 294
17.8.7	TX_BD_NUM	. 295
17.8.8	MIIMODE	. 295
17.8.9	MIICOMMAND	. 296
17.8.10	MIIADDRESS	. 296
17.8.11	I MIITX_DATA	. 297
17.8.12	2 MIIRX_DATA	. 297
17.8.13	3 MIISTATUS	. 298
17.8.14	4 MAC_ADDR0	. 298
17.8.15	MAC_ADDR1	. 299
	- 5 HASH0_ADDR	



17.8.17	HASH1_ADDR						 •			•		•	299
17.8.18	TXCTRL												300
18 USB													301
18.1 简介													301
18.2 主要特	寺征												301
18.3 功能排	描述						 •						301
18.3.1	USB 使用步骤												301
18.3.2	部分寄存器配置及功能描述												302
18.3.3	USB 枚举阶段中断处理流程												304
18.3.4	各传输事务的寄存器操作流程												304
18.4 寄存器	器描述												308
18.4.1	usb_config												310
18.4.2	usb_lpm_config												311
18.4.3	usb_resume_config												312
18.4.4	usb_frame_no												312
18.4.5	usb_error												313
18.4.6	usb_int_en												313
18.4.7	usb_int_sts												315
18.4.8	usb_int_mask												316
18.4.9	usb_int_clear												317
18.4.10	ep1_config												319
18.4.11	ep2_config												320
18.4.12	ep3_config												321
18.4.13	ep4_config												322
18.4.14	ep5_config												323
18.4.15	ep6_config												324
	ep7_config												325
18.4.17	ep0_fifo_config												326
18.4.18	ep0_fifo_status												326
18.4.19	ep0_tx_fifo_wdata												327
18.4.20	ep0_rx_fifo_rdata												327
18.4.21	ep1_fifo_config												328
18.4.22	ep1_fifo_status												328
18.4.23	ep1_tx_fifo_wdata												329
18.4.24	ep1_rx_fifo_rdata												329
18.4.25	ep2_fifo_config												330
18.4.26	ep2_fifo_status												330
18.4.27	ep2_tx_fifo_wdata								. .				331
18.4.28	ep2_rx_fifo_rdata												331



18.4.29	9 ep3_fifo_config	. 332
18.4.30	0 ep3_fifo_status	. 332
18.4.31	1 ep3_tx_fifo_wdata	. 333
18.4.32	2 ep3_rx_fifo_rdata	. 333
18.4.33	3 ep4_fifo_config	. 334
18.4.34	4 ep4_fifo_status	. 334
18.4.35	5 ep4_tx_fifo_wdata	. 335
18.4.36	6 ep4_rx_fifo_rdata	. 335
18.4.37	7 ep5_fifo_config	. 336
18.4.38	8 ep5_fifo_status	. 336
18.4.39	9 ep5_tx_fifo_wdata	. 337
18.4.40	0 ep5_rx_fifo_rdata	. 337
18.4.41	1 ep6_fifo_config	. 338
18.4.42	2 ep6_fifo_status	. 338
18.4.43	3 ep6_tx_fifo_wdata	. 339
18.4.44	4 ep6_rx_fifo_rdata	. 339
18.4.45	5 ep7_fifo_config	. 340
18.4.46	6 ep7_fifo_status	. 340
18.4.47	7 ep7_tx_fifo_wdata	. 341
18.4.48	8 ep7_rx_fifo_rdata	. 341
18.4.49	9 xcvr_if_config	. 342
19 LowPower	er	. 343
19.1 概述	È	. 343
19.2 主要	「特征	. 343
19.3 功能	#描述	. 344
19.3.1	电源域	. 344
19.3.2	唤醒源	. 345
19.3.3	功耗模式	. 346
19.4 PDS	3 寄存器描述	. 347
19.4.1	PDS_CTL	. 347
19.4.2	PDS_TIME1	. 349
19.4.3	PDS_INT	. 350
19.4.4	PDS_CTL2	. 351
19.4.5	PDS_CTL3	. 352
19.4.6	PDS_CTL4	. 353
19.4.7	pds_stat	. 355
19.4.8	pds_ram1	. 356
19.4.9	pds_gpio_set_pu_pd	. 357
19.4.10	0 pds_gpio_int	. 359



19.5 H	HBN ⁴	寄存器描述														359
19.	5.1	HBN_CTL														360
19.	5.2	HBN_TIME_L														361
19.	5.3	HBN_TIME_H														361
19.	5.4	RTC_TIME_L														362
19.	5.5	RTC_TIME_H														362
19.	5.6	HBN_IRQ_MO	DE .													362
19.	5.7	HBN_IRQ_STA	AT .													363
19.	5.8	HBN_IRQ_CLI	₹													364
19.	5.9	HBN_PIR_CF	Э.,													364
19.	5.10	HBN_PIR_VTH	┨													365
19.	5.11	HBN_PIR_INT	ERVA	۸L.												365
19.	5.12	HBN_MISC .														366
19.	5.13	HBN_GLB .														367
19.	5.14	HBN_SRAM														368
20 版本信	息 .							 								370

List of Figures


	复位源	27 28
3.1	GPIO 基本框图	32
	ADC 基本框图	93 95
5.1	DAC 基本框图	113
	DMA 框图	120 122
	LIC 架构	156 158
8.2 8.3	NEC 逻辑波形 NEC 协议波形 RC5 逻辑波形 RC5 协议波形	162 162 162 163
	SPI 时序图	177 178
10.2 10.3 10.4	UART 数据格式 UART 时钟 UART 采样波形图 UART 固定字符模式波形图 UART 硬件流控图	188 188 189 190 191
	I2C 起始和停止条件	



11.2	I2C 数据传输格式	204
11.3	主发送和从接收的时序	205
11.4	主接收和从发送的时序	205
11.5	同时传输数据波形示意图	206
12.1	PWM 波形图	219
13.1	定时器框图	236
13.2	看门狗定时器框图	237
13.3	定时器在 PreLoad 模式下工作时序	238
13.4	Watchdog 工作时序	239
13.5	看门狗报警机制	240
14.1	QDEC 功能框图	258
17.1	EMAC 框图	285
18.1	USB 中断触发方式	303
18.2	USB 通信方式	306
19.1	低功耗模式	343

List of Tables

1.1	总线连接	22
1.2	地址映像	23
1.2	地址映像	24
1.3	中断源	24
1.3	中断源	25
1.5	tip tip	20
3.1	软件复位功能表	29
3.1	软件复位功能表	30
3.2	GPIO 功能表 1	33
3.2	GPIO 功能表 1	34
3.3	GPIO 功能表 2	34
3.3	GPIO 功能表 2	35
3.4	GPIO 功能表 3	35
3.4	GPIO 功能表 3	36
	ADC 内部信号	93
	ADC 内部信号	94
4.2	ADC 外部引脚	94
4.3	ADC 转换结果含义	96
5.1	DAC 外部引脚	114
J. 1	DAG / Elp 1/1/4	11-
7.1	WayDisable 的设定	157
11.1	I2C 引脚	203
40.4	上帝儿女业	000
12.1	占空比参数	220
16.1	I2S 引脚	275
17.1	传输信号	286





18.1	寄存器配置	1	 																		307
18.2	寄存器配置	. 2	 																		307
18.2	寄存器配置	. 2	 																		308
19.1	电源模式		 																		345
20.1	修改记录		 																		370

系统和存储器概述

1.1 简介

芯片内处理器采用 32-bit 带浮点的 RISC-V。搭配高速缓存 (详见 L1C 章节),达到优质的运算效率。处理器外部为多层 32-bit AHB 架构,具有低功耗、低延迟、高弹性的特性。内存部分包含高速紧耦合内存以及缓存和系统共享内存。片外存储器支持 Flash 扩充。

1.2 主要特征

- RISC-V 32-bit 带浮点
- 多层 32-bit AHB 总线架构
- 132KB RAM
- 192KB ROM
- 片外存储器 Flash

1.3 功能描述

BL702/704/706 总线连接与地址访问总结如下:总线主机包括 CPU,以太网,DMA,加密引擎,调试接口。总线从机包括内存,外设,Zigbee/BLE。除了以太网和加密引擎只能访问内存外,其余总线主机皆可访问所有总线从机。

表 1.1: 总线连接

从 / 主	CPU	以太网	DMA	加密引擎	调试接口
内存	V	V	V	V	V
外设	V	-	V	-	V
Zigbee/BLE	V	-	V	-	V



地址访问主要以 [27:24] 来区分"存储"或"外设",可忽略 [31:28]。内存空间是连续的 X2010000~X202FFFF (128KB SRAM),只读内存 X1000000,深度睡眠内存 X0010000。片外空间是 X3000000 (最大支持 8MB Flash)。外设空间是 X0000000~X000F000。

表 1.2: 地址映像

目标	开始地址	大小	描述
RETRAM	0x40010000	4KB	深度睡眠内存(保留 RAM)
HBN	0x4000F000	4KB	深度睡眠控制 (休眠)
PDS	0x4000E000	4KB	睡眠控制(掉电睡眠)
USB	0x4000D800	1KB	USB 控制
EMAC	0x4000D000	2KB	EMAC 控制
DMA	0x4000C000	4KB	DMA 控制
QSPI	0x4000B000	4KB	闪存/pSRAM QSPI 控制
128	0x4000AA00	256B	12S 控制
KYS	0x4000A900	256B	Key-Scan 控制
QDEC2	0x4000A880	64B	求积译码器控制
QDEC1	0x4000A840	64B	求积译码器控制
QDEC0	0x4000A800	64B	求积译码器控制
IRR	0x4000A600	256B	红外遥控器
TIMER	0x4000A500	256B	计时器控制
PWM	0x4000A400	256B	脉冲宽度调制控制
I2C	0x4000A300	256B	I2C 控制
SPI	0x4000A200	256B	SPI 主/从控制
UART1	0x4000A100	256B	UART 控制
UART0	0x4000A000	256B	UART 控制
L1C	0x40009000	4KB	缓存控制
eFuse	0x40007000	4KB	eFuse 存储器控制
SEC	0x40004000	4KB	安全引擎
GPIP	0x40002000	4KB	通用 DAC / ADC / ACOMP 接口控制
MIX	0x40001000	4KB	混合信号寄存器
GLB	0x40000000	4KB	全局寄存器
pSRAM	0x24000000	8MB	pSRAM 存储器
XIP	0x23000000	8MB	XIP 闪存
OCRAM	0x22020000	64KB	片上存储器



表 1.2: 地址映像

目标	开始地址	大小	描述
DTCM	0x22014000	48KB	数据高速缓存
ITCM	0x22010000	16KB	指令高速缓存
ROM	0x21000000	192KB	只读存储器

中断源共 64 个,列举如下,电平或边沿触发由 CPU 配置,可屏蔽使用。

表 1.3: 中断源

编号	信号源
54~63	wireless
53	brown-out
51~52	hbn_irq
50	pds_int
47~49	wireless
44	gpio_irq
40~42	qdec_int
39	kys_int
35~38	timer_irq
34	pwm_int
32	i2c_int
30	uart1_irq
29	uart0_irq
27	spi_int
26	efuse_int
25	adc_int
23	flash_int
22	emac_int
21	usb_int
19~20	ir_remote_int



表 1.3: 中断源

编号	信号源
18	i2s_int
15	dma_int
9~14	sec_eng_int
8	err_int
5~6	rf_int
0~4	err_int

复位和时钟

2.1 简介

芯片内部包含的复位源:硬件重置,看门狗重置,软件复位。芯片内包含多个时钟源:XTAL,DLL,RC。搭配分频等配置送至各模块。

2.2 复位源

复位源包含

- 硬件重置: 通过管脚进行重置
 - 管脚电源重置 (PU_CHIP = 0-> 1): 类似电源上电重置
 - 电源上电重置: 芯片从断电中复电, HBN 逻辑将芯片系统进行重置
- 看门狗重置
 - 当看门狗报警触发重置信号时,重置管理单元将在必要准备后,重置芯片系统,看门狗内部逻辑会记录看门狗 重置的状态
- 软件复位: 通过软件设置寄存器进行全局或局部复位
 - 软件初始重置 (reg ctrl pwron rst): 通过软件将该位置 1,进行芯片系统重置
 - 软件 CPU 复位 (reg_ctrl_cpu_reset): 通过软件将该位置 1,进行 CPU 部分系统复位
 - 软件系统复位 (reg_ctrl_sys_reset): 通过软件将该位置 1,保留必要的逻辑处理如电源管理单元,进行芯片部分系统复位
 - 软件模块复位: 根据特定模块的需求,设置软件复位






图 2.1: 复位源

2.3 时钟源

时钟源包含:

- XTAL: 外部晶振时钟,主要支持频率 32MHz
- XTAL32K: 外部晶振时钟,频率 32KHz
- RC32M: RC 振荡器时钟, 频率 32MHz, 提供校准
- DLL: 锁相回路时钟,内部系统高速时钟,最高频率支持 144MHz

时钟控制单元将来自振荡器的时钟分配给内核和外围设备。可通过选择系统时钟源,动态分频器,时钟配置,睡眠使用 32KHz 时钟,以达到低功耗时钟管理。

外围设备时钟包括: Flash、USB2.0、Ethernet、UART、I2C、I2S、SPI、PWM、IR-remote、QDEC、KeyScan、ADC、DAC。

BL702/704/706 参考手册 27/ 370 @2021 Bouffalo Lab






图 2.2: 时钟架构

3.1 简介

GLB(Global Register) 是芯片通用全局设定模块,主要包含了时钟管理、复位管理、总线管理、内存管理以及 GPIO 管理等功能。

3.2 功能描述

3.2.1 时钟管理

时钟管理功能主要用于设定处理器、总线、各个外设的时钟,通过该模块可以设定上述模块工作的时钟源,时钟分频等,同时也可以实现对上述模块时钟的门控,以达到系统低功耗的目的。详细设定可以参考复位和时钟章节。

3.2.2 复位管理

提供各个外设模块的单独复位功能以及芯片复位功能。芯片复位包括:

- CPU 复位:仅仅复位 CPU 模块,程序会重新运行,外设不会被复位
- 系统复位:各个外设和 CPU 会被复位,但是 AON 域的相关寄存器不会被复位
- 上电复位:整个系统包括 AON 域的相关寄存器都会被复位

应用程序可以根据需要,选择使用对应的复位方式。

表 3.1: 软件复位功能表

BL702	EXT_RST (GPIO) ana_powb(HBN 产生) wdt_rst_src_n(Watch Dog 产生) reg_ctrl_pwron_rst	SW.Reset	cpuresetreq (CPU 产生) pds_rst_soc reg_ctrl_sys_reset	pds_rst_np reg_ctrl_cpu_reset	pds_rst_usb
CPU	✓			✓	



表 3.1: 软件复位功能表

BL702	EXT_RST (GPIO) ana_powb(HBN 产生) wdt_rst_src_n(Watch Dog 产生) reg_ctrl_pwron_rst	SW.Reset	cpuresetreq (CPU 产生) pds_rst_soc reg_ctrl_sys_reset	pds_rst_np reg_ctrl_cpu_reset	pds_rst_usb
bus	✓		1		
glb	✓	swrst_s1[0]			
gpip	1	swrst_s1[2]	1		
l1c	1	swrst_s1[9]	1	1	
dma	✓	swrst_s1[12]	/		
emac	✓	swrst_s1[13]	1		
usb	1	swrst_s1a[12]	✓		1
pds		swrst_s1[14]			
uart0	1	swrst_s1a[0]	1		
uart1	1	swrst_s1a[1]	1		
spi	1	swrst_s1a[2]	1		
I2C	1	swrst_s1a[3]	1		
pwm	✓	swrst_s1a[4]	1		
timer	1	swrst_s1a[5]	1		
irr	1	swrst_s1a[6]	1		
qdec0	✓	swrst_s1a[8]	/		
qdec1	1	swrst_s1a[8]	1		
qdec2	1	swrst_s1a[8]	1		
kys	1	swrst_s1a[9]	1		
i2s	1	swrst_s1a[10]	1		



3.2.3 总线管理

提供总线的仲裁设定以及总线出错设定,可以设定在总线出错时是否产生中断,并提供出错总线地址信息,方便用户调试程序。

3.2.4 内存管理

提供各个内存模块在芯片系统进入低功耗模式时的功耗管理,包含两种设定模式:

- retention 模式: 在该模式下,内存上的数据可以保存,但是在退出低功耗模式之前,无法读写。
- sleep 模式:在该模式下,内存的数据会丢失,仅用于降低系统功耗。

3.2.5 GPIO 概述

GPIO 管理功能提供 GPIO 控制寄存器,实现软件对 GPIO 属性的配置,使用户能够方便地操作 GPIO。每个 GPIO 可以配置为 software GPIO 或其它复用功能。在每个功能下,提供设置上拉,下拉,浮空三种端口状态 (配置为模拟功能时必须设置为浮空),此外 GPIO 还提供中断功能,可以配置为上升沿触发,下降沿触发、高电平触发或者低电平触发。每个 GPIO 可以拥有两组中断配置,两组中断配置可以同时起效,例如 GPIO0 的 INTO 配置为上升沿触发、INT1 配置为下降沿触发,则最终效果为 GPIO 双边沿都会触发中断。

3.2.6 GPIO 主要特点

- 可以配置为 software GPIO 功能
- 可以配置为其它复用功能,搭配外设功能使用,在配置为模拟功能时,必须设置为浮空
- 可以设置输入或输出模式,并设定为上拉,下拉或者浮空
- 可以设置驱动能力,以提供更大的输出电流
- 可以设置施密特触发器功能,提供简单硬件防抖功能

3.2.7 GPIO 功能描述

每个 GPIO 可以通过软件配置为:

- 复用功能: I2S、SPI、I2C、UART、PWM、USB、SWGPIO...... 多达 24 种 function
- InputEnable/OutputEnable: 输入、输出、高阻(ie=0,oe=0)
- PullUp/PullDown: 上拉、下拉、浮空(pu=0,pd=0)
- drive strength: 0、1、2、3 四个档位,数值越大,驱动能力越强
- smt 触发器: smt enable、smt disable,用以防止触发阈值附近的抖动

当 GPIO 复用功能配置为 SWGPIO input 时还可以为其配置中断触发方式,且每个 GPIO 可以有两个中断模式,两个中断模式均可以单独/同时起效:



- 中断模式 1: 上升沿触发、下降沿触发、高电平触发、低电平触发
- 中断模式 2: 上升沿触发、下降沿触发、高电平触发、低电平触发

GPIO 模块基本框图如下图所示。




图 3.1: GPIO 基本框图

3.2.8 GPIO 功能设定

GPIO 的功能通过 GPIO_CFGCTL 寄存器组设定,主要设定项包括:

- func_sel: 选择 GPIO 功能
- pu: 选择是否上拉
- pd: 选择是否下拉
- drv: 设定驱动能力
- smt: 选择是否使能施密特触发器
- ie: 设定输入使能
- oe: 设定输出使能

GPIO 可以设定的功能包括:

• Flash/QSPI:设定 GPIO 为 QSPI 功能,可以连接 Flash,作为程序存储/运行介质



• SPI: 设定 GPIO 为 SPI 功能

• I2C: 设定 GPIO 为 I2C 功能

• UART: 设定 GPIO 为 UART 功能

• PWM: 设定 GPIO 为 PWM 功能

• ANA: 设定 GPIO 为 Analog 功能

• SWGPIO:设定 GPIO 为通用 IO 功能

• JTAG:设定 GPIO 为 JTAG 功能

• 其它复用功能

为了最大限度的满足客户需求,每个 GPIO 基本上都可以选择上述可选功能,当选择某个可选功能时,GPIO 与对应的功能信号如下表所示:

表 3.2: GPIO 功能表 1

GPIO	CLK_OUT	Flash_PSRAM	I2S	SPI0	I2C	UART	PWM
GPIO0	clk_out[0]		BCLK	MISO/MOSI	SCL	SIG0/SIG4	PWM[0]
GPIO1	clk_out[1]		FS	MOSI/MISO	SDA	SIG1/SIG5	PWM[1]
GPIO2	clk_out[0]		DIO/DO	SS	SCL	SIG2/SIG6	PWM[2]
GPIO3	clk_out[1]		RCLK_O/DI	SCLK	SDA	SIG3/SIG7	PWM[3]
GPIO4	clk_out[0]		BCLK	MISO/MOSI	SCL	SIG4/SIG0	PWM[4]
GPIO5	clk_out[1]		FS	MOSI/MISO	SDA	SIG5/SIG1	PWM[0]
GPIO6	clk_out[0]		DIO/DO	SS	SCL	SIG6/SIG2	PWM[1]
GPIO7	clk_out[1]		RCLK_O/DI	SCLK	SDA	SIG7/SIG3	PWM[2]
GPIO8	clk_out[0]		BCLK	MISO/MOSI	SCL	SIG0/SIG4	PWM[3]
GPIO9	clk_out[1]		FS	MOSI/MISO	SDA	SIG1/SIG5	PWM[4]
GPIO10	clk_out[0]		DIO/DO	SS	SCL	SIG2/SIG6	PWM[0]
GPIO11	clk_out[1]		RCLK_O/DI	SCLK	SDA	SIG3/SIG7	PWM[1]
GPIO12	clk_out[0]		BCLK	MISO/MOSI	SCL	SIG4/SIG0	PWM[2]
GPIO13	clk_out[1]		FS	MOSI/MISO	SDA	SIG5/SIG1	PWM[3]
GPIO14	clk_out[0]		DIO/DO	SS	SCL	SIG6/SIG2	PWM[4]
GPIO15	clk_out[1]		RCLK_O/DI	SCLK	SDA	SIG7/SIG3	PWM[0]
GPIO16	clk_out[0]		BCLK	MISO/MOSI	SCL	SIG0/SIG4	PWM[1]
GPIO17	clk_out[1]	SF_IO_0/SF2_CS2	FS	MOSI/MISO	SDA	SIG1/SIG5	PWM[2]
GPIO18	clk_out[0]	SF_IO_1	DIO/DO	SS	SCL	SIG2/SIG6	PWM[3]



表 3.2: GPIO 功能表 1

GPIO	CLK_OUT	Flash_PSRAM	128	SPI0	I2C	UART	PWM
GPIO19	clk_out[1]	SF_CS	RCLK_O/DI	SCLK	SDA	SIG3/SIG7	PWM[4]
GPIO20	clk_out[0]	SF_IO_3	BCLK	MISO/MOSI	SCL	SIG4/SIG0	PWM[0]
GPIO21	clk_out[1]	SF_CLK	FS	MOSI/MISO	SDA	SIG5/SIG1	PWM[1]
GPIO22	clk_out[0]	SF_IO_2	DIO/DO	SS	SCL	SIG6/SIG2	PWM[2]
GPIO23	clk_out[1]	SF2_IO_2	RCLK_O/DI	SCLK	SDA	SIG7/SIG3	PWM[3]
GPIO24	clk_out[0]	SF2_IO_1	BCLK	MISO/MOSI	SCL	SIG0/SIG4	PWM[4]
GPIO25	clk_out[1]	SF2_CS	FS	MOSI/MISO	SDA	SIG1/SIG5	PWM[0]
GPIO26	clk_out[0]	SF2_IO_3	DIO/DO	SS	SCL	SIG2/SIG6	PWM[1]
GPIO27	clk_out[1]	SF2_CLK	RCLK_O/DI	SCLK	SDA	SIG3/SIG7	PWM[2]
GPIO28	clk_out[0]	SF2_IO_0	BCLK	MISO/MOSI	SCL	SIG4/SIG0	PWM[3]
GPIO29	clk_out[1]		FS	MOSI/MISO	SDA	SIG5/SIG1	PWM[4]
GPIO30	clk_out[0]		DIO/DO	SS	SCL	SIG6/SIG2	PWM[0]
GPIO31	clk_out[1]		RCLK_O/DI	SCLK	SDA	SIG7/SIG3	PWM[1]

表 3.3: GPIO 功能表 2

GPIO	Analog	SWGPIO	JTAG	Ether_Mac	QDEC
GPIO0		GPIO[0]	TMS/TCK	MII_REF_CLK	а
GPIO1		GPIO[1]	TDI/TDO	MII_TXD[0]	b
GPIO2		GPIO[2]	TCK/TMS	MII_TXD[1]	led
GPIO3		GPIO[3]	TDO/TDI		а
GPIO4		GPIO[4]	TMS/TCK		b
GPIO5		GPIO[5]	TDI/TDO		led
GPIO6		GPIO[6]	TCK/TMS		а
GPIO7	USB_DP/gpip_ch[6]/gpdac_vref_ext	GPIO[7]	TDO/TDI	MII_RXD[0]	b
GPIO8	USB_DM/gpip_ch[0]	GPIO[8]	TMS/TCK	MII_RXD[1]	led
GPIO9	pmip_dc_tp/clkpll_dc_tp/gpip_ch[7]	GPIO[9]	TDI/TDO		а
GPIO10	MICBIAS	GPIO[10]	TCK/TMS		b
GPIO11	gpip_ch[3]	GPIO[11]	TDO/TDI		led
GPIO12	gpip_ch[4]	GPIO[12]	TMS/TCK		а



表 3.3: GPIO 功能表 2

GPIO	Analog	SWGPIO	JTAG	Ether_Mac	QDEC
GPIO13		GPIO[13]	TDI/TDO		b
GPIO14	gpip_ch[5]/atest_out_0	GPIO[14]	TCK/TMS		led
GPIO15	gpip_ch[1]/atest_out_1	GPIO[15]	TDO/TDI		а
GPIO16		GPIO[16]	TMS/TCK		b
GPIO17	gpip_ch[2]/psw_irrcv	GPIO[17]	TDI/TDO		led
GPIO18	gpip_ch[8]	GPIO[18]	TCK/TMS	RMII_MDC	а
GPIO19	gpip_ch[9]	GPIO[19]	TDO/TDI	RMII_MDIO	b
GPIO20	gpip_ch[10]	GPIO[20]	TMS/TCK	RMII_RXERR	led
GPIO21	gpip_ch[11]	GPIO[21]	TDI/TDO	RMII_TX_EN	а
GPIO22	leddrv[0]	GPI0[22]	TCK/TMS	RMII_RX_DV	b
GPIO23	leddrv[1]/flash_pull_out[0]	GPIO[23]	TDO/TDI		led
GPIO24	flash_pull_out[1]	GPI0[24]	TMS/TCK	RMII_MDC	а
GPIO25	flash_pull_out[2]	GPIO[25]	TDI/TDO	RMII_MDIO	b
GPIO26	flash_pull_out[3]	GPIO[26]	TCK/TMS	RMII_RXERR	led
GPIO27	flash_pull_out[4]	GPIO[27]	TDO/TDI	RMII_TX_EN	а
GPIO28	flash_pull_out[5]	GPIO[28]	TMS/TCK	RMII_RX_DV	b
GPIO29		GPIO[29]	TDI/TDO		led
GPIO30		GPIO[30]	TCK/TMS		а
GPIO31		GPIO[31]	TDO/TDI		b

表 3.4: GPIO 功能表 3

GPIO	SWGPIO
GPIO	SWGPIO
GPIO17	pad_irrx_i,irrxgpsl=1
GPIO18	pad_irrx_i,irrxgpsl=2
GPIO19	pad_irrx_i,irrxgpsl=3
GPIO20	pad_irrx_i,irrxgpsl=4
GPIO21	pad_irrx_i,irrxgpsl=5
GPIO22	pad_irrx_i,irrxgpsl=6



表 3.4: GPIO 功能表 3

GPIO	SWGPIO
GPIO23	pad_irrx_i,irrxgpsl=7
GPIO24	pad_irrx_i,irrxgpsl=8
GPIO25	pad_irrx_i,irrxgpsl=9
GPIO26	pad_irrx_i,irrxgpsl=10
GPIO27	pad_irrx_i,irrxgpsl=11
GPIO28	pad_irrx_i,irrxgpsl=12
GPIO29	pad_irrx_i,irrxgpsl=13
GPIO30	pad_irrx_i,irrxgpsl=14
GPIO31	pad_irrx_i,irrxgpsl=15

当使用 IR 功能时,需要将 GPIO 设置为 SWGPIO,并设置 irrxgpsl 寄存器(GPIO17~GPIO31 可以作为 IR 引脚)

在上述表格中,当选择 UART 功能时,只是选择了 UART 的一个信号,并没有指定该引脚的具体功能(比如是 UART TX 还是 UART RX),还需要通过 UART_SIGX_SEL(X=0-7)进一步选择具体的 UART 信号及对应的功能。每一个 UART_-SIGX_SEL 可以选择的信号包括:

• 0: UART0_RTS

• 1: UART0_CTS

2 : UART0_TXD

• 3: UARTO_RXD

• 4 : UART1_RTS

• 5 : UART1_CTS

• 6 : UART1_TXD

• 7: UART1_RXD

以 GPIO0 为例,当 fun_sel 选择 UART 的时候,GPIO0 选择的是 UART_SIG0, 在默认情况下 UART_SIG0_SEL 的值是 0,也就是 UART0_RTS,即 GPIO 是 UART0_RTS 功能。如果应用程序想把 GPIO 作为 UART1_TXD, 那只要把 UART_SIG0_SEL 设置为 6, 那么 GPIO0 的功能就是 UART1_TXD。



3.2.9 GPIO 输出设置

通过设定 func_sel 为 SWGPIO,GPIO 可以作为普通 GPIO 的输入/输出,将 IE 设置为 0,OE 设置为 1,就可以将 GPIO 配置为输出功能,输出的数值通过 GPIO_O 寄存器组设定。当 GPIO_O 对应 Bit 设置为 0 时,GPIO 输出低电平,当 GPIO O 对应 Bit 设置为 1 时,GPIO 输出高电平。可以通过 DRV 控制位设置输出能力。

3.2.10 GPIO 输入设置

通过设定 func_sel 为 SWGPIO,将 IE 设置为 1,OE 设置为 0,就可以将 GPIO 配置为输入功能,可以通过 SMT 控制位设置是否使能施密特触发器,通过 PD,PU 控制位设置上拉下拉属性。外部输入的数值,可以通过读取 GPIO_I 寄存器对应的 Bit 获取到。

3.2.11 GPIO 可选功能设置

通过设定 func_sel 为对应的外设功能,可以实现 GPIO 与外设的连接,实现外设的输入输出,从 GPIO 的基础功能框图可以看出,当选择可选功能时,需要将 IE 设置为 1,OE 设置为 0,也就是断开普通 GPIO 的输出控制功能。这样,对于固定输入功能的外设,外设的 OE 信号始终为 0,从而实现输入功能;对于固定输出的外设,其 OE 信号始终为 1,从而实现输出是被外设控制,而此时的输入信号就是输出信号,但是不会被正在输出的外设采集;当外设既需要输入又要输出时,通过控制外设 OE 信号就可以实现输入输出。即:对于除了 SWGPIO 以外的 function,作为输出方向的功能时,IE 和 OE 的配置值不影响功能,但是作为输入方向时,IE 必须置一而 OE 的配置不影响功能;当作为 SWGPIO时,IE 和 OE 都需要正确配置。

3.2.12 GPIO 中断设置

要使用 GPIO 的中断功能,需要先将 GPIO 设置为输入模式,中断触发模式通过 GPIO_INT_MODE_SET 寄存器组进行设定。可以设定的中断模式包括:

- 下降沿触发中断
- 上升沿触发中断
- 低电平触发中断
- 高电平触发中断

每个 GPIO 都可以设定为中断功能,是否使能某个 GPIO 中断可以通过 GPIO_INT_MASK 寄存器进行设定,中断产生时,在中断函数中可以通过 GPIO_INT_STAT 寄存器获取到产生中断的 GPIO 引脚号,同时可以通过 GPIO_INT_CLR 清除掉对应的中断信号。

BL702/704/706 参考手册 37/ 370 @2021 Bouffalo Lab



3.3 寄存器描述

名称	描述
clk_cfg0	Clock configuration-processor, bus
clk_cfg1	Clock configuration1-ble,qdec,i2s
clk_cfg2	Clock configuration-UART,Flash
clk_cfg3	Clock configuration-I2C,SPI
swrst_cfg0	software reset configuration0
swrst_cfg1	software reset configuration1
swrst_cfg2	software reset configuration2
cgen_cfg0	clock ungate configuration0
cgen_cfg1	clock ungate configuration1
bmx_cfg1	Bus configuration1
bmx_cfg2	Bus configuration2
bmx_err_addr	Bus error address
seam_misc	em select
CPU_CLK_CFG	CPU clock configuration
GPADC_32M_SRC_CTRL	Clock configuration-GPADC
DIG32K_WAKEUP_CTRL	DIG32K wakeup control
UART_SIG_SEL_0	UART Signal Select
GPIO_CFGCTL0	GPIO0, GPIO1 configuration
GPIO_CFGCTL1	GPIO2, GPIO3 configuration
GPIO_CFGCTL2	GPIO4, GPIO5 configuration
GPIO_CFGCTL3	GPIO6, GPIO7 configuration
GPIO_CFGCTL4	GPIO8, GPIO9 configuration
GPIO_CFGCTL5	GPIO10, GPIO11 configuration
GPIO_CFGCTL6	GPIO12, GPIO13 configuration
GPIO_CFGCTL7	GPIO14, GPIO15 configuration
GPIO_CFGCTL8	GPIO16, GPIO17 configuration
GPIO_CFGCTL9	GPIO18, GPIO19 configuration
GPIO_CFGCTL10	GPIO20, GPIO21 configuration



名称	描述
GPIO_CFGCTL11	GPIO22, GPIO23 configuration
GPIO_CFGCTL12	GPIO24, GPIO25 configuration
GPIO_CFGCTL13	GPIO26, GPIO27 configuration
GPIO_CFGCTL14	GPIO28,GPIO29 configuration
GPIO_CFGCTL15	GPIO30,GPIO31 configuration
GPIO_CFGCTL16	GPIO32,GPIO33 configuration
GPIO_CFGCTL17	GPIO34,GPIO35 configuration
GPIO_CFGCTL18	GPIO36,GPIO37 configuration
GPIO_CFGCTL30	Register Controlled GPIO Input value
GPIO_CFGCTL32	Register controlled GPIO output value
GPIO_CFGCTL34	Register controlled GPIO output enable
GPIO_CFGCTL35	Register controlled GPIO output enable
GPIO_INT_MASK1	GPIO interrupt mask
GPIO_INT_STAT1	GPIO interrupt state
GPIO_INT_CLR1	GPIO interrupt clear
GPIO_INT_MODE_SET1	GPIO interrupt mode set1
GPIO_INT_MODE_SET2	GPIO interrupt mode set2
GPIO_INT_MODE_SET3	GPIO interrupt mode set3
GPIO_INT_MODE_SET4	GPIO interrupt mode set4
GPIO_INT2_MASK1	GPIO interrupt2 mask1
GPIO_INT2_STAT1	GPIO interrupt2 state1
GPIO_INT2_CLR1	GPIO interrupt2 clear1
GPIO_INT2_MODE_SET1	GPIO interrupt 2 mode set1
GPIO_INT2_MODE_SET2	GPIO interrupt 2 mode set2
GPIO_INT2_MODE_SET3	GPIO interrupt 2 mode set3
GPIO_INT2_MODE_SET4	GPIO interrupt 2 mode set4
led_driver	Led driver
usb_xcvr	USB configuration
usb_xcvr_config	USB xcvr configuration



名称	描述
gpdac_ctrl	GPDAC control
gpdac_actrl	GPDAC channelA control
gpdac_bctrl	GPDAC channelB control
gpdac_data	GPDAC data

3.3.1 clk_cfg0

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16		
	RSVD							BCLKDIV									
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0		
	HCLKDIV								SEL	PLL	SEL	BLCK	HCLK	FCLK	PLL		
												EN	EN	EN	EN		

位	名称	权限	复位值	描述
31:24	RSVD			
23:16	BCLKDIV	R/W	0	bclk divide from hclk
15:8	HCLKDIV	R/W	0	hclk divide from root clock (clock source selected by hbn root_clk_sel)
7:6	RCSEL	R	0	root clock selection from HBN (0: RC32M 1: XTAL 2/3: PLL others)
5:4	PLLSEL	R/W	0	pll clock selection 0: 57.6MHz 1: 96MHz 2: 144MHz 3: 120MHz (Clock Freq will be changes with Audio PLL, not sugges use this CLK)
3	BLCKEN	R/W	1	bclk force on
2	HCLKEN	R/W	1	hclk force on
1	FCLKEN	R/W	1	fclk force on
0	PLLEN	R/W	1	pll clock enable for fclk



3.3.2 clk_cfg1

地址: 0x40000004

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	RSVD					MAC ZBEN	BLE EN	RSVD BLECLKSL							
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
RSVD	I2S CLK	I2S CLEN	I2S CSEL	RS	VD	USB DIV	USB CLK	QDEC CSEL	RS	VD	QDECCDIV				

位	名称	权限	复位值	描述
31:26	RSVD			
25	MACZBEN	R/W	1	mac154 zigbee clock enable
24	BLEEN	R/W	1	ble clock enable
23:22	RSVD			
21:16	BLECLKSL	R/W	6'd16	HW reserved ; for ble to generate 1us/0.5us tick pulse
15	RSVD			
14	I2SCLK	R/W	0	0 : no output reference clock on I2S_0 ref_clock port ; 1: output reference clock on I2S_0 ref_clock port
13	I2SCLEN	R/W	0	I2S0 Clock Enable
12	I2SCSEL	R/W	0	I2S Clock Source Select. 0: Audio PLL, 1: reserved
11:10	RSVD			
9	USBDIV	R/W	1	USB Clock div2 from 96MHz
8	USBCLK	R/W	1	USB Clock Enable
7	QDECCSEL	R/W	0	QDEC Clock Source Select. 0:xclk 1:f32k (PDS mode)
6:5	RSVD			
4:0	QDECCDIV	R/W	5'd31	QDEC Clock Divider qdec_clk_sel/(N+1), default 1MHz

BL702/704/706 参考手册 41/ 370 @2021 Bouffalo Lab



3.3.3 clk_cfg2

地址: 0x4000008

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	
DMAEN								IRCL EN	RSVD	IRCLDIV						
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	
SFS	SEL2	SFS	SEL	SFEN		SFDIV		HUC	RS	SVD UART RSVD UARTDIV						
								SEL			EN					

位	名称	权限	复位值	描述
31:24	DMAEN	R/W	8'hff	DMA CH0 7 Clock Enable ; config all 0 if disable DMA
23	IRCLEN	R/W	1	IR remote Clock Enable
22	RSVD			
21:16	IRCLDIV	R/W	6'd15	IR remote Clock Divider xclk(N+1)
15:14	SFSEL2	R/W	0	For sf_clk_sel=0 0: 144MHz 1: xclk 3: 57.6MHz
13:12	SFSEL	R/W	2'd2	Flash Clock Select (0:sf_clk_sel2, 1:72M, 2:bclk, 3:96M)
11	SFEN	R/W	1	Flash Clock Enable
10:8	SFDIV	R/W	3'd3	Flash Clock Divider (Selected Flash Clock)/(N+1)
7	HUCSEL	R	0	uart clock selection from HBN (0:fclk 1:96MHz)
6:5	RSVD			
4	UARTEN	R/W	1	UART Clock Enable
3	RSVD			
2:0	UARTDIV	R/W	3'd7	UART Clock Divider hbn_uart_clk_sel/(N+1)

3.3.4 clk_cfg3

地址: 0x400000c

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
CC	CCO1S CCO0S RSVD						I2C	I2CDIV							
							EN								
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
		RSVD			ICT	IRFT	SPI	ICT	ICT	SREF	SPIDIV				
					MRX	CLK	EN	MTX	PHY	CLK					

BL702/704/706 参考手册 42/ 370 @2021 Bouffalo Lab



位	名称	权限	复位值	描述
31:30	CCO1S	R/W	2'b0	clk_out_1 selection (0: no chip clock out, 1: i2s_ref_clk out, 2: audio_pll_clk out, 3: clk_xtal_soc_32M)
29:28	CCO0S	R/W	2'b0	clk_out_0 selection (0: no chip clock out, 1: i2s_ref_clk out, 2: audio_pll_clk out, 3: clk_xtal_soc_32M)
27:25	RSVD			
24	I2CEN	R/W	1	I2C Master Clock Out Enable
23:16	I2CDIV	R/W	8'd255	I2C Master Clock Out Divider (Freq_of_BCLK/(N+1))
15:11	RSVD			
10	ICTMRX	R/W	1'b1	Invert clock to our RMII MAC RX
9	IRFTCLK	R/W	1	1: invert rf_test_clk out, 0 : no change
8	SPIEN	R/W	1	SPI Clock Enable (Default : Enable)
7	ICTMTX	R/W	1'b1	Invert clock to our RMII MAC TX
6	ICTPHY	R/W	1'b1	if [5] = 1, set this bit to 1 will invert the clock to RMII PHY
5	SREFCLK	R/W	1'b0	0 : select outside 50MHz RMII ref clock, 1: select inside 50MHz RMII ref clock
4:0	SPIDIV	R/W	5'd3	SPI Clock Divider (BUS_CLK/(N+1)), default BUS_CLK/4

3.3.5 swrst_cfg0

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
RSVD															
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
RSVD						SR						RSVD			
							S30				S20				

位	名称	权限	复位值	描述
31:9	RSVD			
8	SRS30	R/W	0	software reset BLE
7:5	RSVD			
4	SRS20	R/W	0	software reset M154
3:0	RSVD			



3.3.6 swrst_cfg1

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	RSVD		SR	RSVD	SR										
			S1AC		S1AA	S1A9	S1A8	S1A7	S1A6	S1A5	S1A4	S1A3	S1A2	S1A1	S1A0
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
RSVD	SR	SR	SR	SR	RSVD	SR									
	1											1	I		

位	名称	权限	复位值	描述
31:29	RSVD			
28	SRS1AC	R/W	0	software reset USB
27	RSVD			
26	SRS1AA	R/W	0	software reset I2S
25	SRS1A9	R/W	0	software reset KYS
24	SRS1A8	R/W	0	software reset QDEC
23	SRS1A7	R/W	0	software reset Checksum
22	SRS1A6	R/W	0	software reset IR Remote
21	SRS1A5	R/W	0	software reset Timer
20	SRS1A4	R/W	0	software reset PWM
19	SRS1A3	R/W	0	software reset I2C
18	SRS1A2	R/W	0	software reset SPI
17	SRS1A1	R/W	0	software reset UART1
16	SRS1A0	R/W	0	software reset UART0
15	RSVD			
14	SRS1E	R/W	0	software reset PDS
13	SRS1D	R/W	0	software reset EMAC
12	SRS1C	R/W	0	software reset DMA
11	SRS1B	R/W	0	software reset SF
10	RSVD			
9	SRS19	R/W	0	software reset L1C
8	SRS18	R/W	0	software reset CCI
7	SRS17	R/W	0	software reset eFuse
6	SRS16	R/W	0	software reset TZ2



位	名称	权限	复位值	描述
5	SRS15	R/W	0	software reset TZ1
4	SRS14	R/W	0	software reset SEC_ENG
3	SRS13	R/W	0	software reset SEC_DBG
2	SRS12	R/W	0	software reset GPIP
1	SRS11	R/W	0	software reset MIX
0	SRS10	R/W	0	software reset GLB

3.3.7 swrst_cfg2

地址: 0x40000018

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	RSVD							PKA RSVD							
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	RSVD								RST	DUM		RSVD	SYS	CPU	PWO
												l	RST	RST	RST

位	名称	权限	复位值	描述
31:25	RSVD			
24	PKACLK	R/W	0	pka clock select 0:HCLK 1:96M
23:8	RSVD			
7:4	RSTDUM	R/W	0	reset dummy
3	RSVD			
2	SYSRST	R/W	0	system reset, see the software reset table for details
1	CPURST	R/W	0	cpu reset, see the software reset table for details
0	PWORST	R/W	0	power on reset, see the software reset table for details

BL702/704/706 参考手册 45/ 370 @2021 Bouffalo Lab



3.3.8 cgen_cfg0

地址: 0x40000020

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	RSVD														
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	RSVD							CGENM							

位	名称	权限	复位值	描述
31:8	RSVD			
7:0	CGENM	R/W	8'hff	[0] CPU clock ungate enable[1] SDU clock ungate enable[2] SEC clock ungate enable[3] DMA clock ungate enable[4] CCI clock ungate enable

3.3.9 cgen_cfg1

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	CGENS1A														
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	CGENS1														

位	名称	权限	复位值	描述
31:16	CGENS1A	R/W	16'h9B23	[0] uart0 clock ungate enable [1] uart1 clock ungate enable [2] spi clock ungate enable [3] i2c clock ungate enable
				[4] pwm clock ungate enable [5] timer clock ungate enable [6] ir_remote clock ungate enable [7] checksum clock ungate enable [8] qdec0 clock ungate enable [9] qdec1 clock ungate enable [10] i2s and qdec2 clock ungate enable [11] kys clock ungate enable [12] usb clock ungate enable



位	名称	权限	复位值	描述
15:0	CGENS1	R/W	16'hCFFF	[2] gpip (gpadc, gpdac) clock ungate enable [3] sec_dbg clock ungate enable [4] sec_eng clock ungate enable [5] tzc clock ungate enable [7] ef_ctrl clock ungate enable [11] sf_ctrl clock ungate enable [12] DMA clock ungate enable [13] emac clock ungate enable

3.3.10 bmx_cfg1

地址: 0x40000050

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	RSVD														
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	RSVD							RS	VD	ARBN	MODE		TIMO	UTEN	

位	名称	权限	复位值	描述
31:9	RSVD			
8	ERREN	R/W	0	Bus error response enable
7:6	RSVD			
5:4	ARBMODE	R/W	0	Bus arbiter: 0:fix, 2:round-robin, 3:random
3:0	TIMOUTEN	R/W	0	Bus timeout enable: detect slave no reaponse in 1024 cycles

3.3.11 bmx_cfg2

地址: 0x40000054

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
							RS	VD							
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
				RS	VD					ERR	ERR		RSVD		ADDR
										TZ	DEC				DIS

BL702/704/706 参考手册 47/ 370 @2021 Bouffalo Lab



位	名称	权限	复位值	描述
31:6	RSVD			
5	ERRTZ	R	0	Bus trustzone decode error
4	ERRDEC	R	0	Bus addr decode error
3:1	RSVD			
0	ADDRDIS	R/W	0	Bus addr error monitor disable

3.3.12 bmx_err_addr

地址: 0x40000058

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	ADDR														
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	ADDR														

位	名称	权限	复位值	描述
31:0	ADDR	R	0	Bus error addr (the first one)

3.3.13 **seam_misc**

地址: 0x4000007c

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	RSVD														
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	RSVD												EM	SEL	

位	名称	权限	复位值	描述
31:4	RSVD			
3:0	EMSEL	R/W	4'h3	em/ocram share memory em select 0x0: 0KB; 0x3:8KB; 0xF:16KB

BL702/704/706 参考手册 48/ 370 @2021 Bouffalo Lab



3.3.14 CPU_CLK_CFG

地址: 0x40000090

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	RSVD												RTC EN	RSVD	RTC DIV
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	RTCDIV														

位	名称	权限	复位值	描述
31:20	RSVD			
19	RTCSEL	R/W	1	0: Bus clock 1: 32KHz
18	RTCEN	R/W	0	CPU RTC clock enable
17	RSVD			
16:0	RTCDIV	R/W	17'h10	CPU RTC clock = (e21_rtc_sel) / (e21_rtc_div+1)

3.3.15 GPADC_32M_SRC_CTRL

地址: 0x400000a4

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
							RS	VD							
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
			RSVD				GADC	GADC	RSVD	GADCDIV					
							DIV	SEL							

位	名称	权限	复位值	描述
31:9	RSVD			
8	GADCDIV	R/W	1	GPADC 32M Clock Dvider Enable
7	GADCSEL	R/W	0	GPADC Clock Source Select. 0: Audio PLL, 1: xclk
6	RSVD			
5:0	GADCDIV	R/W	6'd2	GPADC 32M Clock Divider (gpadc clock)/(N+1)



3.3.16 DIG32K_WAKEUP_CTRL

地址: 0x400000a8

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
RS	SVD	CLKS	CSEL	RS	VD COMP 512K RSVD 512KDIV EN										
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
RS	SVD	32K	32K	RSVD		32KDIV									
		COMP	EN												

位	名称	权限	复位值	描述
31:30	RSVD			
29:28	CLKSCSEL	R/W	0	0:PLL 32MHz 1:xclk 2:Audio PLL
27:26	RSVD			
25	COMP	R/W	1	Compensation => Duty of dig_512k_out = N : N+1
24	512KEN	R/W	1	Enable dig_512k_out
23	RSVD			
22:16	512KDIV	R/W	7'd62	(PLL 32MHz or xclk) / dig_512k_div Ex: Set 46 for 24MHz; Set 62 for 32MHz; Set 75 for 38.4MHz; Set 78 for 40MHz
15:14	RSVD			
13	32KCOMP	R/W	0	Compensation => Duty of dig_32k_out = dig_32k_div : (dig_32k_div+1)
12	32KEN	R/W	1	Enable dig_32k_out
11	RSVD			
10:0	32KDIV	R/W	11'd1000	(PLL 32MHz or xclk) / dig_32k_div Ex: Set 750 for 24MHz; Set 1000 for 32MHz; Set 1200 for 38.4MHz; Set 1250 for 40MHz

3.3.17 **UART_SIG_SEL_0**

地址: 0x40000c0

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16		
	SIG	7SEL			SIG6SEL				SIG5SEL				SIG4SEL				
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0		
	SIG	3SEL		SIG2SEL				SIG1SEL				SIGOSEL					



位	名称	权限	复位值	描述
31:28	SIG7SEL	R/W	4'd7	UART Signal7 Select: 0: UART0_RTS 1: UART0_CTS 2: UART0_TXD 3: UART0_RXD 4: UART1_RTS 5: UART1_CTS 6: UART1_TXD 7: UART1_RXD
27:24	SIG6SEL	R/W	4'd6	UART Signal6 Select: 0: UART0_RTS 1: UART0_CTS 2: UART0_TXD 3: UART0_RXD 4: UART1_RTS 5: UART1_CTS 6: UART1_TXD 7: UART1_RXD
23:20	SIG5SEL	R/W	4'd5	UART Signal5 Select: 0: UART0_RTS 1: UART0_CTS 2: UART0_TXD 3: UART0_RXD 4: UART1_RTS 5: UART1_CTS 6: UART1_TXD 7: UART1_RXD
19:16	SIG4SEL	R/W	4'd4	UART Signal4 Select: 0: UART0_RTS 1: UART0_CTS 2: UART0_TXD 3: UART0_RXD 4: UART1_RTS 5: UART1_CTS 6: UART1_TXD 7: UART1_RXD



位	名称	权限	复位值	描述
15:12	SIG3SEL	R/W	4'd3	UART Signal3 Select: 0: UART0_RTS 1: UART0_CTS 2: UART0_TXD 3: UART0_RXD 4: UART1_RTS 5: UART1_CTS 6: UART1_TXD 7: UART1_RXD
11:8	SIG2SEL	R/W	4'd2	UART Signal2 Select: 0: UART0_RTS 1: UART0_CTS 2: UART0_TXD 3: UART0_RXD 4: UART1_RTS 5: UART1_CTS 6: UART1_TXD 7: UART1_RXD
7:4	SIG1SEL	R/W	4'd1	UART Signal1 Select: 0: UART0_RTS 1: UART0_CTS 2: UART0_TXD 3: UART0_RXD 4: UART1_RTS 5: UART1_CTS 6: UART1_TXD 7: UART1_RXD
3:0	SIGOSEL	R/W	0	UART Signal0 Select: 0: UART0_RTS 1: UART0_CTS 2: UART0_TXD 3: UART0_RXD 4: UART1_RTS 5: UART1_CTS 6: UART1_TXD 7: UART1_RXD



3.3.18 GPIO_CFGCTL0

地址: 0x40000100

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	RSVD GP1FUNC						RSVD		GP1	GP1	GP1DRV		GP1	GP1	
										PD	PU			SMT	IE
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	RSVD			(GP0FUN	<u> </u>		RS	VD	GP0	GP0	GP0	DRV	GP0	GP0
										PD	PU			SMT	IE

位	名称	权限	复位值	描述
31:29	RSVD			
28:24	GP1FUNC	R/W	5'hE	GPIO Function Select (Default : JTAG)
23:22	RSVD			
21	GP1PD	R/W	0	GPIO Pull Down Control
20	GP1PU	R/W	0	GPIO Pull Up Control
19:18	GP1DRV	R/W	0	GPIO Driving Control
17	GP1SMT	R/W	1	GPIO SMT Control
16	GP1IE	R/W	1	GPIO Input Enable
15:13	RSVD			
12:8	GP0FUNC	R/W	5'hE	GPIO Function Select (Default : JTAG)
7:6	RSVD			
5	GP0PD	R/W	0	GPIO Pull Down Control
4	GP0PU	R/W	0	GPIO Pull Up Control
3:2	GP0DRV	R/W	0	GPIO Driving Control
1	GP0SMT	R/W	1	GPIO SMT Control
0	GP0IE	R/W	1	GPIO Input Enable

BL702/704/706 参考手册 53/ 370 @2021 Bouffalo Lab



3.3.19 GPIO_CFGCTL1

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	RSVD GP3FUNC						RSVD		GP3	GP3	GP3DRV		GP3	GP3	
										PD	PU			SMT	IE
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	RSVD			(GP2FUNG	<u> </u>		RS	VD	GP2	GP2	GP2	DRV	GP2	GP2
										PD	PU			SMT	IE

位	名称	权限	复位值	描述
31:29	RSVD			
28:24	GP3FUNC	R/W	5'hB	GPIO Function Select (Default : SWGPIO)
23:22	RSVD			
21	GP3PD	R/W	0	GPIO Pull Down Control
20	GP3PU	R/W	0	GPIO Pull Up Control
19:18	GP3DRV	R/W	0	GPIO Driving Control
17	GP3SMT	R/W	1	GPIO SMT Control
16	GP3IE	R/W	1	GPIO Input Enable
15:13	RSVD			
12:8	GP2FUNC	R/W	5'hE	GPIO Function Select (Default : JTAG)
7:6	RSVD			
5	GP2PD	R/W	0	GPIO Pull Down Control
4	GP2PU	R/W	0	GPIO Pull Up Control
3:2	GP2DRV	R/W	0	GPIO Driving Control
1	GP2SMT	R/W	1	GPIO SMT Control
0	GP2IE	R/W	1	GPIO Input Enable



3.3.20 GPIO_CFGCTL2

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	RSVD GP5FUNC						RS	VD	GP5	GP5	GP5	DRV	GP5	GP5	
										PD	PU			SMT	IE
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	RSVD			(SP4FUNG	2		RS	VD	GP4	GP4	GP4	DRV	GP4	GP4
										PD	PU			SMT	ΙE

位	名称	权限	复位值	描述
31:29	RSVD			
28:24	GP5FUNC	R/W	5'hB	GPIO Function Select (Default : SWGPIO)
23:22	RSVD			
21	GP5PD	R/W	0	GPIO Pull Down Control
20	GP5PU	R/W	0	GPIO Pull Up Control
19:18	GP5DRV	R/W	0	GPIO Driving Control
17	GP5SMT	R/W	1	GPIO SMT Control
16	GP5IE	R/W	1	GPIO Input Enable
15:13	RSVD			
12:8	GP4FUNC	R/W	5'hB	GPIO Function Select (Default : SWGPIO)
7:6	RSVD			
5	GP4PD	R/W	0	GPIO Pull Down Control
4	GP4PU	R/W	0	GPIO Pull Up Control
3:2	GP4DRV	R/W	0	GPIO Driving Control
1	GP4SMT	R/W	1	GPIO SMT Control
0	GP4IE	R/W	1	GPIO Input Enable



3.3.21 GPIO_CFGCTL3

地址: 0x4000010c

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	RSVD GP7FUNC						RSVD		GP7	GP7	GP7DRV		GP7	GP7	
										PD	PU			SMT	ΙE
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	RSVD			(SP6FUNG	<u> </u>		RS	VD	GP6	GP6	GP6	DRV	GP6	GP6
										PD	PU			SMT	ΙE

位	名称	权限	复位值	描述
31:29	RSVD			
28:24	GP7FUNC	R/W	5'hB	GPIO Function Select (Default : SWGPIO)
23:22	RSVD			
21	GP7PD	R/W	0	GPIO Pull Down Control
20	GP7PU	R/W	0	GPIO Pull Up Control
19:18	GP7DRV	R/W	0	GPIO Driving Control
17	GP7SMT	R/W	1	GPIO SMT Control
16	GP7IE	R/W	1	GPIO Input Enable
15:13	RSVD			
12:8	GP6FUNC	R/W	5'hB	GPIO Function Select (Default : SWGPIO)
7:6	RSVD			
5	GP6PD	R/W	0	GPIO Pull Down Control
4	GP6PU	R/W	0	GPIO Pull Up Control
3:2	GP6DRV	R/W	0	GPIO Driving Control
1	GP6SMT	R/W	1	GPIO SMT Control
0	GP6IE	R/W	1	GPIO Input Enable



3.3.22 GPIO_CFGCTL4

地址: 0x40000110

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	RSVD			(SP9FUNO			RS	VD	GP9	GP9	GP9	DRV	GP9	GP9
										PD	PU			SMT	IE
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	RSVD			(SP8FUNG			RS	VD	GP8	GP8	GP8	DRV	GP8	GP8
										PD	PU			SMT	ΙE

位	名称	权限	复位值	描述
31:29	RSVD			
28:24	GP9FUNC	R/W	5'hE	GPIO Function Select (Default : JTAG)
23:22	RSVD			
21	GP9PD	R/W	0	GPIO Pull Down Control (Use this bit if reg_en_hw_pu_pd := 0 (0x4000F014[16])
20	GP9PU	R/W	0	GPIO Pull Up Control (Use this bit if reg_en_hw_pu_pd := 0 (0x4000F014[16])
19:18	GP9DRV	R/W	0	GPIO Driving Control
17	GP9SMT	R/W	1	GPIO SMT Control(Useless, IE depend on reg_aon_padie_smt[0]: 0x4000F014[8])
16	GP9IE	R/W	0	GPIO Input Enable (Useless, IE depend on reg_aon_padie_smt[0]: 0x4000F014[8])
15:13	RSVD			
12:8	GP8FUNC	R/W	5'hB	GPIO Function Select (Default : SWGPIO)
7:6	RSVD			
5	GP8PD	R/W	0	GPIO Pull Down Control
4	GP8PU	R/W	0	GPIO Pull Up Control
3:2	GP8DRV	R/W	0	GPIO Driving Control
1	GP8SMT	R/W	1	GPIO SMT Control
0	GP8IE	R/W	1	GPIO Input Enable

BL702/704/706 参考手册 57/ 370 @2021 Bouffalo Lab



3.3.23 GPIO_CFGCTL5

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	RSVD			G	P11FUN	С		RS	VD	GP11	GP11	GP11	IDRV	GP11	GP11
										PD	PU			SMT	IE
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	RSVD			G	P10FUN	С		RS	VD	GP10	GP10	GP10	DRV	GP10	GP10
										PD	PU			SMT	ΙE

位	名称	权限	复位值	描述
31:29	RSVD			
28:24	GP11FUNC	R/W	5'hB	GPIO Function Select (Default : SWGPIO)
23:22	RSVD			
21	GP11PD	R/W	0	GPIO Pull Down Control
20	GP11PU	R/W	0	GPIO Pull Up Control
19:18	GP11DRV	R/W	0	GPIO Driving Control
17	GP11SMT	R/W	1	GPIO SMT Control(Useless, IE depend on reg_aon_padie_smt[2]: 0x4000F014[10])
16	GP11IE	R/W	1	GPIO Input Enable (Useless, IE depend on reg_aon_padie_smt[2]: 0x4000F014[10])
15:13	RSVD			
12:8	GP10FUNC	R/W	5'hB	GPIO Function Select (Default : SWGPIO)
7:6	RSVD			
5	GP10PD	R/W	0	GPIO Pull Down Control
4	GP10PU	R/W	0	GPIO Pull Up Control
3:2	GP10DRV	R/W	0	GPIO Driving Control
1	GP10SMT	R/W	1	GPIO SMT Control(Useless, IE depend on reg_aon_padie_smt[1]: 0x4000F014[9])
0	GP10IE	R/W	1	GPIO Input Enable (Useless, IE depend on reg_aon_padie_smt[1]: 0x4000F014[9])



3.3.24 GPIO_CFGCTL6

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	RSVD			G	P13FUN	С		RS	VD	GP13 PD	GP13 PU	GP13	BDRV	GP13 SMT	GP13 IE
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	RSVD		GP12FUNC					RS	VD	GP12	GP12	GP12	2DRV	GP12	GP12
										PD	PU			SMT	ΙE

位	名称	权限	复位值	描述
31:29	RSVD			
28:24	GP13FUNC	R/W	5'hB	GPIO Function Select (Default : SWGPIO)
23:22	RSVD			
21	GP13PD	R/W	0	GPIO Pull Down Control
20	GP13PU	R/W	0	GPIO Pull Up Control
19:18	GP13DRV	R/W	0	GPIO Driving Control
17	GP13SMT	R/W	1	GPIO SMT Control(Useless, IE depend on reg_aon_padie_smt[4]: 0x4000F014[12])
16	GP13IE	R/W	1	GPIO Input Enable (Useless, IE depend on reg_aon_padie_smt[4]: 0x4000F014[12])
15:13	RSVD			
12:8	GP12FUNC	R/W	5'hB	GPIO Function Select (Default : SWGPIO)
7:6	RSVD			
5	GP12PD	R/W	0	GPIO Pull Down Control
4	GP12PU	R/W	0	GPIO Pull Up Control
3:2	GP12DRV	R/W	0	GPIO Driving Control
1	GP12SMT	R/W	1	GPIO SMT Control(Useless, IE depend on reg_aon_padie_smt[3]: 0x4000F014[11])
0	GP12IE	R/W	1	GPIO Input Enable (Useless, IE depend on reg_aon_padie_smt[3]: 0x4000F014[11])



3.3.25 GPIO_CFGCTL7

地址: 0x4000011c

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	RSVD			G	P15FUN	С		RS	VD	GP15	GP15	GP1	5DRV	GP15	GP15
										PD	PU			SMT	ΙE
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	RSVD			G	P14FUN	С		RS	VD	GP14	GP14	GP14	1DRV	GP14	GP14
										PD	PU			SMT	ΙE

位	名称	权限	复位值	描述
31:29	RSVD			
28:24	GP15FUNC	R/W	5'hB	GPIO Function Select (Default : SWGPIO)
23:22	RSVD			
21	GP15PD	R/W	0	GPIO Pull Down Control
20	GP15PU	R/W	0	GPIO Pull Up Control
19:18	GP15DRV	R/W	0	GPIO Driving Control
17	GP15SMT	R/W	1	GPIO SMT Control
16	GP15IE	R/W	1	GPIO Input Enable
15:13	RSVD			
12:8	GP14FUNC	R/W	5'hB	GPIO Function Select (Default : SWGPIO)
7:6	RSVD			
5	GP14PD	R/W	0	GPIO Pull Down Control
4	GP14PU	R/W	0	GPIO Pull Up Control
3:2	GP14DRV	R/W	0	GPIO Driving Control
1	GP14SMT	R/W	1	GPIO SMT Control
0	GP14IE	R/W	1	GPIO Input Enable



3.3.26 GPIO_CFGCTL8

地址: 0x40000120

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	RSVD			G	P17FUN	С		RS	VD	GP17	GP17	GP17	DRV	GP17	GP17
										PD	PU			SMT	ΙE
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	RSVD			G	P16FUN	С		RS	VD	GP16	GP16	GP16	BDRV	GP16	GP16
										PD	PU			SMT	ΙE

位	名称	权限	复位值	描述
31:29	RSVD			
28:24	GP17FUNC	R/W	5'hB	GPIO Function Select (Default : SWGPIO)
23:22	RSVD			
21	GP17PD	R/W	0	GPIO Pull Down Control (Use this bit if reg_en_hw_pu_pd := 0 (0x4000F014[16])
20	GP17PU	R/W	0	GPIO Pull Up Control (Use this bit if reg_en_hw_pu_pd := 0 (0x4000F014[16])
19:18	GP17DRV	R/W	0	GPIO Driving Control
17	GP17SMT	R/W	1	GPIO SMT Control
16	GP17IE	R/W	1	GPIO Input Enable
15:13	RSVD			
12:8	GP16FUNC	R/W	5'hB	GPIO Function Select (Default : SWGPIO)
7:6	RSVD			
5	GP16PD	R/W	0	GPIO Pull Down Control
4	GP16PU	R/W	0	GPIO Pull Up Control
3:2	GP16DRV	R/W	0	GPIO Driving Control
1	GP16SMT	R/W	1	GPIO SMT Control
0	GP16IE	R/W	1	GPIO Input Enable

BL702/704/706 参考手册 61/ 370 @2021 Bouffalo Lab



3.3.27 GPIO_CFGCTL9

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	RSVD			G	P19FUN	С		RS	VD	GP19	GP19	GP19	DRV	GP19	GP19
										PD	PU			SMT	ΙE
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	RSVD			G	P18FUN	С		RS	VD	GP18	GP18	GP18	BDRV	GP18	GP18
										PD	PU			SMT	ΙE

位	名称	权限	复位值	描述
31:29	RSVD			
28:24	GP19FUNC	R/W	5'hB	GPIO Function Select (Default : SWGPIO)
23:22	RSVD			
21	GP19PD	R/W	0	GPIO Pull Down Control
20	GP19PU	R/W	0	GPIO Pull Up Control
19:18	GP19DRV	R/W	0	GPIO Driving Control
17	GP19SMT	R/W	1	GPIO SMT Control
16	GP19IE	R/W	1	GPIO Input Enable
15:13	RSVD			
12:8	GP18FUNC	R/W	5'hB	GPIO Function Select (Default : SWGPIO)
7:6	RSVD			
5	GP18PD	R/W	0	GPIO Pull Down Control
4	GP18PU	R/W	0	GPIO Pull Up Control
3:2	GP18DRV	R/W	0	GPIO Driving Control
1	GP18SMT	R/W	1	GPIO SMT Control
0	GP18IE	R/W	1	GPIO Input Enable



3.3.28 **GPIO_CFGCTL10**

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	RSVD			G	P21FUN	С		RS	VD	GP21	GP21	GP2	1DRV	GP21	GP21
										PD	PU			SMT	ΙE
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	RSVD			G	P20FUN	С		RS	VD	GP20	GP20	GP20	DRV	GP20	GP20
										PD	PU			SMT	ΙE

位	名称	权限	复位值	描述
31:29	RSVD			
28:24	GP21FUNC	R/W	5'hB	GPIO Function Select (Default : SWGPIO)
23:22	RSVD			
21	GP21PD	R/W	0	GPIO Pull Down Control
20	GP21PU	R/W	0	GPIO Pull Up Control
19:18	GP21DRV	R/W	0	GPIO Driving Control
17	GP21SMT	R/W	1	GPIO SMT Control
16	GP21IE	R/W	1	GPIO Input Enable
15:13	RSVD			
12:8	GP20FUNC	R/W	5'hB	GPIO Function Select (Default : SWGPIO)
7:6	RSVD			
5	GP20PD	R/W	0	GPIO Pull Down Control
4	GP20PU	R/W	0	GPIO Pull Up Control
3:2	GP20DRV	R/W	0	GPIO Driving Control
1	GP20SMT	R/W	1	GPIO SMT Control
0	GP20IE	R/W	1	GPIO Input Enable



3.3.29 **GPIO_CFGCTL11**

地址: 0x4000012c

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	RSVD			G	P23FUN	С		RS	VD	GP23	GP23	GP23	BDRV	GP23	GP23
										PD	PU			SMT	IE
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	RSVD			G	P22FUN	С		RS	VD	GP22	GP22	GP22	2DRV	GP22	GP22
										PD	PU			SMT	ΙE

位	名称	权限	复位值	描述
31:29	RSVD			
28:24	GP23FUNC	R/W	5'hB	GPIO Function Select (Default : SWGPIO)
23:22	RSVD			
21	GP23PD	R/W	0	GPIO Pull Down Control
20	GP23PU	R/W	0	GPIO Pull Up Control
19:18	GP23DRV	R/W	0	GPIO Driving Control
17	GP23SMT	R/W	1	GPIO SMT Control
16	GP23IE	R/W	1	GPIO Input Enable
15:13	RSVD			
12:8	GP22FUNC	R/W	5'hB	GPIO Function Select (Default : SWGPIO)
7:6	RSVD			
5	GP22PD	R/W	0	GPIO Pull Down Control
4	GP22PU	R/W	0	GPIO Pull Up Control
3:2	GP22DRV	R/W	0	GPIO Driving Control
1	GP22SMT	R/W	1	GPIO SMT Control
0	GP22IE	R/W	1	GPIO Input Enable



3.3.30 GPIO_CFGCTL12

地址: 0x40000130

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	RSVD			G	P25FUN	С		RS	VD	GP25 PD	GP25 PU	GP2	DRV	GP25 SMT	GP25 IE
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	RSVD			G	P24FUN	С		RS	VD	GP24	GP24	GP24	1DRV	GP24	GP24
										PD	PU			SMT	ΙE

位	名称	权限	复位值	描述
31:29	RSVD			
28:24	GP25FUNC	R/W	5'hB	GPIO Function Select (Default : SWGPIO)
23:22	RSVD			
21	GP25PD	R/W	0	GPIO Pull Down Control
20	GP25PU	R/W	0	GPIO Pull Up Control
19:18	GP25DRV	R/W	0	GPIO Driving Control
17	GP25SMT	R/W	1	GPIO SMT Control
16	GP25IE	R/W	1	GPIO Input Enable
15:13	RSVD			
12:8	GP24FUNC	R/W	5'hB	GPIO Function Select (Default : SWGPIO)
7:6	RSVD			
5	GP24PD	R/W	1	GPIO Pull Down Control
4	GP24PU	R/W	0	GPIO Pull Up Control
3:2	GP24DRV	R/W	0	GPIO Driving Control
1	GP24SMT	R/W	1	GPIO SMT Control
0	GP24IE	R/W	1	GPIO Input Enable

BL702/704/706 参考手册 65/ 370 @2021 Bouffalo Lab



3.3.31 **GPIO_CFGCTL13**

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	RSVD			G	P27FUN	С		RS	VD	GP27	GP27	GP27	DRV	GP27	GP27
										PD	PU			SMT	ΙE
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	RSVD			G	P26FUN	С		RS	VD	GP26	GP26	GP26	BDRV	GP26	GP26
										PD	PU			SMT	ΙE

位	名称	权限	复位值	描述
31:29	RSVD			
28:24	GP27FUNC	R/W	5'hB	GPIO Function Select (Default : SWGPIO)
23:22	RSVD			
21	GP27PD	R/W	0	GPIO Pull Down Control
20	GP27PU	R/W	0	GPIO Pull Up Control
19:18	GP27DRV	R/W	0	GPIO Driving Control
17	GP27SMT	R/W	1	GPIO SMT Control
16	GP27IE	R/W	1	GPIO Input Enable
15:13	RSVD			
12:8	GP26FUNC	R/W	5'hB	GPIO Function Select (Default : SWGPIO)
7:6	RSVD			
5	GP26PD	R/W	0	GPIO Pull Down Control
4	GP26PU	R/W	0	GPIO Pull Up Control
3:2	GP26DRV	R/W	0	GPIO Driving Control
1	GP26SMT	R/W	1	GPIO SMT Control
0	GP26IE	R/W	1	GPIO Input Enable



3.3.32 **GPIO_CFGCTL14**

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	RSVD			G	P29FUN	С		RS	VD	GP29 PD	GP29 PU	GP29	DRV	GP29 SMT	GP29 IE
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	RSVD			G	P28FUN	С		RS	VD	GP28 PD	GP28 PU	GP28	BDRV	GP28 SMT	GP28 IE

位	名称	权限	复位值	描述
31:29	RSVD			
28:24	GP29FUNC	R/W	5'hB	GPIO Function Select (Default : SWGPIO)
23:22	RSVD			
21	GP29PD	R/W	0	GPIO Pull Down Control
20	GP29PU	R/W	0	GPIO Pull Up Control
19:18	GP29DRV	R/W	0	GPIO Driving Control
17	GP29SMT	R/W	1	GPIO SMT Control
16	GP29IE	R/W	1	GPIO Input Enable
15:13	RSVD			
12:8	GP28FUNC	R/W	5'hB	GPIO Function Select (Default : SWGPIO)
7:6	RSVD			
5	GP28PD	R/W	0	GPIO Pull Down Control
4	GP28PU	R/W	0	GPIO Pull Up Control
3:2	GP28DRV	R/W	0	GPIO Driving Control
1	GP28SMT	R/W	1	GPIO SMT Control
0	GP28IE	R/W	1	GPIO Input Enable



3.3.33 GPIO_CFGCTL15

地址: 0x4000013c

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	RSVD			G	P31FUN	С		RS	VD	GP31	GP31	GP31	IDRV	GP31	GP31
										PD	PU			SMT	ΙE
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	RSVD			G	P30FUN	С		RS	VD	GP30	GP30	GP30	DRV	GP30	GP30
										PD	PU			SMT	ΙE

位	名称	权限	复位值	描述
31:29	RSVD			
28:24	GP31FUNC	R/W	5'hB	GPIO Function Select (Default : SWGPIO)
23:22	RSVD			
21	GP31PD	R/W	0	GPIO Pull Down Control
20	GP31PU	R/W	0	GPIO Pull Up Control
19:18	GP31DRV	R/W	0	GPIO Driving Control
17	GP31SMT	R/W	1	GPIO SMT Control
16	GP31IE	R/W	1	GPIO Input Enable
15:13	RSVD			
12:8	GP30FUNC	R/W	5'hB	GPIO Function Select (Default : SWGPIO)
7:6	RSVD			
5	GP30PD	R/W	0	GPIO Pull Down Control
4	GP30PU	R/W	0	GPIO Pull Up Control
3:2	GP30DRV	R/W	0	GPIO Driving Control
1	GP30SMT	R/W	1	GPIO SMT Control
0	GP30IE	R/W	1	GPIO Input Enable



3.3.34 GPIO_CFGCTL16

地址: 0x40000140

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
				RS	GP33	GP33P	U GP33	BDRV	GP33	GP33					
										PD				SMT	ΙE
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	RSVD											GP32	2DRV	GP32	GP32
														SMT	ΙE

位	名称	权限	复位值	描述
31:22	RSVD			
21	GP33PD	R/W	0	GPIO Pull Down Control
20	GP33PU	R/W	0	GPIO Pull Up Control
19:18	GP33DRV	R/W	0	GPIO Driving Control
17	GP33SMT	R/W	1	GPIO SMT Control
16	GP33IE	R/W	1	GPIO Input Enable
15:6	RSVD			
5	GP32PD	R/W	0	GPIO Pull Down Control
4	GP32PU	R/W	0	GPIO Pull Up Control
3:2	GP32DRV	R/W	0	GPIO Driving Control
1	GP32SMT	R/W	1	GPIO SMT Control
0	GP32IE	R/W	1	GPIO Input Enable

3.3.35 **GPIO_CFGCTL17**

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
				RS	GP35	GP35	GP35	5DRV	GP35	GP35					
					PD	PU			SMT	ΙE					
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	RSVD											GP34	1DRV	GP34	GP34
														SMT	ΙE

位	名称	权限	复位值	描述
31:22	RSVD			



位	名称	权限	复位值	描述
21	GP35PD	R/W	0	GPIO Pull Down Control
20	GP35PU	R/W	0	GPIO Pull Up Control
19:18	GP35DRV	R/W	0	GPIO Driving Control
17	GP35SMT	R/W	1	GPIO SMT Control
16	GP35IE	R/W	1	GPIO Input Enable
15:6	RSVD			
5	GP34PD	R/W	0	GPIO Pull Down Control
4	GP34PU	R/W	0	GPIO Pull Up Control
3:2	GP34DRV	R/W	0	GPIO Driving Control
1	GP34SMT	R/W	1	GPIO SMT Control
0	GP34IE	R/W	1	GPIO Input Enable

3.3.36 GPIO_CFGCTL18

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
				RS	GP37	GP37	GP37	7DRV	GP37	GP37					
										PD	PU			SMT	ΙE
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	RSVD											GP36	BDRV	GP36	GP36
														SMT	ΙE

位	名称	权限	复位值	描述
31:22	RSVD			
21	GP37PD	R/W	0	GPIO Pull Down Control
20	GP37PU	R/W	0	GPIO Pull Up Control
19:18	GP37DRV	R/W	0	GPIO Driving Control
17	GP37SMT	R/W	1	GPIO SMT Control
16	GP37IE	R/W	1	GPIO Input Enable
15:6	RSVD			
5	GP36PD	R/W	0	GPIO Pull Down Control
4	GP36PU	R/W	0	GPIO Pull Up Control
3:2	GP36DRV	R/W	0	GPIO Driving Control



位	名称	权限	复位值	描述
1	GP36SMT	R/W	1	GPIO SMT Control
0	GP36IE	R/W	1	GPIO Input Enable

3.3.37 GPIO_CFGCTL30

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
GP31	GP30	GP29	GP28	GP27	GP26	GP25	GP24	GP23	GP22	GP21	GP20	GP19	GP18	GP17	GP16
I	I	I	I	I	I	I	I	Ţ	Ţ	I	1	I	I	Ţ	I
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
GP15	GP14	GP13	GP12	GP11	GP10	GP9	GP8	GP7	GP6	GP5	GP4	GP3	GP2	GP1	GP0
1		1	I	I		I				I		l	1		l

位	名称	权限	复位值	描述
31	GP31I	R	0	Register Controlled GPIO Input value
30	GP30I	R	0	Register Controlled GPIO Input value
29	GP29I	R	0	Register Controlled GPIO Input value
28	GP28I	R	0	Register Controlled GPIO Input value
27	GP27I	R	0	Register Controlled GPIO Input value
26	GP26I	R	0	Register Controlled GPIO Input value
25	GP25I	R	0	Register Controlled GPIO Input value
24	GP24I	R	0	Register Controlled GPIO Input value
23	GP23I	R	0	Register Controlled GPIO Input value
22	GP22I	R	0	Register Controlled GPIO Input value
21	GP21I	R	0	Register Controlled GPIO Input value
20	GP20I	R	0	Register Controlled GPIO Input value
19	GP19I	R	0	Register Controlled GPIO Input value
18	GP18I	R	0	Register Controlled GPIO Input value
17	GP17I	R	0	Register Controlled GPIO Input value
16	GP16I	R	0	Register Controlled GPIO Input value
15	GP15I	R	0	Register Controlled GPIO Input value
14	GP14I	R	0	Register Controlled GPIO Input value
13	GP13I	R	0	Register Controlled GPIO Input value



位	名称	权限	复位值	描述
12	GP12I	R	0	Register Controlled GPIO Input value
11	GP11I	R	0	Register Controlled GPIO Input value
10	GP10I	R	0	Register Controlled GPIO Input value
9	GP9I	R	0	Register Controlled GPIO Input value
8	GP8I	R	0	Register Controlled GPIO Input value
7	GP7I	R	0	Register Controlled GPIO Input value
6	GP6I	R	0	Register Controlled GPIO Input value
5	GP5I	R	0	Register Controlled GPIO Input value
4	GP4I	R	0	Register Controlled GPIO Input value
3	GP3I	R	0	Register Controlled GPIO Input value
2	GP2I	R	0	Register Controlled GPIO Input value
1	GP1I	R	0	Register Controlled GPIO Input value
0	GP0I	R	0	Register Controlled GPIO Input value

3.3.38 GPIO_CFGCTL32

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
GP31	GP30	GP29	GP28	GP27	GP26	GP25	GP24	GP23	GP22	GP21	GP20	GP19	GP18	GP17	GP16
0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
GP15	GP14	GP13	GP12	GP11	GP10	GP9	GP8	GP7	GP6	GP5	GP4	GP3	GP2	GP1	GP0
0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0

位	名称	权限	复位值	描述
31	GP310	R/W	0	Register Controlled GPIO Output Value
30	GP30O	R/W	0	Register Controlled GPIO Output Value
29	GP29O	R/W	0	Register Controlled GPIO Output Value
28	GP28O	R/W	0	Register Controlled GPIO Output Value
27	GP270	R/W	0	Register Controlled GPIO Output Value
26	GP26O	R/W	0	Register Controlled GPIO Output Value
25	GP25O	R/W	0	Register Controlled GPIO Output Value
24	GP24O	R/W	0	Register Controlled GPIO Output Value



位	名称	权限	复位值	描述
23	GP230	R/W	0	Register Controlled GPIO Output Value
22	GP220	R/W	0	Register Controlled GPIO Output Value
21	GP210	R/W	0	Register Controlled GPIO Output Value
20	GP200	R/W	0	Register Controlled GPIO Output Value
19	GP190	R/W	0	Register Controlled GPIO Output Value
18	GP180	R/W	0	Register Controlled GPIO Output Value
17	GP170	R/W	0	Register Controlled GPIO Output Value
16	GP160	R/W	0	Register Controlled GPIO Output Value
15	GP150	R/W	0	Register Controlled GPIO Output Value
14	GP140	R/W	0	Register Controlled GPIO Output Value
13	GP130	R/W	0	Register Controlled GPIO Output Value
12	GP120	R/W	0	Register Controlled GPIO Output Value
11	GP110	R/W	0	Register Controlled GPIO Output Value
10	GP100	R/W	0	Register Controlled GPIO Output Value
9	GP9O	R/W	0	Register Controlled GPIO Output Value
8	GP8O	R/W	0	Register Controlled GPIO Output Value
7	GP70	R/W	0	Register Controlled GPIO Output Value
6	GP6O	R/W	0	Register Controlled GPIO Output Value
5	GP5O	R/W	0	Register Controlled GPIO Output Value
4	GP40	R/W	0	Register Controlled GPIO Output Value
3	GP3O	R/W	0	Register Controlled GPIO Output Value
2	GP2O	R/W	0	Register Controlled GPIO Output Value
1	GP10	R/W	0	Register Controlled GPIO Output Value
0	GP0O	R/W	0	Register Controlled GPIO Output Value



3.3.39 **GPIO_CFGCTL34**

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
GP31	GP30	GP29	GP28	GP27	GP26	GP25	GP24	GP23	GP22	GP21	GP20	GP19	GP18	GP17	GP16
OE															
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
GP15	GP14	GP13	GP12	GP11	GP10	GP9	GP8	GP7	GP6	GP5	GP4	GP3	GP2	GP1	GP0
OE															

位	名称	权限	复位值	描述
31	GP310E	R/W	0	Register Controlled GPIO Output Enable (Used when GPIO Function select to Register Control GPIO)
30	GP300E	R/W	0	Register Controlled GPIO Output Enable (Used when GPIO Function select to Register Control GPIO)
29	GP290E	R/W	0	Register Controlled GPIO Output Enable (Used when GPIO Function select to Register Control GPIO)
28	GP280E	R/W	0	Register Controlled GPIO Output Enable (Used when GPIO Function select to Register Control GPIO)
27	GP270E	R/W	0	Register Controlled GPIO Output Enable (Used when GPIO Function select to Register Control GPIO)
26	GP26OE	R/W	0	Register Controlled GPIO Output Enable (Used when GPIO Function select to Register Control GPIO)
25	GP25OE	R/W	0	Register Controlled GPIO Output Enable (Used when GPIO Function select to Register Control GPIO)
24	GP24OE	R/W	0	Register Controlled GPIO Output Enable (Used when GPIO Function select to Register Control GPIO)
23	GP230E	R/W	0	Register Controlled GPIO Output Enable (Used when GPIO Function select to Register Control GPIO)
22	GP22OE	R/W	0	Register Controlled GPIO Output Enable (Used when GPIO Function select to Register Control GPIO)
21	GP210E	R/W	0	Register Controlled GPIO Output Enable (Used when GPIO Function select to Register Control GPIO)
20	GP200E	R/W	0	Register Controlled GPIO Output Enable (Used when GPIO Function select to Register Control GPIO)
19	GP190E	R/W	0	Register Controlled GPIO Output Enable (Used when GPIO Function select to Register Control GPIO)
18	GP18OE	R/W	0	Register Controlled GPIO Output Enable (Used when GPIO Function select to Register Control GPIO)



位	名称	权限	复位值	描述			
17	GP170E	R/W	0	Register Controlled GPIO Output Enable (Used when GPIO Function select to Register Control GPIO)			
16	GP16OE	R/W	0	Register Controlled GPIO Output Enable (Used when GPIO Function select to Register Control GPIO)			
15	GP15OE	R/W	0	Register Controlled GPIO Output Enable (Used when GPIO Function select to Register Control GPIO)			
14	GP140E	R/W	0	Register Controlled GPIO Output Enable (Used when GPIO Function select to Register Control GPIO)			
13	GP13OE	R/W	0	Register Controlled GPIO Output Enable (Used when GPIO Function select to Register Control GPIO)			
12	GP120E	R/W	0	Register Controlled GPIO Output Enable (Used when GPIO Function select to Register Control GPIO)			
11	GP110E	R/W	0	Register Controlled GPIO Output Enable (Used when GPIO Function select to Register Control GPIO)			
10	GP100E	R/W	0	Register Controlled GPIO Output Enable (Used when GPIO Function select to Register Control GPIO)			
9	GP90E	R/W	0	Register Controlled GPIO Output Enable (Used when GPIO Function select to Register Control GPIO)			
8	GP8OE	R/W	0	Register Controlled GPIO Output Enable (Used when GPIO Function select to Register Control GPIO)			
7	GP70E	R/W	0	Register Controlled GPIO Output Enable (Used when GPIO Function select to Register Control GPIO)			
6	GP60E	R/W	0	Register Controlled GPIO Output Enable (Used when GPIO Function select to Register Control GPIO)			
5	GP50E	R/W	0	Register Controlled GPIO Output Enable (Used when GPIO Function select to Register Control GPIO)			
4	GP40E	R/W	0	Register Controlled GPIO Output Enable (Used when GPIO Function select to Register Control GPIO)			
3	GP3OE	R/W	0	Register Controlled GPIO Output Enable (Used when GPIO Function select to Register Control GPIO)			
2	GP2OE	R/W	0	Register Controlled GPIO Output Enable (Used when GPIO Function select to Register Control GPIO)			
1	GP10E	R/W	0	Register Controlled GPIO Output Enable (Used when GPIO Function select to Register Control GPIO)			
0	GP00E	R/W	0	Register Controlled GPIO Output Enable (Used when GPIO Function select to Register Control GPIO)			



3.3.40 **GPIO_CFGCTL35**

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
							RS	VD							
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	RSVD							GP39	GP38	GP37	GP36	GP35	GP34	GP33	GP32
								OE							

位	名称	权限	复位值	描述
31:9	RSVD			
8	GP400E	R/W	0	Register Controlled GPIO Output Enable (Used when GPIO Function select to Register Control GPIO)
7	GP390E	R/W	0	Register Controlled GPIO Output Enable (Used when GPIO Function select to Register Control GPIO)
6	GP380E	R/W	0	Register Controlled GPIO Output Enable (Used when GPIO Function select to Register Control GPIO)
5	GP370E	R/W	0	Register Controlled GPIO Output Enable (Used when GPIO Function select to Register Control GPIO)
4	GP360E	R/W	0	Register Controlled GPIO Output Enable (Used when GPIO Function select to Register Control GPIO)
3	GP350E	R/W	0	Register Controlled GPIO Output Enable (Used when GPIO Function select to Register Control GPIO)
2	GP340E	R/W	0	Register Controlled GPIO Output Enable (Used when GPIO Function select to Register Control GPIO)
1	GP330E	R/W	0	Register Controlled GPIO Output Enable (Used when GPIO Function select to Register Control GPIO)
0	GP320E	R/W	0	Register Controlled GPIO Output Enable (Used when GPIO Function select to Register Control GPIO)



3.3.41 GPIO_INT_MASK1

地址: 0x400001a0

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	GPITMS1														
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	GPITMS1														

位	名称	权限	复位值	描述
31:0	GPITMS1	R/W	32'hFFFFFFF	reg_gpio_int_mask[31:0]

3.3.42 GPIO_INT_STAT1

地址: 0x400001a8

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	GPITSTA1														
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	GPITSTA1														

位	名称	权限	复位值	描述
31:0	GPITSTA1	R	0	gpio_int_stat[31:0]

3.3.43 **GPIO_INT_CLR1**

地址: 0x400001b0

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	GPITCLR1														
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	GPITCLR1														

位	名称	权限	复位值	描述
31:0	GPITCLR1	R/W	0	reg_gpio_int_clr[31:0]

BL702/704/706 参考手册 77/ 370 @2021 Bouffalo Lab



3.3.44 GPIO_INT_MODE_SET1

地址: 0x400001c0

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
RS	RSVD GPITMS1														
15	14	13	13 12 11 10 9 8 7 6 5 4 3 2 1 0									0			
	GPITMS1														

位	名称	权限	复位值	描述
31:30	RSVD			
29:0	GPITMS1	R/W	0	[2:0]: GPIO 0 Interrupt Mode Control[2:0] [5:3]: GPIO 1 Interrupt Mode Control[2:0] [8:6]: GPIO 2 Interrupt Mode Control[2:0] [11:9]: GPIO 3 Interrupt Mode Control[2:0] [14:12]: GPIO 4 Interrupt Mode Control[2:0] [17:15]: GPIO 5 Interrupt Mode Control[2:0] [20:18]: GPIO 6 Interrupt Mode Control[2:0] [23:21]: GPIO 7 Interrupt Mode Control[2:0] [26:24]: GPIO 8 Interrupt Mode Control[2:0] [29:27]: GPIO 9 Interrupt Mode Control[2:0] [29:27]: GPIO 9 Interrupt Mode Control[2:0] [2]: 1: async mode 0: sync mode [1:0]: 00: negedge pulse 10: negedge level (32k 3T) 11: posedge level (32k 3T)

3.3.45 GPIO_INT_MODE_SET2

地址: 0x400001c4

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
RS	RSVD GPITMS2														
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	GPITMS2														



名称	权限	复位值	描述
RSVD			
GPITMS2	R/W	0	[2:0]: GPIO 10 Interrupt Mode Control[2:0] [5:3]: GPIO 11 Interrupt Mode Control[2:0] [8:6]: GPIO 12 Interrupt Mode Control[2:0] [11:9]: GPIO 13 Interrupt Mode Control[2:0] [14:12]: GPIO 14 Interrupt Mode Control[2:0] [17:15]: GPIO 15 Interrupt Mode Control[2:0] [20:18]: GPIO 16 Interrupt Mode Control[2:0] [23:21]: GPIO 17 Interrupt Mode Control[2:0] [26:24]: GPIO 18 Interrupt Mode Control[2:0] [29:27]: GPIO 19 Interrupt Mode Control[2:0] [2]: 1: async mode 0: sync mode 0: sync mode [1:0]: 00: negedge pulse 10: negedge level (32k 3T) 11: posedge level (32k 3T)
	RSVD	RSVD	RSVD

3.3.46 GPIO_INT_MODE_SET3

地址: 0x400001c8

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
RS	RSVD GPITMS3														
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
				GPITMS3											

位	名称	权限	复位值	描述
31:30	RSVD			



位	名称	权限	复位值	描述
29:0	GPITMS3	R/W	0	[2:0]: GPIO 20 Interrupt Mode Control[2:0] [5:3]: GPIO 21 Interrupt Mode Control[2:0] [8:6]: GPIO 22 Interrupt Mode Control[2:0] [11:9]: GPIO 23 Interrupt Mode Control[2:0] [14:12]: GPIO 24 Interrupt Mode Control[2:0] [17:15]: GPIO 25 Interrupt Mode Control[2:0] [20:18]: GPIO 26 Interrupt Mode Control[2:0] [23:21]: GPIO 27 Interrupt Mode Control[2:0] [26:24]: GPIO 28 Interrupt Mode Control[2:0] [29:27]: GPIO 29 Interrupt Mode Control[2:0] [29:27]: GPIO 29 Interrupt Mode Control[2:0] [2]: 1: async mode 0: sync mode [1:0]: 00: negedge pulse 10: negedge level (32k 3T) 11: posedge level (32k 3T)

3.3.47 GPIO_INT_MODE_SET4

地址: 0x400001cc

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	RSVD														
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	RSVD											GPIT	MS4		

位	名称	权限	复位值	描述
31:6	RSVD			



位	名称	权限	复位值	描述
5:0	GPITMS4	R/W	0	[2:0] : GPIO 30 Interrupt Mode Control[2:0]
				[5:3] : GPIO 31 Interrupt Mode Control[2:0]
				[8:6] : GPIO 32 Interrupt Mode Control[2:0]
				[11:9] : GPIO 33 Interrupt Mode Control[2:0]
				[14:12] : GPIO 34 Interrupt Mode Control[2:0]
				[17:15] : GPIO 35 Interrupt Mode Control[2:0]
				[20:18] : GPIO 36 Interrupt Mode Control[2:0]
				[23:21] : GPIO 37 Interrupt Mode Control[2:0]
				[26:24] : GPIO 38 Interrupt Mode Control[2:0]
				[29:27] : GPIO 39 Interrupt Mode Control[2:0]
				GPIO X Interrupt Mode Control [2:0]
				[2] :
				1 : async mode
				0 : sync mode
				[1:0]:
				00 : negedge pulse
				01 : posedge pulse
				10 : negedge level (32k 3T)
				11 : posedge level (32k 3T)

3.3.48 **GPIO_INT2_MASK1**

地址: 0x400001d0

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	GPIT2M1														
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	GPIT2M1														

位	名称	权限	复位值	描述
31:0	GPIT2M1	R/W	32'hFFFFFFF	reg_gpio_int2_mask[31:0]



3.3.49 GPIO_INT2_STAT1

地址: 0x400001d4

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	GPIT2ST1														
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	GPIT2ST1														

位	名称	权限	复位值	描述
31:0	GPIT2ST1	R	0	gpio_int2_stat[31:0]

3.3.50 GPIO_INT2_CLR1

地址: 0x400001d8

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	GPIT2CL1														
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	GPIT2CL1														

位	名称	权限	复位值	描述
31:0	GPIT2CL1	R/W	0	reg_gpio_int2_clr[31:0]

3.3.51 GPIO_INT2_MODE_SET1

地址: 0x400001dc

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
RS	SVD		GPIT2MS1												
15	14	13	3 12 11 10 9 8 7 6 5 4 3 2 1 0								0				
	GPIT2MS1														

位	名称	权限	复位值	描述
31:30	RSVD			

BL702/704/706 参考手册 82/ 370 @2021 Bouffalo Lab



位 名称 权限 复位值 描述	
29:0 GPIT2MS1 R/W 0 [2:0] : GPIO 0 Interrupt [5:3] : GPIO 1 Interrupt [8:6] : GPIO 2 Interrupt [11:9] : GPIO 3 Interrupt [14:12] : GPIO 4 Interrupt [17:15] : GPIO 5 Interrupt [20:18] : GPIO 6 Interrupt [23:21] : GPIO 7 Interrupt [26:24] : GPIO 8 Interrupt [26:24]	pt Mode Control[2:0] pt Mode Control[2:0] upt Mode Control[2:0] rrupt Mode Control[2:0] de Control [2:0]

3.3.52 GPIO_INT2_MODE_SET2

地址: 0x400001e0

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
RS	DVS	GPIT2MS2													
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	GPIT2MS2														

位	名称	权限	复位值	描述
31:30	RSVD			



位	名称	权限	复位值	描述
29:0	GPIT2MS2	R/W	0	[2:0]: GPIO 10 Interrupt Mode Control[2:0] [5:3]: GPIO 11 Interrupt Mode Control[2:0] [8:6]: GPIO 12 Interrupt Mode Control[2:0] [11:9]: GPIO 13 Interrupt Mode Control[2:0] [14:12]: GPIO 14 Interrupt Mode Control[2:0] [17:15]: GPIO 15 Interrupt Mode Control[2:0] [20:18]: GPIO 16 Interrupt Mode Control[2:0] [23:21]: GPIO 17 Interrupt Mode Control[2:0] [26:24]: GPIO 18 Interrupt Mode Control[2:0] [29:27]: GPIO 19 Interrupt Mode Control[2:0] GPIO X Interrupt Mode Control [2:0] [2]: 1: async mode 0: sync mode [1:0]: 00: negedge pulse 10: negedge level (32k 3T) 11: posedge level (32k 3T)

3.3.53 GPIO_INT2_MODE_SET3

地址: 0x400001e4

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
RS	SVD	/D GPIT2MS3													
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	GPIT2MS3														

位	名称	权限	复位值	描述
31:30	RSVD			



位	名称	权限	复位值	描述
29:0	名称 GPIT2MS3	权限 R/W	复位值 0	[2:0]: GPIO 20 Interrupt Mode Control[2:0] [5:3]: GPIO 21 Interrupt Mode Control[2:0] [8:6]: GPIO 22 Interrupt Mode Control[2:0] [11:9]: GPIO 23 Interrupt Mode Control[2:0] [14:12]: GPIO 24 Interrupt Mode Control[2:0] [17:15]: GPIO 25 Interrupt Mode Control[2:0] [20:18]: GPIO 26 Interrupt Mode Control[2:0] [23:21]: GPIO 27 Interrupt Mode Control[2:0] [26:24]: GPIO 28 Interrupt Mode Control[2:0]
				[29:27]: GPIO 29 Interrupt Mode Control[2:0] GPIO X Interrupt Mode Control [2:0] [2]: 1: async mode 0: sync mode [1:0]: 00: negedge pulse 01: posedge pulse 10: negedge level (32k 3T) 11: posedge level (32k 3T)

3.3.54 GPIO_INT2_MODE_SET4

地址: 0x400001e8

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	RSVD														
15	15 14 13 12 11 10 9 8 7 6 5 4 3 2 1 0														
	RSVD											GPIT	2MS4		

位	名称	权限	复位值	描述
31:6	RSVD			



位	名称	权限	复位值	描述
5:0	GPIT2MS4	R/W	0	[2:0]: GPIO 30 Interrupt Mode Control[2:0] [5:3]: GPIO 31 Interrupt Mode Control[2:0] [8:6]: GPIO 32 Interrupt Mode Control[2:0] [11:9]: GPIO 33 Interrupt Mode Control[2:0] [14:12]: GPIO 34 Interrupt Mode Control[2:0]
				[17:15]: GPIO 35 Interrupt Mode Control[2:0] [20:18]: GPIO 36 Interrupt Mode Control[2:0] [23:21]: GPIO 37 Interrupt Mode Control[2:0] [26:24]: GPIO 38 Interrupt Mode Control[2:0] [29:27]: GPIO 39 Interrupt Mode Control[2:0] GPIO X Interrupt Mode Control [2:0] [2]: 1: async mode
				0 : sync mode [1:0] : 00 : negedge pulse 01 : posedge pulse 10 : negedge level (32k 3T) 11 : posedge level (32k 3T)

3.3.55 led_driver

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
PU LDRV	RSVD	LDR\	/OEN		RSVD										
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	RS	VD			IRRX	GPSL			LDR\	/IBIA			RSVD		

位	名称	权限	复位值	描述
31	PULDRV	R/W	1'b0	power up ir led drive
30	RSVD			
29:28	LDRVOEN	R/W	2'd3	ir led output enable [1]GPIO23 [0]GPIO22
27:12	RSVD			



位	名称	权限	复位值	描述
11:8	IRRXGPSL	R/W	4'h0	0 : disable ir_rx select gpio 1 15 :select gpio 19 33 as ir_rx (GPIO need to set as SWG-PIO mode)
7:4	LDRVIBIA	R/W	4'h8	ir led drive strength, [7:4]*8mA
3:0	RSVD			

3.3.56 usb_xcvr

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	RS	VD		RCV	VIP	VIM	BD	PU	SUS	SPD	ENUM		RSVD		DACV
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
RSVD	OEB	OEB REG	OEB SEL	RSVD	R	OUTPMC	os	RSVD	R	OUTNMC	os	PU IDO		IDOVFB	

位	名称	权限	复位值	描述
31:28	RSVD			
27	RCV	R	1'b0	rx_d
26	VIP	R	1'b0	rx_dp
25	VIM	R	1'b0	rx_dm
24	BD	R	1'b0	bd output
23	PU	R/W	1'b0	set 1 for power up usb transceiver
22	sus	R/W	1'b0	suspend mode enable set 1 for suspend
21	SPD	R/W	1'b1	full-speed/low-speed mode select must be 1
20	ENUM	R/W	1'b0	O: 1.5k pull up resistor floating; 1: 1.5k pull up resistor connect to D+/D- depends on spd set 1 for enumerate
19:17	RSVD			
16	DACV	RW	1'b0	0: original vip/vim; 1: converted vip/vim Leave it as the default
14	OEB	R	1'b1	oeb



位	名称	权限	复位值	描述
13	OEBREG	RW	1'b1	Leave it as the default
12	OEBSEL	RW	1'b0	0: usb_oeb; 1: usb_oeb_reg Leave it as the default
11	RSVD			
10:8	ROUTPMOS	R/W	3'h3	Leave it as the default
7	RSVD			
6:4	ROUTNMOS	R/W	3'h3	Leave it as the default
3	PUIDO	R/W	1'b0	power up usb Ido Leave it as the default
2:0	IDOVFB	R/W	3'h3	usb Ido ref voltage Leave it as the default

3.3.57 usb_xcvr_config

地址: 0x4000022c

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
RSVD		SRPR		RSVD		SRPF		RSVD		SRMR		RSVD		SRMF	
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
RSVD		PUTUNE		USE		STRDRV		USE		BDVTH		VHY	/SP	VHY	′SM
				CTRL				XCVR							

位	名称	权限	复位值	描述
31	RSVD			
30:28	SRPR	R/W	3'h4	D+ rise slew rate control
				Leave it as the default
27	RSVD			
26:24	SRPF	R/W	3'h3	D+ fall slew rate control
				Leave it as the default
23	RSVD			
22:20	SRMR	R/W	3'h4	D- rise slew rate control
				Leave it as the default
19	RSVD			
18:16	SRMF	R/W	3'h3	D- fall slew rate control
				Leave it as the default



位	名称	权限	复位值	描述
15	RSVD			
14:12	PUTUNE	R/W	3'h2	pull up resistor tuning Leave it as the default
11	USECTRL	R/W	1'b1	1: USB XCVR use on-chip usb controller; 0: USB XCVR usb off-chip usb controller Leave it as the default
10:8	STRDRV	R/W	3'h0	driver strength Leave it as the default
7	USEXCVR	R/W	1'b1	1: USB core use on-chip usb_xcvr; 0: USB core usb off-chip usb_xcvr Leave it as the default
6:4	BDVTH	R/W	3'h1	bd threashold voltage set 7
3:2	VHYSP	R/W	2'b1	D+ input hysteresis select Leave it as the default
1:0	VHYSM	R/W	2'b1	D- input hysteresis select Leave it as the default

3.3.58 gpdac_ctrl

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
							RS	VD							
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
			RSVD				REF	TSEN			RSVD			BRS	ARS
							SEL							ANA	ANA

位	名称	权限	复位值	描述
31:9	RSVD			
8	REFSEL	R/W	1'h0	Reference select 1'h0 Internal reference 1'h1 External reference
7	TSEN	R/W	1'h0	Test enable 1'h0 analog test disabled (ATEST is set in Hi-Z state) 1'h1 analog test point enabled to ATEST
6:2	RSVD			
1	BRSANA	R/W	1'h1	Soft reset for DAC channel B, active low



位	名称	权限	复位值	描述
0	ARSANA	R/W	1'h1	Soft reset for DAC channel A, active low

3.3.59 gpdac_actrl

地址: 0x4000030c

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
				RSVD						AOMUX		AR	NG	RS	VD
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
						RS	VD							IOA	AEN
														EN	

位	名称	权限	复位值	描述
31:23	RSVD			
22:20	AOMUX	R/W	3'h0	
19:18	ARNG	R/W	2'h3	Output voltage range control with internal/external reference
17:2	RSVD			
1	IOAEN	R/W	1'h0	Channel A conversion output to pad enable 1'h0 Disable channel A conversion result to GPIO 1'h1 Enable channel A conversion result to GPIO
0	AEN	R/W	1'h0	Channel A enable/disable signal 1'h0 Disable channel A conversion. 1'h1 Enable channel A conversion

3.3.60 gpdac_bctrl

地址: 0x40000310

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
				RSVD						вом		BR	NG	RS	VD
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	,					RS	SVD							IOB	BEN
														EN	

BL702/704/706 参考手册 90/ 370 @2021 Bouffalo Lab



位	名称	权限	复位值	描述
31:23	RSVD			
22:20	вом	R/W	3'h0	
19:18	BRNG	R/W	2'h3	Output voltage range control with internal/external reference
17:2	RSVD			
1	IOBEN	R/W	1'h0	channel B conversion output to pad enable 1'h0 Disable channel B conversion result to GPIO 1'h1 Enable channel B conversion result to GPIO
0	BEN	R/W	1'h0	channel B enable/disable signal 1'h0 Disable channel B conversion. 1'h1 Enable channel B conversion

3.3.61 gpdac_data

地址: 0x40000314

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
		RS	SVD							ADA	ATA				
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	RSVD								BD	ATA					

位	名称	权限	复位值	描述
31:26	RSVD			
25:16	ADATA	R/W	10'h0	Channel A Data input
15:10	RSVD			
9:0	BDATA	R/W	10'h0	Channel B Data input

BL702/704/706 参考手册 91/ 370 @2021 Bouffalo Lab

4.1 简介

芯片內置一个 12bits 的逐次逼近式模拟数字转换器 (ADC), 支持 12 路外部模拟输入和若干內部模拟信号选择。ADC 支持以下四种模式:单次单通道转换、连续单通道转换、单次多通道转换和连续多通道转换模式。转换结果为 12/14/16bits 左对齐模式。ADC 拥有深度为 32 的 FIFO, 支持多种中断和 DMA 操作。ADC 除了用于普通模拟信号测量外,还可以用于测量供电电压,此外 ADC 还可以通过测量内/外部二极管电压用于温度检测。

4.2 主要特点

- 高性能
 - 可以选择 12/14/16bits 转换结果输出
 - ADC 最大工作时钟为 2MHZ
 - 支持 2.0V,3.2V 可选内部参考电压
 - 支持 DMA 将转换结果搬运到内存
 - 支持单次单通道转换、连续单通道转换、单次多通道转换和连续多通道转换模式四种模式
 - 支持单端与差分两种输入模式
 - 支持抖动补偿
 - 支持用户自行设定转换结果偏移值
- 模拟通道数
 - 12 路外部模拟通道
 - 2 路 DAC 内部通道
 - 1 路 VBAT/2 通道
 - 1 路 TSEN 通道



4.3 功能描述

ADC 模块基本框图如图所示。




图 4.1: ADC 基本框图

ADC 模块包含五大部分:分别为前端输入通道选择器,程控放大器,ADC 采样模块,数据处理模块以及 FIFO。输入通道选择器用于选择需要采样的通道,既包含外部模拟信号,也包含内部模拟信号。程控放大器用于对输入信号做进一步处理,可以根据输入信号的特点进行设定,以便得到更准确的转换值。ADC 采样模块是最主要的功能模块,通过逐次比较的方式,实现模拟信号到数字信号的转换。转换结果的精度为 12bits,数据处理模块负责进一步处理转换的结果,包括添加通道信息等。最后得到的数据会被推送到最后端的 FIFO 中。

4.3.1 ADC 引脚和内部信号

表 4.1: ADC 内部信号

内部信号	信号类型	信号描述
VBAT/2	Input	从电源引脚分压过来的电压信号
TSEN	Input	内部温度传感器输出电压

BL702/704/706 参考手册 93/ 370 @2021 Bouffalo Lab



表 4.1: ADC 内部信号

内部信号	信号类型	信号描述
VREF	Input	内部模拟模块参考电压
DACOUTA	Input	DAC 模块输出
DACOUTB	Input	DAC 模块输出

表 4.2: ADC 外部引脚

外部引脚	信号类型	信号描述
VDDA	Input	模拟模块供电电压正极
VSSA	Input	模拟模块供电地
ADC_CHX	Input	模拟输入引脚,总共 12 路

4.3.2 ADC 通道

ADC 采样可以选择的通道包括外部模拟引脚的输入信号和芯片内部可选信号,具体包括:

- ADC CH0
- ADC CH1
- ADC CH2
- ADC CH3
- ADC CH4
- ADC CH5
- ADC CH6
- ADC CH7
- ADC CH8
- ADC CH9
- ADC CH10
- ADC CH11
- VDDA
- VSSA



- DAC OUTA
- DAC OUTB
- VBAT/2
- TSEN
- VREF
- GND

需要注意的是,如果选择 VBAT/2 或 TSEN 作为输入待采信号,需要把 gpadc_vbat_en 或 gpadc_ts_en 置位。ADC 模块可以支持单端输入或者差分输入,如果是单端输入模式,负极输入通道需要选择 GND。

4.3.3 ADC 时钟

ADC 模块的工作时钟来源如下图所示。




图 4.2: ADC 时钟

ADC 的时钟源可以选择来自 Audio PLL, XCLK 或者 f32k, 时钟源的选择在 GLB 模块中设定, 选择的同时可以通过分 频器对时钟源进行分频。在一般的电压测量应用下, 会选择使用 XCLK 作为时钟源。如果是在音频应用下,可以使用 Audio PLL 去产生诸如 8KHZ,44.1KHZ 这样的常用采样时钟。f32k 是低频时钟,为 MCU 睡眠的时候提供唤醒的时钟。

在 ADC 模块内部,提供了一个时钟分频,可以对输入时钟进行 1/4/8/12/16/20/24/32 分频。用户可以根据实际采样需求,自行调整 ADC 的时钟源和分频系数,注意 ADC 的最大输入时钟是 2MHZ。

gpadc_32m_clk_div 分频寄存器宽度为 6Bits,最大分频为 64,分频公式为 fout=fsource/(gpadc_32m_clk_div+1)。gpadc_-clk_div_ratio 分频寄存器位于 ADC 模块内部,宽度为 3Bits,其分频值定义如下:

(下页继续)



(续上页)

用户若想调整 ADC 的输入时钟,将有四种方式。

- 1. 切换时钟源, XTAL 默认是 32MHZ, Audio PLL(可配置为 11.288MHZ 或 11.2896MHZ)。
- 2. 使用在时钟模块中长度为 6BITS 的分频器。
- 3. 使用 ADC 模块内部分频器,可选分频为 1/4/8/12/16/20/24/32 分频。
- 4. 通过配置 gpadc_res_sel 寄存器,改变 OSR 的值,达成分频效果。如果 OSR=256,实际等效 ADC 的输入时钟做了 256 分频。

假设时钟源选择选择 Audio PLL=11.2896MHZ, GLB 分频选择配置为 1, ADC 内部分频器选择 ADC_CLK_DIV_4, OSR=128 则最终的时钟输出为 fout = 11289600 / (1 + 1) / 4 / 128 = 11025HZ

4.3.4 ADC 转换模式

ADC 支持单通道转换和扫描转换两种模式,在单通道转换模式下,用户需要通过 gpadc_pos_sel 选择正极输入通道,通过 gpadc_neg_sel 选择负极输入通道,同时把 gpadc_cont_conv_en 控制位设置为 0,表示单通道转换,然后设置 gpadc conv start 控制位启动转换即可。

在扫描转换模式下,gpadc_cont_conv_en 控制位需要设置为 1,ADC 根据 gpadc_scan_length 控制位设定的转换通 道个数,依次按照 gpadc_reg_scn_posX(X=1, 2) 和 gpadc_reg_scn_negX(X=1, 2) 寄存器组所设定的通道顺序,逐个进行转换,转换的结果会自动推入 ADC 的 FIFO。gpadc_reg_scn_posX(X=1, 2) 和 gpadc_reg_scn_negX(X=1, 2) 寄存器组所设定的通道可以相同,这也就意味着用户可以实现对一个通道进行多次采样转换。

ADC 的转换结果一般都是放入 FIFO 中,ADC 模块不提供转换完成中断,用户需要根据实际转换通道数,设定 FIFO 接收数据阈值中断,通过 FIFO 的阈值中断,作为 ADC 转换完成中断。

4.3.5 ADC 结果

gpadc_raw_data 寄存器存放了 ADC 的原始结果,在单端模式下,数据有效位是 12bits,无符号位,在差分模式下,最高位为符号位,剩下 11bits 代表转换的结果。

gpadc_dma_rdata 寄存器存放了 ADC 的结果,这个结果里包含了 ADC 结果,符号位和通道信息,数据格式如下:

19 18 17 bits 25 24 23 22 21 20 16 15 14 13 12 11 10 9 8 7 6 5 4 3 2 1 0 含 正极通道号 负极通道号 转换结果 义

表 4.3: ADC 转换结果含义

转换结果的 bit21-bit25 是正极通道号, bit16-bit20 是负极通道号, bit0-bit15 是转换的数值。



gpadc_res_sel 控制位可以设定转换结果的位数为 12 位,14 位,和 16 位,其中 14 位和 16 位是多次采样提高精度得到的结果,其可以设置的值如下:

- 3'b000 12bit 2MS/s, OSR=1
- 3'b001 14bit 125kS/s, OSR=16
- 3'b010 14bit 31.25kS/s, OSR=64
- 3'b011 16bit 15.625KS/s, OSR=128
- 3'b100 16bit 7.8125KS/s. OSR=256

ADC 转换结果为左对齐模式,当选择 12 位时,转换结果的 bit15-bit4 有效,当选择 14 位时,转换结果的 bit15-bit2 有效,当选择 16 位时,转换结果的 bit15-bit0 有效。同样,在差分模式下,最高为是符号为,也就是,当选择 14 位时,bit15 是符号位,bit14-bit2 是转换结果,bit14 是 MSB,在单端模式下,没有符号位,也就是,当选择 12 位时,bit15-bit4 是转换结果,bit15 是 MSB。

在实际使用中,ADC 的结果一般都是放入 FIFO,这在多通道扫描模式下尤为重要,所以用户一般都是从 ADC FIFO 获取转换结果,ADC FIFO 的数据格式 gpadc_dma_rdata 寄存器中数据格式相同。

4.3.6 ADC 异常中断

ADC 模块在正极采样饱和和负极采样饱和时可以产生中断,可以通过 gpadc_pos_satur_mask,gpadc_neg_satur_mask 屏蔽各自中断,当中断产生时,可以通过 gpadc_pos_satur,和 gpadc_neg_satur 寄存器查询中断状态,同时可以通过 gpadc_pos_satur_clr 和 gpadc_neg_satur_clr 清除中断。该功能可以用来判断输入电压是否异常。

4.3.7 ADC FIFO 与阈值中断

ADC 模块拥有深度为 32 的 FIFO,数据宽度为 26Bits,当 ADC 完成转换后,会自动将结果推入到 FIFO。ADC 的 FIFO 有如下状态和中断管理功能:

- FIFO Overrun 中断
- FIFO Underrun 中断
- FIFO 阈值中断

当 FIFO 已经填满,但是用户没有通过 DMA 或者直接访问寄存器的方式把读取取走,此时又有数据进入 FIFO,那么此时模块会产生一个 FIFO Overrun 中断。当 FIFO 为空,但是用户依旧向 FIFO 请求数据,那么此时模块会产生 FIFO Underrun 中断。

用户可以配置 FIFO 的阈值寄存器 gpadc_fifo_thl,选择 FIFO 产生中断的阈值,1、4、8、16 四种选择可选。如果 ADC 的 FIFO 数量达到设定的阈值数,那么会产生阈值中断。

当中断产生时,可以通过对应的 clear 位将中断标志清除掉。

利用 ADC 的 FIFO 用户可以实现三种模式获取数据:查询模式,中断模式,DMA 模式

查询模式



CPU 轮询 ADC FIFO 的长度,当 FIFO 的长度不为空的时候,说明 FIFO 中存在有效数据,CPU 可以从 FIFO 中读出这些数据。

中断模式

利用 FIFO 的阈值中断,当中断产生,ADC 的数据个数到达阈值,CPU 可以在中断服务函数中可以读取 ADC FIFO 的长度,将其全部读出。

DMA 模式

用户设定 dmaen 控制位,可以配合 DMA 完成转换数据到内存的搬运,在使用 DMA 模式时,通过 fifothl 设置 ADC FIFO 发送 DMA 请求的数据个数阈值,DMA 在收到请求时,会自动根据用户设定的参数,从 FIFO 搬运指定个数的结果到对应的内存。

4.3.8 ADC 设置流程

设置 ADC 时钟

根据 ADC 转换速度需求,确定 ADC 的工作时钟,设定 GLB 模块的 ADC 时钟源和分频,结合 clkdvrt,确定最终 ADC 模块的工作时钟频率。

根据使用的通道设置 GPIO

根据使用的模拟引脚,确定使用的通道号,初始化对应的 GPIO 为模拟功能,需要注意的是,在设定 GPIO 为模拟输入的时候,不要设置 GPIO 的上拉或者下拉,需要设置为浮空输入。

设定要转换的通道

根据使用的模拟通道和转换模式,设定对应的通道寄存器,对于单通道转换,在 possel 和 negsel 寄存器中设置转换的通道信息。对于多通道扫描模式,根据要扫描通道数目和扫描顺序,设定 sclen,scpX 和 scnX。

设定数据读取方式

根据 ADC FIFO 介绍的读取数据方式,选择使用的模式,设置对应的寄存器。如果使用 DMA,同样需要配置 DMA 的一个通道,配合 ADC FIFO 完成数据的搬运。

启动转换

最后设置 ressel 选择数据转换结果的精度,最后设置 gben=1, cvst=1 就可以启动 ADC 开始转换。当转换完成,需要再次转换时,需要将 cvst 设置为 0,再设置为 1,以便再次触发转换。

4.3.9 VBAT 测量

这里的 VBAT/2 测量的是芯片 VDD33 的电压,而不是外部的比如锂电池的电压,如果需要测量锂电池等供电源头的电压,可以将电压分压,然后输入 ADC 的 GPIO 模拟通道,测量 VDD33 的电压可以减少 GPIO 的使用。

ADC 模块测量的 VBAT/2 电压是经过分压的,实际输入到 ADC 模块的电压是 VDD33 的一半,即 VBAT/2=VDD33/2。由于电压经过分压,为了得到较高的精确度,建议 ADC 的参考电压选择 2V,采用单端模式,正极输入电压选择 VBAT/2,负极输入电压选择 GND,同时将 vbaten 设置为 1,启动转换后,将对应的转换结果乘以 2 就可以得到 VDD33 电压。



4.3.10 TSEN 测量

ADC 可以测量内部二极管或者外部二极管电压值,而二极管的压差和温度有关,所以通过测量二极管的电压,可以计算得到环境温度,我们称之为 Temperature Sensor,简称 TSEN。

TSEN 的测量原理是通过一个二极管上面测量两次不同大小的电流产生的电压差 ΔV 随着温度的变化拟合的曲线,无论外部或者内部二极管的测量,最终输出的值和温度有关,都可以表示成 $\Delta(ADC_out)=7.753T+X$,当我们知道了电压值,也就知道了温度 T。这里的 X 是一个偏移值,可以作为标准值,在实际使用前,我们需要确定 X。芯片厂商会在芯片出厂前,在标准温度下,例如室温 Z5 度,测量 Z6 度,测量 Z7 及 Z8 及 Z9 度,测量 Z9 度,则是 Z9 度,则是

在使用 TSEN 时,建议把 ADC 设置成 16bits 模式,通过多次采样以减少误差,参考电压选择 2V 以提高精度,设置 tsen 为 1 以便启动 TSEN 功能,如果选择内部二极管,tsxten=0,如果选择外部二极管,tsxten=1,根据实际情况选择正向输入通道,如果是内部二极管,选择 TSEN 通道,如果是外部,选择对应的模拟 GPIO 通道,负极输入端选择 GND。在上述设定完毕后,设置 tsdc=0,启动测量,得到测量结果 V0,再设置 tsdc=1,启动测量,得到测量结果 V1, Δ (ADC_out)=V1-V0,根据公式 T=[Δ (ADC_out)-X]/7.753,得到温度 T。

4.4 寄存器描述

名称	描述
gpadc_config	GPADC configuration
gpadc_dma_rdata	GPADC DMA read data
gpadc_reg_cmd	GPADC register configuration 0
gpadc_reg_config1	GPADC register configuration 1
gpadc_reg_config2	GPADC register configuration 2
gpadc_reg_scn_pos1	adc converation sequence 1
gpadc_reg_scn_pos2	adc converation sequence 2
gpadc_reg_scn_neg1	adc converation sequence 3
gpadc_reg_scn_neg2	adc converation sequence 4
gpadc_reg_status	GPADC register status
gpadc_reg_isr	GPADC register operation
gpadc_reg_raw_result	GPADC register raw result
gpadc_reg_define	GPADC register define



4.4.1 gpadc_config

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	RSVD							FIFOTHL FIFODACN							
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
FIFO	FURM	FORM	RDYM	RSVD	URCL	ORCL	RDY	FIFO	FIFO	FIFO	RDY	FIFO	FIFO	FIFO	DMA
RDYM							CLR	RDY	UR	OR		FULL	NE	CLR	EN

位	名称	权限	复位值	描述
31:24	RSVD			
23:22	FIFOTHL	R/W	2'd0	fifo threshold
				2'b00: 1 data
				2'b01: 4 data
				2'b10: 8 data
				2'b11: 16 data
21:16	FIFODACN	R	6'd0	fifo data number
15	FIFORDYM	R/W	1'b1	write 1 mask
14	FURM	R/W	1'b0	write 1 mask
13	FORM	R/W	1'b0	write 1 mask
12	RDYM	R/W	1'b0	write 1 mask
11	RSVD			
10	URCL	W1C	1'b0	Write 1 to clear flag
9	ORCL	W1C	1'b0	Write 1 to clear flag
8	RDYCLR	W1C	1'b0	Write 1 to clear flag
7	FIFORDY	R	1'b0	FIFO ready interrupt flag
6	FIFOUR	R	1'b0	FIFO underrun interrupt flag
5	FIFOOR	R	1'b0	FIFO overrun interrupt flag
4	RDY	R	1'b0	Conversion data ready interrupt flag
3	FIFOFULL	R	1'b0	FIFO full flag
2	FIFONE	R	1'b0	FIFO not empty flag
1	FIFOCLR	W1C	1'b0	FIFO clear signal
0	DMAEN	R/W	1'b0	GPADC DMA enbale



4.4.2 gpadc_dma_rdata

地址: 0x40002004

31	30	29	28	27	26	25	25 24 23 22 21 20 19 18 17 16							16	
	RSVD						DMARDA								
15	14	13	12	11	10	9 8 7 6 5 4 3 2						1	0		
							DMA	RDA							

位	名称	权限	复位值	描述
31:26	RSVD			
25:0	DMARDA	R	26'd0	GPADC finial conversion result stored in the FIFO

4.4.3 gpadc_reg_cmd

地址: 0x4000f90c

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
RSVD	SENT EN	SEN	SEL	CSEN PU		RSVD		MB32 EN	MF	2G	M1DF	M2DF	DWA EN	RSVD	МВВР
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
MPEN	MBEN	NGGR			POSSEL					NEGSEL			SFRS	CVST	GBEN

位	名称	权限	复位值	描述
31	RSVD			
30	SENTEN	R/W	1'b0	enable sensor dc test mux
29:28	SENSEL	R/W	2'h0	selected output current channel and measurement channel 2'h0: 1st channel 2'h1: 2nd channel 2'h2: 3rd channel 2'h3: 4th channel
27	CSENPU	R/W	1'b0	enable chip sensor test 1'b0: disable 1'b1: enable
26:24	RSVD MB32EN	R/W	1'b0	micboost 32db enable 1'b0: 16dB 1'b1: 32dB



位	名称	权限	复位值	描述
22:21	MP2G	R/W	2'h0	mic_pga2_gain 2'h0: 0dB 2'h1: 6dB 2'h2: -6dB 2'h3: 12dB
20	M1DF	R/W	1'b0	mic1 diff enable 1'b0: single 1'b1: diff
19	M2DF	R/W	1'b0	mic2 diff enable 1'b0: single 1'b1: diff
18	DWAEN	R/W	1'b0	dwa enable 1'b0: dwa disable 1'b1: dwa enable
17	RSVD			
16	МВВР	R/W	1'b0	micboost amp bypass 1'b0: not bypass 1'b1: bypass
15	MPEN	R/W	1'b0	micpga enable 1'b0: micpga disable 1'b1: miapga enable
14	MBEN	R/W	1'b0	enable micbias 1'b0: micbias power down 1'b1: miabias power on
13	NGGR	R/W	1'b0	set negative input of adc to ground 1'b0: disable 1'b1: enable



位	名称	权限	复位值	描述
12:8	POSSEL	R/W	5'hf	select adc positive input in none-scan mode 5'h0 gpip_ch[0] 5'h1 gpip_ch[1] 5'h2 gpip_ch[2] 5'h3 gpip_ch[3] 5'h4 gpip_ch[4] 5'h5 gpip_ch[5] 5'h6 gpip_ch[6] 5'h7 gpip_ch[6] 5'h7 gpip_ch[8] 5'h9 gpip_ch[9] 5'h10 gpip_ch[10] 5'h11 gpip_ch[11] 5'h12 daca 5'h13 dacb 5'h14 temp_p 5'h16 vref 5'h18 vbat/2 5'h23 31 avss
7:3	NEGSEL	R/W	5'hf	select adc negative input in none-scan mode 5'h0 gpip_ch[0] 5'h1 gpip_ch[1] 5'h2 gpip_ch[2] 5'h3 gpip_ch[3] 5'h4 gpip_ch[4] 5'h5 gpip_ch[5] 5'h6 gpip_ch[6] 5'h7 gpip_ch[7] 5'h8 gpip_ch[8] 5'h9 gpip_ch[9] 5'h10 gpip_ch[10] 5'h11 gpip_ch[11] 5'h12 daca 5'h13 dacb 5'h14 temp_p 5'h16 vref 5'h18 vbat/2 5'h23 31 avss
2	SFRS	R/W	1'b0	user reset the whole block 1'h0: not reset 1'h1: reset
1	CVST	R/W	1'b0	1'h0: stop converation 1'h1: start converation
0	GBEN	R/W	1'b0	1'h0: disable ADC 1'h1: enable ADC



4.4.4 gpadc_reg_config1

地址: 0x4000f910

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
RSVD	V18	SEL	V11	SEL	DTEN	SCEN	SCLEN			CLKDVRT			ALCLK INV	RSVD	
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
		RSVD			LDEN	HYST	SEL		RSVD			RESSEL		CTCV	CAL
						SEL	EN							EN	OSEN

位	名称	权限	复位值	描述
31	RSVD			
30:29	V18SEL	R/W	2'h0	internal vdd18 select
28:27	V11SEL	R/W	2'h0	internal vdd11 select
26	DTEN	R/W	1'h0	Dither compensation enable
25	SCEN	R/W	1'h0	select scan mode enable: 0: select gpadc_pos/neg_sel;1: select : select gpadc_scan_pos_x and gpadc_scan_neg_x

BL702/704/706 参考手册 104/ 370 @2021 Bouffalo Lab



位	名称	权限	复位值	描述
24:21	SCLEN	R/W	4'h0	select scan mode length 4'b0000: select gpadc_scan_pos_0 and gpadc_scan neg_0 4'b0001: select gpadc_scan_pos_1 and gpadc_scan neg_1 4'b0010: select gpadc_scan_pos_2 and gpadc_scan neg_2 4'b0011: select gpadc_scan_pos_3 and gpadc_scan neg_3 4'b0100: select gpadc_scan_pos_4 and gpadc_scan neg_4 4'b0101: select gpadc_scan_pos_5 and gpadc_scan neg_5 4'b0110: select gpadc_scan_pos_6 and gpadc_scan neg_6 4'b0111: select gpadc_scan_pos_7 and gpadc_scan neg_7 4'b1000: select gpadc_scan_pos_8 and gpadc_scan neg_8 4'b1001: select gpadc_scan_pos_9 and gpadc_scan neg_9 4'b1010: select gpadc_scan_pos_10 and gpadc_scan neg_9 4'b1011: select gpadc_scan_pos_11 and gpadc_scan neg_10 4'b1011: select gpadc_scan_pos_11 and gpadc_scan neg_10
20:18	CLKDVRT	R/W	3'h3	analog 32M clock division ratio 3'b000: div=1 3'b001: div=4 3'b010: div=8 3'b011: div=12 3'b100: div=16 3'b101: div=20 3'b111: div=24 3'b111: div=32
17	ALCLKINV	R/W	1'b0	analog clock 2M inverted
16:11	RSVD			
10	LDEN	R/W	1'b0	Low power supply detected enable
9	HYSTSEL	R/W	1'b0	pga vcm hystersis select when vcm_sel_en is enabled
8	SELEN	R/W	1'b0	pga vcm selected when lowv_det_en is enable
7:5	RSVD			



位	名称	权限	复位值	描述
4:2	RESSEL	R/W	3'h0	adc resolution/over-sample rate select 3'b000 12bit 2MS/s, OSR=1 3'b001 14bit 125kS/s, OSR=16 3'b010 14bit 31.25kS/s, OSR=64 3'b011 16bit 15.625KS/s, OSR=128 (voice mode16KS/s) 3'b100 16bit 7.8125KS/s, OSR=256 (voice mode 8KS/s)
1	CTCVEN	R/W	1'b1	To enable continuous conversion 1'h0: one shot conversion 1'h1: continuous conversion
0	CALOSEN	R/W	1'b0	offset calibration enable

4.4.5 gpadc_reg_config2

地址: 0x4000f914

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
TSDC	C CVSP PGA1GAIN				PGA2GAIN			-	TESTSEL	_	TEST	BSEL	СНОМ		
													EN		
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
СНОМ	PVB	PGA		POSCAL			PGA'	VCM	TSEN	TSXT	VBAT	VREF	DFMD	RS	VD
	EN	EN								EN	EN	SEL			

位	名称	权限	复位值	描述
31	TSDC	R/W	1'b0	tsen diode current
30:28	CVSP	R/W	3'h0	adc conversion speed
27:25	PGA1GAIN	R/W	3'h0	3'h0: disable
				3'h1: gain=1
				3'h2: gain=2
				3'h3: gain=4
				3'h4: gain=8
				3'h5: gain=16
				3'h6: gain=32
				3'h7: gain=32



位	名称	权限	复位值	描述
24:22	PGA2GAIN	R/W	3'h0	3'h0: disable 3'h1: gain=1 3'h2: gain=2 3'h3: gain=4 3'h4: gain=8 3'h5: gain=16 3'h6: gain=32 3'h7: gain=32
21:19	TESTSEL	R/W	3'h0	select test point 0 7
18	TESTEN	R/W	1'b0	Analog test enable.
17	BSEL	R/W	1'b0	adc analog portion low power mode select 1'h0: bandgap system 1'h1:aon bandgap
16:15	CHOM	R/W	2'h3	2'b11 all off 2'b11 Vref AZ on 2'b11 Vref AZ and PGA chop on 2'b11 Vref AZ and PGA chop+RPC on
14	PVBEN	R/W	1'b0	enable pga input vcm bias
13	PGAEN	R/W	1'b0	1'h0: disable PGA 1'h1 enable PGA
12:9	POSCAL	R/W	4'h8	pga offset calibration
8:7	PGAVCM	R/W	2'h2	Audio PGA output common mode control 2'b00: cm=1.3V 2'b11: cm=1.4V 2'b11: cm=1.5V 2'b11: cm=1.6V
6	TSEN	R/W	1'b0	1'h0: disable temperature sensor 1'h1: enable temperature sensor
5	TSXTEN	R/W	1'b0	1'h0: internal diode mode 1'h1: external diode mode
4	VBATEN	R/W	1'b0	1'h0: disable VBAT sensor 1'h1 enable VBAT sensor
3	VREFSEL	R/W	1'b0	ADC reference select 1'h0 3.2V 1'h1 2.0V
2	DFMD	R/W	1'b0	1'h0 single-ended 1'h1 differential
1:0	RSVD			



4.4.6 gpadc_reg_scn_pos1

地址: 0x4000f918

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
RS	RSVD SCP5					SCP4					SCP3				
15	14	13 12 11 10 9				9	8 7 6 5 4					3	2	1	0
SCP3		SCP2						SCP1					SCP0		

位	名称	权限	复位值	描述			
31:30	RSVD						
29:25	SCP5	R/W	5'hf	definition is the same as adc_reg_cmd.adc_pos_sel			
24:20	SCP4	R/W	5'hf	definition is the same as adc_reg_cmd.adc_pos_sel			
19:15	SCP3	R/W	5'hf	definition is the same as adc_reg_cmd.adc_pos_sel			
14:10	SCP2	R/W	5'hf	definition is the same as adc_reg_cmd.adc_pos_sel			
9:5	SCP1	R/W	5'hf	definition is the same as adc_reg_cmd.adc_pos_sel			
4:0	SCP0	R/W	5'hf	definition is the same as adc_reg_cmd.adc_pos_sel			

4.4.7 gpadc_reg_scn_pos2

地址: 0x4000f91c

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
RS	RSVD SCP11					SCP10						SCP9			
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
SCP9	SCP8							SCP7					SCP6		

位	名称	权限	复位值	描述
31:30	RSVD			
29:25	SCP11	R/W	5'hf	definition is the same as adc_reg_cmd.adc_pos_sel
24:20	SCP10	R/W	5'hf	definition is the same as adc_reg_cmd.adc_pos_sel
19:15	SCP9	R/W	5'hf	definition is the same as adc_reg_cmd.adc_pos_sel
14:10	SCP8	R/W	5'hf	definition is the same as adc_reg_cmd.adc_pos_sel
9:5	SCP7	R/W	5'hf	definition is the same as adc_reg_cmd.adc_pos_sel
4:0	SCP6	R/W	5'hf	definition is the same as adc_reg_cmd.adc_pos_sel



4.4.8 gpadc_reg_scn_neg1

地址: 0x4000f920

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	
RS	SVD	SCN5							SCN4			SCN3				
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	
SCN3		SCN2					SCN1						SCN0			

位	名称	权限	复位值	描述
31:30	RSVD			
29:25	SCN5	R/W	5'hf	definition is the same as adc_reg_cmd.adc_neg_sel
24:20	SCN4	R/W	5'hf	definition is the same as adc_reg_cmd.adc_neg_sel
19:15	SCN3	R/W	5'hf	definition is the same as adc_reg_cmd.adc_neg_sel
14:10	SCN2	R/W	5'hf	definition is the same as adc_reg_cmd.adc_neg_sel
9:5	SCN1	R/W	5'hf	definition is the same as adc_reg_cmd.adc_neg_sel
4:0	SCN0	R/W	5'hf	definition is the same as adc_reg_cmd.adc_neg_sel

4.4.9 gpadc_reg_scn_neg2

地址: 0x4000f924

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	
RS	SVD	SCN11							SCN10			SCN9				
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	
SCN9		SCN8					SCN7					SCN6				

位	名称	权限	复位值	描述
31:30	RSVD			
29:25	SCN11	R/W	5'hf	definition is the same as adc_reg_cmd.adc_neg_sel
24:20	SCN10	R/W	5'hf	definition is the same as adc_reg_cmd.adc_neg_sel
19:15	SCN9	R/W	5'hf	definition is the same as adc_reg_cmd.adc_neg_sel
14:10	SCN8	R/W	5'hf	definition is the same as adc_reg_cmd.adc_neg_sel
9:5	SCN7	R/W	5'hf	definition is the same as adc_reg_cmd.adc_neg_sel
4:0	SCN6	R/W	5'hf	definition is the same as adc_reg_cmd.adc_neg_sel



4.4.10 gpadc_reg_status

地址: 0x4000f928

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	RSVD														
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	RSVD										DARD				

位	名称	权限	复位值	描述
31:1	RSVD			
0	DARD	R	1'b0	ADC final conversion data ready

4.4.11 gpadc_reg_isr

地址: 0x4000f92c

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	RSVD														
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	RSVD						NSM	RS	VD	PSC	NSC	RS	VD	PS	NS

位	名称	权限	复位值	描述
31:10	RSVD			
9	PSM	R/W	1'h0	write 1 mask
8	NSM	R/W	1'h0	write 1 mask
7:6	RSVD			
5	PSC	R/W	1'b0	Write 1 to clear flag
4	NSC	R/W	1'b0	Write 1 to clear flag
3:2	RSVD			
1	PS	R	1'b0	ADC data positive side saturation interrupt flag
0	NS	R	1'b0	ADC data negative side saturation interrupt flag

BL702/704/706 参考手册 110/ 370 @2021 Bouffalo Lab



4.4.12 gpadc_reg_raw_result

地址: 0x4000f934

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	RSVD														
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	RS	VD							RAV	VDA					

位	名称	权限	复位值	描述
31:12	RSVD			
11:0	RAWDA	R	12'h0	ADC Raw data

4.4.13 gpadc_reg_define

地址: 0x4000f938

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	RSVD														
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	OSCALDA														

位	名称	权限	复位值	描述
31:16	RSVD			
15:0	OSCALDA	R/W	16'h0	User defined or self calculated offset data 16-bit signed

BL702/704/706 参考手册 111/ 370 @2021 Bouffalo Lab

DAC

5.1 简介

芯片内置一个 10bits 的数字模拟转换器 (DAC),FIFO 深度为 1,支持 2 路 DAC 调制输出。可用于音频播放,常规的模拟信号调制。

5.2 主要特点

- DAC 调制精度为 10bits
- DAC 的输入时钟可选为 32M 或者 Audio PLL
- 支持 DMA 从内存将数据搬运至 DAC 调制寄存器
- 支持双声道播放模式
- DAC 的输出引脚固定,ChannelA 固定为 GPIO11,ChannelB 固定为 GPIO17
- DAC 的参考电压可选择内部或者外部

5.3 功能描述

DAC 模块基本框图如图所示。






图 5.1: DAC 基本框图

DAC 模块包含两路 DAC 调制电路,以及调制模拟信号相关的电源电路,用户可以通过 Ref_Sel 来选择 DAC 的参考电压 是外部/内部,Ref_Rng 来选择内部参考电压源。DAC 的调制数据可以由 CPU 直接写入 DAC 调制寄存器(0x40000314中的 GLB_GPDAC_A_DATA、GLB_GPDAC_B_DATA),也可以由 DMA 搬运至 gpdac_dma_wdata(0x40002048)寄存器。

DAC 的数据写入方式

CPU 直接写入 GLB_GPDAC_A_DATA、GLB_GPDAC_B_DATA 寄存器完成调制,或者使用 DMA,将需要调制的数据搬运到 gpdac_dma_wdata 中。

DMA 的搬运模式

gpdac_dma_wdata(0x40002048)是一个 32BITS 的寄存器,默认含义为,32BITS 值按顺序全部调制在 ChannelA 引脚上,也可配置为高 16 位默认是对应 Channel B 的模拟电压输出,低 16 位对应 Channel A 的模拟电压输出。注意无论是 32/16 位调制,都只有低 10 位有效,因为 DAC 的最大调制精度为 10BITS。用户可以通过配置 gpdac_dma_format 寄存器来修改 DMA 搬运的高低字节含义。

gpdac_dma_format 为 0,则 DMA 搬运进 gpdac_dma_wdata 的数据全部依次调制在 Channel A,调制顺序为 {A0},{A1},{A2},...。gpdac_dma_format 为 1,则 DMA 搬运进 gpdac_dma_wdata 的数据高 16 位调制在 Channel B,低 16 位调制在 Channel B,低 16 位调制在 Channel A。调制顺序为 {B0,A0},{B1,A1},{B2,A2},...。这样的特性在立体声播放中非常有作用。gpdac_dma_format 为 2,则 DMA 搬运进 gpdac_dma_wdata 的数据全部调制在 Channel A,但调制的顺序为 {A1,A0},{A3,A2},{A5,A4},...。

DAC 外部参考电压选择



用户可以通过配置 gpdac_ref_sel(0x40000308[8])来配置选择外部参考电压还是内部参考电压。

如果选择内部参考电压, 配置如下表所示。

表 5.1: DAC 外部引脚

gpdac_a_rng	gpdac_ref_sel	输出范围
00	0	0.2-1
01/10	0	0.225-1.425
11	0	0.2-1.8

如果选择外部参考电压,请将外部电压连入固定的 GPIO7。

5.4 寄存器描述

名称	描述
gpdac_config	GPDAC configuration
gpdac_dma_config	GPDAC dma configuration
gpdac_dma_wdata	GPDAC dma write data
gpdac_ctrl	GPDAC control
gpdac_actrl	GPDAC channelA control
gpdac_bctrl	GPDAC channelB control
gpdac_data	GPDAC data

5.4.1 gpdac_config

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	RSVD							CHBSEL CHASEL					SEL		
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	RSVD MODE							RS	VD	DSMN	/ODE	RS	VD	EN2	EN

位	名称	权限	复位值	描述
31:24	RSVD			



位	名称	权限	复位值	描述
23:20	CHBSEL	R/W	0	Channel B Source Select 0: Reg 1: DMA 2: DMA + Filter 3: Sin Gen 4: A (The same as channel A) 5: A (Inverse of channel A)
19:16	CHASEL	R/W	0	Channel A Source Select 0: Reg 1: DMA 2: DMA + Filter 3: Sin Gen
15:11	RSVD			
10:8	MODE	R/W	0	0:32k, 1:16k, 3:8k, 4:512k(for DMA only)
7:6	RSVD			
5:4	DSMMODE	R/W	0	0:bypass, 1:dsm order=1, 2: dsm order=2
3:2	RSVD			
1	EN2	R/W	0	GPDAC enable 2 (for B channel)
0	EN	R/W	0	GPDAC enable

5.4.2 gpdac_dma_config

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
							RS	VD							
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
				RS	VD					DM/	AFM		RSVD		DMA TXEN

位	名称	权限	复位值	描述
31:6	RSVD			
5:4	DMAFM	R/W	0	DMA TX format (Data 12-bit) 0: A0, A1, A2··· 1: B0,A0, B1,A1, B2,A2··· 2: A1,A0, A3,A2, A5,A4··· (Note: 20'h0,[11:0] or 4'h0,[27:16],4'h0,[11:0])



位	名称	权限	复位值	描述
3:1	RSVD			
0	DMATXEN	R/W	0	GPDAC DMA TX enable

5.4.3 gpdac_dma_wdata

地址: 0x40002048

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
							DMA	WDA							
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
							DMA	WDA							

位	名称	权限	复位值	描述
31:0	DMAWDA	W	х	GPDAC DMA TX data

5.4.4 gpdac_ctrl

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
							RS	VD							
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
			RSVD	,			REF	TSEN			RSVD		,	BRS	ARS
							SEL							ANA	ANA

位	名称	权限	复位值	描述
31:9	RSVD			
8	REFSEL	R/W	1'h0	Reference select 1'h0 Internal reference 1'h1 External reference
7	TSEN	R/W	1'h0	Test enable 1'h0 analog test disabled (ATEST is set in Hi-Z state) 1'h1 analog test point enabled to ATEST
6:2	RSVD			
1	BRSANA	R/W	1'h1	Soft reset for DAC channel B, active low
0	ARSANA	R/W	1'h1	Soft reset for DAC channel A, active low



5.4.5 gpdac_actrl

地址: 0x4000030c

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
				RSVD						AOMUX		AR	NG	RS	VD
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
						RS	VD							IOA	AEN
														EN	

位	名称	权限	复位值	描述
31:23	RSVD			
22:20	AOMUX	R/W	3'h0	
19:18	ARNG	R/W	2'h3	Output voltage range control with internal/external reference
17:2	RSVD			
1	IOAEN	R/W	1'h0	Channel A conversion output to pad enable 1'h0 Disable channel A conversion result to GPIO 1'h1 Enable channel A conversion result to GPIO
0	AEN	R/W	1'h0	Channel A enable/disable signal 1'h0 Disable channel A conversion. 1'h1 Enable channel A conversion

5.4.6 gpdac_bctrl

地址: 0x40000310

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
RSVD								BOM BRNG			RSVD				
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
						RS	VD				•			IOB	BEN
														EN	

位	名称	权限	复位值	描述
31:23	RSVD			
22:20	ВОМ	R/W	3'h0	
19:18	BRNG	R/W	2'h3	Output voltage range control with internal/external reference

BL702/704/706 参考手册 117/ 370 @2021 Bouffalo Lab



位	名称	权限	复位值	描述
17:2	RSVD			
1	IOBEN	R/W	1'h0	channel B conversion output to pad enable 1'h0 Disable channel B conversion result to GPIO 1'h1 Enable channel B conversion result to GPIO
0	BEN	R/W	1'h0	channel B enable/disable signal 1'h0 Disable channel B conversion. 1'h1 Enable channel B conversion

5.4.7 gpdac_data

地址: 0x40000314

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	RSVD					ADATA									
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	RSVD						BDATA								

位	名称	权限	复位值	描述
31:26	RSVD			
25:16	ADATA	R/W	10'h0	Channel A Data input
15:10	RSVD			
9:0	BDATA	R/W	10'h0	Channel B Data input

BL702/704/706 参考手册 118/ 370 @2021 Bouffalo Lab

6.1 简介

DMA(Direct Memory Access) 是一种内存存取技术,可以独立地直接读写系统内存,而不需处理器介入处理。在同等程度的处理器负担下,DMA 是一种快速的数据传送方式。DMA 控制器有 8 组独立专用通道,管理外围设备和内存之间的数据传输以提高总线效率。主要有四种类型传输包括内存至内存、内存至外设、外设至内存和外设至外设。并支持 LLI 链接列表功能。使用上由软件配置传输数据大小、数据源地址和目标地址。

6.2 主要特征

- 8 组独立专用通道
- 独立控制来源与目标存取宽度 (单字节、双字节、四字节)
- 每个通道独立作为读写缓存
- 每个通道可被独立的外设硬件触发或是软件触发
- 支持外设包括 UART、I2C、SPI、ADC、I2S、DAC
- 四种流程控制
 - DMA 流程控制,来源内存、目标内存
 - DMA 流程控制,来源内存、目标外设
 - DMA 流程控制,来源外设、目标内存
 - DMA 流程控制,来源外设、目标外设
- 支持 LLI 链表功能,提高 DMA 效率



6.3 功能描述

6.3.1 工作原理

当一个设备试图通过总线直接向另一个设备传输数据 (一般是大批量的数据) 时,它会先向 CPU 发送 DMA 请求信号。外设通过 DMA 向 CPU 提出接管总线控制权的总线请求,CPU 收到该信号后,在当前的总线周期结束后,会按 DMA 信号的优先级和提出 DMA 请求的先后顺序响应 DMA 信号。CPU 对某个设备接口响应 DMA 请求时,会让出总线控制权。于是在 DMA 控制器的管理下,外设和存储器直接进行数据交换,而不需 CPU 干预。数据传送完毕后,设备会向 CPU 发送 DMA 结束信号,交还总线控制权。




图 6.1: DMA 框图

DMA 包含一组 AHB Master 接口和一组 AHB Slave 接口。AHB Master 接口根据当前配置需求通过系统总线主动存取内存或是外设,做为数据搬移的端口。AHB Slave 接口作为配置 DMA 的接口,只支持 32-bit 存取。



6.3.2 DMA 通道配置

DMA 共支持 8 路通道,各通道之间互不干涉,可以同时运行,下面是 DMA 通道 x 的配置过程:

- 1. 在 DMA COSrcAddr 寄存器中设置 32-bit 来源地址
- 2. 在 DMA_C0DstAddr 寄存器中设置 32-bit 目标地址
- 3. 地址自动累加,可通过配置 DMA_C0Control 寄存器中 SI(来源)、DI(目标) 设定是否开启地址自动累加模式,设置为 1 时,开启地址自动累加模式
- 4. 设置传输数据宽度,可通过配置 DMA_C0Control 寄存器中 STW(来源)、DTW(目标) 位,宽度选项有单字节、双字节、四字节
- 5. Burst 型态,可通过配置 DMA_C0Control 寄存器中 SBS(来源)、DBS(目标) 位来设置,配置选项有 Single、INCR4、INCR8、INCR16
- 6. 需要特别注意的是所配置的组合,单笔 burst 不能超过 16 字节
- 7. 设置数据传输长度的范围为: 0-4095

6.3.3 外设支持

可通过配置 SrcPeripheral(来源) 和 DstPeripheral(目标) 来决定当前 DMA 配合的外设,关系为 0-5: UART / 6-9: I2C / 10-13: SPI / 18-21: I2S / 22: ADC / 23: DAC

UART 使用 DMA 传输数据

UART 发送数据包,使用 DMA 方式能大量减轻 CPU 处理的时间,使其 CPU 资源不被大量浪费,尤其在 UART 收发 大量数据包(如高频率收发指令)时具有明显优势。

- 以 UARTO 传输为例,配置过程如下:
- 1. 将寄存器 DMA_C0Config[SRCPH] 位的值设置为 1, 即将 Source peripheral 设置为 UART_TX
- 2. 将寄存器 DMA C0Config[DSTPH] 位的值设置为 0, 即将 Destination peripheral 设置为 UART RX

I2C 使用 DMA 传输数据

配置如下:

- 1. 将寄存器 DMA_C0Config[SRCPH] 位的值设置为 7, 即将 Source peripheral 设置为 I2C_TX
- 2. 将寄存器 DMA_C0Config[DSTPH] 位的值设置为 6, 即将 Destination peripheral 设置为 I2C_RX

SPI 使用 DMA 传输数据

配置如下:

- 1. 将寄存器 DMA C0Config[SRCPH] 位的值设置为 11,即将 Source peripheral 设置为 SPI TX
- 2. 将寄存器 DMA C0Config[DSTPH] 位的值设置为 10, 即将 Destination peripheral 设置为 SPI RX



ADC0/1 使用 DMA 传输数据

配置如下:

1. 将寄存器 DMA_C0Config[SRCPH] 位的值设置为 22, 即将 Source peripheral 设置为 GPADC

DAC 使用 DMA 传输数据

配置如下:

1. 将寄存器 DMA_C0Config[SRCPH] 位的值设置为 23, 即将 Source peripheral 设置为 GPDAC

6.3.4 链表模式

DMA 支持链表工作模式。在进行一次 DMA 读或写操作时,可以向下一条链表中填写数据,当完成当前链表的数据传输后,通过读取 DMA_COLLI 寄存器的数值获取下一条链表的起始地址,直接传输下一条链表中的数据。保证 DMA 传输过程中连续不间断的工作,提高 CPU 和 DMA 的效率。




图 6.2: LLI 框架

BL702/704/706 参考手册 122/ 370 @2021 Bouffalo Lab



6.3.5 DMA 中断

- DMA INT TCOMPLETED
 - 数据传输完成中断, 当一次数据传输完毕后, 会进入此中断
- DMA INT ERR
 - 数据传输出错中断, 当数据传输过程中出现错误时, 会进入此中断

6.4 传输模式

6.4.1 内存到内存

这个模式启动后,DMA 会根据设定好的搬移数量 (TransferSize),将数据从来源地址搬到目标地址,传输完毕后 DMA 控制器会自动回到空闲状态,等待下一次的搬运。

具体配置流程如下:

- 1. 将寄存器 DMA COSrcAddr 的值设置为来源的内存地址
- 2. 将寄存器 DMA C0DstAddr 的值设置为目标的内存地址
- 3. 选择传输模式,将寄存器 DMA_C0Config[FLOWCTRL] 位的值设置为 0,即选择 memory-to-memory 模式
- 4. 设置 DMA_C0Control 寄存器中对应的位的数值: DI、SI 位设置为 1,开启地址自动累加模式,DTW、STW 位分别设置目标和来源的传输宽度,DBS、SBS 位分别设置目标和来源的 burst 型态,
- 5. 选择合适的通道, 使能 DMA, 完成数据传输

6.4.2 内存到外设

在这种工作模式下,DMA 会根据设定好的搬移数量 (TransferSize),把数据从来源端搬至内部缓存,当缓存空间不够时自动暂停,待有足够的缓存空间时继续,直到设定的搬移数量达到。另外一方面当目标外设请求触发会将目标配置burst 到目标地址,直到达到设定搬移数量完成自动回到空闲状态,等待下一次启动。

具体配置流程如下:

- 1. 将寄存器 DMA_C0SrcAddr 的值设置为来源的内存地址
- 2. 将寄存器 DMA C0DstAddr 的值设置为目标的外设地址
- 3. 选择传输模式,将寄存器 DMA_COConfig[FLOWCTRL] 位的值设置为 1,即选择 Memory-to-peripheral 模式
- 4. 设置 DMA_C0Control 寄存器中对应的位的数值: SI 位设置为 1, 开启地址自动累加模式, DI 位设置为 0, 禁用地址自动累加模式, DTW、STW 位分别设置来源和目标的传输宽度, DBS、SBS 位分别设置来源和目标的 burst 型态,
- 5. 选择合适的通道, 使能 DMA, 完成数据传输



6.4.3 外设到内存

在这种工作模式下,当来源外设请求触发时将来源配置 burst 到缓存,直到设定的搬移数量达到停止。另外一方面,当内部缓存足够一次目标 burst 数量时,DMA 会自动将缓存的内容搬到目标地址直到达到设定搬移数量完成自动回到空闲状态,等待下一次启动。

具体配置流程如下:

- 1. 将寄存器 DMA_COSrcAddr 的值设置为来源的外设地址
- 2. 将寄存器 DMA_C0DstAddr 的值设置为目标的内存地址
- 3. 选择传输模式,将寄存器 DMA_C0Config[FLOWCTRL] 位的值设置为 2,即选择 Peripheral-to-memory 模式
- 4. 设置 DMA_C0Control 寄存器中对应的位的数值: DI、SI 位设置为 1,开启地址自动累加模式,DTW、STW 位分别设置来源和目标的传输宽度,DBS、SBS 位分别设置来源和目标的 burst 型态,
- 5. 选择合适的通道, 使能 DMA, 完成数据传输

6.4.4 外设到外设

在这种工作模式下,当来源外设请求触发时将来源配置 burst 到缓存,直到设定的搬移数量达到停止。另外一方面,当内部缓存足够一次目标 burst 数量时,DMA 会自动将缓存的内容搬到目标地址直到达到设定搬移数量完成自动回到空闲状态,等待下一次启动。

具体配置流程如下:

- 1. 将寄存器 DMA_COSrcAddr 的值设置为来源的外设地址
- 2. 将寄存器 DMA_C0DstAddr 的值设置为目标的外设地址
- 3. 选择传输模式,将寄存器 DMA_C0Config[FLOWCTRL] 位的值设置为 3, 即选择 Peripheral-to-Peripheral 模式
- 4. 设置 DMA_C0Control 寄存器中对应的位的数值: DI、SI 位设置为 0,禁用地址自动累加模式,STW、DTW 位分别设置来源和目标的传输宽度,SBS、DBS 位分别设置来源和目标的 burst 型态
- 5. 选择合适的通道, 使能 DMA, 完成数据传输

6.5 寄存器描述

名称	描述
DMA_IntStatus	Interrupt status
DMA_IntTCStatus	Interrupt terminal count request status
DMA_IntTCClear	Terminal count request clear
DMA_IntErrorStatus	Interrupt error status
DMA_IntErrClr	Interrupt error clear

BL702/704/706 参考手册 124/ 370 @2021 Bouffalo Lab



名称	描述
DMA_RawIntTCStatus	Status of the terminal count interrupt prior to masking
DMA_RawIntErrorStatus	Status of the error interrupt prior to masking
DMA_EnbldChns	Channel enable status
DMA_SoftBReq	Software burst request
DMA_SoftSReq	Software single request
DMA_SoftLBReq	Software last burst request
DMA_SoftLSReq	Software last single request
DMA_Config	DMA general configuration
DMA_Sync	DMA request asynchronous setting
DMA_C0SrcAddr	Channel DMA source address
DMA_C0DstAddr	Channel DMA Destination address
DMA_C0LLI	Channel DMA link list
DMA_C0Control	Channel DMA bus control
DMA_C0Config	Channel DMA configuration
DMA_C1SrcAddr	Channel DMA source address
DMA_C1DstAddr	Channel DMA Destination address
DMA_C1LLI	Channel DMA link list
DMA_C1Control	Channel DMA bus control
DMA_C1Config	Channel DMA configuration
DMA_C2SrcAddr	Channel DMA source address
DMA_C2DstAddr	Channel DMA Destination address
DMA_C2LLI	Channel DMA link list
DMA_C2Control	Channel DMA bus control
DMA_C2Config	Channel DMA configuration
DMA_C3SrcAddr	Channel DMA source address
DMA_C3DstAddr	Channel DMA Destination address
DMA_C3LLI	Channel DMA link list
DMA_C3Control	Channel DMA bus control
DMA_C3Config	Channel DMA configuration



名称	描述
DMA_C4SrcAddr	Channel DMA source address
DMA_C4DstAddr	Channel DMA Destination address
DMA_C4LLI	Channel DMA link list
DMA_C4Control	Channel DMA bus control
DMA_C4Config	Channel DMA configuration
DMA_C5SrcAddr	Channel DMA source address
DMA_C5DstAddr	Channel DMA Destination address
DMA_C5LLI	Channel DMA link list
DMA_C5Control	Channel DMA bus control
DMA_C5Config	Channel DMA configuration
DMA_C6SrcAddr	Channel DMA source address
DMA_C6DstAddr	Channel DMA Destination address
DMA_C6LLI	Channel DMA link list
DMA_C6Control	Channel DMA bus control
DMA_C6Config	Channel DMA configuration
DMA_C7SrcAddr	Channel DMA source address
DMA_C7DstAddr	Channel DMA Destination address
DMA_C7LLI	Channel DMA link list
DMA_C7Control	Channel DMA bus control
DMA_C7Config	Channel DMA configuration

6.5.1 DMA_IntStatus

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
							RS	VD							
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
			RS	SVD							INT	STA			



位	名称	权限	复位值	描述
31:8	RSVD			
7:0	INTSTA	R	0	Status of the DMA interrupts after masking

6.5.2 DMA_IntTCStatus

地址: 0x40007004

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
RSVD															
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	15 14 13 12 11 10 9 8 RSVD										INTT	CSTA			

位	名称	权限	复位值	描述
31:8	RSVD			
7:0	INTTCSTA	R	0	Interrupt terminal count request status

6.5.3 DMA_IntTCClear

地址: 0x40007008

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	
RSVD																
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	
	RSVD								TCRC							

位	名称	权限	复位值	描述
31:8	RSVD			
7:0	TCRC	W	0	Terminal count request clear



6.5.4 DMA_IntErrorStatus

地址: 0x4000700c

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
RSVD															
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	RSVD										IE	S			

位	名称	权限	复位值	描述
31:8	RSVD			
7:0	IES	R	0	Interrupt error status

6.5.5 DMA_IntErrCIr

地址: 0x40007010

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
RSVD															
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	RSVD										IE	:C			

位	名称	权限	复位值	描述
31:8	RSVD			
7:0	IEC	W	0	Interrupt error clear

6.5.6 DMA_RawIntTCStatus

地址: 0x40007014

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
RSVD															
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	RSVD										SOTO	CIPTM			

位	名称	权限	复位值	描述
31:8	RSVD			
7:0	SOTCIPTM	R	0	Status of the terminal count interrupt prior to masking



位	名称	权限	复位值	描述
---	----	----	-----	----

6.5.7 DMA_RawIntErrorStatus

地址: 0x40007018

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
RSVD															
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	15 14 13 12 11 10 9 8 RSVD										SOTE	IPTM			

位	名称	权限	复位值	描述
31:8	RSVD			
7:0	SOTEIPTM	R	0	Status of the error interrupt prior to masking

6.5.8 DMA_EnbldChns

地址: 0x4000701c

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
							RS	VD							
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	RSVD CES														

位	名称	权限	复位值	描述
31:8	RSVD			
7:0	CES	R	0	Channel enable status

6.5.9 DMA_SoftBReq

地址: 0x40007020

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	SBR														
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	SBR														

BL702/704/706 参考手册 129/ 370 @2021 Bouffalo Lab



位	名称	权限	复位值	描述
31:0	SBR	R/W	0	Software burst request

6.5.10 DMA_SoftSReq

地址: 0x40007024

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
							SS	SR							
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	SSR														

位	名称	权限	复位值	描述
31:0	SSR	R/W	0	Software single request

6.5.11 DMA_SoftLBReq

地址: 0x40007028

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
							SL	BR							
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	SLBR														

位	名称	权限	复位值	描述
31:0	SLBR	R/W	0	Software last burst request

6.5.12 DMA_SoftLSReq

地址: 0x4000702c

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
							SL	SR							
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	SLSR														

BL702/704/706 参考手册 130/ 370 @2021 Bouffalo Lab



位	名称	权限	复位值	描述
31:0	SLSR	R/W	0	Software last single request

6.5.13 DMA_Config

地址: 0x40007030

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
							RS	VD							
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
				,		RS	VD			,				AHB	SDMA
														MEC	EN

位	名称	权限	复位值	描述
31:2	RSVD			
1	AHBMEC	R/W	0	AHB Master endianness configuration: 0 = little-endian, 1 = big-endian
0	SDMAEN	R/W	0	SMDMA Enable.

6.5.14 DMA_Sync

地址: 0x40007034

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	DSLFDRS														
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	DSLFDRS														

位	名称	权限	复位值	描述
31:0	DSLFDRS	R/W	0	DMA synchronization logic for DMA request signals: 0 = enable, 1 = disable



6.5.15 DMA_C0SrcAddr

地址: 0x40007100

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	DMASA														
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	DMASA														

位	名称	权限	复位值	描述
31:0	DMASA	R/W	0	DMA source address

6.5.16 DMA_C0DstAddr

地址: 0x40007104

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	DMADA														
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	DMADA														

位	名称	权限	复位值	描述
31:0	DMADA	R/W	0	DMA Destination address

6.5.17 DMA_C0LLI

地址: 0x40007108

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	FLLI														
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	FLLI														

位	名称	权限	复位值	描述
31:0	FLLI	R/W	0	First linked list item. Bits [1:0] must be 0.

BL702/704/706 参考手册 132/ 370 @2021 Bouffalo Lab



6.5.18 DMA_C0Control

地址: 0x4000710c

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
TCI EN	F	PROTEC [*]	Т	DI	DI SI RSVD FIXCNT					DTW		RSVD STW		ADD MODE	DBS
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
DBS	MIN MODE	SI	38						Т	S					

位	名称	权限	复位值	描述
31	TCIEN	R/W	0	Terminal count interrupt enable bit. It controls whether the current LLI is expected to trigger the terminal count interrupt.
30:28	PROTECT	R/W	0	Protection.
27	DI	R/W	1	Destination increment. When set, the Destination address is incremented after each transfer.
26	SI	R/W	1	Source increment. When set, the source address is incremented after each transfer.
25	RSVD			
24:23	FIXCNT	R/W	2'd0	Only effect when dst_min_mode = 1 Destination transfer cnt = (total src byte cnt - (fix cnt«DWidth))«DWidth
22:21	DTW	R/W	2'b10	Destination transfer width: 8/16/32
20	RSVD			
19:18	STW	R/W	2'b10	Source transfer width: 8/16/32
17	ADDMODE	R/W	1'b0	Add mode : issue remain destination traffic
16:15	DBS	R/W	2'b01	Destination burst size: 1/4/8/16
14	MINMODE	R/W	1'b0	Minus mode : Not issue all destination traffic
13:12	SBS	R/W	2'b01	Source burst size: 1/4/8/16. Note CH FIFO Size is 16Bytes and SBSize*Swidth should <= 16B
11:0	TS	R/W	0	Transfer size: 0 4095. Number of data transfers left to complete when the SMDMA is the flow controller.

BL702/704/706 参考手册 133/ 370 @2021 Bouffalo Lab



6.5.19 DMA_C0Config

地址: 0x40007110

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
RS	OVD					LLICO	TNUC					RSVD	HALT	AC TIVE	LOCK
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
TCIM	IEM	F	FLOWCTRL DSTPH SRCPH								CHEN				

位	名称	权限	复位值	描述
31:30	RSVD			
29:20	LLICOUNT	R	0	LLI counter. Increased 1 each LLI run. Cleared 0 when config Control.
19	RSVD			
18	HALT	R/W	0	Halt: 0 = enable DMA requests, 1 = ignore subsequent source DMA requests.
17	ACTIVE	R	0	Active: 0 = no data in FIFO of the channel, 1 = FIFO of the channel has data.
16	LOCK	R/W	0	Lock.
15	TCIM	R/W	0	Terminal count interrupt mask.
14	IEM	R/W	0	Interrupt error mask.
13:11	FLOWCTRL	R/W	0	000: Memory-to-memory (DMA) 001: Memory-to-peripheral (DMA) 010: Peripheral-to-memory (DMA) 011: Source peripheral-to-Destination peripheral (DMA)
10:6	DSTPH	R/W	0	Destination peripheral. [23:22] GPADC [21:18] I2S [17:14] PDM [13:10] SSP [9: 6] I2C [5: 0] UART
5:1	SRCPH	R/W	0	Source peripheral.
0	CHEN	R/W	0	Channel enable.

BL702/704/706 参考手册 134/ 370 @2021 Bouffalo Lab



6.5.20 DMA_C1SrcAddr

地址: 0x40007200

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	DMASA														
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	DMASA														

位	名称	权限	复位值	描述
31:0	DMASA	R/W	0	DMA source address

6.5.21 DMA_C1DstAddr

地址: 0x40007204

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	DMADA														
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	DMADA														

位	名称	权限	复位值	描述
31:0	DMADA	R/W	0	DMA Destination address

6.5.22 DMA_C1LLI

地址: 0x40007208

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	FLLI														
15	15 14 13 12 11 10 9 8 7 6 5 4 3 2											2	1	0	
	FLLI												RS	VD	

位	名称	权限	复位值	描述
31:2	FLLI	R/W	0	First linked list item. Bits [1:0] must be 0.
1:0	RSVD			



6.5.23 DMA_C1Control

地址: 0x4000720c

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
TCI EN	F	ROTEC	Γ	DI	SI	RSVD	FIX	CNT	רם	ΓW		STW		ADD MODE	DBS
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
DBS	MIN MODE	SE	38		TS										

位	名称	权限	复位值	描述
31	TCIEN	R/W	0	Terminal count interrupt enable bit. It controls whether the current LLI is expected to trigger the terminal count interrupt.
30:28	PROTECT	R/W	0	Protection.
27	DI	R/W	1	Destination increment. When set, the Destination address is incremented after each transfer.
26	SI	R/W	1	Source increment. When set, the source address is incremented after each transfer.
25	RSVD			
24:23	FIXCNT	R/W	2'd0	Only effect when dst_min_mode = 1 Destination transfer cnt = (total src byte cnt - (fix cnt«DWidth))«DWidth
22:21	DTW	R/W	3'b010	Destination transfer width: 8/16/32
20:18	STW	R/W	3'b010	Source transfer width: 8/16/32
17	ADDMODE	R/W	1'b0	Add mode : issue remain destination traffic
16:15	DBS	R/W	3'b001	Destination burst size: 1/4/8/16
14	MINMODE	R/W	1'b0	Minus mode : Not issue all destination traffic
13:12	SBS	R/W	3'b001	Source burst size: 1/4/8/16. Note CH FIFO Size is 16Bytes and SBSize*Swidth should <= 16B
11:0	TS	R/W	0	Transfer size: 0 4095. Number of data transfers left to complete when the SMDMA is the flow controller.

BL702/704/706 参考手册 136/ 370 @2021 Bouffalo Lab



6.5.24 DMA_C1Config

地址: 0x40007210

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	RSVD										HALT	AC TIVE	LOCK		
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
TCIM	IEM	F	LOWCTF	RL			DSTPH			SRCPH					CHEN

位	名称	权限	复位值	描述
31:19	RSVD			
18	HALT	R/W	0	Halt: 0 = enable DMA requests, 1 = ignore subsequent source DMA requests.
17	ACTIVE	R	0	Active: 0 = no data in FIFO of the channel, 1 = FIFO of the channel has data.
16	LOCK	R/W	0	Lock.
15	TCIM	R/W	0	Terminal count interrupt mask.
14	IEM	R/W	0	Interrupt error mask.
13:11	FLOWCTRL	R/W	0	000: Memory-to-memory (DMA) 001: Memory-to-peripheral (DMA) 010: Peripheral-to-memory (DMA) 011: Source peripheral-to-Destination peripheral (DMA)
10:6	DSTPH	R/W	0	Destination peripheral. [23:22] GPADC [21:18] I2S [17:14] PDM [13:10] SSP [9: 6] I2C [5: 0] UART
5:1	SRCPH	R/W	0	Source peripheral.
0	CHEN	R/W	0	Channel enable.

BL702/704/706 参考手册 137/ 370 @2021 Bouffalo Lab



6.5.25 DMA_C2SrcAddr

地址: 0x40007300

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	DMASA														
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	DMASA														

位	名称	权限	复位值	描述
31:0	DMASA	R/W	0	DMA source address

6.5.26 DMA_C2DstAddr

地址: 0x40007304

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	DMADA														
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	DMADA														

位	名称	权限	复位值	描述
31:0	DMADA	R/W	0	DMA Destination address

6.5.27 DMA_C2LLI

地址: 0x40007308

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	FLLI														
15	15 14 13 12 11 10 9 8 7 6 5 4 3 2											2	1	0	
	FLLI												RS	VD	

位	名称	权限	复位值	描述
31:2	FLLI	R/W	0	First linked list item. Bits [1:0] must be 0.
1:0	RSVD			

BL702/704/706 参考手册 138/ 370 @2021 Bouffalo Lab



6.5.28 DMA_C2Control

地址: 0x4000730c

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
TCI EN	F	ROTEC	Т	DI	SI	RSVD	FIX	CNT	רם	ΓW		STW		ADD MODE	DBS
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
DBS	MIN	SE	3S						Т	S					
	MODE														

位	名称	权限	复位值	描述
31	TCIEN	R/W	0	Terminal count interrupt enable bit. It controls whether the current LLI is expected to trigger the terminal count interrupt.
30:28	PROTECT	R/W	0	Protection.
27	DI	R/W	1	Destination increment. When set, the Destination address is incremented after each transfer.
26	SI	R/W	1	Source increment. When set, the source address is incremented after each transfer.
25	RSVD			
24:23	FIXCNT	R/W	2'd0	Only effect when dst_min_mode = 1 Destination transfer cnt = (total src byte cnt - (fix cnt«DWidth))«DWidth
22:21	DTW	R/W	3'b010	Destination transfer width: 8/16/32
20:18	STW	R/W	3'b010	Source transfer width: 8/16/32
17	ADDMODE	R/W	1'b0	Add mode : issue remain destination traffic
16:15	DBS	R/W	3'b001	Destination burst size: 1/4/8/16
14	MINMODE	R/W	1'b0	Minus mode : Not issue all destination traffic
13:12	SBS	R/W	3'b001	Source burst size: 1/4/8/16. Note CH FIFO Size is 16Bytes and SBSize*Swidth should <= 16B
11:0	TS	R/W	0	Transfer size: 0 4095. Number of data transfers left to complete when the SMDMA is the flow controller.

BL702/704/706 参考手册 139/ 370 @2021 Bouffalo Lab



6.5.29 DMA_C2Config

地址: 0x40007310

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
						RSVD							HALT	AC TIVE	LOCK
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
TCIM	IEM	F	LOWCTF	RL			DSTPH					SRCPH			CHEN

位	名称	权限	复位值	描述
31:19	RSVD			
18	HALT	R/W	0	Halt: 0 = enable DMA requests, 1 = ignore subsequent source DMA requests.
17	ACTIVE	R	0	Active: 0 = no data in FIFO of the channel, 1 = FIFO of the channel has data.
16	LOCK	R/W	0	Lock.
15	TCIM	R/W	0	Terminal count interrupt mask.
14	IEM	R/W	0	Interrupt error mask.
13:11	FLOWCTRL	R/W	0	000: Memory-to-memory (DMA) 001: Memory-to-peripheral (DMA) 010: Peripheral-to-memory (DMA) 011: Source peripheral-to-Destination peripheral (DMA)
10:6	DSTPH	R/W	0	Destination peripheral. [23:22] GPADC [21:18] I2S [17:14] PDM [13:10] SSP [9: 6] I2C [5: 0] UART
5:1	SRCPH	R/W	0	Source peripheral.
0	CHEN	R/W	0	Channel enable.

BL702/704/706 参考手册 140/ 370 @2021 Bouffalo Lab



6.5.30 DMA_C3SrcAddr

地址: 0x40007400

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	DMASA														
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	DMASA														

位	名称	权限	复位值	描述
31:0	DMASA	R/W	0	DMA source address

6.5.31 DMA_C3DstAddr

地址: 0x40007404

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	DMADA														
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	DMADA														

位	名称	权限	复位值	描述
31:0	DMADA	R/W	0	DMA Destination address

6.5.32 DMA_C3LLI

地址: 0x40007408

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	FLLI														
15	15 14 13 12 11 10 9 8 7 6 5 4 3 2											2	1	0	
	FLLI													RS	VD

位	名称	权限	复位值	描述
31:2	FLLI	R/W	0	First linked list item. Bits [1:0] must be 0.
1:0	RSVD			



6.5.33 DMA_C3Control

地址: 0x4000740c

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
TCI EN	F	PROTEC [*]	Т	DI	SI	RSVD	FIX	CNT	TO	ΓW		STW		ADD MODE	DBS
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
DBS	MIN MODE	SI	BS .						Т	S					

位	名称	权限	复位值	描述
31	TCIEN	R/W	0	Terminal count interrupt enable bit. It controls whether the current LLI is expected to trigger the terminal count interrupt.
30:28	PROTECT	R/W	0	Protection.
27	DI	R/W	1	Destination increment. When set, the Destination address is incremented after each transfer.
26	SI	R/W	1	Source increment. When set, the source address is incremented after each transfer.
25	RSVD			
24:23	FIXCNT	R/W	2'd0	Only effect when dst_min_mode = 1 Destination transfer cnt = (total src byte cnt - (fix cnt«DWidth))«DWidth
22:21	DTW	R/W	3'b010	Destination transfer width: 8/16/32
20:18	STW	R/W	3'b010	Source transfer width: 8/16/32
17	ADDMODE	R/W	1'b0	Add mode : issue remain destination traffic
16:15	DBS	R/W	3'b001	Destination burst size: 1/4/8/16
14	MINMODE	R/W	1'b0	Minus mode : Not issue all destination traffic
13:12	SBS	R/W	3'b001	Source burst size: 1/4/8/16. Note CH FIFO Size is 16Bytes and SBSize*Swidth should <= 16B
11:0	TS	R/W	0	Transfer size: 0 4095. Number of data transfers left to complete when the SMDMA is the flow controller.

BL702/704/706 参考手册 142/ 370 @2021 Bouffalo Lab



6.5.34 DMA_C3Config

地址: 0x40007410

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	RSVD											HALT	AC TIVE	LOCK	
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
TCIM	IEM	F	LOWCTF	RL			DSTPH					SRCPH			CHEN

位	名称	权限	复位值	描述
31:19	RSVD			
18	HALT	R/W	0	Halt: 0 = enable DMA requests, 1 = ignore subsequent source DMA requests.
17	ACTIVE	R	0	Active: 0 = no data in FIFO of the channel, 1 = FIFO of the channel has data.
16	LOCK	R/W	0	Lock.
15	TCIM	R/W	0	Terminal count interrupt mask.
14	IEM	R/W	0	Interrupt error mask.
13:11	FLOWCTRL	R/W	0	000: Memory-to-memory (DMA) 001: Memory-to-peripheral (DMA) 010: Peripheral-to-memory (DMA) 011: Source peripheral-to-Destination peripheral (DMA)
10:6	DSTPH	R/W	0	Destination peripheral. [23:22] GPADC [21:18] I2S [17:14] PDM [13:10] SSP [9: 6] I2C [5: 0] UART
5:1	SRCPH	R/W	0	Source peripheral.
0	CHEN	R/W	0	Channel enable.

BL702/704/706 参考手册 143/ 370 @2021 Bouffalo Lab



6.5.35 DMA_C4SrcAddr

地址: 0x40007500

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	DMASA														
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	DMASA														

位	名称	权限	复位值	描述
31:0	DMASA	R/W	0	DMA source address

6.5.36 DMA_C4DstAddr

地址: 0x40007504

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	DMADA														
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	DMADA														

位	名称	权限	复位值	描述
31:0	DMADA	R/W	0	DMA Destination address

6.5.37 DMA_C4LLI

地址: 0x40007508

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	FLLI														
15	15 14 13 12 11 10 9 8 7 6 5 4 3 2											2	1	0	
	FLLI													RS	VD

位	名称	权限	复位值	描述
31:2	FLLI	R/W	0	First linked list item. Bits [1:0] must be 0.
1:0	RSVD			

BL702/704/706 参考手册 144/ 370 @2021 Bouffalo Lab



6.5.38 DMA_C4Control

地址: 0x4000750c

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
TCI EN	F	ROTEC	Т	DI	SI	RSVD	FIX	CNT	רם	ΓW		STW		ADD MODE	DBS
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
DBS	MIN	SE	3S						Т	S					
	MODE														

位	名称	权限	复位值	描述
31	TCIEN	R/W	0	Terminal count interrupt enable bit. It controls whether the current LLI is expected to trigger the terminal count interrupt.
30:28	PROTECT	R/W	0	Protection.
27	DI	R/W	1	Destination increment. When set, the Destination address is incremented after each transfer.
26	SI	R/W	1	Source increment. When set, the source address is incremented after each transfer.
25	RSVD			
24:23	FIXCNT	R/W	2'd0	Only effect when dst_min_mode = 1 Destination transfer cnt = (total src byte cnt - (fix cnt«DWidth))«DWidth
22:21	DTW	R/W	3'b010	Destination transfer width: 8/16/32
20:18	STW	R/W	3'b010	Source transfer width: 8/16/32
17	ADDMODE	R/W	1'b0	Add mode : issue remain destination traffic
16:15	DBS	R/W	3'b001	Destination burst size: 1/4/8/16
14	MINMODE	R/W	1'b0	Minus mode : Not issue all destination traffic
13:12	SBS	R/W	3'b001	Source burst size: 1/4/8/16. Note CH FIFO Size is 16Bytes and SBSize*Swidth should <= 16B
11:0	TS	R/W	0	Transfer size: 0 4095. Number of data transfers left to complete when the SMDMA is the flow controller.

BL702/704/706 参考手册 145/ 370 @2021 Bouffalo Lab



6.5.39 DMA_C4Config

地址: 0x40007510

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	RSVD								HALT	AC TIVE	LOCK				
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
TCIM	IEM	F	LOWCTF	RL			DSTPH					SRCPH			CHEN

位	名称	权限	复位值	描述
31:19	RSVD			
18	HALT	R/W	0	Halt: 0 = enable DMA requests, 1 = ignore subsequent source DMA requests.
17	ACTIVE	R	0	Active: 0 = no data in FIFO of the channel, 1 = FIFO of the channel has data.
16	LOCK	R/W	0	Lock.
15	TCIM	R/W	0	Terminal count interrupt mask.
14	IEM	R/W	0	Interrupt error mask.
13:11	FLOWCTRL	R/W	0	000: Memory-to-memory (DMA) 001: Memory-to-peripheral (DMA) 010: Peripheral-to-memory (DMA) 011: Source peripheral-to-Destination peripheral (DMA)
10:6	DSTPH	R/W	0	Destination peripheral. [23:22] GPADC [21:18] I2S [17:14] PDM [13:10] SSP [9: 6] I2C [5: 0] UART
5:1	SRCPH	R/W	0	Source peripheral.
0	CHEN	R/W	0	Channel enable.

BL702/704/706 参考手册 146/ 370 @2021 Bouffalo Lab



6.5.40 DMA_C5SrcAddr

地址: 0x40007600

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
							DM	ASA							
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
							DM	ASA							

位	名称	权限	复位值	描述
31:0	DMASA	R/W	0	DMA source address

6.5.41 DMA_C5DstAddr

地址: 0x40007604

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
							DMA	ADA							
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
							DMA	ADA							

位	名称	权限	复位值	描述
31:0	DMADA	R/W	0	DMA Destination address

6.5.42 DMA_C5LLI

地址: 0x40007608

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
		FLLI													
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	FLLI									RS	VD				

位	名称	权限	复位值	描述
31:2	FLLI	R/W	0	First linked list item. Bits [1:0] must be 0.
1:0	RSVD			

BL702/704/706 参考手册 147/ 370 @2021 Bouffalo Lab



6.5.43 DMA_C5Control

地址: 0x4000760c

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
TCI EN	F	PROTEC [*]	Т	DI	SI	RSVD	FIX	CNT	רם	ΓW		STW		ADD MODE	DBS
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
DBS	MIN MODE	SI	3S					•	Т	S	•				

位	名称	权限	复位值	描述
31	TCIEN	R/W	0	Terminal count interrupt enable bit. It controls whether the current LLI is expected to trigger the terminal count interrupt.
30:28	PROTECT	R/W	0	Protection.
27	DI	R/W	1	Destination increment. When set, the Destination address is incremented after each transfer.
26	SI	R/W	1	Source increment. When set, the source address is incremented after each transfer.
25	RSVD			
24:23	FIXCNT	R/W	2'd0	Only effect when dst_min_mode = 1 Destination transfer cnt = (total src byte cnt - (fix cnt«DWidth))«DWidth
22:21	DTW	R/W	3'b010	Destination transfer width: 8/16/32
20:18	STW	R/W	3'b010	Source transfer width: 8/16/32
17	ADDMODE	R/W	1'b0	Add mode : issue remain destination traffic
16:15	DBS	R/W	3'b001	Destination burst size: 1/4/8/16
14	MINMODE	R/W	1'b0	Minus mode : Not issue all destination traffic
13:12	SBS	R/W	3'b001	Source burst size: 1/4/8/16. Note CH FIFO Size is 16Bytes and SBSize*Swidth should <= 16B
11:0	TS	R/W	0	Transfer size: 0 4095. Number of data transfers left to complete when the SMDMA is the flow controller.

BL702/704/706 参考手册 148/ 370 @2021 Bouffalo Lab



6.5.44 DMA_C5Config

地址: 0x40007610

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
						RSVD							HALT	AC TIVE	LOCK
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
TCIM	IEM	F	LOWCTF	RL			DSTPH					SRCPH			CHEN

位	名称	权限	复位值	描述
31:19	RSVD			
18	HALT	R/W	0	Halt: 0 = enable DMA requests, 1 = ignore subsequent source DMA requests.
17	ACTIVE	R	0	Active: 0 = no data in FIFO of the channel, 1 = FIFO of the channel has data.
16	LOCK	R/W	0	Lock.
15	TCIM	R/W	0	Terminal count interrupt mask.
14	IEM	R/W	0	Interrupt error mask.
13:11	FLOWCTRL	R/W	0	000: Memory-to-memory (DMA) 001: Memory-to-peripheral (DMA) 010: Peripheral-to-memory (DMA) 011: Source peripheral-to-Destination peripheral (DMA)
10:6	DSTPH	R/W	0	Destination peripheral. [23:22] GPADC [21:18] I2S [17:14] PDM [13:10] SSP [9: 6] I2C [5: 0] UART
5:1	SRCPH	R/W	0	Source peripheral.
0	CHEN	R/W	0	Channel enable.

BL702/704/706 参考手册 149/ 370 @2021 Bouffalo Lab



6.5.45 DMA_C6SrcAddr

地址: 0x40007700

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
							DM	ASA							
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	DMASA														

位	名称	权限	复位值	描述
31:0	DMASA	R/W	0	DMA source address

6.5.46 DMA_C6DstAddr

地址: 0x40007704

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
							DMA	ADA							
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
							DMA	ADA							

位	名称	权限	复位值	描述
31:0	DMADA	R/W	0	DMA Destination address

6.5.47 DMA_C6LLI

地址: 0x40007708

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
							FL	.LI							
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	FLLI									RS	VD				

位	名称	权限	复位值	描述
31:2	FLLI	R/W	0	First linked list item. Bits [1:0] must be 0.
1:0	RSVD			

BL702/704/706 参考手册 150/ 370 @2021 Bouffalo Lab



6.5.48 DMA_C6Control

地址: 0x4000770c

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
TCI EN	F	PROTEC [*]	Т	DI	SI	RSVD	FIX	CNT	TO	ΓW		STW		ADD MODE	DBS
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
DBS	MIN MODE	SI	BS						Т	S					

位	名称	权限	复位值	描述
31	TCIEN	R/W	0	Terminal count interrupt enable bit. It controls whether the current LLI is expected to trigger the terminal count interrupt.
30:28	PROTECT	R/W	0	Protection.
27	DI	R/W	1	Destination increment. When set, the Destination address is incremented after each transfer.
26	SI	R/W	1	Source increment. When set, the source address is incremented after each transfer.
25	RSVD			
24:23	FIXCNT	R/W	2'd0	Only effect when dst_min_mode = 1 Destination transfer cnt = (total src byte cnt - (fix cnt«DWidth))«DWidth
22:21	DTW	R/W	3'b010	Destination transfer width: 8/16/32
20:18	STW	R/W	3'b010	Source transfer width: 8/16/32
17	ADDMODE	R/W	1'b0	Add mode : issue remain destination traffic
16:15	DBS	R/W	3'b001	Destination burst size: 1/4/8/16
14	MINMODE	R/W	1'b0	Minus mode : Not issue all destination traffic
13:12	SBS	R/W	3'b001	Source burst size: 1/4/8/16. Note CH FIFO Size is 16Bytes and SBSize*Swidth should <= 16B
11:0	TS	R/W	0	Transfer size: 0 4095. Number of data transfers left to complete when the SMDMA is the flow controller.



6.5.49 DMA_C6Config

地址: 0x40007710

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
						RSVD							HALT	AC TIVE	LOCK
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
TCIM	IEM	F	LOWCTF	RL			DSTPH					SRCPH			CHEN

位	名称	权限	复位值	描述
31:19	RSVD			
18	HALT	R/W	0	Halt: 0 = enable DMA requests, 1 = ignore subsequent source DMA requests.
17	ACTIVE	R	0	Active: 0 = no data in FIFO of the channel, 1 = FIFO of the channel has data.
16	LOCK	R/W	0	Lock.
15	TCIM	R/W	0	Terminal count interrupt mask.
14	IEM	R/W	0	Interrupt error mask.
13:11	FLOWCTRL	R/W	0	000: Memory-to-memory (DMA) 001: Memory-to-peripheral (DMA) 010: Peripheral-to-memory (DMA) 011: Source peripheral-to-Destination peripheral (DMA)
10:6	DSTPH	R/W	0	Destination peripheral. [23:22] GPADC [21:18] I2S [17:14] PDM [13:10] SSP [9: 6] I2C [5: 0] UART
5:1	SRCPH	R/W	0	Source peripheral.
0	CHEN	R/W	0	Channel enable.



6.5.50 DMA_C7SrcAddr

地址: 0x40007800

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	DMASA														
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	DMASA														

位	名称	权限	复位值	描述
31:0	DMASA	R/W	0	DMA source address

6.5.51 DMA_C7DstAddr

地址: 0x40007804

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	DMADA														
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	DMADA														

位	名称	权限	复位值	描述
31:0	DMADA	R/W	0	DMA Destination address

6.5.52 DMA_C7LLI

地址: 0x40007808

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	FLLI														
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	FLLI										RS	VD			

位	名称	权限	复位值	描述
31:2	FLLI	R/W	0	First linked list item. Bits [1:0] must be 0.
1:0	RSVD			

BL702/704/706 参考手册 153/ 370 @2021 Bouffalo Lab



6.5.53 DMA_C7Control

地址: 0x4000780c

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
TCI EN	F	PROTEC [*]	Т	DI	SI	RSVD	FIX	CNT	רם	ΓW		STW		ADD MODE	DBS
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
DBS	MIN MODE	SI	3S	тѕ											

位	名称	权限	复位值	描述
31	TCIEN	R/W	0	Terminal count interrupt enable bit. It controls whether the current LLI is expected to trigger the terminal count interrupt.
30:28	PROTECT	R/W	0	Protection.
27	DI	R/W	1	Destination increment. When set, the Destination address is incremented after each transfer.
26	SI	R/W	1	Source increment. When set, the source address is incremented after each transfer.
25	RSVD			
24:23	FIXCNT	R/W	2'd0	Only effect when dst_min_mode = 1 Destination transfer cnt = (total src byte cnt - (fix cnt«DWidth))«DWidth
22:21	DTW	R/W	3'b010	Destination transfer width: 8/16/32
20:18	STW	R/W	3'b010	Source transfer width: 8/16/32
17	ADDMODE	R/W	1'b0	Add mode : issue remain destination traffic
16:15	DBS	R/W	3'b001	Destination burst size: 1/4/8/16
14	MINMODE	R/W	1'b0	Minus mode : Not issue all destination traffic
13:12	SBS	R/W	3'b001	Source burst size: 1/4/8/16. Note CH FIFO Size is 16Bytes and SBSize*Swidth should <= 16B
11:0	TS	R/W	0	Transfer size: 0 4095. Number of data transfers left to complete when the SMDMA is the flow controller.



6.5.54 DMA_C7Config

地址: 0x40007810

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	RSVD									HALT	AC TIVE	LOCK			
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
TCIM	IEM	F	LOWCTF	RL		DSTPH						SRCPH			CHEN

位	名称	权限	复位值	描述
31:19	RSVD			
18	HALT	R/W	0	Halt: 0 = enable DMA requests, 1 = ignore subsequent source DMA requests.
17	ACTIVE	R	0	Active: 0 = no data in FIFO of the channel, 1 = FIFO of the channel has data.
16	LOCK	R/W	0	Lock.
15	TCIM	R/W	0	Terminal count interrupt mask.
14	IEM	R/W	0	Interrupt error mask.
13:11	FLOWCTRL	R/W	0	000: Memory-to-memory (DMA) 001: Memory-to-peripheral (DMA) 010: Peripheral-to-memory (DMA) 011: Source peripheral-to-Destination peripheral (DMA)
10:6	DSTPH	R/W	0	Destination peripheral. [23:22] GPADC [21:18] I2S [17:14] PDM [13:10] SSP [9: 6] I2C [5: 0] UART
5:1	SRCPH	R/W	0	Source peripheral.
0	CHEN	R/W	0	Channel enable.

7.1 简介

L1 Cache Controller 是位于处理器外部, 用于管理 Flash/pSRAM 上代码或者数据缓冲, 提高 CPU 访问 Flash/pSRAM 速度的单元模块。架构如下图:




图 7.1: LIC 架构

L1C 是集成在处理器和 Flash/pSRAM 中间的高速单元,因为处理器的速度非常快,当处理器访问 Flash/pSRAM 时需要等待的时间较长,等待的时间即代表浪费的时间,浪费的时间越少代表效能越高,L1C 缓存可以在处理器与 Flash/pSRAM 中间当作润滑的角色,让处理器效率提升。



7.2 主要特征

- 4 路相联映射缓存 (4-way Set-Associative mapping)
- 可调变的缓存空间大小
- · 与 TCM 地址空间连续,可以方便的配置 L1C 空间为 TCM 空间
- 支持缓存效能统计

7.3 功能描述

7.3.1 TCM 与 Cache RAM 资源相互变换

为了增加内存使用效率,支持将 Cache 的 16K RAM 全部或者部分调整为 TCM 空间,这样方便用户根据实际情况,调整内存使用方式和效率。Cache 最大可设置为 16K,分为 4 条 way,每条 way 是 4K,调整的单位是 1 条 way,也就是 4K。ITCM 的默认大小是 16K。通过 WayDisable 的设定可以灵活的调整 Cache 和 ITCM 的实际空间大小。

表 7.1: WayDisable 的设定

WayDisable	Cache	ITCM
none	16K	0K
one way	12K	4K
two way	8K	8K
three way	4K	12K
four way	0K	16K

7.3.2 缓存 (Cache)

缓存每条 line buffer 单位为 32 字节,采用 4 路相联映射缓存,应用架构如下:






图 7.2: 缓存架构

每组相联映射缓存包含两个部分,第一个是 tag,包含了有效值和地址映像关系,第二部分是数据储存。当处理器存取缓存时,缓存处理器会比对地址和 tag 的关系,当地址比对成功时代表可以直接从缓存取数据,反之缓存处理器则会通过 AHB Master 抓取相关的数据并同时放进缓存和响应处理器的数据。当大部分的数据都可以在 tag 中比对成功时,可以大幅度缩短处理器的等待时间,增加使用效率。

7.4 寄存器描述

名称	描述
I1c_config	L1C configuration
hit_cnt_lsb	Low 32-bit hit couter
hit_cnt_msb	High 32-bit hit counter
miss_cnt	Miss counter



7.4.1 l1c_config

地址: 0x40009000

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
							RS	VD							
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	RS	VD	,		WAY	'DIS				RS	VD			CNT	CAC
														EN	ABLE

位	名称	权限	复位值	描述
31:12	RSVD			
11:8	WAYDIS	R/W	4'b1111	Disable part of cache ways & used as ITCM
7:2	RSVD			
1	CNTEN	R/W	0	
0	CACABLE	R/W	0	

7.4.2 hit_cnt_lsb

地址: 0x40009004

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	CNTLSB														
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	CNTLSB														

位	名称	权限	复位值	描述
31:0	CNTLSB	R	0	

7.4.3 hit_cnt_msb

地址: 0x40009008

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	CNTMSB														
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	CNTMSB														

BL702/704/706 参考手册 159/ 370 @2021 Bouffalo Lab



位	名称	权限	复位值	描述
31:0	CNTMSB	R	0	total hit count = hit_cnt_msb*232 + hit_cnt_lsb

7.4.4 miss_cnt

地址: 0x4000900c

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	MISSCNT														
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	MISSCNT														

位	名称	权限 复位值		描述
31:0	MISSCNT	R	0	

BL702/704/706 参考手册 160/ 370 @2021 Bouffalo Lab

8.1 简介

红外遥控(Infrared remote,简称 IR)是一种无线、非接触式控制技术,具有抗干扰能力强、信息传输可靠、功耗低、成本低等优点。红外遥控的发射电路是采用红外发光二极管来发出经过调制的红外光波;接收电路由红外接收二极管、三极管或硅光电池组成,它们将红外发射器发射的红外光转换为相应的电信号,再送至后置放大器。

8.2 主要特征

- 支持以固定协议 NEC、RC-5 接收数据
- 支持以脉冲宽度计数方式接收任意格式数据
- 强大的红外波形编辑能力,可发出符合各种协议的波形
- 多达 15 个档位的功率设定,以适应不同的功耗要求
- 最多支持 64-bit 数据位
- 64 字节的接收 FIFO
- 载波频率与占空比可编程

8.3 功能描述

8.3.1 固定协议接收

IR 接收支持两种固定的协议,分别为 NEC 协议和 RC-5 协议。

• NEC 协议

NEC 协议的逻辑 1 与逻辑 0 波形如下图所示:






图 8.1: NEC 逻辑波形

逻辑 1 为 2.25ms, 脉冲时间 560us; 逻辑 0 位 1.12ms, 脉冲时间 560us。NEC 协议的具体格式如下图所示:




图 8.2: NEC 协议波形

头脉冲是 9ms 的高电平脉冲和 4.5ms 的低电平,之后是 8-bit 的地址码及其反码,然后是 8-bit 的命令码及其反码,尾脉冲是 560us 高电平与 560us 低电平。

• RC-5 协议

RC-5 协议的逻辑 1 与逻辑 0 波形如下图所示:




图 8.3: RC5 逻辑波形

逻辑 1 为 1.778ms, 先是 889us 的低电平后是 889us 的高电平;逻辑 0 与逻辑 1 波形相反。RC-5 协议的具体格式如下图所示:

BL702/704/706 参考手册 162/ 370 @2021 Bouffalo Lab






图 8.4: RC5 协议波形

前两位为开始位,固定为逻辑 1,第三位是翻转位,当一个键值发出然后再按下时该位会取反。之后 5 位是地址码与 6 位命令码。需要注意的是,常见的红外一体接收头为了提高接收灵敏度,接收到高电平后输出的是低电平,所以在使用 IR 接收功能时要将接收翻转功能打开。

8.3.2 脉冲宽度接收

对于 NEC、RC-5 协议以外的其他任意格式的数据,IR 会以其时钟去依次计数每个高低电平的持续时间,然后将数据 存入到深度为 64 字节的接收 FIFO 之中。

8.3.3 普通发送模式

用户可根据具体协议分别对头脉冲、尾脉冲、逻辑 0 和逻辑 1 脉冲进行相应的配置。在设置时需要计算出所使用的协议内各种不同宽度脉冲的公共脉冲宽度单位,即最大公约数,填入寄存器 IRTX_PULSE_WIDTH 的低 12 位,各脉冲将其所对应的倍数填入寄存器 IRTX_PW 中。IR 最大支持 64-bit 数据位,分为两个 32 位寄存器 IRTX_DATA_WORD0 和 IRTX DATA WORD1。

8.3.4 脉冲宽度发送

对于不适用于普通发送模式的协议,IR 提供了脉冲宽度发送的方式。先计算出所使用的协议内各种不同宽度脉冲的公共脉冲宽度单位,即最大公约数,填入寄存器 IRTX_PULSE_WIDTH 的低 12 位。然后将从第一个电平开始到最后一个电平为止的各个电平宽度所对应的倍数填入寄存器 IRTX_SWM_PW_n(0<=n<=7) 中,每个电平宽度倍数占 4-bit。

8.3.5 载波调制

通过设置寄存器 IRTX_PULSE_WIDTH 的高 16 位可以产生不同频率和占空比的载波,该寄存器的 <TXMPH1W> 位设置的是载波相位 1 的宽度, <TXMPH0W> 位设置的是载波相位 0 的宽度。

BL702/704/706 参考手册 163/ 370 @2021 Bouffalo Lab



8.3.6 IR 中断

IR 有单独的发送和接收中断,当一次发送动作结束时,会产生发送中断。当接收到一段数据时,它会等待电平持续长度达到设定的结束阈值时产生接收中断。可以通过寄存器 IRTX_INT_STS 查询发送中断状态和清除中断,通过寄存器 IRRX_INT_STS 查询接收中断状态和清除中断。

8.4 寄存器描述

名称	描述
irtx_config	IR TX configuration register
irtx_int_sts	IR TX interrupt status
irtx_data_word0	IR TX data word0
irtx_data_word1	IR TX data word1
irtx_pulse_width	IR TX pulse width
irtx_pw	IR TX pulse width of phase
irtx_swm_pw_0	IR TX Software Mode pulse width data0
irtx_swm_pw_1	IR TX Software Mode pulse width data1
irtx_swm_pw_2	IR TX Software Mode pulse width data2
irtx_swm_pw_3	IR TX Software Mode pulse width data3
irtx_swm_pw_4	IR TX Software Mode pulse width data4
irtx_swm_pw_5	IR TX Software Mode pulse width data5
irtx_swm_pw_6	IR TX Software Mode pulse width data6
irtx_swm_pw_7	IR TX Software Mode pulse width data7
irrx_config	IR RX configuration register
irrx_int_sts	IR RX interrupt status
irrx_pw_config	IR RX pulse width configuration
irrx_data_count	IR RX data bit count
irrx_data_word0	IR RX data word0
irrx_data_word1	IR RX data word1
irrx_swm_fifo_config_0	IR RX FIFO configuration
irrx_swm_fifo_rdata	IR RX software mode pulse width data



8.4.1 irtx_config

地址: 0x4000a600

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	RSVD 1											TXDATANU			
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	TXDATANU TPHL TXTP TXH TXH IS EN HLI EN								TXL1 HLI	TXL0 HLI	TXDA EN	TXSW EN	TXMD EN	TXO EN	TXEN

位	名称	权限	复位值	描述
31:18	RSVD			
17:12	TXDATANU	R/W	6'd31	Bit count of Data phase (unit: bit / PW for normal / SWM)
11	TPHLIS	R/W	1'b0	Tail pulse H/L inverse signal (Don't care if SWM is enabled) 0: Phase 0 is High (Active), phase 1 is Low (Idle) (H -> L) 1: Phase 0 is Low (Idle), phase 1 is High (Active) (L -> H)
10	TXTPEN	R/W	1'b1	Enable signal of tail pulse (Don't care if SWM is enabled)
9	TXHHLI	R/W	1'b0	Tail pulse H/L inverse signal (Don't care if SWM is enabled) 0: Phase 0 is High (Active), phase 1 is Low (Idle) (H -> L) 1: Phase 0 is Low (Idle), phase 1 is High (Active) (L -> H)
8	TXHEN	R/W	1'b1	Enable signal of head pulse (Don't care if SWM is enabled)
7	RSVD			
6	TXL1HLI	R/W	1'b0	Logic 1 H/L inverse signal (Don't care if SWM is enabled) 0: Phase 0 is High (Active), phase 1 is Low (Idle) (H -> L) 1: Phase 0 is Low (Idle), phase 1 is High (Active) (L -> H)
5	TXL0HLI	R/W	1'b0	Logic 0 H/L inverse signal (Don't care if SWM is enabled) 0: Phase 0 is High (Active), phase 1 is Low (Idle) (H -> L) 1: Phase 0 is Low (Idle), phase 1 is High (Active) (L -> H)
4	TXDAEN	R/W	1'b1	Enable signal of data phase (Don't care if SWM is enabled)
3	TXSWEN	R/W	1'b0	Enable signal of IRTX Software Mode (SWM)
2	TXMDEN	R/W	1'b0	Enable signal of output modulation
1	TXOEN	R/W	1'b0	Output inverse signal 1'b0: Output stays at Low during idle state 1'b1: Output stays at High during idle state
0	TXEN	R/W	1'b0	Enable signal of IRTX function Asserting this bit will trigger the transaction, and should be de-asserted after finish



8.4.2 irtx_int_sts

地址: 0x4000a604

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
			RSVD				TXE				RSVD				TXE
							EN								CLR
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
			RSVD				TXE				RSVD				TXE
							MASK								INT

位	名称	权限	复位值	描述
31:25	RSVD			
24	TXEEN	R/W	1'b1	Interrupt enable of irtx_end_int
23:17	RSVD			
16	TXECLR	W1C	1'b0	Interrupt clear of irtx_end_int
15:9	RSVD			
8	TXEMASK	R/W	1'b1	Interrupt mask of irtx_end_int
7:1	RSVD			
0	TXEINT	R	1'b0	IRTX transfer end interrupt

8.4.3 irtx_data_word0

地址: 0x4000a608

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	TXDW0														
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	TXDW0														

位	名称	权限	复位值	描述
31:0	TXDW0	R/W	32'h0	TX data word 0 (Don't care if SWM is enabled)

BL702/704/706 参考手册 166/ 370 @2021 Bouffalo Lab



8.4.4 irtx_data_word1

地址: 0x4000a60c

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	TXDW1														
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	TXDW1														

位	名称	权限	复位值	描述
31:0	TXDW1	R/W	32'h0	TX data word 1 (Don't care if SWM is enabled)

8.4.5 irtx_pulse_width

地址: 0x4000a610

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16			
	TXMPH1W								TXMPH0W									
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0			
	RSVD								TXF	UW								

位	名称	权限	复位值	描述
31:24	TXMPH1W	R/W	8'd34	Modulation phase 1 width
23:16	TXMPH0W	R/W	8'd17	Modulation phase 0 width
15:12	RSVD			
11:0	TXPWU	R/W	12'd1124	Pulse width unit

8.4.6 irtx_pw

地址: 0x4000a614

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	
	TXTPH1W TXTPH0W							TXHF	PH1W		TXHPH0W					
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	
	TXL1PH1W TXL1PH0W								TXL0	PH1W			TXL0F	H0WS		

BL702/704/706 参考手册 167/ 370 @2021 Bouffalo Lab



位	名称	权限	复位值	描述
31:28	TXTPH1W	R/W	4'd0	Pulse width of tail pulse phase 1 (Don't care if SWM is enabled)
27:24	TXTPH0W	R/W	4'd0	Pulse width of tail pulse phase 0 (Don't care if SWM is enabled)
23:20	TXHPH1W	R/W	4'd7	Pulse width of head pulse phase 1 (Don't care if SWM is enabled)
19:16	TXHPH0W	R/W	4'd15	Pulse width of head pulse phase 0 (Don't care if SWM is enabled)
15:12	TXL1PH1W	R/W	4'd2	Pulse width of logic1 phase 1 (Don't care if SWM is enabled)
11:8	TXL1PH0W	R/W	4'd0	Pulse width of logic1 phase 0 (Don't care if SWM is enabled)
7:4	TXL0PH1W	R/W	4'd0	Pulse width of logic0 phase 1 (Don't care if SWM is enabled)
3:0	TXL0PH0WS	R/W	4'd0	Pulse width of logic0 phase 0 (Don't care if SWM is enabled)

8.4.7 irtx_swm_pw_0

地址: 0x4000a640

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	TXSWPW0														
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	TXSWPW0														

位	名称	权限	复位值	描述
31:0	TXSWPW0	R/W	32'h0	IRTX Software Mode pulse width data #0 #7, each pulse is represented by 4-bit ([3:0] is the 1st pulse, [7:4] is the 2nd pulse, [11:8] is the 3rd pulse, etc)

8.4.8 irtx_swm_pw_1

地址: 0x4000a644

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	TXSWPW1														
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	TXSWPW1														

BL702/704/706 参考手册 168/ 370 @2021 Bouffalo Lab



位	名称	权限	复位值	描述
31:0	TXSWPW1	R/W	32'h0	IRTX Software Mode pulse width data #8 #15, each pulse is represented by 4-bit ([3:0] is the 1st pulse, [7:4] is the 2nd pulse, [11:8] is the 3rd pulse, etc)

8.4.9 irtx_swm_pw_2

地址: 0x4000a648

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	TXSWPW2														
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
							TXSV	VPW2			•	•			

位	名称	权限	复位值	描述
31:0	TXSWPW2	R/W	32'h0	IRTX Software Mode pulse width data #16 #23, each pulse is represented by 4-bit ([3:0] is the 1st pulse, [7:4] is the 2nd pulse, [11:8] is the 3rd pulse, etc)

8.4.10 irtx_swm_pw_3

地址: 0x4000a64c

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	TXSWPW3														
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	TXSWPW3														

位	名称	权限	复位值	描述
31:0	TXSWPW3	R/W	32'h0	IRTX Software Mode pulse width data #24 #31, each pulse is represented by 4-bit ([3:0] is the 1st pulse, [7:4] is the 2nd pulse, [11:8] is the 3rd pulse, etc)

BL702/704/706 参考手册 169/ 370 @2021 Bouffalo Lab



8.4.11 irtx_swm_pw_4

地址: 0x4000a650

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	TXSWPW4														
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	TXSWPW4														

位	名称	权限	复位值	描述
31:0	TXSWPW4	R/W	32'h0	IRTX Software Mode pulse width data #32 #39, each pulse is represented by 4-bit ([3:0] is the 1st pulse, [7:4] is the 2nd pulse, [11:8] is the 3rd pulse, etc)

8.4.12 irtx_swm_pw_5

地址: 0x4000a654

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	TXSWPW5														
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
							TXSV	VPW5	•		•	•			

位	名称	权限	复位值	描述
31:0	TXSWPW5	R/W	32'h0	IRTX Software Mode pulse width data #40 #47, each pulse is represented by 4-bit ([3:0] is the 1st pulse, [7:4] is the 2nd pulse, [11:8] is the 3rd pulse, etc)

8.4.13 irtx_swm_pw_6

地址: 0x4000a658

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	TXSWPW6														
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
							TXSV	VPW6							

BL702/704/706 参考手册 170/ 370 @2021 Bouffalo Lab



位	名称	权限	复位值	描述
31:0	TXSWPW6	R/W	32'h0	IRTX Software Mode pulse width data #48 #55, each pulse is represented by 4-bit ([3:0] is the 1st pulse, [7:4] is the 2nd pulse, [11:8] is the 3rd pulse, etc)

8.4.14 irtx_swm_pw_7

地址: 0x4000a65c

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	TXSWPW7														
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
							TXSV	VPW7			•				

位	名称	权限	复位值	描述
31:0	TXSWPW7	R/W	32'h0	IRTX Software Mode pulse width data #56 #63, each pulse is represented by 4-bit ([3:0] is the 1st pulse, [7:4] is the 2nd pulse, [11:8] is the 3rd pulse, etc)

8.4.15 irrx_config

地址: 0x4000a680

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
							RS	VD							
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	RS	RSVD RXDEGCNT RSVD RXDG EN					RXDEGCNT					RXM	ODE	RXIN INV	RXEN

位	名称	权限	复位值	描述
31:12	RSVD			
11:8	RXDEGCNT	R/W	4'd0	De-glitch function cycle count
7:5	RSVD			
4	RXDGEN R/		1'b0	Enable signal of IRRX input de-glitch function



位	名称	权限	复位值	描述
3:2	RXMODE	R/W	2 ¹ d0	IRRX mode 0: NEC 1: RC5 2: SW pulse-width detection mode (SWM) 3: Reserved
1	RXININV	R/W	1'b1	Input inverse signal
0	RXEN	R/W	1'b0	Enable signal of IRRX function Asserting this bit will trigger the transaction, and should be de-asserted after finish

8.4.16 irrx_int_sts

地址: 0x4000a684

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
			RSVD				RXE				RSVD				RXE
							EN								CLR
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
			RSVD				RXE	·			RSVD				RXE
							MASK								INT

位	名称	权限	复位值	描述
31:25	RSVD			
24	RXEEN	R/W	1'b1	Interrupt enable of irrx_end_int
23:17	RSVD			
16	RXECLR	W1C	1'b0	Interrupt clear of irrx_end_int
15:9	RSVD			
8	RXEMASK	R/W	1'b1	Interrupt mask of irrx_end_int
7:1	RSVD			
0	RXEINT	R	1'b0	IRRX transfer end interrupt



8.4.17 irrx_pw_config

地址: 0x4000a688

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	RXETH														
15	15 14 13 12 11 10 9 8 7 6 5 4 3 2 1 0														
	RXDATH														

位	名称	权限	复位值	描述
31:16	RXETH	R/W	16'd8999	Pulse width threshold to trigger END condition
15:0	RXDATH	R/W	16'd3399	Pulse width threshold for Logic0/1 detection (Don't care if SWM is enabled)

8.4.18 irrx_data_count

地址: 0x4000a690

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	RSVD														
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	RSVD										F	RXDACN	Т		

位	名称	权限	复位值	描述
31:7	RSVD			
6:0	RXDACNT	R	7'd0	RX data bit count (pulse-width count for SWM)

8.4.19 irrx_data_word0

地址: 0x4000a694

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	RXDAW0														
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
							RXD	AW0			•				

位	名称	权限	复位值	描述
31:0	RXDAW0	R	32'h0	RX data word 0



位	名称	权限	复位值	描述
---	----	----	-----	----

8.4.20 irrx_data_word1

地址: 0x4000a698

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	RXDAW1														
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	RXDAW1														

位	名称	权限	复位值	描述
31:0	RXDAW1	R	32'h0	RX data word 1

8.4.21 irrx_swm_fifo_config_0

地址: 0x4000a6c0

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	RSVD														
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
		RSVD					R	XFIFOCI	N			RXF	RXF	RSVD	RXF
													OF		CLR

位	名称	权限	复位值	描述
31:11	RSVD			
10:4	RXFIFOCN	R	7'd0	RX FIFO available count
3	RXFUF	R	1'b0	Underflow flag of RX FIFO, can be cleared by rx_fifo_clr
2	RXFOF	R	1'b0	Overflow flag of RX FIFO, can be cleared by rx_fifo_clr
1	RSVD			
0	RXFCLR	W1C	1'b0	Clear signal of RX FIFO



8.4.22 irrx_swm_fifo_rdata

地址: 0x4000a6c4

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	RSVD														
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	RXFRDA														

位	名称	权限	复位值	描述
31:16	RSVD			
15:0	RXFRDA	R	16'h0	IRRX Software Mode pulse width data

SPL

9.1 简介

串行外设接口(Serial Peripheral Interface Bus, SPI)是一种用于短程通信的同步串行通信接口规范,装置之间使用全双工模式通信,是一个主机和一个或多个从机的主从模式。需要至少 4 根线,事实上 3 根也可以(单向传输时),包括SDI(数据输入)、SDO(数据输出)、SCLK(时钟)、CS(片选)。

9.2 主要特征

- 既可作为 SPI 主设备,也可作为 SPI 从设备
- 发送和接收通道各有深度为 4 帧的 FIFO
- 主从设备都支持 4 种时钟格式 (CPOL, CPHA)
- 主从设备都支持 1/2/3/4 字节传输模式
- 灵活的时钟配置,最高可支持 40M 时钟
- 可配置 MSB/LSB 优先传输
- 接收过滤功能
- 从设备下的超时机制
- 支持 DMA 传输模式



9.3 功能描述

9.3.1 时钟控制

依照不同的时钟相位以及极性设定,SPI 时钟共有四种模式,可以通过寄存器 SPI_CONFIG 的 bit4(CPOL)和 bit5(CPHA)进行设置。CPOL 用来决定 SCK 时钟信号空闲时的电平,CPOL=0 则空闲电平为低电平,CPOL=1 则空闲电平为高电平。CPHA 用来决定采样时刻,CPHA=0 则在每个周期的第一个时钟沿采样,CPHA=1 则在每个周期的第二个时钟沿采样。通过设置寄存器 SPI_PRD_0 和 SPI_PRD_1,还可以调整时钟的开始和结束电平持续时间、相位 0/1 的时间以及每帧数据之间的间隔。四种模式下的具体设置如下图所示:




图 9.1: SPI 时序图

其中各数字含义如下: 1 是起始条件的长度, 2 是停止条件的长度, 3 是相位 0 的长度, 4 是相位 1 的长度, 5 是每帧数据之间的间隔。

9.3.2 主设备持续传输模式

开启该模式后,在发送完当前数据而 FIFO 里还存在可用数据时,CS 信号不会被释放。

9.3.3 接收过滤功能

通过设置需要过滤掉的开始位和结束位, SPI 会将接收到数据中的对应数据段丢弃。如下图所示:

BL702/704/706 参考手册 177/ 370 @2021 Bouffalo Lab






图 9.2: SPI Ignore 波形图

上图中过滤的开始位设为 0,结束位设为 7 则 Dummy Byte 会被收到,结束位设为 15 则 Dummy Byte 会被丢弃。

9.3.4 接收去差错功能

通过使能该功能和设置门限值, SPI 会将达不到门限值宽度的数据丢弃。

9.3.5 从模式超时机制

通过设定一个超时门限,当从模式下 SPI 超过该时间值未收到时钟信号时,会触发中断。

9.3.6 I/O 传输模式

芯片通信处理器可以响应来自 FIFO 的中断来执行 FIFO 填充和清空操作。每个 FIFO 都有一个可编程的 FIFO 触发阈值来触发中断。当 RX FIFO 中的数值超过 SPI 控制器 1 中的 RX FIFO 触发阈值时,将产生一个中断,向芯片通信处理器发送信号来清空 RX FIFO。当 TX FIFO 中的数值小于或等于 SPI 控制寄存器 1 中的 TX FIFO 触发阈值加 1 时,将产生中断,向芯片通信处理器发送信号来重新填充 TX FIFO。可以通过查询 SPI 状态寄存器来确定 FIFO 中的采样值以及 FIFO 的状态。软件负责确保正确的 RX FIFO 触发阈值和 TX FIFO 触发阈值,以防止接收 FIFO 超限和发送 FIFO 欠载。

9.3.7 DMA 传输模式

SPI 支持 DMA 传输模式。使用该模式需要分别设置 TX 和 RX FIFO 的阈值,当该模式启用后,UART 会对 TX/RX FIFO 进行检查,一旦 TX/RX 的 FIFO 可用计数值大于其设定的阈值,将会发起 DMA 请求,DMA 会按照设定将数据 搬移至 TX FIFO 中或从 RX FIFO 中移出。



9.3.8 SPI 中断

SPI 有着丰富的中断控制,包括以下几种中断模式:

- SPI 传输结束中断
- TX FIFO 请求中断
- RX FIFO 请求中断
- 从模式传输超时中断
- 从模式 TX 过载中断
- TX/RX FIFO 溢出中断

在主模式下,SPI 传输结束中断会在每帧数据传输结束时触发;在从模式下,SPI 传输结束中断会在 CS 信号被释放时触发。TX/RX FIFO 请求中断会在其 FIFO 可用计数值大于其设定的阈值时触发,当条件不满足时该中断标志会自动清除。从模式传输超时中断会在从模式下超过超时门限值未收到时钟信号时触发。如果 TX/RX FIFO 发生了上溢或者下溢,会触发 TX/RX FIFO 溢出中断,当 FIFO 清除位 TFC/RFC 被置 1 时,对应的 FIFO 会被清空,同时溢出中断标志会自动清除。可以通过寄存器 SPI_INT_STS 查询各中断状态和对相应的位写 1 清除中断。

9.4 寄存器描述

名称	描述					
spi_config	SPI configuration register					
spi_int_sts	SPI interrupt status					
spi_bus_busy	SPI bus busy					
spi_prd_0	PI length control register					
spi_prd_1	SPI length of interval					
spi_rxd_ignr	SPI ingnore function					
spi_sto_value	SPI time-out value					
spi_fifo_config_0	SPI FIFO configuration register0					
spi_fifo_config_1	SPI FIFO configuration register1					
spi_fifo_wdata	SPI FIFO write data					
spi_fifo_rdata	SPI FIFO read data					



9.4.1 spi_config

地址: 0x4000a200

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	RSVD														
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	DEGCNT				RSVD	MCEN	IGNR	BYTE	BIT	SCLK	SCLK	FS	IZE	SEN	MEN
				EN			EN	INV	INV	PH	POL				

位	名称	权限	复位值	描述
31:16	RSVD			
15:12	DEGCNT	R/W	4'd0	De-glitch function cycle count
11	DEGEN	R/W	1'b0	Enable signal of all input de-glitch function
10	RSVD			
9	MCEN	R/W	1'b0	Enable signal of master continuous transfer mode 1'b0: Disabled, SS_n will de-assert between each data frame 1'b1: Enabled, SS_n will stay asserted between each consecutive data frame if the next data is valid in the FIFO
8	IGNREN	R/W	1'b0	Enable signal of RX data ignore function
7	BYTEINV	R/W	1'b0	Byte-inverse signal for each FIFO entry data 0: Byte[0] is sent out first 1: Byte[3] is sent out first
6	BITINV	R/W	1'b0	Bit-inverse signal for each data byte 0: Each byte is sent out MSB-first 1: Each byte is sent out LSB-first
5	SCLKPH	R/W	1'b0	SCLK clock phase inverse signal
4	SCLKPOL	R/W	1'b0	SCLK polarity 0: SCLK output LOW at IDLE state 1: SCLK output HIGH at IDLE state
3:2	FSIZE	R/W	2'd0	SPI frame size (also the valid width for each FIFO entry) 2'd0: 8-bit 2'd1: 16-bit 2'd2: 24-bit 2'd3: 32-bit
1	SEN	R/W	1'b0	Enable signal of SPI Slave function, Master and Slave should not be both enabled at the same time (This bit becomes don't-care if cr_spi_m_en is enabled)

BL702/704/706 参考手册 180/ 370 @2021 Bouffalo Lab



位	名称	权限	复位值	描述
0	MEN	R/W	1'b0	Enable signal of SPI Master function Asserting this bit will trigger the transaction, and should be de-asserted after finish

9.4.2 spi_int_sts

地址: 0x4000a204

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
RS	SVD	FER	TXU	STO	RXF	TXF	END		RSVD		TXU	STO	RS	VD	END
		EN	EN	EN	EN	EN	EN				CLR	CLR			CLR
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
RS	SVD	FER	TXU	STO	RXF	TXF	END	RS	VD	FER	TXU	STO	RXF	TXF	END

位	名称	权限	复位值	描述
31:30	RSVD			
29	FEREN	R/W	1'b1	Interrupt enable of spi_fer_int
28	TXUEN	R/W	1'b1	Interrupt enable of spi_txu_int
27	STOEN	R/W	1'b1	Interrupt enable of spi_sto_int
26	RXFEN	R/W	1'b1	Interrupt enable of spi_rxv_int
25	TXFEN	R/W	1'b1	Interrupt enable of spi_txe_int
24	ENDEN	R/W	1'b1	Interrupt enable of spi_end_int
23:21	RSVD			
20	TXUCLR	W1C	1'b0	Interrupt clear of spi_txu_int
19	STOCLR	W1C	1'b0	Interrupt clear of spi_sto_int
18:17	RSVD			
16	ENDCLR	W1C	1'b0	Interrupt clear of spi_end_int
15:14	RSVD			
13	FERMASK	R/W	1'b1	Interrupt mask of spi_fer_int
12	TXUMASK	R/W	1'b1	Interrupt mask of spi_txu_int
11	STOMASK	R/W	1'b1	Interrupt mask of spi_sto_int
10	RXFMASK	R/W	1'b1	Interrupt mask of spi_rxv_int
9	TXFMASK	R/W	1'b1	Interrupt mask of spi_txe_int
8	ENDMASK	R/W	1'b1	Interrupt mask of spi_end_int



位	名称	权限	复位值	描述
7:6	RSVD			
5	FERINT	R	1'b0	SPI TX/RX FIFO error interrupt, auto-cleared when FIFO overflow/underflow error flag is cleared
4	TXUINT	R	1'b0	SPI slave mode TX underrun error flag, triggered when TXD is not ready during transfer in slave mode
3	STOINT	R	1'b0	SPI slave mode transfer time-out interrupt, triggered when SPI bus is idle for a given value
2	RXFINT	R	1'b0	SPI RX FIFO ready (rx_fifo_cnt > rx_fifo_th) interrupt, auto- cleared when data is popped
1	TXFINT	R	1'b0	SPI TX FIFO ready (tx_fifo_cnt > tx_fifo_th) interrupt, auto- cleared when data is pushed
0	ENDINT	R	1'b0	SPI transfer end interrupt, shared by both master and slave mode Master mode: Triggered when the final frame is transferred Slave mode: Triggered when CS_n is de-asserted

9.4.3 spi_bus_busy

地址: 0x4000a208

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
							RS	VD							
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
		•			•		RSVD				•				BUS
															BUSY

位	名称	权限	复位值	描述
31:1	RSVD			
0	BUSBUSY	R	1'b0	Indicator of SPI bus busy



9.4.4 spi_prd_0

地址: 0x4000a210

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	
			PRD	PH1							PRD	PH0				
15	15 14 13 12 11 10 9 8							7	6	5	4	3	2	1	0	
	PRDP									PRDS						

位	名称	权限	复位值	描述
31:24	PRDPH1	R/W	8'd15	Length of DATA phase 1 (please refer to "Timing" tab)
23:16	PRDPH0	R/W	8'd15	Length of DATA phase 0 (please refer to "Timing" tab)
15:8	PRDP	R/W	8'd15	Length of STOP condition (please refer to "Timing" tab)
7:0	PRDS	R/W	8'd15	Length of START condition (please refer to "Timing" tab)

9.4.5 spi_prd_1

地址: 0x4000a214

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
							RS	VD							
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	RSVD								PRDI						

位	名称	权限	复位值	描述
31:8	RSVD			
7:0	PRDI	R/W	8'd15	Length of INTERVAL between frame (please refer to "Timing" tab)

9.4.6 spi_rxd_ignr

地址: 0x4000a218

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16		
	RSVD											RXDIGS					
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0		
	RSVD												RXDIGP				



位	名称	权限	复位值	描述
31:21	RSVD			
20:16	RXDIGS	R/W	5'd0	Starting point of RX data ignore function
15:5	RSVD			
4:0	RXDIGP	R/W	5'd0	Stopping point of RX data ignore function

9.4.7 spi_sto_value

地址: 0x4000a21c

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	RSVD														
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
RSVD STOV															

位	名称	权限	复位值	描述
31:12	RSVD			
11:0	STOV	R/W	12'hFFF	Time-out value for spi_sto_int triggering

9.4.8 spi_fifo_config_0

地址: 0x4000a280

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
							RS	VD							
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
			RS	SVD				RFUF	RFOF	TFUF	TFOF	RFC	TFC	DMAR	DMAT
														EN	EN

位	名称	权限	复位值	描述
31:8	RSVD			
7	RFUF	R	1'b0	Underflow flag of RX FIFO, can be cleared by rx_fifo_clr
6	RFOF	R	1'b0	Overflow flag of RX FIFO, can be cleared by rx_fifo_clr
5	TFUF	R	1'b0	Underflow flag of TX FIFO, can be cleared by tx_fifo_clr
4	TFOF	R	1'b0	Overflow flag of TX FIFO, can be cleared by tx_fifo_clr
3	RFC	W1C	1'b0	Clear signal of RX FIFO



位	名称	权限 复位值		描述
2	TFC	W1C	1'b0	Clear signal of TX FIFO
1	DMAREN	R/W	1'b0	Enable signal of dma_rx_req/ack interface
0	DMATEN	R/W	1'b0	Enable signal of dma_tx_req/ack interface

9.4.9 spi_fifo_config_1

地址: 0x4000a284

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	
	RSVD					RF	TH	RSVD							TFTH	
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	
	RSVD					RFCNT				RSVD				TFCNT		

位	名称	权限	复位值	描述
31:26	RSVD			
25:24	RFTH	R/W	2'd0	RX FIFO threshold, dma_rx_req will not be asserted if tx fifo_cnt is less than this value
23:18	RSVD			
17:16	TFTH	R/W	2'd0	TX FIFO threshold, dma_tx_req will not be asserted if tx fifo_cnt is less than this value
15:11	RSVD			
10:8	RFCNT	R	3'd0	RX FIFO available count
7:3	RSVD			
2:0	TFCNT	R	3'd4	TX FIFO available count

9.4.10 spi_fifo_wdata

地址: 0x4000a288

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
							FWD	ATA							
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
							FWD	ATA							

BL702/704/706 参考手册 185/ 370 @2021 Bouffalo Lab



位	名称	权限 复位值		描述
31:0	FWDATA	W	х	SPI FIFO write data

9.4.11 spi_fifo_rdata

地址: 0x4000a28c

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	FRDATA														
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	FRDATA														

位	名称	权限	复位值	描述
31:0	FRDATA	R	32'h0	SPI FIFO read data

BL702/704/706 参考手册 186/ 370 @2021 Bouffalo Lab

10.1 简介

通用异步收发传输器(Universal Asynchronous Receiver/Transmitter,通常称为 UART)是一种异步收发传输器,提供了与外部设备进行全双工数据交换的灵活方式。BL70x 共有 2 组 UART 口(UART0 和 UART1),通过配合 DMA 使用,可以实现高效的数据通信。

10.2 主要特征

- 全双工异步通信
- 数据位长度可选择 5/6/7/8 比特
- 停止位长度可选择 0.5/1/1.5/2 比特
- 支持奇/偶/无校验比特
- 可侦测错误的起始比特
- 支持 LIN 协议(收发 BREAK/SYNC)
- 丰富的中断控制
- 支持硬件流控(RTS/CTS)
- 便捷的波特率编程
- 可配置 MSB/LSB 优先传输
- 普通/固定字符的自动波特率检测
- 128 字节发送/接收 FIFO
- · 支持 DMA 传输模式



10.3 功能描述

10.3.1 数据格式描述

正常的 UART 通信数据是由起始位、数据位、奇偶校验位、停止位组成的。BL70x 的 UART 支持可配置的数据位、奇偶校验位和停止位,这些都在寄存器 UTX CONFIG 和 URX CONFIG 中设置。一帧数据的波形如下图所示:




图 10.1: UART 数据格式

数据帧的起始位占用 1-bit,停止位可以通过配置 <TXBCNTP> 和 <CR_URX_BIT_CNT_P> 实现 0.5/1/1.5/2 位宽。起始位为低电平,停止位为高电平。数据位宽可以通过 <TXBCNTD> 和 <RXBCNTD> 配置为 5/6/7/8 位宽。当置位 <TXPREN> 和 <RXPREN> 时,数据帧会在数据之后添加一位奇偶校验位。<TXPRSEL> 和 <RXPRSEL> 用于选择 奇校验还是偶校验。当接收器检测到输入数据的校验位错误时会产生校验错误中断。奇校验的计算方法:如果当前数据位 1 的个数是奇数个,奇校验位为 0;反之为 1。偶校验的计算方法:如果当前数据位 1 的个数是奇数个,偶校验位为 1;反之为 0。

10.3.2 基本架构图

10.3.3 时钟源

UART 有两个时钟源: 96MHz PLL_CLK 以及 FCLK。时钟中的分频器用于对时钟源进行分频,然后产生时钟信号来驱动 UART 模块。如下图所示:




图 10.2: UART 时钟

BL702/704/706 参考手册 188/ 370 @2021 Bouffalo Lab



10.3.4 波特率设定

使用者可通过设置寄存器 UART_BIT_PRD 来产生所需的波特率,该寄存器的高 16 位和低 16 位分别对应 RX 与 TX,即 RX 与 TX 的波特率可单独进行设置,该 16 位值需要通过计算得出,公式如下: 波特率 = UART 时钟/(16 位系数 +1)即: 16 位系数 = UART 时钟/波特率-1 该 16 位系数的含义是以 UART 时钟去计数当前波特率位宽所得到的计数值。由于 16 位系数最大值为 65535,所以 UART 支持的最小波特率为: UART 时钟/65536。UART 支持的最大波特率为 10Mbps。在 UART 对数据进行采样之前,会先对数据进行滤波,将波形当中的毛刺滤掉。然后会在上述 16 位系数的中间值时刻进行采样,这样根据不同的波特率调整不同的采样时刻,以保持其采到的始终是中间值,大大提高了灵活性与精度。采样过程如下图所示:




图 10.3: UART 采样波形图

10.3.5 发送器

发送器包含一个 128 字节的发送 FIFO,用来存放待发送的数据。软件可以通过 APB 总线写 TX FIFO,也可以通过 DMA 将数据搬入 TX FIFO。当发送使能位被设置时,FIFO 中存放的数据会从 TX 引脚输出。软件可以选择通过 DMA 或 APB 总线这两种方式将数据传入 TX FIFO。软件可以通过寄存器 UART_FIFO_CONFIG_1 的位 <TFICNT> 查询 TX FIFO 剩余可用空间计数值来检查发送器的状态。发送器的自由运行(FreeRun)模式如下:

- 如果没有开启自由运行(FreeRun)模式,则当发送字节达到指定长度时发送行为终止并产生中断,如果要继续发送则需重新关闭再使能发送使能位。
- 如果开启自由运行(FreeRun)模式,则当 TX FIFO 里存在数据时,发送器就会进行发送,不会因为发送字节达到指定长度而终止。

BL702/704/706 参考手册 189/ 370 @2021 Bouffalo Lab



10.3.6 接收器

接收器包含一个 128 字节的接收 FIFO,用来存放接收到的数据。软件可以通过寄存器 UART_FIFO_CONFIG_1 的位 <RFICNT> 查询 RX FIFO 可用数据计数值来检查接收器的状态。寄存器 URX_RTO_TIMER 的低 8 位用于设定一个接收超时门限,当接收器超过该时间值未收到数据时,会触发中断。寄存器 URX_CONFIG 的位 <DEGEN> 和 <DEGCNT> 用于使能去毛刺功能和设置门限值,其控制的是 UART 采样之前的滤波部分,UART 会将波形当中宽度低于门限值的毛刺滤掉,然后再将其送去采样。

10.3.7 自动波特率检测

UART 模块支持自动波特率检测,该检测分为两种,一种是通用模式,一种是固定字符模式。置位寄存器 URX_CONFIG 的位 <ABREN>每次开启时,这两种检测模式都会启用。

通用模式

对于所接收到的任意字符数据,UART 模块会计数起始位宽当中的时钟数,此数字会接着被写入寄存器 STS_URX_-ABR_PRD 的低 16 位并用以计算波特率,因此当最先接收到的数据位为 1 时即可得到正确的波特率,如 LSB-FIRST下的'0x01'。

固定字符模式

该模式下, UART 模块在计数起使位宽当中的时钟数后, 会继续计数后续数据位的时钟数, 并与起始位相比较, 如果上下浮动在允许误差范围内, 则通过检测, 否则计数值会被丢弃。因此, 只有在 LSB-FIRST 下接收到固定字符'0x55'/'0xD5'或 MSB-FIRST 下的'0xAA'/'0xAB'时, UART 模块才会将起使位宽当中的时钟数计数值写入寄存器 STS_URX_ABR_-PRD 的高 16 位。如下图所示:




图 10.4: UART 固定字符模式波形图

对于某一未知的波特率, UART 用 UART_CLK 去计数起始位的位宽为 1000, 第二位的位宽为 1001, 与前一位宽上下 浮动不超过 4 个 UART_CLK,则 UART 会继续计数第三位,第三位为 1005, 与起始位相差超过 4,则检测不通过,数据丢弃。UART 会依次将数据位的前 6 位位宽与起始位进行比较。

计算检测到的波特率的公式如下:波特率 = 源时钟/(16 位检测值 +1)

BL702/704/706 参考手册 190/ 370 @2021 Bouffalo Lab



10.3.8 硬件流控

UART 支持 CTS/RTS 方式的硬件流控,以防止 FIFO 里的数据由于来不及处理而丢失。硬件流控连接如下图所示:




图 10.5: UART 硬件流控图

当使用硬件流控功能时,输出信号 RTS 为低电平表示请求对方发送数据,RTS 为高电平表示通知对方中止数据发送 直到 RTS 恢复为低电平。发送器的硬件流控有两种方式。

- 寄存器 URX_CONFIG 的位 <RTSSWM> 等于 0: 当 RX FIFO 中的剩余空间小于等于 1 字节时拉高 RTS 的电平。
- 寄存器 URX_CONFIG 的位 <RTSSWM> 等于 1: 可以通过配置寄存器 URX_CONFIG 的位 <RTSSWV> 改变 RTS 的电平。

通过配置寄存器 UTX_CONFIG 的位 <CTSEN>,可以使能 TX CTS。当设备检测到输入信号 CTS 拉高时,TX 会停止 发送数据,直到检测到 CTS 拉低时再继续发送。

10.3.9 LIN 传输模式

当发送器需使用 LIN 传输模式时,可以通过配置 <TXLINEN> 来送出间隔 (BREAK) 栏位以及同步 (SYNC) 栏位,间隔栏位的宽度由 <TXBCNTB> 决定。而当接收器需使用 LIN 传输模式时,则可以通过配置 <RXLINEN> 来检测间隔栏位以及同步栏位,并在同步栏位格式错误时触发对应的中断 <RLSEINT>。

10.3.10 DMA 传输模式

UART 支持 DMA 传输模式。使用该模式需要通过寄存器 UART_FIFO_CONFIG_1 的位 <TFITH> 和 <RFITH> 分别设置 TX 和 RX FIFO 的阈值,当该模式启用后,UART 会对 TX/RX FIFO 进行检查,一旦 TX/RX 的 FIFO 可用计数值大于其设定的阈值,将会发起 DMA 请求,DMA 会按照设定将数据搬移至 TX FIFO 中或从 RX FIFO 中移出。

10.3.11 UART 中断

UART 有着丰富的中断控制,包括以下几种中断模式:

- TX 传输结束中断
- RX 传输结束中断
- TX FIFO 请求中断

BL702/704/706 参考手册 191/ 370 @2021 Bouffalo Lab



- RX FIFO 请求中断
- RX 超时中断
- RX 奇偶校验错误中断
- TX FIFO 溢出中断
- RX FIFO 溢出中断
- RX LIN 模式同步栏位(SYNC Field)错误中断

TX 和 RX 可以通过寄存器 UTX_CONFIG 和 URX_CONFIG 的高 16 位分别设置一个传输长度值,当传输的字节数 达到这个数值时,就会触发对应的 TX/RX 传输结束中断。TX/RX FIFO 请求中断会在其 FIFO 可用计数值大于寄存器 UART_FIFO_CONFIG_1 中所设定的阈值时触发,当条件不满足时该中断标志会自动清除。RX 超时中断会在接收器 超过超时门限值未收到数据时触发,而 RX 奇偶校验错误中断会发生在奇偶校验出错时。如果 TX/RX FIFO 发生了上 溢或者下溢,会触发对应的溢出中断,当 FIFO 清除位 TFICLR/RFICLR 被置 1 时,对应的 FIFO 会被清空,同时溢出中断标志会自动清除。当启用 LIN 模式时,同步栏位 (SYNC Field) 依协议应为 0x55,因此当接收到的数据非 0x55 时,即触发同步栏位错误中断。可以通过寄存器 UART_INT_STS 查询各中断状态,通过向寄存器 UART_INT_CLEAR 相应的位写 1 清除中断。

10.4 寄存器描述

名称	描述
utx_config	UART TX configuration register
urx_config	UART RX configuration register
uart_bit_prd	UART period control register
data_config	UART data configuration register
utx_ir_position	UART TX ir position control register
urx_ir_position	UART RX ir position control register
urx_rto_timer	RTO interrupt control register
uart_sw_mode	UART SW mode configuration register
uart_int_sts	UART interrupt status
uart_int_mask	UART interrupt mask
uart_int_clear	UART interrupt clear
uart_int_en	UART interrupt enable
uart_status	UART status control register
sts_urx_abr_prd	Auto baud detection control register
uart_fifo_config_0	UART FIFO configuration register0

BL702/704/706 参考手册 192/ 370 @2021 Bouffalo Lab



名称	描述
uart_fifo_config_1	UART FIFO configuration register1
uart_fifo_wdata	UART FIFO write data
uart_fifo_rdata	UART FIFO read data

10.4.1 utx_config

地址: 0x4000a000

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
							EN								
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	TXBCNTF)	ТХВС	CNTP	7	TXBCNTD			IRTX	TXPR	TXPR	TLIN	FRM	CTS	EN
								INV	EN	SEL	EN	EN	EN	EN	

位	名称	权限	复位值	描述
31:16	TXLEN	R/W	16'd0	Length of UART TX data transfer (Unit: character/byte) (Don't-care if cr_utx_frm_en is enabled)
15:13	TXBCNTP	R/W	3'd4	UART TX BREAK bit count (for LIN protocol) Note: Additional 8 bit times will be added since LIN Break field requires at least 13 bit times
12:11	TXBCNTP	R/W	2'd1	UART TX STOP bit count (unit: 0.5 bit)
10:8	TXBCNTD	R/W	3'd7	UART TX DATA bit count for each character
7	IRTXINV	R/W	1'b0	Inverse signal of UART TX output in IR mode
6	IRTXEN	R/W	1'b0	Enable signal of UART TX IR mode
5	TXPRSEL	R/W	1'b0	Select signal of UART TX parity bit 1: Odd parity 0: Even parity
4	TXPREN	R/W	1'b0	Enable signal of UART TX parity bit
3	TLINEN	R/W	1'b0	Enable signal of UART TX LIN mode (LIN header will be sent before sending data)
2	FRMEN	R/W	1'b0	Enable signal of UART TX freerun mode (utx_end_int will be disabled)
1	CTSEN	R/W	1'b0	Enable signal of UART TX CTS flow control function

BL702/704/706 参考手册 193/ 370 @2021 Bouffalo Lab



位	名称	权限	复位值	描述
0	EN	R/W	1'b0	Enable signal of UART TX function Asserting this bit will trigger the transaction, and should be de-asserted after finish

10.4.2 urx_config

地址: 0x4000a004

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
							RXI	_EN							
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	DEG	CNT		DEG	F	RXBCNTD			IRRX	RXPR	RXPR	RLIN	RSVD	ABR	EN
				EN				INV	EN	SEL	EN	EN		EN	

位	名称	权限	复位值	描述
31:16	RXLEN	R/W	16'd0	Length of UART RX data transfer (Unit: character/byte) urx_end_int will assert when this length is reached
15:12	DEGCNT	R/W	4'd0	De-glitch function cycle count
11	DEGEN	R/W	1'b0	Enable signal of RXD input de-glitch function
10:8	RXBCNTD	R/W	3'd7	UART RX DATA bit count for each character
7	IRRXINV	R/W	1'b0	Inverse signal of UART RX input in IR mode
6	IRRXEN	R/W	1'b0	Enable signal of UART RX IR mode
5	RXPRSEL	R/W	1'b0	Select signal of UART RX parity bit 1: Odd parity 0: Even parity
4	RXPREN	R/W	1'b0	Enable signal of UART RX parity bit
3	RLINEN	R/W	1'b0	Enable signal of UART RX LIN mode (LIN header will be required and checked before receiving data)
2	RSVD			
1	ABREN	R/W	1'b0	Enable signal of UART RX Auto Baud Rate detection function
0	EN	R/W	1'b0	Enable signal of UART RX function

BL702/704/706 参考手册 194/ 370 @2021 Bouffalo Lab



10.4.3 uart_bit_prd

地址: 0x4000a008

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	RBITPRD														
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	TBITPRD														

位	名称	权限	复位值	描述
31:16	RBITPRD	R/W	16'd255	Period of each UART RX bit, related to baud rate
15:0	TBITPRD	R/W	16'd255	Period of each UART TX bit, related to baud rate

10.4.4 data_config

地址: 0x4000a00c

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	RSVD														
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
							RSVD								BIT
															INV

位	名称	权限	复位值	描述
31:1	RSVD			
0	BITINV	R/W	1'b0	Bit-inverse signal for each data byte 0: Each byte is sent out LSB-first 1: Each byte is sent out MSB-first

10.4.5 utx_ir_position

地址: 0x4000a010

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	TXIRPP														
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	TXIRPS														

BL702/704/706 参考手册 195/ 370 @2021 Bouffalo Lab



位	名称	权限	复位值	描述
31:16	TXIRPP	R/W	16'd159	STOP position of UART TX IR pulse
15:0	TXIRPS	R/W	16'd112	START position of UART TX IR pulse

10.4.6 urx_ir_position

地址: 0x4000a014

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	RSVD														
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	RXIRPS														

位	名称	权限	复位值	描述
31:16	RSVD			
15:0	RXIRPS	R/W	16'd111	START position of UART RXD pulse recovered from IR signal

10.4.7 urx_rto_timer

地址: 0x4000a018

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	RSVD														
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	RSVD														

位	名称	权限	复位值	描述
31:8	RSVD			
7:0	RXRTOVA	R/W	8'd15	Time-out value for triggering RTO interrupt (unit: bit time)

BL702/704/706 参考手册 196/ 370 @2021 Bouffalo Lab



10.4.8 uart_sw_mode

地址: 0x4000a01c

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
RSVD															
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	RSVD											RRV	RRM	TTV	TTM

位	名称	权限	复位值	描述
31:4	RSVD			
3	RRV	R/W	1'b0	UART RX RTS output SW control value
2	RRM	R/W	1'b0	UART RX RTS output SW control mode
1	TTV	R/W	1'b0	UART TX TXD output SW control value
0	TTM	R/W	1'b0	UART TX TXD output SW control mode

10.4.9 uart_int_sts

地址: 0x4000a020

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
							RS	VD							
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
			RSVD				RLSE	RFER	TFIN	RPCE	RRTO	RFIN	TFIN	REIN	TEIN
							INT	INT		INT	INT				

位	名称	权限	复位值	描述
31:9	RSVD			
8	RLSEINT	R	1'b0	UART RX LIN mode sync field error interrupt
7	RFERINT	R	1'b0	UART RX FIFO error interrupt, auto-cleared when FIFO overflow/underflow error flag is cleared
6	TFIN	R	1'b0	UART TX FIFO error interrupt, auto-cleared when FIFO overflow/underflow error flag is cleared
5	RPCEINT	R	1'b0	UART RX parity check error interrupt
4	RRTOINT	R	1'b0	UART RX Time-out interrupt
3	RFIN	R	1'b0	UART RX FIFO ready (rx_fifo_cnt > rx_fifo_th) interrupt, auto-cleared when data is popped



位	名称	权限	复位值	描述
2	TFIN	R	1'b0	UART TX FIFO ready (tx_fifo_cnt > tx_fifo_th) interrupt, auto-cleared when data is pushed
1	REIN	R	1'b0	UART RX transfer end interrupt (set according to cr_urxlen)
0	TEIN	R	1'b0	UART TX transfer end interrupt (set according to cr_utxlen)

10.4.10 uart_int_mask

地址: 0x4000a024

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
							RS	VD							
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
		RSVD		RLSE	RFER	TFER	RPCE	RRTO	RFMS	TFMS	REMS	TEMS			
							MASK	MASK	MASK	MASK	MASK				

位	名称	权限	复位值	描述
31:9	RSVD			
8	RLSEMASK	R/W	1'b1	Interrupt mask of urx_lse_int
7	RFERMASK	R/W	1'b1	Interrupt mask of urx_fer_int
6	TFERMASK	R/W	1'b1	Interrupt mask of utx_fer_int
5	RPCEMASK	R/W	1'b1	Interrupt mask of urx_pce_int
4	RRTOMASK	R/W	1'b1	Interrupt mask of urx_rto_int
3	RFMS	R/W	1'b1	Interrupt mask of urx_fifo_int
2	TFMS	R/W	1'b1	Interrupt mask of utx_fifo_int
1	REMS	R/W	1'b1	Interrupt mask of urx_end_int
0	TEMS	R/W	1'b1	Interrupt mask of utx_end_int

BL702/704/706 参考手册 198/ 370 @2021 Bouffalo Lab



10.4.11 uart_int_clear

地址: 0x4000a028

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
							RS	VD							
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	RSVD							RS	VD	RPCE CLR	RRTO CLR	RS	VD	RECL	TECL

位	名称	权限	复位值	描述
31:9	RSVD			
8	RLSECLR	W1C	1'b0	Interrupt clear of urx_lse_int
7:6	RSVD			
5	RPCECLR	W1C	1'b0	Interrupt clear of urx_pce_int
4	RRTOCLR	W1C	1'b0	Interrupt clear of urx_rto_int
3:2	RSVD			
1	RECL	W1C	1'b0	Interrupt clear of urx_end_int
0	TECL	W1C	1'b0	Interrupt clear of utx_end_int

10.4.12 uart_int_en

地址: 0x4000a02c

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
							RS	VD							
15	15 14 13 12 11 10 9 8 7 6 5 4 3 2 1 0										0				
	RSVD							RFER	TFER	RPCE	RRTO	RFIF	TFIF	REND	TEND

位	名称	权限	复位值	描述
31:9	RSVD			
8	RLSE	R/W	1'b1	Interrupt enable of urx_lse_int
7	RFER	R/W	1'b1	Interrupt enable of urx_fer_int
6	TFER	R/W	1'b1	Interrupt enable of utx_fer_int
5	RPCE	R/W	1'b1	Interrupt enable of urx_pce_int
4	RRTO	R/W	1'b1	Interrupt enable of urx_rto_int
3	RFIF	R/W	1'b1	Interrupt enable of urx_fifo_int



位	名称	权限	复位值	描述
2	TFIF	R/W	1'b1	Interrupt enable of utx_fifo_int
1	REND	R/W	1'b1	Interrupt enable of urx_end_int
0	TEND	R/W	1'b1	Interrupt enable of utx_end_int

10.4.13 uart_status

地址: 0x4000a030

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	RSVD														
15	15 14 13 12 11 10 9 8 7 6 5 4 3 2										2	1	0		
	RSVD										RBB	ТВВ			

位	名称	权限	复位值	描述
31:2	RSVD			
1	RBB	R	1'b0	Indicator of UART RX bus busy
0	TBB	R	1'b0	Indicator of UART TX bus busy

10.4.14 sts_urx_abr_prd

地址: 0x4000a034

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	ABRPRD														
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	ABRPRDS														

位	名称	权限	复位值	描述
31:16	ABRPRD	R	16'd0	Bit period of Auto Baud Rate detection using codeword 0x55
15:0	ABRPRDS	R	16'd0	Bit period of Auto Baud Rate detection using START bit

BL702/704/706 参考手册 200/ 370 @2021 Bouffalo Lab



10.4.15 uart_fifo_config_0

地址: 0x4000a080

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
							RS	VD							
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	RSVD								RFIO	TFIU	TFIO	RFI	TFI	UDR	UDT
												CLR	CLR	EN	EN

位	名称	权限	复位值	描述
31:8	RSVD			
7	RFIU	R	1'b0	Underflow flag of RX FIFO, can be cleared by rx_fifo_clr
6	RFIO	R	1'b0	Overflow flag of RX FIFO, can be cleared by rx_fifo_clr
5	TFIU	R	1'b0	Underflow flag of TX FIFO, can be cleared by tx_fifo_clr
4	TFIO	R	1'b0	Overflow flag of TX FIFO, can be cleared by tx_fifo_clr
3	RFICLR	W1C	1'b0	Clear signal of RX FIFO
2	TFICLR	W1C	1'b0	Clear signal of TX FIFO
1	UDREN	R/W	1'b0	Enable signal of dma_rx_req/ack interface
0	UDTEN	R/W	1'b0	Enable signal of dma_tx_req/ack interface

10.4.16 uart_fifo_config_1

地址: 0x4000a084

31	30 29 28 27 26 25 24								22	21	20	19	18	17	16
RSVD				RFITH				RSVD TFITH							
15	14	14 13 12 11 10 9 8							7 6 5 4 3 2 1 0						0
	RFICNT										TFI	CNT			

位	名称	权限	复位值	描述
31	RSVD			
30:24	RFITH	R/W	7'd0	RX FIFO threshold, dma_rx_req will not be asserted if tx fifo_cnt is less than this value
23	RSVD			
22:16	TFITH	R/W	7'd0	TX FIFO threshold, dma_tx_req will not be asserted if tx fifo_cnt is less than this value



位	名称	权限	复位值	描述
15:8	RFICNT	R	8'd0	RX FIFO available count
7:0	TFICNT	R	8'd128	TX FIFO available count

10.4.17 uart_fifo_wdata

地址: 0x4000a088

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
							RS	VD							
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	RSVD										UFI	WD			

位	名称	权限	复位值	描述
31:8	RSVD			
7:0	UFIWD	W	Х	UART FIFO write data

10.4.18 uart_fifo_rdata

地址: 0x4000a08c

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
RSVD															
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	RSVD										UFI	RD			

位	名称	权限	复位值	描述
31:8	RSVD			
7:0	UFIRD	R	8'h0	UART FIFO read data

BL702/704/706 参考手册 202/ 370 @2021 Bouffalo Lab

11.1 简介

I2C (Inter-Intergrated Circuit) 是一种串行通讯总线,使用多主从架构,用来连接低速外围装置。每个器件都有一个唯一的识别地址,并且都可以作为一个发送器或接收器。如果有两个或多个主机同时初始化,数据传输可以通过冲突检测和仲裁防止数据被破坏。BL702 包含一个 I2C 控制器主机,可灵活配置 slaveAddr、subAddr 以及传输数据,方便与从设备通信,提供 2 个 word 深度的 fifo,提供中断功能,可搭配 DMA 使用提高效率,可灵活调整时钟频率。

11.2 主要特征

- 支持主机模式
- 支持多主机模式和仲裁功能
- 时钟频率可灵活调整

11.3 功能描述

引脚列表:

表 11.1: I2C 引脚

名称	类型	描述
I2Cx_SCL	输入/输出	I2C 串行时钟信号
I2Cx_SDA	输入/输出	I2C 串行数据信号



11.3.1 起始和停止条件

所有传输都由起始条件 (START condition) 开始,以停止条件 (STOP condition) 结束。起始条件和停止条件一般都由 主机产生,总线在起始条件后被认为处于总线忙的状态,在停止条件后的某段时间内被认为处于空闲状态。

起始条件:SCL 为高电平时 SDA 产生一高至低的电平转换;

停止条件:SCL 为高电平时 SDA 产生一低至高的电平转换。

波形示意图如下:




图 11.1: I2C 起始和停止条件

11.3.2 数据传输格式

传输的第一个 8 位为寻址字节,包括 7 位从机地址和 1 位方向位。数据由主机发送或接收是由主机所送出的第 1 个字节的第 8 位控制,若为 0 表示数据由主机发送;为 1 则表示数据由主机接收,紧接着从机发出应答位 (ACK),在数据传输完成后,主机发出停止信号,波形图如下:




图 11.2: I2C 数据传输格式

主发送和从接收的时序

BL702/704/706 参考手册 204/ 370 @2021 Bouffalo Lab






图 11.3: 主发送和从接收的时序

主接收和从发送的时序




图 11.4: 主接收和从发送的时序

11.3.3 仲裁

当 I2C 总线存在多个主机时,可能会发生多个主机同时启动传输的情况,此时必须要依靠仲裁机制来决定哪个主机有权利完成接下来的数据传输,其余主机则须放弃对总线的控制,等到总线再次空出来后才能重新启动传输。

在传输过程中,所有主机都需要在 SCL 为高电平时检查 SDA 是否与自己所想送出的资料相符,当 SDA 电平与预期不同时,表示有别的主机也在同时进行传输,而发现 SDA 电平不同的主机则失去此次仲裁,由其他主机完成数据传输。

两主机同时传输数据并启动仲裁机制的波形示意图如下:

BL702/704/706 参考手册 205/ 370 @2021 Bouffalo Lab






图 11.5: 同时传输数据波形示意图

11.4 I2C 时钟设定

I2C 的时钟是由 bclk(bus clock) 而来,可以在 bclk 时钟的基础上做分频处理。寄存器 I2C_PRD_DATA 可以对数据段的时钟做分频处理。i2c 模块将数据发送分为 4 个阶段,每个阶段在寄存器中用单独一个字节来控制,每个阶段的采样个数是可以设置的,4 个采样数共同决定了 i2c clock 的分频系数。比如现在 bclk 是 32M,寄存器 I2C_PRD_DATA 在不做配置默认情况下的值是 0x0f0f0f0f,那么 I2C 的时钟频率为 32M/((15 + 1) * 4) = 500K。同理,寄存器 I2C_PRD_START和 I2C PRD_STOP 也会分别对起始位和停止位的时钟做分频处理。

11.5 I2C 配置流程

11.5.1 配置项

- 读写标志位
- 从设备地址
- 从设备寄存器地址
- 从设备寄存器地址长度
- 数据 (发送时,配置发送的数据;接收时,存储接收到的数据)
- 数据长度
- 使能信号



11.5.2 读写标志位

I2C 支持发送和接收两种工作状态,寄存器 PKTDIR 表示发送或者接收状态,设置为 0 时,表示发送状态,设置为 1 时,表示接收状态。

11.5.3 从设备地址

每个对接 I2C 的从设备,都会有唯一设备地址,通常该地址是 7 位长度,将从设备地址写入寄存器 SLVADDR,I2C 在将从设备地址发送出去之前,会自动左移 1 位,并在最低位补上发送接收方向位。

11.5.4 从设备寄存器地址

从设备寄存器地址表示 I2C 需要对从设备某个寄存器做读写操作的寄存器地址。将从设备寄存器地址写入寄存器 I2C_SUB_ADDR,同时需要将寄存器 SAEN 置 1。如果将寄存器 SAEN 置 0,那么 I2C 主机发送时会跳过从设备寄存器地址段。

11.5.5 从设备寄存器地址长度

将从设备寄存器地址长度减 1 再写入寄存器 SABC。

11.5.6 数据

数据部分表示需要发送到从设备的数据,或者需要从从设备接收的数据。当 I2C 发送数据时,需要将数据依次以 word 为单位写入 I2C FIFO,发送数据写 FIFO 的寄存器地址 I2C_FIFO_WDATA。当 I2C 接收数据时,需要依次以 word 为单位从 I2C FIFO 中将数据读出来,接收数据读 FIFO 的寄存器地址 I2C_FIFO_RDATA。

11.5.7 数据长度

将数据长度减 1 再写入寄存器 PKTLEN。

11.5.8 使能信号

将以上几项配置完成后,再将使能信号寄存器 MEN 写 1,就自动启动 I2C 发送流程了。

当读写标志位配置为 0 时, I2C 发送数据, 主机发送流程:

- 1. 起始位
- 2. (从设备地址左移 1 位 + 0) + ACK
- 3. 从设备寄存器地址 + ACK
- 4. 1 字节数据 + ACK
- 5. 1 字节数据 + ACK
- 6. 停止位



当读写标志位配置为 1 时, I2C 接收数据, 主机发送流程:

- 1. 起始位
- 2. (从设备地址左移 1 位 + 0) + ACK
- 3. 从设备寄存器地址 + ACK
- 4. 起始位
- 5. (从设备地址左移 1 位 + 1) + ACK
- 6. 1字节数据 + ACK
- 7. 1 字节数据 + ACK
- 8. 停止位

11.6 FIFO 管理

I2C FIFO 深度为 2 个 word, I2C 发送和接收可分为 RX FIFO 和 TX FIFO。寄存器 RFICNT 表示 RX FIFO 中有多少数据 (单位 word) 需要读取。寄存器 TFICNT 表示 TX FIFO 中剩余多少空间 (单位 Word) 可供写入。

I2C FIFO 状态:

- RX FIFO underflow: 当 RX FIFO 中的数据被读取完毕或者为空时,继续从 RX FIFO 中读取数据,寄存器 RFIU 会被置位:
- RX FIFO overflow: 当 I2C 接收数据直到 RX FIFO 的 2 个 word 被填满后,在没有读取 RX FIFO 的情况下, I2C 再次接收到数据,寄存器 RFIO 会被置位;
- TX FIFO underflow: 当向 TX FIFO 中填入的数据大小不满足配置的 I2C 数据长度 PKTLEN,并且已经没有新数据 继续填入 TX FIFO 中时,寄存器 TFIU 会被置位;
- TX FIFO overflow: 当 TX FIFO 的 2 个 word 被填满后,在 TX FIFO 中的数据没有发出去之前,再次向 TX FIFO 中填入数据,寄存器 TFIO 会被置位。

11.7 搭配使用 DMA

I2C 可以使用 DMA 进行数据的发送和接收。将 DTEN 置 1,则开启 DMA 发送模式,为 I2C 分配好通道后,DMA 会将数据从存储区传输到 I2C_FIFO_WDATA 寄存器中。将 DREN 置 1,则开启 DMA 接收模式,为 I2C 分配好通道后,DMA 会将 I2C_FIFO_RDATA 寄存器中的数据传输到存储区中。I2C 模块搭配使用 DMA 时,数据部分将由 DMA 自动完成搬运,不需要 CPU 再将数据写入 I2C TX FIFO 或者从 I2C RX FIFO 中读取数据。

BL702/704/706 参考手册 208/ 370 @2021 Bouffalo Lab



11.7.1 DMA 发送流程

- 1. 配置读写标志位 i2c_config[PKTDIR] 为 0
- 2. 配置从设备地址 i2c_config[SLVADDR]
- 3. 如有有从设备寄存器地址,则配置从设备寄存器地址 i2c_sub_addr、从设备寄存器地址长度 i2c_config[SABC], 配置从设备寄存器地址使能位 i2c_config[SAEN] 为 1
- 4. 设置发送数据的长度 i2c config[PKTLEN]
- 5. 使能 DMA 模式发送,设置 i2c_fifo_config_0[DTEN] 为 1
- 6. 配置 DMA 传输的数据长度 DMA_CxControl[TS](x=0~7)
- 7. 配置 DMA 源地址 DMA_CxSrcAddr、数据宽度 DMA_CxControl[STW]、burst 大小 DMA_CxControl[SBS],将 DMA_-CxControl[SI] 置 1 开启地址自动累加模式
- 8. 配置 DMA 目的地址 DMA_CxDstAddr 为 i2c_fifo_wdata、数据宽度 DMA_CxControl[DTW] 为 32 和 burst 大小 DMA_CxControl[DBS],将 DMA_CxControl[DI] 清零禁用地址自动累加模式
- 9. 使能 DMA
- 10. 配置 i2c_config[MEN] 为 1 使能 I2C

11.7.2 DMA 接收流程

- 1. 配置读写标志位 i2c_config[PKTDIR] 为 1
- 2. 配置从设备地址 i2c_config[SLVADDR]
- 3. 如有有从设备寄存器地址,则配置从设备寄存器地址 i2c_sub_addr、从设备寄存器地址长度 i2c_config[SABC], 配置从设备寄存器地址使能位 i2c_config[SAEN] 为 1
- 4. 设置接收数据的长度 i2c_config[PKTLEN]
- 5. 使能 DMA 模式接收,设置 i2c_fifo_config_0[DREN] 为 1
- 7. 配置 DMA 传输的数据长度 DMA_CxControl[TS](x=0~7)
- 8. 配置 DMA 源地址 DMA_CxSrcAddr 为 i2c_fifo_rdata、数据宽度 DMA_CxControl[STW] 为 32 和 burst 大小 DMA_-CxControl[SBS],将 DMA_CxControl[SI] 清零禁用地址自动累加模式
- 7. 配置 DMA 目的地址 DMA_CxDstAddr、数据宽度 DMA_CxControl[DTW]、burst 大小 DMA_CxControl[DBS],将 DMA_CxControl[DI] 置 1 开启地址自动累加模式
- 9. 使能 DMA
- 10. 配置 i2c_config[MEN] 为 1 使能 I2C



11.8 中断

I2C 包括如下几种中断:

- I2C_TRANS_END_INT: I2C 传输结束中断
- I2C_TX_FIFO_READY_INT: 当 I2C TX FIFO 有空闲空间可用于填充时,触发中断
- I2C_RX_FIFO_READY_INT: 当 I2C RX FIFO 接收到数据时,触发中断
- I2C_NACK_RECV_INT: 当 I2C 模块检测到 NACK 状态,触发中断
- I2C_ARB_LOST_INT: I2C 仲裁丢失中断
- I2C_FIFO_ERR_INT: I2C FIFO ERROR 中断

11.9 寄存器描述

名称	描述		
i2c_config	I2C configuration register		
i2c_int_sts	I2C interrupt status		
i2c_sub_addr	I2C sub-address configuration		
i2c_bus_busy	I2C bus busy control register		
i2c_prd_start	I2C length of start phase		
i2c_prd_stop	I2C length of stop phase		
i2c_prd_data	I2C length of data phase		
i2c_fifo_config_0	I2C FIFO configuration register0		
i2c_fifo_config_1	I2C FIFO configuration register1		
i2c_fifo_wdata I2C FIFO write data			
i2c_fifo_rdata	I2C FIFO read data		



11.9.1 i2c_config

地址: 0x4000a300

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	DEGCNT RSVD						PKTLEN								
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
RSVD		SLVADDR						RSVD	SA	BC	SAEN	SCLS	DEG	PKT	MEN
												EN	EN	DIR	

位	名称	权限	复位值	描述
31:28	DEGCNT	R/W	4'd0	De-glitch function cycle count
27:24	RSVD			
23:16	PKTLEN	R/W	8'd0	Packet length (unit: byte)
15	RSVD			
14:8	SLVADDR	R/W	7'd0	Slave address for I2C transaction (target address)
7	RSVD			
6:5	SABC	R/W	2'd0	Sub-address field byte count 2'd0: 1-byte, 2'd1: 2-byte, 2'd2: 3-byte, 2'd3: 4-byte
4	SAEN	R/W	1'b0	Enable signal of I2C sub-address field
3	SCLSEN	R/W	1'b1	Enable signal of I2C SCL synchronization, should be enabled to support Multi-Master and Clock-Stretching (Normally should not be turned-off)
2	DEGEN	R/W	1'b0	Enable signal of I2C input de-glitch function (for all input pins)
1	PKTDIR	R/W	1'b1	Transfer direction of the packet 1'b0: Write; 1'b1: Read
0	MEN	R/W	1'b0	Enable signal of I2C Master function Asserting this bit will trigger the transaction, and should be de-asserted after finish

BL702/704/706 参考手册 211/ 370 @2021 Bouffalo Lab



11.9.2 i2c_int_sts

地址: 0x4000a304

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
RS	SVD	FER	ARB	NAK	RXF	TXF	END		RSVD		ARB	NAK	RS	VD	END
		EN	EN	EN	EN	EN	EN				CLR	CLR			CLR
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
RS	SVD	FER	ARB	NAK	RXF	TXF	END	RS	VD	FER	ARB	NAK	RXF	TXF	END
		MASK	MASK	MASK	MASK	MASK	MASK			INT	INT	INT	INT	INT	INT

位	名称	权限	复位值	描述
31:30	RSVD			
29	FEREN	R/W	1'b1	Interrupt enable of i2c_fer_int
28	ARBEN	R/W	1'b1	Interrupt enable of i2c_arb_int
27	NAKEN	R/W	1'b1	Interrupt enable of i2c_nak_int
26	RXFEN	R/W	1'b1	Interrupt enable of i2c_rxf_int
25	TXFEN	R/W	1'b1	Interrupt enable of i2c_txf_int
24	ENDEN	R/W	1'b1	Interrupt enable of i2c_end_int
23:21	RSVD			
20	ARBCLR	W1C	1'b0	Interrupt clear of i2c_arb_int
19	NAKCLR	W1C	1'b0	Interrupt clear of i2c_nak_int
18:17	RSVD			
16	ENDCLR	W1C	1'b0	Interrupt clear of i2c_end_int
15:14	RSVD			
13	FERMASK	R/W	1'b1	Interrupt mask of i2c_fer_int
12	ARBMASK	R/W	1'b1	Interrupt mask of i2c_arb_int
11	NAKMASK	R/W	1'b1	Interrupt mask of i2c_nak_int
10	RXFMASK	R/W	1'b1	Interrupt mask of i2c_rxf_int
9	TXFMASK	R/W	1'b1	Interrupt mask of i2c_txf_int
8	ENDMASK	R/W	1'b1	Interrupt mask of i2c_end_int
7:6	RSVD			
5	FERINT	R	1'b0	I2C TX/RX FIFO error interrupt, auto-cleared when FIFO overflow/underflow error flag is cleared
4	ARBINT	R	1'b0	I2C arbitration lost interrupt
3	NAKINT	R	1'b0	I2C NACK-received interrupt



位	名称	权限	复位值	描述
2	RXFINT	R	1'b0	I2C RX FIFO ready (rx_fifo_cnt > rx_fifo_th) interrupt, auto- cleared when data is popped
1	TXFINT	R	1'b0	I2C TX FIFO ready (tx_fifo_cnt > tx_fifo_th) interrupt, auto- cleared when data is pushed
0	ENDINT	R	1'b0	I2C transfer end interrupt

11.9.3 i2c_sub_addr

地址: 0x4000a308

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	SUBAB3							SUBAB2							
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	15 14 13 12 11 10 9 8 SUBAB1										SUB	AB0			

位	名称	权限	复位值	描述
31:24	SUBAB3	R/W	8'd0	I2C sub-address field - byte[3]
23:16	SUBAB2	R/W	8'd0	I2C sub-address field - byte[2]
15:8	SUBAB1	R/W	8'd0	I2C sub-address field - byte[1]
7:0	SUBAB0	R/W	8'd0	I2C sub-address field - byte[0] (sub-address starts from this byte)

11.9.4 i2c_bus_busy

地址: 0x4000a30c

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	RSVD														
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	RSVD												BUSY	BUSY	
														CLR	

位	名称	权限	复位值	描述
31:2	RSVD			
1	BUSYCLR	W1C	1'b0	Clear signal of bus_busy status, not for normal usage (in case I2C bus hangs)

BL702/704/706 参考手册 213/ 370 @2021 Bouffalo Lab



位	名称	权限	复位值	描述
0	BUSY	R	1'b0	Indicator of I2C bus busy

11.9.5 i2c_prd_start

地址: 0x4000a310

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	
		PRDSPH3						PRDSPH2								
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	
	15 14 13 12 11 10 9 8 PRDSPH1										PRDS	SPH0				

位	名称	权限	复位值	描述
31:24	PRDSPH3	R/W	8'd15	Length of START condition phase 3
23:16	PRDSPH2	R/W	8'd15	Length of START condition phase 2
15:8	PRDSPH1	R/W	8'd15	Length of START condition phase 1
7:0	PRDSPH0	R/W	8'd15	Length of START condition phase 0

11.9.6 i2c_prd_stop

地址: 0x4000a314

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16			
		PRDPPH3							PRDPPH2									
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0			
	PRDPPH1										PRDI	PPH0						

位	名称	权限	复位值	描述
31:24	PRDPPH3	R/W	8'd15	Length of STOP condition phase 3
23:16	PRDPPH2	R/W	8'd15	Length of STOP condition phase 2
15:8	PRDPPH1	R/W	8'd15	Length of STOP condition phase 1
7:0	PRDPPH0	R/W	8'd15	Length of STOP condition phase 0

BL702/704/706 参考手册 214/ 370 @2021 Bouffalo Lab



11.9.7 i2c_prd_data

地址: 0x4000a318

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	
	PRDDPH3							PRDDPH2								
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	
	15 14 13 12 11 10 9 8 PRDDPH1										PRDI	DPH0				

位	名称	权限	复位值	描述
31:24	PRDDPH3	R/W	8'd15	Length of DATA phase 3
23:16	PRDDPH2	R/W	8'd15	Length of DATA phase 2
15:8	PRDDPH1	R/W	8'd15	Length of DATA phase 1 Note: This value should not be set to 8'd0, adjust source clock rate instead if higher I2C clock rate is required
7:0	PRDDPH0	R/W	8'd15	Length of DATA phase 0

11.9.8 i2c_fifo_config_0

地址: 0x4000a380

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
							RS	VD							
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	RSVD								RFIO	TFIU	TFIO	RFI	TFI	DREN	DTEN
												CLR	CLR		

位	名称	权限	复位值	描述
31:8	RSVD			
7	RFIU	R	1'b0	Underflow flag of RX FIFO, can be cleared by rx_fifo_clr
6	RFIO	R	1'b0	Overflow flag of RX FIFO, can be cleared by rx_fifo_clr
5	TFIU	R	1'b0	Underflow flag of TX FIFO, can be cleared by tx_fifo_clr
4	TFIO	R	1'b0	Overflow flag of TX FIFO, can be cleared by tx_fifo_clr
3	RFICLR	W1C	1'b0	Clear signal of RX FIFO
2	TFICLR	W1C	1'b0	Clear signal of TX FIFO
1	DREN	R/W	1'b0	Enable signal of dma_rx_req/ack interface
0	DTEN	R/W	1'b0	Enable signal of dma_tx_req/ack interface



11.9.9 i2c_fifo_config_1

地址: 0x4000a384

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	RSVD						RFI	RSVD							TFI
															TH
15	15 14 13 12 11 10 9						8	7 6 5 4 3 2 1						0	
	RSVD RFI					CNT	RSVD TFIG					CNT			

位	名称	权限	复位值	描述			
31:25	RSVD						
24	RFITH	R/W	1'd0	RX FIFO threshold, dma_rx_req will not be asserted if tx fifo_cnt is less than this value			
23:17	RSVD						
16	TFITH	R/W	1'd0	TX FIFO threshold, dma_tx_req will not be asserted if tx fifo_cnt is less than this value			
15:10	RSVD						
9:8	RFICNT	R	2'd0	RX FIFO available count			
7:2	RSVD						
1:0	TFICNT	R	2'd2	TX FIFO available count			

11.9.10 i2c_fifo_wdata

地址: 0x4000a388

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	FIWD														
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	FIWD														

位	名称	权限	复位值	描述
31:0	FIWD	W	х	I2C FIFO write data



11.9.11 i2c_fifo_rdata

地址: 0x4000a38c

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	FIRD														
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	FIRD														

位	名称	权限	复位值	描述
31:0	FIRD	R	32'h0	I2C FIFO read data

BL702/704/706 参考手册 217/ 370 @2021 Bouffalo Lab

PWM

12.1 简介

脉冲宽度调制(Pulse width modulation,简称 PWM)是一种模拟控制方式,根据相应载荷的变化来调制晶体管基极或 MOS 管栅极的偏置,来实现晶体管或 MOS 管导通时间的改变,从而稳定开关电源的输出。这种方式能使电源的输出电压在工作条件变化时保持恒定,是利用微处理器的数字信号对模拟电路进行控制的一种非常有效的技术,广泛应用在从测量、通信、开关电源、电机控制等许多领域中。

12.2 主要特征

- 支持 5 通道 PWM 信号生成
- 三种时钟源可选择(总线时钟 <bclk>、晶振时钟 <xtal>、慢速时钟 <f32k>), 搭配 16-bit 时钟分频器
- 双门限值设定,增加脉冲弹性

12.3 功能描述

12.3.1 时钟与分频器

每个 PWM 计数器时钟来源都有三种选择,来源如下:

- A. bclk 芯片的总线时钟
- B. XTAL 外部晶振时钟
- C. f32k 系统 RTC 时钟

每个计数器都有各自的 16-bit 分频器, PWM 计数器将以分频后的时钟作为计数周期单位, 每经过一个计数周期进行计数器加一的动作。



12.3.2 脉冲产生原理

PWM 内部有计数器,当计数器介于可设定的两个门限值域中间时,PWM 的输出为 1,反之当计数器在设定的两个门限值之外时,PWM 输出为 0,如下图所示:




图 12.1: PWM 波形图

PWM 的周期由两部分决定,一个是时钟分频系数,一个是时钟持续周期。

时钟分频系数由寄存器 PWMn_CLK_DIV[15:0](n 为 0~4) 进行设置,用于对 PWM 的源时钟进行分频。

时钟持续周期由寄存器 PWMn_PERIOD[15:0](n 为 0~4) 进行设置,用于设置 PWM 的一个周期由多少个分频后的时钟周期组成。即 PWM 的周期 =PWM 源时钟/PWMn_CLK_DIV[15:0]/PWMn_PERIOD[15:0]。

PWM 的占空比由时钟持续周期和两个阈值决定。第一个阈值由寄存器 PWMn_THRE1[15:0](n 为 0~4) 进行设置,第二个阈值由寄存器 PWMn_THRE2[15:0](n 为 0~4) 进行设置,PWM 的波形会在第一个阈值处拉高,在第二个阈值处拉低。即 PWM 的占空比 =(PWMn_THRE2[15:0]-PWMn_THRE1[15:0])/PWMn_PERIOD[15:0]。

例: 若 PWM 时钟源选择为 bclk 即 72MHz,要产生 1kHz、占空比 20% 的 PWM 波,则设置如下: PWMn_CLK_- DIV[15:0]=2

PWMn_PERIOD[15:0]=72000000/2/1000=36000

PWMn_THRE1[15:0]=0

PWMn THRE2[15:0]=0+36000*20%=7200

BL702/704/706 参考手册 219/ 370 @2021 Bouffalo Lab



12.3.3 PWM 中断

对于每一个 PWM 通道,可以设置周期计数值,当 PWM 输出的周期数达到这个计数值时,将产生 PWM 中断。

表 12.1: 占空比参数

频 率/MHz		支持的占空比 (n 为整数, 且 2 <= n <= 65535^2)													
36	0%	50%	100%												
24	0%	33.33%	66.67%	100%											
18	0%	25%	50%	75%	100%										
14.4	0%	20%	40%	60%	80%	100%									
12	0%	16.67%	33.33%	50%	66.67%	83.33%	100%								
10.29	0%	14.29%	28.57%	42.86%	57.14%	71.43%	85.71%	100%							
9	0%	12.50%	25%	37.50%	50%	62.50%	75%	87.50%	100%						
8	0%	11.11%	22.22%	33.33%	44.44%	55.56%	66.67%	77.78%	88.89%	100%					
7.2	0%	10%	20%	30%	40%	50%	60%	70%	80%	90%	100%				
•															
•															
•															
72/n	0/n	1/n	2/n	3/n	4/n	5/n	6/n	7/n	8/n	9/n	•••	n/n			

12.4 寄存器描述

名称	描述
pwm_int_config	PWM interrupt configuration register
pwm0_clkdiv	PWM0 clock division configuration register
pwm0_thre1	PWM0 first counter threshold configuration register
pwm0_thre2	PWM0 sencond counter threshold configuration register
pwm0_period	PWM0 period setting register
pwm0_config	PWM0 configuration register
pwm0_interrupt	PWM0 interrupt register
pwm1_clkdiv	PWM1 clock division configuration register
pwm1_thre1	PWM1 first counter threshold configuration register



名称	描述
pwm1_thre2	PWM1 sencond counter threshold configuration register
pwm1_period	PWM1 period setting register
pwm1_config	PWM1 configuration register
pwm1_interrupt	PWM1 interrupt register
pwm2_clkdiv	PWM2 clock division configuration register
pwm2_thre1	PWM2 first counter threshold configuration register
pwm2_thre2	PWM2 sencond counter threshold configuration register
pwm2_period	PWM2 period setting register
pwm2_config	PWM2 configuration register
pwm2_interrupt	PWM2 interrupt register
pwm3_clkdiv	PWM3 clock division configuration register
pwm3_thre1	PWM3 first counter threshold configuration register
pwm3_thre2	PWM3 sencond counter threshold configuration register
pwm3_period	PWM3 period setting register
pwm3_config	PWM3 configuration register
pwm3_interrupt	PWM3 interrupt register
pwm4_clkdiv	PWM4 clock division configuration register
pwm4_thre1	PWM4 first counter threshold configuration register
pwm4_thre2	PWM4 sencond counter threshold configuration register
pwm4_period	PWM4 period setting register
pwm4_config	PWM4 configuration register
pwm4_interrupt	PWM4 interrupt register



12.4.1 pwm_int_config

地址: 0x4000a400

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	RSVD														
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
RS	RSVD INTCLR							RS	VD			INT	STS		

位	名称	权限	复位值	描述
31:14	RSVD			
13:8	INTCLR	W	6'd0	PWM channel interrupt clear
7:6	RSVD			
5:0	INTSTS	R	6'd0	PWM channel interrupt status

12.4.2 pwm0_clkdiv

地址: 0x4000a420

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	RSVD														
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	CLKDIV														

位	名称	权限	复位值	描述
31:16	RSVD			
15:0	CLKDIV	R/W	16'b0	PWM clock division

12.4.3 pwm0_thre1

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	RSVD														
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	THRE1														



位	名称	权限	复位值	描述
31:16	RSVD			
15:0	THRE1	R/W	16'b0	PWM first counter threshold, can't be larger that pwm_thre2

12.4.4 pwm0_thre2

地址: 0x4000a428

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	RSVD														
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	THRE2														

位	名称	权限	复位值	描述
31:16	RSVD			
15:0	THRE2	R/W	16'd0	PWM sencond counter threshold, can't be smaller that pwm_thre1

12.4.5 pwm0_period

地址: 0x4000a42c

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	RSVD														
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	PERIOD														

位	名称	权限	复位值	描述
31:16	RSVD			
15:0	PERIOD	R/W	16'd0	PWM period setting

BL702/704/706 参考手册 223/ 370 @2021 Bouffalo Lab



12.4.6 pwm0_config

地址: 0x4000a430

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
							RS	VD							
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
			RS	VD				STOP	STOP	SW	SW	STOP	OUT	CLK	SEL
								STA	EN	MODE	FVAL	MODE	INV		

位	名称	权限	复位值	描述
31:8	RSVD			
7	STOPSTA	R	1'b0	PWM stop status
6	STOPEN	R/W	1'b0	PWM stop enable
5	SWMODE	R/W	1'b0	PWM SW Mode setting
4	SWFVAL	R/W	1'b0	PWM SW Mode force value
3	STOPMODE	R/W	1'b1	PWM stop mode, 1'b1 - graceful ; 1'b0 - abrupt
2	OUTINV	R/W	1'b0	PWM invert output mode
1:0	CLKSEL	R/W	2'd0	PWM clock source select, 2'b00-xclk; 2'b01-bclk; others-f32k_clk

12.4.7 pwm0_interrupt

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
							RSVD								INT
														EN	
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
INTPECN															

位	名称	权限	复位值	描述
31:17	RSVD			
16	INTEN	R/W	1'b0	PWM interrupt enable
15:0	INTPECN	R/W	16'd0	PWM interrupt period counter threshold



12.4.8 pwm1_clkdiv

地址: 0x4000a440

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	RSVD														
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	CLKDIV														

位	名称	权限	复位值	描述
31:16	RSVD			
15:0	CLKDIV	R/W	16'b0	PWM clock division

12.4.9 pwm1_thre1

地址: 0x4000a444

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	RSVD														
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	THRE1														

位	名称	权限	复位值	描述
31:16	RSVD			
15:0	THRE1	R/W	16'b0	PWM first counter threshold, can't be larger that pwm_thre2

12.4.10 pwm1_thre2

地址: 0x4000a448

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	RSVD														
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	THRE2														

位	名称	权限	复位值	描述
31:16	RSVD			

BL702/704/706 参考手册 225/ 370 @2021 Bouffalo Lab



位	名称	权限	复位值	描述
15:0	THRE2	R/W	16'd0	PWM sencond counter threshold, can't be smaller that pwm_thre1

12.4.11 pwm1_period

地址: 0x4000a44c

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	RSVD														
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	PERIOD														

位	名称	权限	复位值	描述
31:16	RSVD			
15:0	PERIOD	R/W	16'd0	PWM period setting

12.4.12 pwm1_config

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	RSVD														
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	RSVD									sw	SW	STOP	OUT	CLK	SEL
									EN	MODE	FVAL	MODE	INV		

位	名称	权限	复位值	描述
31:8	RSVD			
7	STOPSTA	R	1'b0	PWM stop status
6	STOPEN	R/W	1'b0	PWM stop enable
5	SWMODE	R/W	1'b0	PWM SW Mode setting
4	SWFVAL	R/W	1'b0	PWM SW Mode force value
3	STOPMODE	R/W	1'b1	PWM stop mode, 1'b1 - graceful ; 1'b0 - abrupt
2	OUTINV	R/W	1'b0	PWM invert output mode



位	名称	权限	复位值	描述
1:0	CLKSEL	R/W	2'd0	PWM clock source select, 2'b00-xclk; 2'b01-bclk; others-f32k_clk

12.4.13 pwm1_interrupt

地址: 0x4000a454

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	RSVD														INT
															EN
15	15 14 13 12 11 10 9 8 7 6 5 4 3 2 1													0	
INTPECN															

位	名称	权限	复位值	描述
31:17	RSVD			
16	INTEN	R/W	1'b0	PWM interrupt enable
15:0	INTPECN	R/W	16'd0	PWM interrupt period counter threshold

12.4.14 pwm2_clkdiv

地址: 0x4000a460

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	RSVD														
15	15 14 13 12 11 10 9 8 7 6 5 4 3 2 1 0												0		
	CLKDIV														

位	名称	权限	复位值	描述
31:16	RSVD			
15:0	CLKDIV	R/W	16'b0	PWM clock division



12.4.15 pwm2_thre1

地址: 0x4000a464

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	RSVD														
15	15 14 13 12 11 10 9 8 7 6 5 4 3 2 1 0											0			
	THRE1														

位	名称	权限	复位值	描述
31:16	RSVD			
15:0	THRE1	R/W	16'b0	PWM first counter threshold, can't be larger that pwm_thre2

12.4.16 pwm2_thre2

地址: 0x4000a468

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	RSVD														
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	THRE2														

位	名称	权限	复位值	描述
31:16	RSVD			
15:0	THRE2	R/W	16'd0	PWM sencond counter threshold, can't be smaller that pwm_thre1

12.4.17 pwm2_period

地址: 0x4000a46c

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	RSVD														
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	PERIOD														

位	名称	权限	复位值	描述
31:16	RSVD			

BL702/704/706 参考手册 228/ 370 @2021 Bouffalo Lab



位	名称	权限	复位值	描述
15:0	PERIOD	R/W	16'd0	PWM period setting

12.4.18 pwm2_config

地址: 0x4000a470

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
							RS	VD							
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	RSVD								STOP	SW	SW	STOP	OUT	CLK	SEL
								STA	EN	MODE	FVAL	MODE	INV		

位	名称	权限	复位值	描述
31:8	RSVD			
7	STOPSTA	R	1'b0	PWM stop status
6	STOPEN	R/W	1'b0	PWM stop enable
5	SWMODE	R/W	1'b0	PWM SW Mode setting
4	SWFVAL	R/W	1'b0	PWM SW Mode force value
3	STOPMODE	R/W	1'b1	PWM stop mode, 1'b1 - graceful ; 1'b0 - abrupt
2	OUTINV	R/W	1'b0	PWM invert output mode
1:0	CLKSEL	R/W	2'd0	PWM clock source select, 2'b00-xclk; 2'b01-bclk; others-f32k_clk

12.4.19 pwm2_interrupt

地址: 0x4000a474

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	RSVD														INT
															EN
15	15 14 13 12 11 10 9 8 7 6 5 4 3 2 1												0		
INTPECN															

位	名称	权限	复位值	描述
31:17	RSVD			

BL702/704/706 参考手册 229/ 370 @2021 Bouffalo Lab



位	名称	权限	复位值	描述					
16	INTEN	R/W	1'b0	PWM interrupt enable					
15:0	INTPECN	R/W	16'd0	PWM interrupt period counter threshold					

12.4.20 pwm3_clkdiv

地址: 0x4000a480

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	RSVD														
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	CLKDIV														

位	名称	权限	复位值	描述
31:16	RSVD			
15:0	CLKDIV	R/W	16'b0	PWM clock division

12.4.21 pwm3_thre1

地址: 0x4000a484

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	RSVD														
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	THRE1														

位	名称	权限	复位值	描述
31:16	RSVD			
15:0	THRE1	R/W	16'b0	PWM first counter threshold, can't be larger that pwm_thre2

BL702/704/706 参考手册 230/ 370 @2021 Bouffalo Lab



12.4.22 pwm3_thre2

地址: 0x4000a488

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	RSVD														
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	THRE2														

位	名称	权限	复位值	描述
31:16	RSVD			
15:0	THRE2	R/W	16'd0	PWM sencond counter threshold, can't be smaller that pwm_thre1

12.4.23 pwm3_period

地址: 0x4000a48c

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	RSVD														
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
							PER	RIOD							

位	名称	权限	复位值	描述
31:16	RSVD			
15:0	PERIOD	R/W	16'd0	PWM period setting

12.4.24 pwm3_config

地址: 0x4000a490

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
							RS	VD							
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
			RS	SVD				STOP	STOP	SW	SW	STOP	OUT	CLK	SEL
								STA	EN	MODE	FVAL	MODE	INV		

BL702/704/706 参考手册 231/ 370 @2021 Bouffalo Lab



位	名称	权限	复位值	描述
31:8	RSVD			
7	STOPSTA	R	1'b0	PWM stop status
6	STOPEN	R/W	1'b0	PWM stop enable
5	SWMODE	R/W	1'b0	PWM SW Mode setting
4	SWFVAL	R/W	1'b0	PWM SW Mode force value
3	STOPMODE	R/W	1'b1	PWM stop mode, 1'b1 - graceful ; 1'b0 - abrupt
2	OUTINV	R/W	1'b0	PWM invert output mode
1:0	CLKSEL	R/W	2'd0	PWM clock source select, 2'b00-xclk; 2'b01-bclk; others-f32k_clk

12.4.25 pwm3_interrupt

地址: 0x4000a494

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
							RSVD								INT
														EN	
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	INTPECN														

位	名称	权限	复位值	描述
31:17	RSVD			
16	INTEN	R/W	1'b0	PWM interrupt enable
15:0	INTPECN	R/W	16'd0	PWM interrupt period counter threshold

12.4.26 pwm4_clkdiv

地址: 0x4000a4a0

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	RSVD														
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
							CLK	(DIV							

BL702/704/706 参考手册 232/ 370 @2021 Bouffalo Lab



位	名称	权限	复位值	描述
31:16	RSVD			
15:0	CLKDIV	R/W	16'b0	PWM clock division

12.4.27 pwm4_thre1

地址: 0x4000a4a4

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	RSVD														
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	THRE1														

位	名称	权限	复位值	描述
31:16	RSVD			
15:0	THRE1	R/W	16'b0	PWM first counter threshold, can't be larger that pwm_thre2

12.4.28 pwm4_thre2

地址: 0x4000a4a8

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	RSVD														
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
							THE	RE2							

位	名称	权限	复位值	描述
31:16	RSVD			
15:0	THRE2	R/W	16'd0	PWM sencond counter threshold, can't be smaller that pwm_thre1

BL702/704/706 参考手册 233/ 370 @2021 Bouffalo Lab



12.4.29 pwm4_period

地址: 0x4000a4ac

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	RSVD														
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	PERIOD														

位	名称	权限	复位值	描述
31:16	RSVD			
15:0	PERIOD	R/W	16'd0	PWM period setting

12.4.30 pwm4_config

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
							RS	VD							
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	RSVD								STOP	SW	SW	STOP	OUT	CLK	SEL
								STA	EN	MODE	FVAL	MODE	INV		

位	名称	权限	复位值	描述
31:8	RSVD			
7	STOPSTA	R	1'b0	PWM stop status
6	STOPEN	R/W	1'b0	PWM stop enable
5	SWMODE	R/W	1'b0	PWM SW Mode setting
4	SWFVAL	R/W	1'b0	PWM SW Mode force value
3	STOPMODE	R/W	1'b1	PWM stop mode, 1'b1 - graceful ; 1'b0 - abrupt
2	OUTINV	R/W	1'b0	PWM invert output mode
1:0	CLKSEL	R/W	2'd0	PWM clock source select, 2'b00-xclk; 2'b01-bclk; others-f32k_clk



12.4.31 pwm4_interrupt

地址: 0x4000a4b4

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
							RSVD								INT
															EN
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	INTPECN														

位	名称	权限	复位值	描述
31:17	RSVD			
16	INTEN	R/W	1'b0	PWM interrupt enable
15:0	INTPECN	R/W	16'd0	PWM interrupt period counter threshold

BL702/704/706 参考手册 235/ 370 @2021 Bouffalo Lab

13.1 简介

芯片内置 2 组 32-bit 计数器,每个计数器可独立配置其参数与时钟频率。

芯片内有一组看门狗计数器,不可预知的软件或硬件行为有可能导致应用程序工作失常,看门狗定时器可以帮助系统 从中恢复,如果当前阶段超过预定时间,但没有喂狗或关闭看门狗定时器,可依设定触发中断或系统复位。




图 13.1: 定时器框图






图 13.2: 看门狗定时器框图

13.2 主要特征

- 多种时钟来源选择
- 8-bit 时钟分频器,分频系数为 1-256
- 两组 32-bit 定时器
- 每个定时器包含三组报警值设定,可独立设定每组报警值溢出时报警
- 支持 FreeRun 模式和 PreLoad 模式
- 16-bit 看门狗定时器
- 支持写入密码保护, 防止误设定造成系统异常
- 支持中断或复位两种看门狗溢出方式

13.3 功能描述

13.3.1 8-bit 分频器

看门狗定时器时钟有3种选择:

- Fclk--系统主时钟
- 32K--32K 时钟
- Xtal--外部晶振

每个定时器时钟来源都有四种选择,来源如下:

• Fclk--系统主时钟



- 32K--32K 时钟
- 1K--1K 时钟(32K 的分频)
- Xtal--外部晶振

每个计数器有各自的 8-bit 分频器,可通过 APB 将选择到的时钟进行 1-256 的分频,具体来说设定为 0 时表示不分频,设定为 1 时进行 2 分频以此类推,最大分频系数为 256,计数器将以分频后的时钟作为计数周期单位,每经过一个计数周期进行上数一的动作。

13.3.2 通用定时器工作原理

每个通用定时器都包含三组比较器,一个计数器以及一个预加载寄存器,当设定好时钟源,启动定时器后,计数器开始向上累加计数,当计数器的值与比较器相等的时候,比较标志置位同时可以产生比较中断。

计数器的初始值取决于定时的模式,在 FreeRun 模式下,计数器的初始值是 0,然后累加计数,当达到计数最大值后,然后从 0 再次开始计数。

在 PreLoad 模式下,计数器的初始值是 PreLoad 寄存器的值,然后向上累加计数,当满足 PreLoad 条件时,计数器的值被置为 PreLoad 寄存器的值,然后计数器再次开始向上累加计数,在定时器的计数器计数过程中,一旦计数器的值与三个比较器中的某比较值一致,该比较器的比较标志就会置位,并可以产生相应的比较中断。

若预加载寄存器的值为 10,比较器 0 的值为 13,比较器 1 的值为 16,比较器 2 的值为 19,则定时器在 PreLoad 的模式下工作时序如下图:




图 13.3: 定时器在 PreLoad 模式下工作时序

在 FreeRun 模式下,定时器工作时序与 PreLoad 基本相同,只是计数器会从 0 开始累计到最大值,期间产生的比较标志和比较中断的机制与 PreLoad 模式相同。

BL702/704/706 参考手册 238/ 370 @2021 Bouffalo Lab



13.3.3 看门狗定时器工作原理

Watchdog 定时器包含一个计数器和一个比较器,计数器从 0 开始累加计数,如果计数器被复位 (喂狗),则从 0 再次开始向上计数,当计数器的值与比较器相等的时候,可以产生一个比较中断信号或者系统复位信号,用户可以根据需要选择使用其中一个。看门狗计数器会在每个计数周期单位上加 1,软件可以在任何时间点通过 APB 将看门狗计数器归零。

若比较器的值为 6,Watchdog 的工作时序如下图所示




图 13.4: Watchdog 工作时序

13.3.4 报警设定

每一组计数器有三个比较值提供软件设定,并可设定每一组比较值是否触发报警中断,当计数器与比较值吻合且设定会报警时,计数器会通过中断通知处理器。软件可以通过 APB 读取目前是否发生报警和是哪个比较值触发报警中断,当清理报警中断时亦会同步清理报警状态。

13.3.5 看门狗报警

每个计数器可设定一组比较值,当软件因为系统错误,来不及将看门狗计数器归零,导致看门狗计数器超过比较值时,便会触发看门狗报警,报警方式有两种,第一种是通过中断通知软件进行必要的处置,第二种是进入系统看门狗复位,看门狗复位被触发时,会通知系统复位控制器,并做好系统复位前准备,当一切就绪后进入系统看门狗复位,值得注意的是,软件可通过 APB 读取 WSR 寄存器得知是否曾经发生看门狗系统复位。

BL702/704/706 参考手册 239/ 370 @2021 Bouffalo Lab






图 13.5: 看门狗报警机制

13.4 寄存器描述

名称	描述
TCCR	Timer clock source configuration register
TMR2_0	Timer2 match register 0
TMR2_1	Timer2 match register 1
TMR2_2	Timer2 match register 2
TMR3_0	Timer3 match register 0
TMR3_1	Timer3 match register 1
TMR3_2	Timer3 match register 2
TCR2	Timer2 counter register
TCR3	Timer3 counter register
TMSR2	Timer2 match register status



名称	描述
TMSR3	Timer3 match register status
TIER2	Timer2 match interrupt enable register
TIER3	Timer3 match interrupt enable register
TPLVR2	Timer2 pre-load value register
TPLVR3	Timer3 pre-load value register
TPLCR2	Timer2 pre-load control register
TPLCR3	Timer3 pre-load control register
WMER	WDT reset/interrupt mode register
WMR	WDT counter match value register
WVR	WDT counter value register
WSR	WDT timer reset indication register
TICR2	Timer2 Interrupt clear control register
TICR3	Timer3 Interrupt clear control register
WICR	WDT Interrupt clear register
TCER	Timer count enable register
TCMR	Timer count mode register
TILR2	Timer2 match interrupt mode register
TILR3	Timer3 match interrupt mode register
WCR	WDT timer count reset register
WFAR	WDT access key1 register
WSAR	WDT access key2 register
TCVWR2	Timer2 capture value of counter register
TCVWR3	Timer3 capture value of counter register
TCVSYN2	Timer2 synchronous value of counter register
TCVSYN3	Timer3 synchronous value of counter register
TCDR	WDT/Timer clock division register



13.4.1 TCCR

地址: 0x4000a500

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	RSVD														
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	RSVD CSWDT							RSVD	C	S2	RSVD	C	S1	RS	VD

位	名称	权限	复位值	描述
31:10	RSVD			
9:8	CSWDT	R/W	2'd0	Clock Source for Timer #1/#2/#3/WDT 2'd0 - fclk 2'd1 - f32k_clk 2'd2 - 1 kHz 2'd3 - PLL 32MHz
7	RSVD			
6:5	CS2	R/W	2'd0	Clock Source for Timer #1/#2/#3/WDT 2'd0 - fclk 2'd1 - f32k_clk 2'd2 - 1 kHz 2'd3 - PLL 32MHz
4	RSVD			
3:2	CS1	R/W	2'd0	Clock Source for Timer #1/#2/#3/WDT 2'd0 - fclk 2'd1 - f32k_clk 2'd2 - 1 kHz 2'd3 - PLL 32MHz
1:0	RSVD			

13.4.2 TMR2_0

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	TMR20														
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	TMR20														



位	名称	权限	复位值	描述
31:0	TMR20	R/W	32'hfffffff	Timer2 match register 0

13.4.3 TMR2_1

地址: 0x4000a514

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	TMR21														
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	TMR21														

位	名称	权限	复位值	描述
31:0	TMR21	R/W	32'hfffffff	Timer2 match register 1

13.4.4 TMR2_2

地址: 0x4000a518

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	TMR22														
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	TMR22														

位	名称	权限	复位值	描述
31:0	TMR22	R/W	32'hfffffff	Timer2 match register 2

13.4.5 TMR3_0

地址: 0x4000a51c

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	TMR30														
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	TMR30														

BL702/704/706 参考手册 243/ 370 @2021 Bouffalo Lab



位	名称	权限	复位值	描述
31:0	TMR30	R/W	32'hfffffff	Timer3 match register 0

13.4.6 TMR3_1

地址: 0x4000a520

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	TMR31														
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	TMR31														

位	名称	权限	复位值	描述
31:0	TMR31	R/W	32'hfffffff	Timer3 match register 1

13.4.7 TMR3_2

地址: 0x4000a524

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	TMR32														
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	TMR32														

位	名称	权限	复位值	描述
31:0	TMR32	R/W	32'hfffffff	Timer3 match register 2

13.4.8 TCR2

地址: 0x4000a52c

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	TCR2COUT														
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	TCR2COUT														

BL702/704/706 参考手册 244/ 370 @2021 Bouffalo Lab



位	名称	权限	复位值	描述
31:0	TCR2COUT	R	32'h0	Timer2 counter register

13.4.9 TCR3

地址: 0x4000a530

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	TCR3COUT														
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	TCR3COUT														

位	名称	权限	复位值	描述
31:0	TCR3COUT	R	32'h0	Timer3 counter register

13.4.10 TMSR2

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
							RS	VD							
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
						RSVD							T2M	T2M	T2M
													R2S	R1S	R0S

位	名称	权限	复位值	描述
31:3	RSVD			
2	T2MR2S	R	1'b0	Timer2 match register 2 status/Clear interrupt would also clear this bit
1	T2MR1S	R	1'b0	Timer2 match register 1 status/Clear interrupt would also clear this bit
0	T2MR0S	R	1'b0	Timer2 match register 0 status/Clear interrupt would also clear this bit



13.4.11 TMSR3

地址: 0x4000a53c

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
							RS	VD							
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
				,		RSVD				,			ТЗМ	ТЗМ	ТЗМ
											R2S	R1S	R0S		

位	名称	权限	复位值	描述
31:3	RSVD			
2	T3MR2S	R	1'b0	Timer3 match register 2 status/Clear interrupt would also clear this bit
1	T3MR1S	R	1'b0	Timer3 match register 1 status/Clear interrupt would also clear this bit
0	T3MR0S	R	1'b0	Timer3 match register 0 status/Clear interrupt would also clear this bit

13.4.12 TIER2

地址: 0x4000a544

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
							RS	VD							
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
						RSVD							TIER	TIER	TIER
													22	21	20

位	名称	权限	复位值	描述
31:3	RSVD			
2	TIER22	R/W	1'b0	Timer2 match register 2 interrupt enable register
1	TIER21	R/W	1'b0	Timer2 match register 1 interrupt enable register
0	TIER20	R/W	1'b0	Timer2 match register 0 interrupt enable register

BL702/704/706 参考手册 246/ 370 @2021 Bouffalo Lab



13.4.13 TIER3

地址: 0x4000a548

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
							RS	VD							
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	RSVD											TIER	TIER31	TIER30	
													32		

位	名称	权限	复位值	描述
31:3	RSVD			
2	TIER32	R/W	1'b0	Timer3 match register 2 interrupt enable register
1	TIER31	R/W	1'b0	Timer3 match register 1 interrupt enable register
0	TIER30	R/W	1'b0	Timer3 match register 0 interrupt enable register

13.4.14 TPLVR2

地址: 0x4000a550

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	TPLVR2														
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	TPLVR2														

位	名称	权限	复位值	描述
31:0	TPLVR2	R/W	32'h0	Timer2 pre-load value register

13.4.15 TPLVR3

地址: 0x4000a554

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	TPLVR3														
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	TPLVR3														

BL702/704/706 参考手册 247/ 370 @2021 Bouffalo Lab



位	名称	权限	复位值	描述
31:0	TPLVR3	R/W	32'h0	Timer3 pre-load value register

13.4.16 TPLCR2

地址: 0x4000a55c

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	RSVD														
15	15 14 13 12 11 10 9 8 7 6 5 4 3 2										1	0			
	RSVD												TPL	CR2	

位	名称	权限	复位值	描述
31:2	RSVD			
1:0	TPLCR2	R/W	2'h0	Timer2 pre-load control register 2'd0 - No pre-load 2'd1 - Pre-load with match comparator 0 2'd2 - Pre-load with match comparator 1 2'd3 - Pre-load with match comparator 2

13.4.17 TPLCR3

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	RSVD														
15	15 14 13 12 11 10 9 8 7 6 5 4 3 2										2	1	0		
	RSVD												TPL	CR3	

位	名称	权限	复位值	描述
31:2	RSVD			
1:0	TPLCR3	R/W	2'h0	Timer3 pre-load control register 2'd0 - No pre-load 2'd1 - Pre-load with match comparator 0 2'd2 - Pre-load with match comparator 1 2'd3 - Pre-load with match comparator 2



13.4.18 WMER

地址: 0x4000a564

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	RSVD														
15	15 14 13 12 11 10 9 8 7 6 5 4 3 2										1	0			
	RSVD												WRIE	WE	

位	名称	权限	复位值	描述
31:2	RSVD			
1	WRIE	R/W	1'b0	WDT reset/interrupt mode register 1'b0 - WDT expiration to generate interrupt 1'b1 - WDT expiration to generate reset source
0	WE	R/W	1'b0	WDT enable register

13.4.19 WMR

地址: 0x4000a568

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	RSVD														
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	WMR														

位	名称	权限	复位值	描述
31:16	RSVD			
15:0	WMR	R/W	16'hffff	WDT counter match value register

13.4.20 WVR

地址: 0x4000a56c

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	RSVD														
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	WVR														

BL702/704/706 参考手册 249/ 370 @2021 Bouffalo Lab



位	名称	权限	复位值	描述
31:16	RSVD			
15:0	WVR	R	16'h0	WDT counter value register

13.4.21 WSR

地址: 0x4000a570

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	RSVD														
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	RSVD										WTS				

位	名称	权限	复位值	描述
31:1	RSVD			
0	WTS	R/W	1'b0	WDT timer reset indication, Indicates that reset was caused by the WDT. (Write)1'b0 - clear the WDT reset status (Write)1'b1 - no affect (Read)1'b0 - Watchdog timer did not cause reset because this bit was cleare (Read)1'b1 - Watchdog timer caused reset

13.4.22 TICR2

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
							RS	VD							
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
						RSVD							TCLR	TCLR	TCLR
													22	21	20

位	名称	权限	复位值	描述
31:3	RSVD			
2	TCLR22	W	1'b0	Timer2 Interrupt clear for match comparator 2
1	TCLR21	W	1'b0	Timer2 Interrupt clear for match comparator 1



位	名称	权限	复位值	描述
0	TCLR20	W	1'b0	Timer2 Interrupt clear for match comparator 0

13.4.23 TICR3

地址: 0x4000a57c

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
							RS	VD							
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
			,			RSVD				,			TCLR	TCLR	TCLR
													32	31	30

位	名称	权限	复位值	描述
31:3	RSVD			
2	TCLR32	W	1'b0	Timer3 Interrupt clear for match comparator 2
1	TCLR31	W	1'b0	Timer3 Interrupt clear for match comparator 1
0	TCLR30	W	1'b0	Timer3 Interrupt clear for match comparator 0

13.4.24 WICR

地址: 0x4000a580

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
RSVD															
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	RSVD									WI					
															CLR

位	名称	权限 复位值		描述		
31:1	RSVD					
0	WICLR W		1'b0	WDT Interrupt clear register		

BL702/704/706 参考手册 251/ 370 @2021 Bouffalo Lab



13.4.25 TCER

地址: 0x4000a584

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	RSVD														
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	RSVD									TIM3	TIM2	RSVD			
									EN	EN					

位	名称	权限	复位值	描述
31:3	RSVD			
2	TIM3EN	R/W	1'b0	Timer3 count enable
1	TIM2EN	R/W	1'b0	Timer2 count enable
0	RSVD			

13.4.26 TCMR

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	RSVD														
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	RSVD								TIM3	TIM2	RSVD				
													MODE	MODE	

位	名称	权限	复位值	描述
31:3	RSVD			
2	TIM3MODE	R/W	1'b0	Timer1/2/3 count mode register 1'b0 - pre-load mode 1'b1 - free run mode
1	1 TIM2MODE		1'b0	Timer1/2/3 count mode register 1'b0 - pre-load mode 1'b1 - free run mode
0	RSVD			



13.4.27 TILR2

地址: 0x4000a590

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
							RS	VD							
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
			,			RSVD							TILR	TILR	TILR
													22	21	20

位	名称	权限	复位值	描述
31:3	RSVD			
2	TILR22	R/W	1'b0	Timer2 match 0/1/2 interrupt mode register 1'b0 - level interrupt 1'b1 - pulse interrupt
1	TILR21	R/W	1'b0	Timer2 match 0/1/2 interrupt mode register 1'b0 - level interrupt 1'b1 - pulse interrupt
0	TILR20	R/W	1'b0	Timer2 match 0/1/2 interrupt mode register 1'b0 - level interrupt 1'b1 - pulse interrupt

13.4.28 TILR3

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
							RS	VD							
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
				,		RSVD							TILR	TILR	TILR
													32	31	30

位	名称	权限	复位值	描述
31:3	RSVD			
2	TILR32	R/W	1'b0	Timer3 match 0/1/2 interrupt mode register 1'b0 - level interrupt 1'b1 - pulse interrupt
1	TILR31	R/W	1'b0	Timer3 match 0/1/2 interrupt mode register 1'b0 - level interrupt 1'b1 - pulse interrupt



位	名称	权限	复位值	描述
0	TILR30	R/W	1'b0	Timer3 match 0/1/2 interrupt mode register 1'b0 - level interrupt 1'b1 - pulse interrupt

13.4.29 WCR

地址: 0x4000a598

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	RSVD														
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
												WCR			

位	名称	权限	复位值	描述
31:1	RSVD			
0	WCR	W	1'b0	WDT timer count reset register

13.4.30 WFAR

地址: 0x4000a59c

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	RSVD														
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	WFAR														

位	名称	权限	复位值	描述
31:16	RSVD			
15:0	WFAR	W	16'b0	WDT access key1 - 16'hBABA

BL702/704/706 参考手册 254/ 370 @2021 Bouffalo Lab



13.4.31 WSAR

地址: 0x4000a5a0

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	RSVD														
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
							WS	SAR							

位	名称	权限	复位值	描述
31:16	RSVD			
15:0	WSAR	W	16'b0	WDT access key2 - 16'hEB10

13.4.32 TCVWR2

地址: 0x4000a5a8

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	TCVWR2														
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
							TCV	WR2							

位	名称	权限	复位值	描述
31:0	TCVWR2	R	32'h0	Timer2 capture value of counter

13.4.33 TCVWR3

地址: 0x4000a5ac

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	TCVWR3														
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	TCVWR3														

位	名称	权限	复位值	描述
31:0	TCVWR3	R	32'h0	Timer3 capture value of counter

BL702/704/706 参考手册 255/ 370 @2021 Bouffalo Lab



13.4.34 TCVSYN2

地址: 0x4000a5b4

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	TCVSYN2														
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	TCVSYN2														

位	名称	权限	复位值	描述
31:0	TCVSYN2	R	32'h0	Timer2 synchronous value of counter

13.4.35 TCVSYN3

地址: 0x4000a5b8

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	TCVSYN3														
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	TCVSYN3														

位	名称	权限	复位值	描述
31:0	TCVSYN3	R	32'h0	Timer3 synchronous value of counter

13.4.36 TCDR

地址: 0x4000a5bc

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
			WC	DR				TCDR3							
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	TCDR2									RSVD					

位	名称	权限	复位值	描述
31:24	WCDR	R/W	8'h0	WDT clock division value register
23:16	TCDR3	R/W	8'h0	Timer3 clock division value register
15:8	TCDR2	R/W	8'h0	Timer2 clock division value register
7:0	RSVD			

QDEC

14.1 简介

正交解码器(quadrature decoder),用于将双路旋转编码器产生的两组相位相差 **90** 度的脉冲解码为对应转速和旋转方向。

14.2 主要特征

- 三组 QDEC 可供使用
- QDEC 的时钟源可以为 32K(f32k_clk)或 32M(xclk),正常工作时建议选择 32M 作为时钟源,当进入睡眠模式 并希望可以由 QDEC 唤醒时建议使用 32k
- 支持 5 位分频值,可分频 1~32
- 16 位脉冲计数范围(-32768~32767 pulse/sample)
- 12 种可配置的 sample 周期(32us~131ms per sample at 1MHz)
- 16 位可设置的 report 周期(0~65535 sample/report)
- 内置一个可随采样进行闪烁的 LED 功能(LED on/off 0~511 us/sample)
- 中断可配(sample 中断、report 中断、error 中断、overflow 中断)
- 可配置为 PDS 的唤醒源(clock source 需要配置为 32k)



14.3 功能描述

QDEC 预期的工作频率为 1MHz,检测的速度越快所需的工作频率越高。每次采样会将编码器输出的 A/B 两相脉冲解码为高低电平,对比前次采样结果可获得当前编码器旋转方向与脉冲计数变化情况(顺时针转 +1,逆时针转-1,不转不变,出错报错并计数),经过 report 所设定的采样次数后,即可获得此段时间内编码器的旋转方向和脉冲计数,据此求解出此段 report 时间内转速方向均值。每次采样的周期可配,在工作频率为 1MHz 时,最低 32us 一次采样,最高 131ms 一次采样。可配置中断为单次采样结束触发(sample 中断)、多次采样结束触发(report 中断),以灵活测量转速。可配置的 LED 闪烁功能,闪烁频率 =LED 周期/采样周期,每次闪烁中的 on/off 由 LED 极性决定。




图 14.1: QDEC 功能框图



14.4 寄存器描述

名称	描述
qdec0_ctrl0	QDEC0 control0
qdec0_ctrl1	QDEC0 control1
qdec0_value	QDEC0 value
qdec0_int_en	QDEC0 interrupt enable
qdec0_int_sts	QDEC0 interrupt status
qdec0_int_clr	QDEC0 interrupt clear
qdec1_ctrl0	QDEC1 control0
qdec1_ctrl1	QDEC1 control1
qdec1_value	QDEC1 value
qdec1_int_en	QDEC1 interrupt enable
qdec1_int_sts	QDEC1 interrupt status
qdec1_int_clr	QDEC1 interrupt clear
qdec2_ctrl0	QDEC2 control0
qdec2_ctrl1	QDEC2 control1
qdec2_value	QDEC2 value
qdec2_int_en	QDEC2 interrupt enable
qdec2_int_sts	QDEC2 interrupt status
qdec2_int_clr	QDEC2 interrupt clear

14.4.1 qdec0_ctrl0

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	RS	SVD			RPT										
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	RPT SPL						DEGCNT DEG LED					LED	QDEC		
												EN	POL	EN	EN



位	名称	权限	复位值	描述
31:28	RSVD			
27:12	RPT	R/W	16'd10	"RPT" report period in [samples/report]. Specifies the number of samples to be accumulated in the ACC1 register before the RPT_RDY and DBL_RDY events can be generated "RPT_US" report period in [us/report] = SP * RP
11:8	SPL	R/W	4'h2	"SPL" sample period in [us/sample]. The SAMPLE register will be updated for every new sample (at 1MHz) 0: 32 us 1: 64 2: 128 3: 256 4: 512 5: 1 ms 6: 2 7: 4 8: 8 9: 16 A: 32 B: 65 C: 131
7:4	DEGCNT	R/W	0	deglitch strength
3	DEGEN	R/W	0	deglitch enable
2	LEDPOL	R/W	1	qdec led polarity
1	LEDEN	R/W	0	qdec led enable
0	QDECEN	R/W	0	qdec enable

14.4.2 qdec0_ctrl1

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	RSVD										LEDPED	ı			
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
					RS	VD				,		IS	RPT	SPL	ACC

位	名称	权限	复位值	描述
31:25	RSVD			
24:16	LEDPED	R/W	0	Period in us the LED is switched on prior to sampling



位	名称	权限	复位值	描述
15:4	RSVD			
3	IS	R/W	0	input a/b swap
2	RPT	R/W	0	rpt option 0: Count time only if sample change 1: Continue time
1	SPL	R/W	0	spl option 0: Stop sample if rpt_rdy 1: Continue sample
0	ACC	R/W	1	acc option 0: Stop accumulate if overflow 1: Continue accumulate

14.4.3 qdec0_value

地址: 0x4000a808

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
RS	DVS	SPL	VAL				RS	VD							
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
		•					ACC	1VAL				•			

位	名称	权限	复位值	描述
31:30	RSVD			
29:28	SPLVAL	R	0	Sample value. Direction of last change 00: no change 01: clockwise 11: counter-clockwise 10: Error
27:20	RSVD			
19:16	ACC2VAL	R	0	Double error accumulation (0 15)
15:0	ACC1VAL	R	0	Sample accumulation (-32768 32767) clockwise +1, counter-clockwise -1

BL702/704/706 参考手册 261/ 370 @2021 Bouffalo Lab



14.4.4 qdec0_int_en

地址: 0x4000a810

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	RSVD														
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
					RS	VD						OFEN	DREN	SREN	RREN

位	名称	权限	复位值	描述
31:4	RSVD			
3	OFEN	R/W	0	overflow interrupt enable
2	DREN	R/W	0	double error interrupt enable
1	SREN	R/W	0	sample interrupt enable
0	RREN	R/W	1	report interrupt enable

14.4.5 qdec0_int_sts

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
							RS	VD							
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
					RS	VD						OF	DR	SR	RR
	STS STS STS STS											STS			

位	名称	权限	复位值	描述
31:4	RSVD			
3	OFSTS	R	0	ACC1 or ACC2 overflow
2	DRSTS	R	0	ACC2 double error
1	SRSTS	R	0	Event being generated for every new sample value written to the SAMPLE register
0	RRSTS	R	0	Non-null report ready



14.4.6 qdec0_int_clr

地址: 0x4000a818

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
RSVD															
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
					RS	VD						OFCL	DRCL	SRCL	RRCL

位	名称	权限	复位值	描述
31:4	RSVD			
3	OFCL	W1C	0	overflow interrupt clear
2	DRCL	W1C	0	double error interrupt clear
1	SRCL	W1C	0	sample interrupt clear
0	RRCL	W1C	0	report interrupt clear

14.4.7 qdec1_ctrl0

地址: 0x4000a840

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	RS	VD							RI	PT					
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	RI	PT			SF	PL			DEG	CNT		DEG	LED	LED	QDEC
												EN	POL	EN	EN

位	名称	权限	复位值	描述
31:28	RSVD			
27:12	RPT	R/W	16'd10	"RPT" report period in [samples/report]. Specifies the number of samples to be accumulated in the ACC1 register before the RPT_RDY and DBL_RDY events can be generated "RPT_US" report period in [us/report] = SP * RP

BL702/704/706 参考手册 263/ 370 @2021 Bouffalo Lab



位	名称	权限	复位值	描述
11:8	SPL	R/W	4'h2	"SPL" sample period in [us/sample]. The SAMPLE register will be updated for every new sample (at 1MHz) 0: 32 us 1: 64 2: 128 3: 256 4: 512 5: 1 ms 6: 2 7: 4 8: 8 9: 16 A: 32 B: 65 C: 131
7:4	DEGCNT	R/W	0	deglitch strength
3	DEGEN	R/W	0	deglitch enable
2	LEDPOL	R/W	1	qdec led polarity
1	LEDEN	R/W	0	qdec led enable
0	QDECEN	R/W	0	qdec enable

14.4.8 qdec1_ctrl1

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	RSVD						LEDPED								
15	15 14 13 12 11 10 9						8	7	6	5	4	3	2	1	0
							IS	RPT	SPL	ACC					

位	名称	权限	复位值	描述
31:25	RSVD			
24:16	LEDPED	R/W	0	Period in us the LED is switched on prior to sampling
15:4	RSVD			
3	IS	R/W	0	input a/b swap
2	RPT	R/W	0	rpt option 0: Count time only if sample change 1: Continue time



位	名称	权限	复位值	描述
1	SPL	R/W	0	spl option 0: Stop sample if rpt_rdy 1: Continue sample
0	ACC	R/W	1	acc option 0: Stop accumulate if overflow 1: Continue accumulate

14.4.9 qdec1_value

地址: 0x4000a848

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
RS	SVD	SPLVAL RSVD									ACC2VAL				
15	14	13	12	11	11 10 9 8 7 6 5 4 3 2 1 0						0				
	ACC1VAL														

位	名称	权限	复位值	描述
31:30	RSVD			
29:28	SPLVAL	R	0	Sample value. Direction of last change 00: no change 01: clockwise 11: counter-clockwise 10: Error
27:20	RSVD			
19:16	ACC2VAL	R	0	Double error accumulation (0 15)
15:0	ACC1VAL	R	0	Sample accumulation (-32768 32767) clockwise +1, counter-clockwise -1

14.4.10 qdec1_int_en

地址: 0x4000a850

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	RSVD														
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	RSVD											OFEN	DREN	SREN	RREN

位	名称	权限	复位值	描述
31:4	RSVD			

BL702/704/706 参考手册 265/ 370 @2021 Bouffalo Lab



位	名称	权限	复位值	描述
3	OFEN	R/W	0	overflow interrupt enable
2	DREN	R/W	0	double error interrupt enable
1	SREN	R/W	0	sample interrupt enable
0	RREN	R/W	1	report interrupt enable

14.4.11 qdec1_int_sts

地址: 0x4000a854

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
							RS	VD							
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	RSVD									•	OF	DR	SR	RR	
											STS	STS	STS	STS	

位	名称	权限	复位值	描述
31:4	RSVD			
3	OFSTS	R	0	ACC1 or ACC2 overflow
2	DRSTS	R	0	ACC2 double error
1	SRSTS	R	0	Event being generated for every new sample value written to the SAMPLE register
0	RRSTS	R	0	Non-null report ready

14.4.12 qdec1_int_clr

地址: 0x4000a858

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	RSVD														
15	15 14 13 12 11 10 9 8 7 6 5 4											3	2	1	0
	RSVD											OFCL	DRCL	SRCL	RRCL

位	名称	权限	复位值	描述
31:4	RSVD			
3	OFCL	W1C	0	overflow interrupt clear

BL702/704/706 参考手册 266/ 370 @2021 Bouffalo Lab



位	名称	权限 复位值		描述
2	DRCL	W1C	0	double error interrupt clear
1	SRCL	W1C	0	sample interrupt clear
0	RRCL	W1C	0	report interrupt clear

14.4.13 qdec2_ctrl0

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	RS	SVD		RPT											
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	RPT SPL							DEG	CNT		DEG	LED	LED	QDEC	
								EN POL EN EN							EN

位	名称	权限	复位值	描述
31:28	RSVD			
27:12	RPT	R/W	16'd10	"RPT" report period in [samples/report]. Specifies the number of samples to be accumulated in the ACC1 register before the RPT_RDY and DBL_RDY events can be generated "RPT_US" report period in [us/report] = SP * RP
11:8	SPL	R/W	4'h2	"SPL" sample period in [us/sample]. The SAMPLE register will be updated for every new sample (at 1MHz) 0: 32 us 1: 64 2: 128 3: 256 4: 512 5: 1 ms 6: 2 7: 4 8: 8 9: 16 A: 32 B: 65 C: 131
7:4	DEGCNT	R/W	0	deglitch strength
3	DEGEN	R/W	0	deglitch enable
2	LEDPOL	R/W	1	qdec led polarity



位	名称	权限	复位值	描述
1	LEDEN	R/W	0	qdec led enable
0	QDECEN	R/W	0	qdec enable

14.4.14 qdec2_ctrl1

地址: 0x4000a884

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	RSVD										LEDPED				
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	RSVD											IS	RPT	SPL	ACC

位	名称	权限	复位值	描述
31:25	RSVD			
24:16	LEDPED	R/W	0	Period in us the LED is switched on prior to sampling
15:4	RSVD			
3	IS	R/W	0	input a/b swap
2	RPT	R/W	0	rpt option 0: Count time only if sample change 1: Continue time
1	SPL	R/W	0	spl option 0: Stop sample if rpt_rdy 1: Continue sample
0	ACC	R/W	1	acc option 0: Stop accumulate if overflow 1: Continue accumulate

14.4.15 qdec2_value

地址: 0x4000a888

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
RSVD SPLVAL							RS	VD					ACC	2VAL	
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	ACC1VAL														

位	名称	权限	复位值	描述
31:30	RSVD			

BL702/704/706 参考手册 268/ 370 @2021 Bouffalo Lab



位	名称	权限	复位值	描述
29:28	SPLVAL	R	0	Sample value. Direction of last change 00: no change 01: clockwise 11: counter-clockwise 10: Error
27:20	RSVD			
19:16	ACC2VAL	R	0	Double error accumulation (0 15)
15:0	ACC1VAL	R	0	Sample accumulation (-32768 32767) clockwise +1, counter-clockwise -1

14.4.16 qdec2_int_en

地址: 0x4000a890

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	RSVD														
15	15 14 13 12 11 10 9 8 7 6 5 4 3 2 1												0		
	RSVD											OFEN	DREN	SREN	RREN

位	名称	权限	复位值	描述
31:4	RSVD			
3	OFEN	R/W	0	overflow interrupt enable
2	DREN	R/W	0	double error interrupt enable
1	SREN	R/W	0	sample interrupt enable
0	RREN	R/W	1	report interrupt enable

14.4.17 qdec2_int_sts

地址: 0x4000a894

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	RSVD														
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	RSVD											OF	DR	SR	RR
											STS	STS	STS	STS	

BL702/704/706 参考手册 269/ 370 @2021 Bouffalo Lab



位	名称	权限	复位值	描述
31:4	RSVD			
3	OFSTS	R	0	ACC1 or ACC2 overflow
2	DRSTS	R	0	ACC2 double error
1	SRSTS	R	0	Event being generated for every new sample value written to the SAMPLE register
0	RRSTS	R	0	Non-null report ready

14.4.18 qdec2_int_clr

地址: 0x4000a898

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	RSVD														
15	15 14 13 12 11 10 9 8 7 6 5 4										4	3	2	1	0
RSVD											OFCL	DRCL	SRCL	RRCL	

位	名称	权限	复位值	描述
31:4	RSVD			
3	OFCL	W1C	0	overflow interrupt clear
2	DRCL	W1C	0	double error interrupt clear
1	SRCL	W1C	0	sample interrupt clear
0	RRCL	W1C	0	report interrupt clear

BL702/704/706 参考手册 270/ 370 @2021 Bouffalo Lab

KeyScan

15.1 简介

KYS(Key Scan)模块用于对矩阵键盘进行扫描以获取键值,它会周期性的对键盘连接引脚进行扫描,一旦发现有按键接下会立即产生一个中断。

15.2 主要特征

- 可配置的行列数,最大可支持8行*20列的矩阵键盘
- 最多存储四个键值
- 支持按键中断

15.3 功能描述

15.3.1 可配置的行列数

通过寄存器 KS_CTRL 的位 <ROW_NUM> 和 <COL_NUM> 可以分别配置矩阵键盘的行列数,配置值为实际值减一。 行数最大支持 8 行,列数最大支持 20 列。

15.3.2 GPIO 选择

由于按键扫描固定从功能为 ROW_0 和 COL_0 的 GPIO 引脚开始扫描,所以行引脚需要从功能为 ROW_0 的 GPIO 开始往下依次选择,即从 GPIO0/GPIO8/GPIO16/GPIO24 中的任意一个开始,列引脚需要从功能为 COL_0 的 GPIO 开始往下依次选择,即从 GPIO0/GPIO20 中的任意一个开始。



15.3.3 键值

键值会存储在寄存器 KEYCODE_VALUE 中,每8位为一个键值,第一个键值会存放在最低8位。当寄存器 KEYCODE_-CLR 中对应序号的位被置一时,对应的键值和中断标志位会被清除。键值对应的行号=键值%总行数,键值对应的列号=键值/总行数。

15.3.4 中断

当检测到有按键按下时,中断标志位会置一,同时产生一个中断。

15.4 寄存器描述

名称	描述
ks_ctrl	Keyscan control
ks_int_en	Keyscan interrupt enable
ks_int_sts	Keyscan interrupt status
keycode_clr	Keycode clear
keycode_value	Keycode value

15.4.1 ks_ctrl

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	RSVD						COLNUM						ROWNUM		
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	RSVD RC						EXT DEGCNT					DEG	GHEN	RSVD	KSEN
												EN			

位	名称	权限	复位值	描述
31:25	RSVD			
24:20	COLNUM	R/W	5'd19	col_num + 1
19	RSVD			
18:16	ROWNUM	R/W	3'd7	row_num + 1
15:10	RSVD			
9:8	RCEXT	R/W	2'd3	idle duration between column scans
7:4	DEGCNT	R/W	0	deglitch count



位	名称	权限	复位值	描述
3	DEGEN	R/W	0	deglitch
2	GHEN	R/W	0	ghost key event detection
1	RSVD			
0	KSEN	R/W	0	Keyscan en

15.4.2 ks_int_en

地址: 0x4000a910

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	RSVD														
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	RSVD												KSIT		
													EN		

位	名称	权限	复位值	描述
31:1	RSVD			
0	KSITEN	R/W	1	Keyscan interrupt enable

15.4.3 ks_int_sts

地址: 0x4000a914

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	RSVD														
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
RSVD												KCV	ALID		

位	名称	权限	复位值	描述
31:4	RSVD			
3:0	KCVALID	R	0	Keycode valid

BL702/704/706 参考手册 273/ 370 @2021 Bouffalo Lab



15.4.4 keycode_clr

地址: 0x4000a918

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	RSVD														
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	RSVD												KC	CLR	

位	名称	权限	复位值	描述
31:4	RSVD			
3:0	KCCLR	W1C	0	Keycode clear

15.4.5 keycode_value

地址: 0x4000a91c

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	ксз							KC2							
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	KC1										K	C0			

位	名称	权限	复位值	描述
31:24	кс3	R	8'hff	Col = keycode / (row_num+1) Row = keycode
23:16	KC2	R	8'hff	Col = keycode / (row_num+1) Row = keycode
15:8	KC1	R	8'hff	Col = keycode / (row_num+1) Row = keycode
7:0	KC0	R	8'hff	Col = keycode / (row_num+1) Row = keycode

BL702/704/706 参考手册 274/ 370 @2021 Bouffalo Lab

12S

16.1 简介

I2S 是传输数字音频数据的一种接口标准,采用序列的方式传输 2 组(左右声道)数据。

I2S 将时钟信号与数据信号分开传输,使得接收端不用从数据信号还原时钟,进而降低接收端的设计难度。

16.2 主要特征

- 支持主模式以及从模式
- 支持 Left-justified/Right-justified/DSP 等数据格式
- 支持 8/16/24/32 比特数据宽度
- 除单声道/双声道模式之外,同时支持四声道模式
- 支持动态静音切换功能
- 数据发送 FIFO 的宽度为 32 位,深度 16
- 数据接收 FIFO 的宽度为 32 位,深度 16

16.3 功能描述

引脚列表:

表 16.1: I2S 引脚



名称	类型	描述
I2Sx_DI	输入	串行数据输入
I2Sx_DO	输出	串行数据输出
I2Sx_BCLK	输入/输出	同步传输时钟,作为主机时为输出,作为从机时为输入
I2Sx_FS	输入/输出	数据起始/结束表示信号,作为主机时为输出,作为从机时为输入

16.4 寄存器描述

名称	描述
i2s_config	I2S configuration
i2s_int_sts	I2S interrupt status
i2s_bclk_config	I2S clock configuration
i2s_fifo_config_0	I2S FIFO configuration0
i2s_fifo_config_1	I2S DMA FIFO configuration
i2s_fifo_wdata	I2S FIFO write data
i2s_fifo_rdata	I2S FIFO read data
i2s_io_config	I2S IO configuration

16.4.1 i2s_config

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
RSVD					OFS			OFSCNT	•		MONO RCH		MODE		
				EN							DIAN				
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
DATA	ASIZE	FRAN	ISIZE		RSVD		FSCH	FS4C	FS1T	MUTE	MONO	RXD	TXD	SLA	MAS
							MODE					EN	EN	EN	EN

位	名称	权限	复位值	描述
31:26	RSVD			
25	OFSEN	R/W	1'b0	Offset enable 1'b0: Disabled, 1'b1: Enabled



位	名称	权限	复位值	描述
24:20	OFSCNT	R/W	5'd0	Offset cycle count (unit: cycle of I2S BCLK) 5'd0: 1 cycle 5'd1: 2 cycles
19	MONORCH	R/W	1'b0	RX mono mode channel select signal 1'b0: L-channel 1'b1: R-channel
18	ENDIAN	R/W	1'b0	Data endian (bit reverse) 1'b0: MSB goes out first, 1'b1: LSB goes out first
17:16	MODE	R/W	2'd0	2'd0: Left-Justified, 2'd1: Right-Justified, 2'd2: DSP, 2'd3: Reserved
15:14	DATASIZE	R/W	2'd1	Data bit width of each channel 2'd0: 8, 2'd1: 16, 2'd2: 24, 2'd3: 32 (bits)
13:12	FRAMSIZE	R/W	2'd1	Frame size of each channel 2'd0: 8, 2'd1: 16, 2'd2: 24, 2'd3: 32 (cycles)
11:9	RSVD			
8	FSCHMODE	R/W	1'b0	1'b0: FS 2-channel mode, 1'b1: FS 3-channel mode (DSP mode only) Note: cr_fs_3ch_mode & cr_fs_4ch_mode should NOT be enabled at the same time Note: cr_mono_mode & cr_fifo_lr_merge will be invalid in 3-channel mode Note: When 3-channel mode is enabled, frame_size must equal data_size
7	FS4C	R/W	1'b0	1'b0: FS 2-channel mode, 1'b1: FS 4-channel mode (DSP mode only) Note: cr_fs_3ch_mode & cr_fs_4ch_mode should NOT be enabled at the same time Note: When 4-channel mode is enabled, frame_size must equal data_size
6	FS1T	R/W	1'b0	1'b0: FS high/low is even, 1'b1: FS only asserts for 1 cycle
5	MUTE	R/W	1'b0	1'b0: Normal mode, 1'b1: Mute mode
4	MONO	R/W	1'b0	1'b0: Stereo mode, 1'b1: Mono mode Note: csr_mono_mode & csr_fifo_lr_merge should NOT be enabled at the same time
3	RXDEN	R/W	1'b0	Enable signal of I2S RXD signal
2	TXDEN	R/W	1'b0	Enable signal of I2S TXD signal



位	名称	权限	复位值	描述
1	SLAEN	R/W	1'b0	Enable signal of I2S Slave function, cannot enable both csr_i2s_m_en & csr_i2s_s_en
0	MASEN	R/W	1'b0	Enable signal of I2S Master function, cannot enable both csr_i2s_m_en & csr_i2s_s_en

16.4.2 i2s_int_sts

地址: 0x4000aa04

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	
	RSVD					RXF	TXF		RSVD							
						EN	EN									
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	
		RSVD			FER	RXF	TXF			RSVD			FER	RXF	TXF	
						MASK	MASK						INT	INT	INT	

位	名称	权限	复位值	描述
31:27	RSVD			
26	FEREN	R/W	1'b1	Interrupt enable of i2s_fer_int
25	RXFEN	R/W	1'b1	Interrupt enable of i2s_rxf_int
24	TXFEN	R/W	1'b1	Interrupt enable of i2s_txf_int
23:11	RSVD			
10	FERMASK	R/W	1'b1	Interrupt mask of i2s_fer_int
9	RXFMASK	R/W	1'b1	Interrupt mask of i2s_rxf_int
8	TXFMASK	R/W	1'b1	Interrupt mask of i2s_txf_int
7:3	RSVD			
2	FERINT	R	1'b0	I2S TX/RX FIFO error interrupt, auto-cleared when FIFO overflow/underflow error flag is cleared
1	RXFINT	R	1'b0	I2S RX FIFO ready (rx_fifo_cnt > rx_fifo_th) interrupt, auto- cleared when data is popped
0	TXFINT	R	1'b0	I2S TX FIFO ready (tx_fifo_cnt > tx_fifo_th) interrupt, auto- cleared when data is pushed

BL702/704/706 参考手册 278/ 370 @2021 Bouffalo Lab



16.4.3 i2s_bclk_config

地址: 0x4000aa10

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	
	RS	VD			BDIVH											
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	
	RS	VD							BD	IVL						

位	名称	权限	复位值	描述
31:28	RSVD			
27:16	BDIVH	R/W	12'd1	I2S BCLK active high period (unit: cycle of i2s_clk)
15:12	RSVD			
11:0	BDIVL	R/W	12'd1	I2S BCLK active low period (unit: cycle of i2s_clk)

16.4.4 i2s_fifo_config_0

地址: 0x4000aa80

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	RSVD														
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
		RSVD			24B	LREC	LRMG	RUD	RO	TUD	ТО	RXF	TXF	DMA	DMA
					LJ			FLOW	FLOW	FLOW	FLOW	CLR	CLR	RXEN	TXEN

位	名称	权限	复位值	描述
31:11	RSVD			
10	24BLJ	R/W	1'b0	FIFO 24-bit data left-justified mode 1'b0: Right-justified, 8'h0, data[23:0] 1'b1: Left-justified, data[23:0], 8'h0 Note: Valid only when cr_data_size = 2'd2 (24-bit)
9	LREC	R/W	1'b0	The position of L/R channel data within each entry is exchanged if this bit is enabled Can only be enabled if data size is 8 or 16 bits and csr fifo_lr_merge is enabled

BL702/704/706 参考手册 279/ 370 @2021 Bouffalo Lab



位	名称	权限	复位值	描述
8	LRMG	R/W	1'b0	Each FIFO entry contains both L/R channel data if this bit is enabled Can only be enabled if data size is 8 or 16 bits Note: cr_fifo_lr_merge &cr_mono_mode should NOT be enabled at the same time Note: cr_fifo_lr_merge &cr_fifo_l_shift should NOT be enabled at the same time
7	RUDFLOW	R	1'b0	Underflow flag of RX FIFO, can be cleared by rx_fifo_clr
6	ROFLOW	R	1'b0	Overflow flag of RX FIFO, can be cleared by rx_fifo_clr
5	TUDFLOW	R	1'b0	Underflow flag of TX FIFO, can be cleared by tx_fifo_clr
4	TOFLOW	R	1'b0	Overflow flag of TX FIFO, can be cleared by tx_fifo_clr
3	RXFCLR	W1C	1'b0	Clear signal of RX FIFO
2	TXFCLR	W1C	1'b0	Clear signal of TX FIFO
1	DMARXEN	R/W	1'b0	Enable signal of dma_rx_req/ack interface
0	DMATXEN	R/W	1'b0	Enable signal of dma_tx_req/ack interface

16.4.5 i2s_fifo_config_1

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	
	RSVD RXTH								RS	VD		TXTH				
15	14	13	12 11 10 9 8				7	6	5	4 3 2 1				0		
	RSVD RXCNT						RSVD					TXCNT				

位	名称	权限	复位值	描述
31:28	RSVD			
27:24	RXTH	R/W	4'd0	RX FIFO threshold, dma_rx_req will not be asserted if tx fifo_cnt is less than this value
23:20	RSVD			
19:16	ТХТН	R/W	4'd0	TX FIFO threshold, dma_tx_req will not be asserted if tx fifo_cnt is less than this value
15:13	RSVD			
12:8	RXCNT	R	5'd0	RX FIFO available count
7:5	RSVD			
4:0	TXCNT	R	5'd16	TX FIFO available count



位	名称	权限	复位值	描述
---	----	----	-----	----

16.4.6 i2s_fifo_wdata

地址: 0x4000aa88

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	FIWD														
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	FIWD														

位	名称	权限	复位值	描述
31:0	FIWD	W	Х	I2S FIFO write data

16.4.7 i2s_fifo_rdata

地址: 0x4000aa8c

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	FIRD														
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	FIRD														

位	名称	权限	复位值	描述
31:0	FIRD	R	32'h0	I2S FIFO read data

16.4.8 i2s_io_config

地址: 0x4000aafc

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	RSVD														
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	RSVD						DEG		DEGCNT		BCLK	FS	RXD	TXD	
							EN				INV	INV	INV	INV	

BL702/704/706 参考手册 281/ 370 @2021 Bouffalo Lab



位	名称	权限	复位值	描述	
31:8	RSVD				
7	DEGEN	R/W	1'b0	Deglitch enable (for all th input pins) 1'b0: Disabled, 1'b1: Enabled	
6:4	DEGCNT	R/W	3'd0	Deglitch cycle count (unit: cycle of I2S kernel clock) 3'd0: 1 cycle 3'd1: 2 cycles	
3	BCLKINV	R/W	1'b0	Inverse BCLK signal 0: No inverse, 1: Inverse	
2	FSINV	R/W	1'b0	Inverse FS signal 0: No inverse, 1: Inverse	
1	RXDINV	R/W	1'b0	Inverse RXD signal 0: No inverse, 1: Inverse	
0	TXDINV	R/W	1'b0	Inverse TXD signal 0: No inverse, 1: Inverse	

17.1 简介

EMAC 模块是一个兼容 IEEE 802.3 的 10/100Mbps 以太网 MAC(Ethernet Media Access Controller)。其包含状态及 控制寄存器组,收发模块,收发缓冲描述符组,主机接口,MDIO,物理层芯片 (PHY) 接口。

状态及控制寄存器组包含了 EMAC 的状态位及控制位,是与用户程序的接口,负责控制数据收发,并汇报状态。

收发模块负责根据收发描述符内的控制字,从指定内存位置取得数据帧,添加前导,CRC,并扩充短的帧后通过 PHY 发出;或是从 PHY 接收数据,并根据收发缓冲描述符,将数据放入指定内存。收发完成后配置相关的事件标志。如果使能了事件中断,将通过中断请求到主机进行处理。

MDIO 及 MII/RMII 接口负责与 PHY 进行通信,包括读写 PHY 的寄存器,以及数据包的收发。

17.2 主要特征

- 兼容 IEEE 802.3 定义的 MAC 层功能
- 支持 IEEE 802.3 定义的 MII、RMII 接口的 PHY
- 通过 MDIO 与 PHY 交互
- 支持 10Mbps 与 100Mbps 以太网
- 支持半双工与全双工
- 在全双工模式下,支持自动流控及生成控制帧
- 在半双工模式下, 支持碰撞检测及重传
- 支持 CRC 的生成及校验
- 数据帧前导生成及移除
- 发送时,自动扩展短的数据帧
- 检测过长或过短的数据帧 (长度限制)



- 可传输长数据帧 (> 标准以太帧长度)
- 自动丢弃重发次数超限或帧间隙过小的包
- 广播包过滤
- 用于保存多达 128 个 BD(Buffer Descriptor) 的内部 RAM
- 发送/接收的各种事件标志
- 在事件发生时产生对应中断

17.3 功能描述

EMAC 模块的组成如下图。






图 17.1: EMAC 框图

模块的控制寄存器通过 MDIO,可以读写 PHY 的寄存器从而实现配置、选择模式 (半/全双工)、发起协商等操作。接收模块过滤并检查收到的数据帧:是否有合法的前导,FCS,长度等,并根据描述符,将数据帧存放到指定缓冲地址。发送模块根据数据缓冲描述符,从内存中取得数据,添加前导,FCS,pad 等,然后根据 CSMA/CD 协议,将数据发出。如果检测到 CRS,将会延迟重试。收发缓冲描述符组连接到外部的 RAM,此 RAM 用于保存发送和接收的以太网数据帧。每个描述符包含相应的控制状态字以及对应的缓冲内存地址。描述符一共有 128 组,可以灵活分配,用于发送或者接收。



17.4 时钟

EMAC 模块需要一路时钟用于同步收发 (100Mbps 时, 25MHz(MII) 或 50MHz(RMII); 10Mbps 时, 2.5MHz)。此时钟 必须在 EMAC 与 PHY 之间同步。

17.5 收发缓冲描述符 (BD, Buffer Descriptor)

收发缓冲描述符,用于提供 EAMC 与数据帧缓存地址信息之间的关联,对收发数据帧进行控制,以及提供收发状态提示。每个描述符由两个连续的 word(32bit) 构成,低地址的 word 提供了本 buffer 包含的数据帧的长度,控制及状态位;高地址的 word 是内存指针。具体的 BD 描述可以参考寄存器描述章节。需要注意的是:对于 BD,需要按 word 写入。EMAC 模块支持 128 个 BD,由发送/接收逻辑共享,可自由组合。但发送 BD 总是占据前面的连续区域 (个数由 MAC_-TX_BD_NUM 寄存器中的 TXBDNUM 域来指定)。EMAC 按照 BD 的顺序,循环处理发送/接收 BD,直到遇到标记为WR 的 BD 就回绕到发送/接收各自的首个 BD。

17.6 PHY 交互

PHY 交互寄存器组提供了 PHY 交互需要的命令及数据通信方式。EMAC 通过 MDIO 控制 PHY 的工作模式,并保证 两者匹配 (速率,全/半双工)。数据包通过 MII/RMII 接口在 EMAC 与 PHY 之间交互,可以通过 EMAC 的模式寄存器 (EMAC_MODE) 中的 RMII_EN 选择。当此 bit 为 1,则选择 RMII 模式,否则就是 MII 模式。MII 及 RMII 模式均支持 IEEE 802.3u 标准中指定的 10Mbps 与 100Mbps 的传输速率。MII 及 RMII 的传输信号描述与下表。

名称	MII	RMII
EXTCK_EREFCK	ETXCK: 发送时钟信号	EREFCK:参考时钟
ECRS	ECRS: 载波探测	-
ECOL	ECOL:碰撞检测	-
ERXDV	ERXDV: 数据 valid	ECRSDV: 载波检测/数据 valid
ERX0-ERX3	ERX0-ERX3: 4-bit 接收数据	ERX0-ERX1: 2-bit 接收数据
ERXER	ERXER:接收错误指示	ERXER:接收错误指示
ERXCK	ERXCK: 接收时钟信号	-
ETXEN	ETXEN: 发送使能	ETXEN: 发送使能
ETX0-ETX3	ETX0-ETX3: 4-bit 发送数据	ETX0-ETX1: 2-bit 发送数据
ETXER	ETXER: 发送错误指示	-
EMDC	MDIO Clock	MDIO Clock
EMDIO	MDIO Data Input Output	MDIO Data Input Output

表 17.1: 传输信号

RMII 接口引脚较少,使用 2-bit 数据线用于收发,在 100Mbps 速率时,需要提供 50MHz 的参考时钟。



17.7 编程流程

17.7.1 PHY 初始化

- 根据 PHY 类型,设置 EMAC_MODE 寄存器中的 RMII_EN 位来选择合适的连接方式
- 设置 EMAC 的 MAC 地址到 EMAC_MAC_ADDR0 与 EMAC_MAC_ADDR1 中
- 通过编程 EMAC MIIMODE 寄存器中的域 CLKDIV, 为 MDIO 部分设置合适的时钟
- 设置对应 PHY 的地址到寄存器 EMAC_MIIADDRESS 的域 FIAD 中
- 根据 PHY 的手册,通过 EMAC MIICOMMAND 与 EMAC MIITX DATA 寄存器发送命令
- 读取 PHY 的数据会保存在 EMAC MIIRX DATA 寄存器中
- 通过 EMAC MIISTATUS 寄存器可以查询与 PHY 命令交互的状态

基础的交互完成后,应当使 PHY 进入自动协商状态。协商完成之后,根据协商结果编程模式到 EMAC_MODE 寄存器中的 FULLD 位。

17.7.2 发送数据帧

- 配置 EMAC_MODE 寄存器中数据帧格式、间隔等位域
- 通过配置 EMAC_TX_BD_NUM 寄存器中的 TXBDNUM 域来指定发送所使用的 BD 的个数,那么剩余的就是 RX 的 BD
- 在内存中准备好需要发送的数据帧
- 将数据帧的地址填写到对应发送 BD 的数据指针域 (word 1) 中
- 清空对应发送 BD 的控制与状态域 (wrod 0) 中的状态标记,并设置控制域 (CRC 使能, PAD 使能,中断使能等)
- 写入数据帧长度,并设置好 RD 域,告知 EMAC 此 BD 数据需要发送;如需要,设置上 IRQ 位,以使能中断
- 特别的,如果是最后一个发送的 BD,需要设置上 WR 位,EMAC 会在处理完这个 BD 之后"回绕"到第一个发送 BD 进行处理
- 如果有多个 BD 需要发送,则重复设置 BD 的步骤以填充所有的发送 BD
- 如果需要使能发送中断,还需要配置 EMAC_INT_MASK 寄存器中的 TX 相关位
- 配置 EMAC MODE 寄存器中的 TXEN 位,以使能发送
- 如果使能了中断,在发送的中断中,可用通过 EMAC_TX_BD_NUM 寄存器中的 TXBDNUM 域获取当前的 BD
- 根据当前 BD 的状态字进行相应的处理
- 数据已被发送出去的 BD, 其控制域中的 RD 位会被硬件清零,且不会被再次发送;需要填充新数据后,置位 RD, 此 BD 即可再次用于发送

BL702/704/706 参考手册 287/ 370 @2021 Bouffalo Lab



17.7.3 接收数据帧

- 配置 EMAC_MODE 寄存器中数据帧格式、间隔等位域
- 通过配置 EMAC_TX_BD_NUM 寄存器中的 TXBDNUM 域来指定发送所使用的 BD 的个数,那么剩余的就是 RX 的 BD
- 在内存中准备好接收数据的区域
- 将数据帧的地址填写到对应接收 BD 的数据指针域 (word 1) 中
- 清空对应发送 BD 的控制与状态域 (wrod 0) 中的状态标记,并设置控制域 (中断使能等)
- 写入可接收的数据帧长度,并设置好 E 位域,告知 EMAC 此 BD 空闲,可以用于数据接收;如需要,设置上 IRQ 位,以使能中断
- 特别的,如果是最后一个有效接收 BD,需要设置上 WR 位, EMAC 会在处理完这个 BD 之后"回绕"到第一个接收 BD 进行处理
- 如果有多个 BD 可供接收数据,则重复设置 BD 的步骤以填充所有的 BD
- 如果需要使能接收中断,还需要配置 EMAC_INT_MASK 寄存器中的 RX 相关位
- 配置 EMAC MODE 寄存器中的 RXEN 位,以使能接收
- 如果使能了中断,在接收的中断中,可用通过 EMAC_TX_BD_NUM 寄存器中的 RXBDNUM 域获取当前的 BD
- 根据当前 BD 的状态字进行相应的处理
- 接收完成的 BD, 其控制域中的 E 位会被硬件清零,且不会被再次用于接收;需要取走数据,置位 E,此 BD 即可再次用于接收

17.8 寄存器描述

名称	描述				
MODE	EMAC configuration				
INT_SOURCE	EMAC transmit control				
INT_MASK	EMAC interrupt mask				
IPGT	Inter packet gap				
PACKETLEN	Frame length				
COLLCONFIG	Collision configuration				
TX_BD_NUM	TX buffer descriptors number				
MIIMODE	Management Data configuration				
MIICOMMAND	Trigger command				



名称	描述
MIIADDRESS	Register address
MIITX_DATA	Control data to be written to PHY
MIIRX_DATA	Received data from PHY
MIISTATUS	MIIM I/F status
MAC_ADDR0	Ethernet MAC address0
MAC_ADDR1	Ethernet MAC address1
HASH0_ADDR	Lower 32-bit of HASH register
HASH1_ADDR	Upper 32-bit of HASH register
TXCTRL	TX control

17.8.1 MODE

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
						RS	VD							RMII	RECS
														EN	MALL
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
PAD	HUG	CRC	RS	VD	FULL		RSVD		IFG	PRO	RSVD	BRO	NO	TXEN	RXEN
	EN	EN			D								PRE		

位	名称	权限	复位值	描述
31:18	RSVD			
17	RMIIEN	R/W	1'b0	RMII mode enable 0: MII PHY I/F is used 1: RMII PHY I/F is used
16	RECSMALL	R/W	1'b0	Receive small frame enable 0: Frames smaller than MINFL are ignored. 1: Frames smaller than MINFL are accepted.
15	PAD	R/W	1'b1	Padding enable 0: Do not add pads to frames shorter than MINFL. 1: Add pads to short frames, until the length equals MINFL.



位	名称	权限	复位值	描述
14	HUGEN	R/W	1'b0	Huge frames enable 0: The maximum frame length is MAXFL. All additional bytes are dropped. 1: Frame size is not limited by MAXFL and can be up to 64K bytes.
13	CRCEN	R/W	1'b1	CRC Enable 0: TX MAC does not append CRC field. 1: TX MAC will append CRC field to every frame.
12:11	RSVD			
10	FULLD	R/W	1'b0	Full duplex 0: Half duplex mode. 1: Full duplex mode.
9:7	RSVD			
6	IFG	R/W	1'b0	Inter frame gap check 0: IFG is verified before each frame be received. 1: All frames are received regardless to IFG requirement.
5	PRO	R/W	1'b0	Promiscuous mode enable 0: The destination address is checked before receiving. 1: All frames received regardless of the address.
4	RSVD			
3	BRO	R/W	1'b1	Broadcast address enable 0: Reject all frames containing the broadcast address unless the PRO bit is asserted. 1: Receive all frames containing broadcast address.
2	NOPRE	R/W	1'b0	No preamble mode 0: 7-byte preamble will be sent. 1: No preamble will be sent.
1	TXEN	R/W	1'b0	Transmit enable 0: Transmitter is disabled. 1: Transmitter is enabled. If TX_BD_NUM equals 0x0 (zero buffer descriptors are used), then the transmitter is disabled regardless of TXEN.
0	RXEN	R/W	1'b0	Receiver enable 0: Receiver is disabled. 1: Receiver is enabled. If TX_BD_NUM equals 0x80 (all buffer descriptors are used for TX), then the receiver is disabled regardless of RXEN.



17.8.2 INT_SOURCE

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	RSVD														
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	RSVD								RXC	TXC	BUSY	RXE	RXB	TXE	TXB

位	名称	权限	复位值	描述
31:7	RSVD			
6	RXC	R/W	1'b0	Receive control frame This bit indicates that the control frame was received. It is cleared by writing 1 to it. Bit RXFLOW in the CTRLMODE register must be set to 1 in order to get the RXC bit set.
5	TXC	R/W	1'b0	Transmit control frame This bit indicates that a control frame was transmitted. It is cleared by writing 1 to it. Bit TXFLOW in the CTRLMODE register must be set to 1 in order to get the TXC bit set.
4	BUSY	R/W	1'b0	Busy This bit indicates that RX packet is being received and there is no empty buffer descriptor to use. It iscleared by writing 1 to it. This bit appears regardless to the IRQ bits in the Receive Buffer Descriptor.
3	RXE	R/W	1'b0	Receive error This bit indicates that an error occurred while receiving data (overrun, receiver error, dribble nibble, too long, >64K, CRC error, bus error or late collision. It is cleared by writing 1 to it. This bit appears only when IRQ bit is set in the Receive Buffer Descriptor.
2	RXB	R/W	1'b0	Receive frame This bit indicates that a frame was received. It is cleared by writing 1 to it. This bit appears only when IRQ bit is set in the Receive Buffer Descriptor.



位	名称	权限	复位值	描述
1	TXE	R/W	1'b0	Transmit error This bit indicates that a buffer was not transmitted due to a transmit error (underrun, retransmission limit, late collision, bus error or defer timeout). It is cleared by writing 1 to it. This bit appears only when IRQ bit is set in the Transmit Buffer Descriptor.
0	ТХВ	R/W	1'b0	Transmit buffer This bit indicates that a buffer has been transmitted. It is cleared by writing 1 to it. This bit appears only when IRQ bit is set in the Transmit Buffer Descriptor.

17.8.3 INT_MASK

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	RSVD														
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
				RSVD					RXCM	TXCM	ВМ	RXEM	RXBM	TXEM	TXBM

位	名称	权限	复位值	描述
31:7	RSVD			
6	RXCM	R/W	1'b1	Receive control frame mask ENABLE 0: Interrupt is un-masked 1: Interrupt is masked
5	TXCM	R/W	1'b1	Transmit control frame mask ENABLE 0: Interrupt is un-masked 1: Interrupt is masked
4	ВМ	R/W	1'b1	Busy mask ENABLE 0: Interrupt is un-masked 1: Interrupt is masked
3	RXEM	R/W	1'b1	Receive error mask ENABLE 0: Interrupt is un-masked 1: Interrupt is masked
2	RXBM	R/W	1'b1	Receive frame mask ENABLE 0: Interrupt is un-masked 1: Interrupt is masked



位	名称	权限	复位值	描述
1	TXEM	R/W	1'b1	Transmit error mask ENABLE 0: Interrupt is un-masked 1: Interrupt is masked
0	ТХВМ	R/W	1'b1	Transmit buffer mask ENABLE 0: Interrupt is un-masked 1: Interrupt is masked

17.8.4 IPGT

地址: 0x4000d00c

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	RSVD														
15	15 14 13 12 11 10 9 8 7								6	5	4	3	2	1	0
	RSVD											IPGT			

位	名称	权限	复位值	描述
31:7	RSVD			
6:0	IPGT	R/W	7'h18	Inter packet gap The recommended value is 0x18 (24 clock cycles), which equals 9.6 us for 10 Mbps and 0.96 us for 100 Mbps mode

17.8.5 PACKETLEN

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	MINFL														
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	MAXFL														



位	名称	权限	复位值	描述
31:16	MINFL	R/W	16'h40	Minimum frame length The minimum Ethernet packet is 64 bytes long (0x40). To receive small packets, assert the RECSMALL bit or change the MINFL value. To transmit small packets, assert the PAD bit or change the MINFL value.
15:0	MAXFL	R/W	16'h600	Maximum frame length The maximum Ethernet packet is 1518 bytes long. To support this and to have some additional space for tags, a default maximum packet length equals to 1536 bytes (0x600). For bigger packets, you can assert the HUGEN bit or increase the value of MAXFL field.

17.8.6 COLLCONFIG

地址: 0x4000d01c

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
					RS	VD					MAXRET 5 4 3 2 1				
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	RSVD											COL	LVAL		

位	名称	权限	复位值	描述
31:20	RSVD			
19:16	MAXRET	R/W	4'hF	Maximum retry This field specifies the maximum number of consequential retransmission attempts after the collision is detected. When the maximum number has been reached, the TX MAC reports an error and stops transmitting the current packet. According to the Ethernet standard, the MAXRET default value is set to 0xf (15).
15:6	RSVD			
5:0	COLLVAL	R/W	6'h3F	Collision valid This field specifies a collision time window. A collision that occurs later than the time window is reported as a "Late Collisions" and transmission of the current packet is aborted.



17.8.7 TX_BD_NUM

地址: 0x4000d020

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
RSVD			F	RXBDPTF	₹			RSVD TXBDPTR							
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
			RS	SVD							TXBD	NUM			

位	名称	权限	复位值	描述
31	RSVD			
30:24	RXBDPTR	R	7'h0	RX buffer descriptors (BD) pointer, pointing at the RXBD currently being used
23	RSVD			
22:16	TXBDPTR	R	7'h0	TX buffer descriptors (BD) pointer, pointing at the TXBD currently being used
15:8	RSVD			
7:0	TXBDNUM	R/W	8'h40	TX buffer descriptors (BD) number Number of TX BD. TX and RX share 128 (0x80) descriptors, so the number of RX BD equals 0x80 - TXBDNUM. The maximum number of TXBDNUM is 0x80. Values greater then 0x80 cannot be written into this register.

17.8.8 MIIMODE

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
							RS	VD							
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
			RSVD				MINO PRE				CLK	(DIV			

位	名称	权限	复位值	描述
31:9	RSVD			
8	MINOPRE	R/W	1'b0	No preamble for Management Data (MD) 0: 32-bit preamble will be sent. 1: No preamble will be sent.



位	名称	权限	复位值	描述
7:0	CLKDIV	R/W	8'h64	Clock divider for Management Data Clock (MDC) The source clock is bus clock and can be divided by any even number.

17.8.9 MIICOMMAND

地址: 0x4000d02c

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
							RS	VD							
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	,			,		RSVD				,			WCTR	RSTA	SCAS
													DATA		

位	名称	权限	复位值	描述
31:3	RSVD			
2	WCTRDATA	R/W	1'b0	Write control data, setting this bit to 1 will trigger the command (auto cleared) Note: [2]/[1]/[0] cannot be asserted at the same time, execute one command at a time
1	RSTA	R/W	1'b0	Read status, setting this bit to 1 will trigger the command (auto cleared) Note: [2]/[1]/[0] cannot be asserted at the same time, execute one command at a time
0	SCAS	R/W	1'b0	Scan status, setting this bit to 1 will trigger the command (auto cleared) Note: [2]/[1]/[0] cannot be asserted at the same time, execute one command at a time

17.8.10 MIIADDRESS

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
RSVD															
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	RSVD			RGAD RSVD FIAD											



位	名称	权限	复位值	描述
31:13	RSVD			
12:8	RGAD	R/W	5'h0	Register Address
7:5	RSVD			
4:0	FIAD	R/W	5'h0	PHY Address

17.8.11 MIITX_DATA

地址: 0x4000d034

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	RSVD														
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	CTRLDATA														

位	名称	权限	复位值	描述
31:16	RSVD			
15:0	CTRLDATA	R/W	16'h0	Control Data to be written to PHY

17.8.12 MIIRX_DATA

地址: 0x4000d038

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	RSVD														
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	PRSD														

位	名称	权限	复位值	描述
31:16	RSVD			
15:0	PRSD	R	16'h0	Received Data from PHY

BL702/704/706 参考手册 297/ 370 @2021 Bouffalo Lab



17.8.13 MIISTATUS

地址: 0x4000d03c

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	RSVD														
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	RSVD												MIIM BUSY	MIIM LF	

位	名称	权限	复位值	描述
31:2	RSVD			
1	MIIMBUSY	R	1'b0	MIIM I/F busy signal 0: The MIIM I/F is ready. 1: The MIIM I/F is busy.
0	MIIMLF	R	1'b0	MIIM I/F link fail signal

17.8.14 MAC_ADDR0

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	MACB2										MAG	CB3			
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	MACB4										MAG	CB5			

位	名称	权限	复位值	描述
31:24	MACB2	R/W	8'd0	Ethernet MAC address byte 2
23:16	MACB3	R/W	8'd0	Ethernet MAC address byte 3
15:8	MACB4	R/W	8'd0	Ethernet MAC address byte 4
7:0	MACB5	R/W	8'd0	Ethernet MAC address byte 5



17.8.15 MAC_ADDR1

地址: 0x4000d044

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	RSVD														
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	MACB0										MA	CB1			

位	名称	权限	复位值	描述
31:16	RSVD			
15:8	MACB0	R/W	8'd0	Ethernet MAC address byte 0
7:0	MACB1	R/W	8'd0	Ethernet MAC address byte 1

17.8.16 HASH0_ADDR

地址: 0x4000d048

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	HASH0														
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	HASH0														

位	名称	权限	复位值	描述
31:0	HASH0	R/W	32'h0	Lower 32-bit of HASH register

17.8.17 HASH1_ADDR

地址: 0x4000d04c

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	HASH1														
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	HASH1														

位	名称	权限	复位值	描述
31:0	HASH1	R/W	32'h0	Upper 32-bit of HASH register



17.8.18 TXCTRL

地址: 0x4000d050

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	RSVD													TXP	
														RQ	
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	TXPTV														

位	名称	权限	复位值	描述
31:17	RSVD			
16	TXPRQ	R/W	1'b0	TX Pause Request Writing 1 to this bit starts sending control frame and is automatically cleared to zero.
15:0	TXPTV	R/W	16'h0	TX Pause Timer Value The value that is sent in the pause control frame.

BL702/704/706 参考手册 300/ 370 @2021 Bouffalo Lab

18.1 简介

USB(Universal Serial Bus) 通用串行总线,完全支持 USB1.1 全速设备,对 USB2.0 部分支持。

18.2 主要特征

- 支持 USB full speed device-mode
- 支持 8 个双向端点: EP0 可配置为控制/批量/中断/同步端点, EP1-EP7 可配置为批量/中断/同步端点
- 每个端点均包含 TX、RX 两个方向的 FIFO, FIFO 深度 64 字节,并且支持 DMA
- 支持内部 transceiver
- 支持 suspend/resume
- 支持 LPM
- 支持多种 USB 中断配置

18.3 功能描述

18.3.1 USB 使用步骤

- 1. 配置内部 transceiver, 寄存器在 0x40000228 和 0x4000022C
- 2. 配置 usb_config 及各个端点的 epx_config
- 3. 配置 USB 中断相关寄存器
- 4. 配置 USB DMA 相关(可选)
- 5. 配置 GPIO 为 USB 功能(内部 transceiver----function 为 10)
- 6. 置一 0x40000228[20]usb_enum 以触发主机端枚举流程



18.3.2 部分寄存器配置及功能描述

- swrdy: 只读,仅当此位为 0 时,才可以向 cr_usb_ep0_sw_rdy 写入 1
- crsr: 写 1 自动清零,当软件允许下一包回复 ACK 时向此域写 1,则仅下一包会回复 ACK,对于 OUT/IN 事务数据 会收入 FIFO/从 FIFO 发出(FIFO 放行一次)
- e0snko: 需要置一,代表 OUT 事务会默认回复 NAK,数据不会进入 FIFO(FIFO 不放行)
- e0snki: 需要置一,代表 IN 事务会默认回复 NAK,数据不会从 FIFO 发出(FIFO 不放行)
- e0ss: 写 1 自动清零,当软件允许下一包回复 STALL 时向此域写 1,则仅下一包会回复 STALL
- epxdit: "令牌包 => 触发 xxx_cmd_int => 数据包 => 触发 xxx_done_int => 握手包"
- epxcit: "令牌包 => 触发 xxx_cmd_int => 数据包 => 触发 xxx_done_int => 握手包"
- ep0odit: "令牌包 => 触发 xxx cmd int => 数据包 => 触发 xxx done int => 握手包"
- ep0ocit: "令牌包 => 触发 xxx cmd int => 数据包 => 触发 xxx done int => 握手包"
- ep0idit: "令牌包 => 触发 xxx cmd int => 数据包 => 触发 xxx done int => 握手包"
- ep0icit: "令牌包 => 触发 xxx cmd int => 数据包 => 触发 xxx done int => 握手包"
- ep0sdit: "令牌包 => 触发 xxx cmd int => 数据包 => 触发 xxx done int => 握手包"
- ep0scit: "令牌包 => 触发 xxx cmd int => 数据包 => 触发 xxx done int => 握手包"
- exrs: 只读, 仅当此位为 0 时, 才可以向 cr_epx_rdy 写入 1
- exr: 写 1 自动清零,当软件允许下一包回复 ACK 时向此域写 1,则仅下一包会回复 ACK (FIFO 放行一次)
- exn: 需要置一,代表事务会默认回复 NAK, IN/OUT 取决于当前端点的传输方向配置(FIFO 不放行)
- exs: 当软件希望挂起此端点时置一,置一后此端点永远只回复 STALL






图 18.1: USB 中断触发方式



18.3.3 USB 枚举阶段中断处理流程

- 1. 首先是 10ms 以上的 reset, 会触发 reset 中断。
- 2. 当 reset 结束时, 会触发 reset end 中断。
- 3. 枚举过程的 SETUP 事务、IN 事务、OUT 事务会分别触发 e0sdit、e0icit、ep0dit。
- 4. 枚举结束后, 主机与特定端点 EPx 之间的 IN 事务、OUT 事务会分别触发 epxcit、epxdit。

18.3.4 各传输事务的寄存器操作流程

- 控制传输——SETUP 事务数据接收:
 - 进入中断
 - 判断 eOsdit 中断标志位
 - eOrfr 内存放的就是 setup 事务所传来的数据,根据 eOrfc 读取 eOrfr 即可获得
 - 置一 crsr 以放行后续事务
 - 清除中断标志位
 - 退出中断
- 控制传输——IN 事务数据发送:
 - 进入中断
 - 判断 e0idit 中断标志位
 - 等待 swrdy 为 0 时才可以向 e0tfw 内写入数据
 - 置一 crsr 以放行后续事务
 - 清除中断标志位
 - 退出中断
- · 控制传输——OUT 事务数据接收:
 - 进入中断
 - 判断 ep0dit 中断标志位
 - e0rfr 内存放的就是 OUT 事务所传来的数据,根据 e0rfc 读取 e0rfr 即可获得
 - 置一 crsr 以放行后续事务
 - 清除中断标志位
 - 退出中断



- EPx(x=1...7)——IN 事务数据发送:
 - 进入中断
 - 判断 epxcit 中断标志位
 - 等待 exrs 为 0 时才可以向 extfw 内写入数据(仅当只发送 1 个字节时, exs 需要修改为 1)
 - 置一 exr 以放行后续事务
 - 清除中断标志位
 - 退出中断
- EPx(x=1...7)——OUT 事务数据接收:
 - 进入中断
 - 判断 epxdit 中断标志位
 - exrfr 内存放的就是 OUT 事务所传来的数据,根据 exrfc 读取 exrfr 即可获得
 - 置一 exrs 以放行后续事务
 - 清除中断标志位
 - 退出中断






图 18.2: USB 通信方式

内部 transceiver 寄存器推荐配置:



表 18.1: 寄存器配置 1

GPIO	SWGPIO					
usb_xcvr	value					
usb_rcv	read only					
usb_vip	read only					
usb_vim	read only					
usb_bd	read only					
pu_usb	0->1					
usb_sus	0					
usb_spd	1					
usb_enum	0->1					
usb_data_convert	0					
usb_oeb	read only					
usb_oeb_reg	1					
usb_oeb_sel	0					
usb_rout_pmos	3					
usb_rout_nmos	3					
pu_usb_ldo	0					
usb_ldo_vfb	3					

表 18.2: 寄存器配置 2

GPIO	SWGPIO
usb_xcvr_config	value
usb_slewrate_p_rise	4
usb_slewrate_p_fall	3
usb_slewrate_m_rise	4
usb_slewrate_m_fall	3
usb_res_pullup_tune	2
reg_usb_use_ctrl	0
usb_str_drv	1
reg_usb_use_xcvr	1



表 18.2: 寄存器配置 2

GPIO	SWGPIO
usb_bd_vth	7
usb_v_hys_p	1
usb_v_hys_m	1

注意: 当准备开启内部 transceiver 时需要将 pu_usb 和 usb_enum 置一。

18.4 寄存器描述

名称	描述
usb_config	USB configuration
usb_lpm_config	USB lpm configuration
usb_resume_config	USB resume configuration
usb_frame_no	USB frame number
usb_error	USB error
usb_int_en	USB interrupt enable
usb_int_sts	USB interrupt status
usb_int_mask	USB interrupt mask
usb_int_clear	USB interrupt clear
ep1_config	EP1 configuration
ep2_config	EP2 configuration
ep3_config	EP3 configuration
ep4_config	EP4 configuration
ep5_config	EP5 configuration
ep6_config	EP6 configuration
ep7_config	EP7 configuration
ep0_fifo_config	EP0 fifo configuration
ep0_fifo_status	EP0 fifo status
ep0_tx_fifo_wdata	EP0 tx fifo write data



名称	描述
ep0_rx_fifo_rdata	EP0 rx fifo write data
ep1_fifo_config	EP1 fifo configuration
ep1_fifo_status	EP1 fifo status
ep1_tx_fifo_wdata	EP1 tx fifo write data
ep1_rx_fifo_rdata	EP1 rx fifo write data
ep2_fifo_config	EP2 fifo configuration
ep2_fifo_status	EP2 fifo status
ep2_tx_fifo_wdata	EP2 tx fifo write data
ep2_rx_fifo_rdata	EP2 rx fifo write data
ep3_fifo_config	EP3 fifo configuration
ep3_fifo_status	EP3 fifo status
ep3_tx_fifo_wdata	EP3 tx fifo write data
ep3_rx_fifo_rdata	EP3 rx fifo write data
ep4_fifo_config	EP4 fifo configuration
ep4_fifo_status	EP4 fifo status
ep4_tx_fifo_wdata	EP4 tx fifo write data
ep4_rx_fifo_rdata	EP4 rx fifo write data
ep5_fifo_config	EP5 fifo configuration
ep5_fifo_status	EP5 fifo status
ep5_tx_fifo_wdata	EP5 tx fifo write data
ep5_rx_fifo_rdata	EP5 rx fifo write data
ep6_fifo_config	EP6 fifo configuration
ep6_fifo_status	EP6 fifo status
ep6_tx_fifo_wdata	EP6 tx fifo write data
ep6_rx_fifo_rdata	EP6 rx fifo write data
ep7_fifo_config	EP7 fifo configuration
ep7_fifo_status	EP7 fifo status
ep7_tx_fifo_wdata	EP7 tx fifo write data
ep7_rx_fifo_rdata	EP7 rx fifo write data



名称	描述
xcvr_if_config	

18.4.1 usb_config

地址: 0x4000d800

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	RSVD		SW RDY	CRSR	E0S NKO	E0S NKI	E0SS	E0SIZE							
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	EOSWADDR					E0SC		RSVD		RBEN		RSVD		USB	
														EN	

位	名称	权限	复位值	描述
31:29	RSVD			
28	SWRDY	R	1'b0	EP0 transaction ready status bit. Asserted with sw_rdy, and de-asserted when ACK is sent/received.
27	CRSR	W1C	1'b0	EP0 transaction ready. When NACK is enabled, asserting this bit will allow one packet to be transferred even if NACK is asserted Set 1 when a transaction needs to be released once (respond ACK)
26	E0SNKO	R/W	1'b0	EP0 OUT/SETUP transaction nack response (SW control mode) Note: Should NOT enable both ep0_sw_nack_out and ep0_sw_stall at the same time must be 1
25	EOSNKI	R/W	1'b1	EP0 IN transaction nack response (SW control mode) Note: Should NOT enable both ep0_sw_nack_in and ep0 sw_stall at the same time must be 1
24	EOSS	W1C	1'b0	EP0 stall response (SW control mode) Note: Should NOT enable both ep0_sw_nack_in/out and ep0_sw_stall at the same time Set 1 when a handshake needs to be stall once (respond STALL)

BL702/704/706 参考手册 310/ 370 @2021 Bouffalo Lab



位	名称	权限	复位值	描述
23:16	E0SIZE	R/W	8'd0	EP0 transfer size (SW control mode) max packet size is 64
15:9	EOSWADDR	R/W	7'd0	EP0 address (SW control mode) device address
8	EOSC	R/W	1'b0	EP0 software control enable 1'b1: EP0 IN/OUT transaction is fully contolled by SW 1'b0: EP0 IN/OUT transaction is controlled by HW must be 1
7:5	RSVD			
4	RBEN	R/W	1'b1	Enable signal of ROM-based descriptors (don't care if ep0 sw_ctrl is asserted) 1'b1: USB descriptors stored in ROM will be used 1'b0: SW should prepare the descriptors requested by HOST must be 0
3:1	RSVD			
0	USBEN	R/W	1'b0	Enable signal of USB function

18.4.2 usb_lpm_config

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
LPM					L	_PMATTF	₹						RS	VD	
STS															
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
					RS	VD						LPMF	RESP	RPUD	LPM
															EN

位	名称	权限	复位值	描述
31	LPMSTS	R	1'b0	LPM status bit
30:20	LPMATTR	R	11'h0	LPM attributes received in LPM packet
19:4	RSVD			
3:2	LPMRESP	R/W	2'd2	Response when LPM packet is received 2'd3: NYET 2'd2: STALL 2'd1: NACK 2'd0: ACK



位	名称	权限	复位值	描述
1	RPUD	W1C	1'b0	Response update signal (for async concern) Assert this bit when cr_lpm_resp is updated
0	LPMEN	W1C	1'b0	LPM enable signal

18.4.3 usb_resume_config

地址: 0x4000d808

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
RSFC								RSVD							
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	RSVD		RSTG	RSVD						RSWD					

位	名称	权限	复位值	描述
31	RSFC	R/W	1'b0	Force to output K-state
30:13	RSVD			
12	RSTG	W1C	1'b0	Resume K-state trigger
11	RSVD			
10:0	RSWD	R/W	11'd26	Resume K-state width (unit: 2.67us)

18.4.4 usb_frame_no

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	RSVD EPNO														
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	Р	ID		RSVD	FRANM										

位	名称	权限	复位值	描述
31:20	RSVD			
19:16	EPNO	R	4'd0	Endpoint number of the current transaction
15:12	PID	R	4'd0	PID value of the current transaction
11	RSVD			
10:0	FRANM	R	11'h0	Current frame number



18.4.5 usb_error

地址: 0x4000d81c

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
							RS	VD							
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
				RSVD					CRC16	CRC5	PCSE	PSEO	IEEO	TTEO	UREO
									ERR	ERR					

位	名称	权限	复位值	描述
31:7	RSVD			
6	CRC16ERR	R	1'b0	Data CRC error occurs, cleared by cr_usb_err_clr, enabled by ueen
5	CRC5ERR	R	1'b0	Token CRC error occurs, cleared by cr_usb_err_clr, enabled by ueen
4	PCSE	R	1'b0	PID check sum error occurs, cleared by cr_usb_err_clr, enabled by ueen
3	PSEO	R	1'b0	PID sequence error occurs, cleared by cr_usb_err_clr, enabled by ueen
2	IEEO	R	1'b0	Invalid endpoint error occurs, cleared by cr_usb_err_clr, enabled by ueen
1	TTEO	R	1'b0	Transfer time-out error occurs, cleared by cr_usb_err_clr, enabled by ueen
0	UREO	R	1'b0	UTMI I/F RX error occurs, cleared by cr_usb_err_clr, enabled by ueen

18.4.6 usb_int_en

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
UEEN	S3EN	LPEN	LWEN	RDEN		RSVD		EP7D EN	EP7C EN	EP6D EN	EP6C EN	EP5D EN	EP5C EN	EP4D EN	EP4C EN
15	14	13	12	11	10	9	8	7	6	5	4	2	0	4	0
			12	- 11	10	9	O	,	6	5	4	3	2	ı	0
EP3D	EP3C	EP2D	EP2C	EP1D	EP1C	E0OD	E0OC	E0ID	EOIC	E0SD	E0SC	GDC	VTEN	UREN	SEN



位	名称	权限	复位值	描述
31	UEEN	R/W	1'b1	Interrupt enable of usb_err_int
30	S3EN	R/W	1'b0	Interrupt enable of sof_3ms_int SOF is absent for 3 times (3ms) interrupt enable
29	LPEN	R/W	1'b0	Interrupt enable of lpm_pkt_int receive link power mangement packet interrupt enable
28	LWEN	R/W	1'b0	Interrupt enable of lpm_wkup_int receive link power mangement resume (wakeup) packet interrupt enable
27	RDEN	R/W	1'b0	Interrupt enable of usb_rend_int reset end interrupt enable
26:24	RSVD			
23	EP7DEN	R/W	1'b1	Interrupt enable of ep7_done_int
22	EP7CEN	R/W	1'b1	Interrupt enable of ep7_cmd_int
21	EP6DEN	R/W	1'b1	Interrupt enable of ep6_done_int
20	EP6CEN	R/W	1'b1	Interrupt enable of ep6_cmd_int
19	EP5DEN	R/W	1'b1	Interrupt enable of ep5_done_int
18	EP5CEN	R/W	1'b1	Interrupt enable of ep5_cmd_int
17	EP4DEN	R/W	1'b1	Interrupt enable of ep4_done_int
16	EP4CEN	R/W	1'b1	Interrupt enable of ep4_cmd_int
15	EP3DEN	R/W	1'b1	Interrupt enable of ep3_done_int
14	EP3CEN	R/W	1'b1	Interrupt enable of ep3_cmd_int
13	EP2DEN	R/W	1'b1	Interrupt enable of ep2_done_int
12	EP2CEN	R/W	1'b1	Interrupt enable of ep2_cmd_int
11	EP1DEN	R/W	1'b1	Interrupt enable of ep1_done_int
10	EP1CEN	R/W	1'b1	Interrupt enable of ep1_cmd_int
9	E00DEN	R/W	1'b1	Interrupt enable of ep0_out_done_int
8	E00CEN	R/W	1'b1	Interrupt enable of ep0_out_cmd_int
7	E0IDEN	R/W	1'b1	Interrupt enable of ep0_in_done_int
6	E0ICEN	R/W	1'b1	Interrupt enable of ep0_in_cmd_int
5	EOSDEN	R/W	1'b1	Interrupt enable of ep0_setup_done_int
4	EOSCEN	R/W	1'b1	Interrupt enable of ep0_setup_cmd_int
3	GDCEN	R/W	1'b1	Interrupt enable of get_dct_cmd_int set 0



位	名称	权限	复位值	描述
2	VTEN	R/W	1'b1	Interrupt enable of vbus_tgl_int vbus voltage toggle interrupt enable, for detect equipment plug
1	UREN	R/W	1'b1	Interrupt enable of usb_reset_int reset interrupt enable
0	SEN	R/W	1'b1	Interrupt enable of sof_int SOF interrupt enable

18.4.7 usb_int_sts

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
UEIT	S3IT	LPIT	LWIT	RDIT		RSVD		EP7D	EP7C	EP6D	EP6C	EP5D	EP5C	EP4D	EP4C
								IT							
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
EP3D	EP3C	EP2D	EP2C	EP1D	EP1C	EP0D	E0OC	E0ID	E0IC	E0SD	E0SC	GDC	VTIT	URIT	SIT
l IT	l		l IT	l IT		IT	IT	IT	l IT	I	IT				

位	名称	权限	复位值	描述
31	UEIT	R	1'b0	USB error occurs, check usb_error for detailed error type
30	S3IT	R	1'b0	SOF is absent for 3 ms
29	LPIT	R	1'b0	LPM packet is received
28	LWIT	R	1'b0	LPM resume (wakeup) signal is received
27	RDIT	R	1'b0	USB reset de-assert is triggered
26:24	RSVD			
23	EP7DIT	R	1'b0	EP7 IN or OUT command is finished
22	EP7CIT	R	1'b0	EP7 IN or OUT command is received
21	EP6DIT	R	1'b0	EP6 IN or OUT command is finished
20	EP6CIT	R	1'b0	EP6 IN or OUT command is received
19	EP5DIT	R	1'b0	EP5 IN or OUT command is finished
18	EP5CIT	R	1'b0	EP5 IN or OUT command is received
17	EP4DIT	R	1'b0	EP4 IN or OUT command is finished
16	EP4CIT	R	1'b0	EP4 IN or OUT command is received
15	EP3DIT	R	1'b0	EP3 IN or OUT command is finished



位	名称	权限	复位值	描述
14	EP3CIT	R	1'b0	EP3 IN or OUT command is received
13	EP2DIT	R	1'b0	EP2 IN or OUT command is finished
12	EP2CIT	R	1'b0	EP2 IN or OUT command is received
11	EP1DIT	R	1'b0	EP1 IN or OUT command is finished
10	EP1CIT	R	1'b0	EP1 IN or OUT command is received
9	EP0DIT	R	1'b0	EP0 OUT command is finished
8	E0OCIT	R	1'b0	EP0 OUT command is received
7	E0IDIT	R	1'b0	EP0 IN command is finished
6	E0ICIT	R	1'b0	EP0 IN command is received
5	E0SDIT	R	1'b0	EP0 SETUP command is finished
4	E0SCIT	R	1'b0	EP0 SETUP command is received
3	GDCIT	R	1'b0	GET_DESCRIPTOR command is received
2	VTIT	R	1'b0	VBUS detection is toggled, check 0x1FC[31] for vbus_de-
				tect status
1	URIT	R	1'b0	USB reset is triggered
0	SIT	R	1'b0	SOF is received

18.4.8 usb_int_mask

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
UEM	S3M	LPM	LWM	RDM		RSVD		E7DM	E7CM	E6DM	E6CM	E5DM	E5CM	E4DM	E4CM
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
E3DM	E3CM	E2DM	E2CM	E1DM	E1CM	E0	E0	E0	E0	E0	E0	GDCM	VTM	URM	SM
						ODM	ОСМ	IDM	ICM	SDM	SCM				

位	名称	权限	复位值	描述
31	UEM	R/W	1'b1	Interrupt mask of usb_err_int
30	S3M	R/W	1'b1	Interrupt mask of sof_3ms_int
29	LPM	R/W	1'b1	Interrupt mask of lpm_pkt_int
28	LWM	R/W	1'b1	Interrupt mask of lpm_wkup_int
27	RDM	R/W	1'b1	Interrupt mask of usb_rend_int
26:24	RSVD			



位	名称	权限	复位值	描述
23	E7DM	R/W	1'b1	Interrupt mask of ep7_done_int
22	E7CM	R/W	1'b1	Interrupt mask of ep7_cmd_int
21	E6DM	R/W	1'b1	Interrupt mask of ep6_done_int
20	E6CM	R/W	1'b1	Interrupt mask of ep6_cmd_int
19	E5DM	R/W	1'b1	Interrupt mask of ep5_done_int
18	E5CM	R/W	1'b1	Interrupt mask of ep5_cmd_int
17	E4DM	R/W	1'b1	Interrupt mask of ep4_done_int
16	E4CM	R/W	1'b1	Interrupt mask of ep4_cmd_int
15	E3DM	R/W	1'b1	Interrupt mask of ep3_done_int
14	E3CM	R/W	1'b1	Interrupt mask of ep3_cmd_int
13	E2DM	R/W	1'b1	Interrupt mask of ep2_done_int
12	E2CM	R/W	1'b1	Interrupt mask of ep2_cmd_int
11	E1DM	R/W	1'b1	Interrupt mask of ep1_done_int
10	E1CM	R/W	1'b1	Interrupt mask of ep1_cmd_int
9	E0ODM	R/W	1'b1	Interrupt mask of ep0_out_done_int
8	E0OCM	R/W	1'b1	Interrupt mask of ep0_out_cmd_int
7	E0IDM	R/W	1'b1	Interrupt mask of ep0_in_done_int
6	E0ICM	R/W	1'b1	Interrupt mask of ep0_in_cmd_int
5	E0SDM	R/W	1'b1	Interrupt mask of ep0_setup_done_int
4	E0SCM	R/W	1'b1	Interrupt mask of ep0_setup_cmd_int
3	GDCM	R/W	1'b1	Interrupt mask of get_dct_cmd_int
2	VTM	R/W	1'b1	Interrupt mask of vbus_tgl_int
1	URM	R/W	1'b1	Interrupt mask of usb_reset_int
0	SM	R/W	1'b1	Interrupt mask of sof_int

18.4.9 usb_int_clear

地址: 0x4000d82c

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
UEC	S3C	LPC	LWC	RDC		RSVD		E7DC	E7CC	E6DC	E6CC	E5DC	E5CC	E4DC	E4CC
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
E3DC	E3CC	E2DC	E2CC	E1DC	E1CC	E0	E0	E0	E0	E0	E0	GDCC	VTC	URC	E0
						ODC	occ	IDC	ICC	SDC	SCC				



位	名称	权限	复位值	描述
31	UEC	W1C	1'b0	Interrupt clear of usb_err_int
30	S3C	W1C	1'b0	Interrupt clear of sof_3ms_int
29	LPC	W1C	1'b0	Interrupt clear of lpm_pkt_int
28	LWC	W1C	1'b0	Interrupt clear of lpm_wkup_int
27	RDC	W1C	1'b0	Interrupt clear of usb_rend_int
26:24	RSVD			
23	E7DC	W1C	1'b0	Interrupt clear of ep7_done_int
22	E7CC	W1C	1'b0	Interrupt clear of ep7_cmd_int
21	E6DC	W1C	1'b0	Interrupt clear of ep6_done_int
20	E6CC	W1C	1'b0	Interrupt clear of ep6_cmd_int
19	E5DC	W1C	1'b0	Interrupt clear of ep5_done_int
18	E5CC	W1C	1'b0	Interrupt clear of ep5_cmd_int
17	E4DC	W1C	1'b0	Interrupt clear of ep4_done_int
16	E4CC	W1C	1'b0	Interrupt clear of ep4_cmd_int
15	E3DC	W1C	1'b0	Interrupt clear of ep3_done_int
14	E3CC	W1C	1'b0	Interrupt clear of ep3_cmd_int
13	E2DC	W1C	1'b0	Interrupt clear of ep2_done_int
12	E2CC	W1C	1'b0	Interrupt clear of ep2_cmd_int
11	E1DC	W1C	1'b0	Interrupt clear of ep1_done_int
10	E1CC	W1C	1'b0	Interrupt clear of ep1_cmd_int
9	E0ODC	W1C	1'b0	Interrupt clear of ep0_out_done_int
8	E0OCC	W1C	1'b0	Interrupt clear of ep0_out_cmd_int
7	E0IDC	W1C	1'b0	Interrupt clear of ep0_in_done_int
6	E0ICC	W1C	1'b0	Interrupt clear of ep0_in_cmd_int
5	E0SDC	W1C	1'b0	Interrupt clear of ep0_setup_done_int
4	E0SCC	W1C	1'b0	Interrupt clear of ep0_setup_cmd_int
3	GDCC	W1C	1'b0	Interrupt clear of get_dct_cmd_int
2	VTC	W1C	1'b0	Interrupt clear of vbus_tgl_int
1	URC	W1C	1'b0	Interrupt clear of usb_reset_int
0	E0	W1C	1'b0	Interrupt clear of sof_int



18.4.10 ep1_config

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	RSVD								EPRS	ER	ENRE	ESRE			
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	EPT		EF	D	ЕРМР										

位	名称	权限	复位值	描述
31:20	RSVD			
19	EPRS	R	1'b0	Endpoint ready status bit. Asserted with ep_rdy, and de-asserted when ACK is sent/received.
18	ER	W1C	1'b0	Endpoint ready. When Endpoint NACK is enabled, asserting this bit will allow one packet to be transferred
17	ENRE	R/W	1'b1	Endpoint NACK response enable, should not be enabled with STALL at the same time must be 1
16	ESRE	R/W	1'b0	Endpoint STALL response enable, should not be enabled with NACK at the same time Set 1 when endpoint needs to be suspend (respond STALL)
15:13	EPT	R/W	3'b100	Endpoint type 3'b101: CTRL 3'b010: ISO 3'b100: BULK 3'b000: INT Others: Reserved
12:11	EPD	R/W	2'b01	Endpoint direction 2'b00: Disabled 2'b01: IN 2'b10: OUT 2'b11: Reserved
10:0	EPMP	R/W	11'd64	Endpoint max packet size



18.4.11 ep2_config

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	RSVD										E2RS	E2R	E2N	E2S	
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	E2T E2D					E2S									

位	名称	权限	复位值	描述
31:20	RSVD			
19	E2RS	R	1'b0	Endpoint ready status bit. Asserted with ep_rdy, and de-asserted when ACK is sent/received.
18	E2R	W1C	1'b0	Endpoint ready. When Endpoint NACK is enabled, asserting this bit will allow one packet to be transferred
17	E2N	R/W	1'b1	Endpoint NACK response enable, should not be enabled with STALL at the same time must be 1
16	E2S	R/W	1'b0	Endpoint STALL response enable, should not be enabled with NACK at the same time Set 1 when endpoint needs to be suspend (respond STALL)
15:13	E2T	R/W	3'b100	Endpoint type 3'b101: CTRL 3'b010: ISO 3'b100: BULK 3'b000: INT Others: Reserved
12:11	E2D	R/W	2'b01	Endpoint direction 2'b00: Disabled 2'b01: IN 2'b10: OUT 2'b11: Reserved
10:0	E2S	R/W	11'd64	Endpoint max packet size



18.4.12 ep3_config

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	RSVD										E3RS	E3RS	E3N	E3S	
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	E3T E3D					E3S									

位	名称	权限	复位值	描述
31:20	RSVD			
19	E3RS	R	1'b0	Endpoint ready status bit. Asserted with ep_rdy, and deasserted when ACK is sent/received.
18	E3RS	W1C	1'b0	Endpoint ready. When Endpoint NACK is enabled, asserting this bit will allow one packet to be transferred
17	E3N	R/W	1'b1	Endpoint NACK response enable, should not be enabled with STALL at the same time must be 1
16	E3S	R/W	1'b0	Endpoint STALL response enable, should not be enabled with NACK at the same time Set 1 when endpoint needs to be suspend (respond STALL)
15:13	E3T	R/W	3'b100	Endpoint type 3'b101: CTRL 3'b010: ISO 3'b100: BULK 3'b000: INT Others: Reserved
12:11	E3D	R/W	2'b01	Endpoint direction 2'b00: Disabled 2'b01: IN 2'b10: OUT 2'b11: Reserved
10:0	E3S	R/W	11'd64	Endpoint max packet size



18.4.13 ep4_config

地址: 0x4000d84c

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	RSVD										E4RS	E4R	E4N	E4S	
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
E4T E4D									E4S						

位	名称	权限	复位值	描述
31:20	RSVD			
19	E4RS	R	1'b0	Endpoint ready status bit. Asserted with ep_rdy, and deasserted when ACK is sent/received.
18	E4R	W1C	1'b0	Endpoint ready. When Endpoint NACK is enabled, asserting this bit will allow one packet to be transferred
17	E4N	R/W	1'b1	Endpoint NACK response enable, should not be enabled with STALL at the same time must be 1
16	E4S	R/W	1'b0	Endpoint STALL response enable, should not be enabled with NACK at the same time Set 1 when endpoint needs to be suspend (respond STALL)
15:13	E4T	R/W	3'b100	Endpoint type 3'b101: CTRL 3'b010: ISO 3'b100: BULK 3'b000: INT Others: Reserved
12:11	E4D	R/W	2'b01	Endpoint direction 2'b00: Disabled 2'b01: IN 2'b10: OUT 2'b11: Reserved
10:0	E4S	R/W	11'd64	Endpoint max packet size



18.4.14 ep5_config

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	RSVD										E5RS	E5RS	E5N	E5S	
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	E5T E5D					E5S									

位	名称	权限	复位值	描述
31:20	RSVD			
19	E5RS	R	1'b0	Endpoint ready status bit. Asserted with ep_rdy, and deasserted when ACK is sent/received.
18	E5RS	W1C	1'b0	Endpoint ready. When Endpoint NACK is enabled, asserting this bit will allow one packet to be transferred
17	E5N	R/W	1'b1	Endpoint NACK response enable, should not be enabled with STALL at the same time must be 1
16	E5S	R/W	1'b0	Endpoint STALL response enable, should not be enabled with NACK at the same time Set 1 when endpoint needs to be suspend (respond STALL)
15:13	E5T	R/W	3'b100	Endpoint type 3'b101: CTRL 3'b010: ISO 3'b100: BULK 3'b000: INT Others: Reserved
12:11	E5D	R/W	2'b01	Endpoint direction 2'b00: Disabled 2'b01: IN 2'b10: OUT 2'b11: Reserved
10:0	E5S	R/W	11'd64	Endpoint max packet size



18.4.15 ep6_config

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	RSVD										E6RS	E6R	E6N	E6S	
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	E6T E6D					E6S									

位	名称	权限	复位值	描述
31:20	RSVD			
19	E6RS	R	1'b0	Endpoint ready status bit. Asserted with ep_rdy, and deasserted when ACK is sent/received.
18	E6R	W1C	1'b0	Endpoint ready. When Endpoint NACK is enabled, asserting this bit will allow one packet to be transferred
17	E6N	R/W	1'b1	Endpoint NACK response enable, should not be enabled with STALL at the same time must be 1
16	E6S	R/W	1'b0	Endpoint STALL response enable, should not be enabled with NACK at the same time Set 1 when endpoint needs to be suspend (respond STALL)
15:13	E6T	R/W	3'b100	Endpoint type 3'b101: CTRL 3'b010: ISO 3'b100: BULK 3'b000: INT Others: Reserved
12:11	E6D	R/W	2'b01	Endpoint direction 2'b00: Disabled 2'b01: IN 2'b10: OUT 2'b11: Reserved
10:0	E6S	R/W	11'd64	Endpoint max packet size



18.4.16 ep7_config

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	RSVD											E7RS	E7R	E7N	E7S
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	E7T		E7	7D		E7S									

位	名称	权限	复位值	描述
31:20	RSVD			
19	E7RS	R	1'b0	Endpoint ready status bit. Asserted with ep_rdy, and deasserted when ACK is sent/received.
18	E7R	W1C	1'b0	Endpoint ready. When Endpoint NACK is enabled, asserting this bit will allow one packet to be transferred
17	E7N	R/W	1'b1	Endpoint NACK response enable, should not be enabled with STALL at the same time must be 1
16	E7S	R/W	1'b0	Endpoint STALL response enable, should not be enabled with NACK at the same time Set 1 when endpoint needs to be suspend (respond STALL)
15:13	E7T	R/W	3'b100	Endpoint type 3'b101: CTRL 3'b010: ISO 3'b100: BULK 3'b000: INT Others: Reserved
12:11	E7D	R/W	2'b01	Endpoint direction 2'b00: Disabled 2'b01: IN 2'b10: OUT 2'b11: Reserved
10:0	E7S	R/W	11'd64	Endpoint max packet size



18.4.17 ep0_fifo_config

地址: 0x4000d900

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
							RS	VD							
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	RSVD								E0	E0	E0	E0	E0	E0	E0
										TFU	TFO	RFC	TFC	DREN	DTEN

位	名称	权限	复位值	描述
31:8	RSVD			
7	E0RFU	R	1'b0	Underflow flag of RX FIFO, can be cleared by rx_fifo_clr
6	E0RFO	R	1'b0	Overflow flag of RX FIFO, can be cleared by rx_fifo_clr
5	E0TFU	R	1'b0	Underflow flag of TX FIFO, can be cleared by tx_fifo_clr
4	E0TFO	R	1'b0	Overflow flag of TX FIFO, can be cleared by tx_fifo_clr
3	E0RFC	W1C	1'b0	Clear signal of RX FIFO
2	E0TFC	W1C	1'b0	Clear signal of TX FIFO
1	E0DREN	R/W	1'b0	Enable signal of dma_rx_req/ack interface Set 1 when use DMA for rx FIFO data transfer
0	E0DTEN	R/W	1'b0	Enable signal of dma_tx_req/ack interface Set 1 when use DMA for tx FIFO data transfer

18.4.18 ep0_fifo_status

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	
E0 RFF	E0 RFE				RSVD							E0RFC				
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	
E0 TFF	E0 TFE		RSVD							EOTFC						

位	名称	权限	复位值	描述
31	E0RFF	R	1'b0	RX FIFO full flag
30	E0RFE	R	1'b1	RX FIFO empty flag
29:23	RSVD			



位	名称	权限	复位值	描述
22:16	E0RFC	R	7'd0	RX FIFO available count
15	E0TFF	R	1'b0	TX FIFO full flag
14	E0TFE	R	1'b1	TX FIFO empty flag
13:7	RSVD			
6:0	E0TFC	R	7'd64	TX FIFO available count

18.4.19 ep0_tx_fifo_wdata

地址: 0x4000d908

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
RSVD															
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	RSVD										E01	FW			

位	名称	权限	复位值	描述
31:8	RSVD			
7:0	E0TFW	W	х	EP0 TX FIFO

18.4.20 ep0_rx_fifo_rdata

地址: 0x4000d90c

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
RSVD															
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
RSVD											E0F	RFR			

位	名称	权限	复位值	描述
31:8	RSVD			
7:0	E0RFR	R	8'h0	EP0 RX FIFO

BL702/704/706 参考手册 327/ 370 @2021 Bouffalo Lab



18.4.21 ep1_fifo_config

地址: 0x4000d910

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
							RS	VD							
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
RSVD								E1	E1	E1	E1	E1	E1	E1	E1
									RFO	TFU	TFO	RFC	TFC	DREN	DTEN

位	名称	权限	复位值	描述
31:8	RSVD			
7	E1RFU	R	1'b0	Underflow flag of RX FIFO, can be cleared by rx_fifo_clr
6	E1RFO	R	1'b0	Overflow flag of RX FIFO, can be cleared by rx_fifo_clr
5	E1TFU	R	1'b0	Underflow flag of TX FIFO, can be cleared by tx_fifo_clr
4	E1TFO	R	1'b0	Overflow flag of TX FIFO, can be cleared by tx_fifo_clr
3	E1RFC	W1C	1'b0	Clear signal of RX FIFO
2	E1TFC	W1C	1'b0	Clear signal of TX FIFO
1	E1DREN	R/W	1'b0	Enable signal of dma_rx_req/ack interface
				Set 1 when use DMA for rx FIFO data transfer
0	E1DTEN	R/W	1'b0	Enable signal of dma_tx_req/ack interface Set 1 when use DMA for tx FIFO data transfer

18.4.22 ep1_fifo_status

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
E1 RFF	E1 RFE				RSVD			E1RFC							
15	14	13	12	11	10	9	8	7	6 5 4 3 2 1						
E1 TFF	E1 TFE		RSVD							E1TFC					

位	名称	权限	复位值	描述
31	E1RFF	R	1'b0	RX FIFO full flag
30	E1RFE	R	1'b1	RX FIFO empty flag
29:23	RSVD			



位	名称	权限	复位值	描述
22:16	E1RFC	R	7'd0	RX FIFO available count
15	E1TFF	R	1'b0	TX FIFO full flag
14	E1TFE	R	1'b1	TX FIFO empty flag
13:7	RSVD			
6:0	E1TFC	R	7'd64	TX FIFO available count

18.4.23 ep1_tx_fifo_wdata

地址: 0x4000d918

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
							RS	VD							
15	15 14 13 12 11 10 9 8 7 6 5 4 3 2 1 0														
	RSVD								E1TFW						

位	名称	权限	复位值	描述
31:8	RSVD			
7:0	E1TFW	W	Х	EP1 TX FIFO

18.4.24 ep1_rx_fifo_rdata

地址: 0x4000d91c

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
							RS	VD							
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	RSVD								E1RFR						

位	名称	权限	复位值	描述
31:8	RSVD			
7:0	E1RFR	R	8'h0	EP1 RX FIFO

BL702/704/706 参考手册 329/ 370 @2021 Bouffalo Lab



18.4.25 ep2_fifo_config

地址: 0x4000d920

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
							RS	VD							
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	RSVD									E2	E2	E2	E2	E2	E2
										TFU	TFO	RFC	TFC	DREN	DTEN

位	名称	权限	复位值	描述
31:8	RSVD			
7	E2RFU	R	1'b0	Underflow flag of RX FIFO, can be cleared by rx_fifo_clr
6	E2RFO	R	1'b0	Overflow flag of RX FIFO, can be cleared by rx_fifo_clr
5	E2TFU	R	1'b0	Underflow flag of TX FIFO, can be cleared by tx_fifo_clr
4	E2TFO	R	1'b0	Overflow flag of TX FIFO, can be cleared by tx_fifo_clr
3	E2RFC	W1C	1'b0	Clear signal of RX FIFO
2	E2TFC	W1C	1'b0	Clear signal of TX FIFO
1	E2DREN	R/W	1'b0	Enable signal of dma_rx_req/ack interface Set 1 when use DMA for rx FIFO data transfer
0	E2DTEN	R/W	1'b0	Enable signal of dma_tx_req/ack interface Set 1 when use DMA for tx FIFO data transfer

18.4.26 ep2_fifo_status

地址: 0x4000d924

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
E2 RFF	E2 RFE				RSVD			E2RFC							
15	14	13	12	11	10	9	8	7	6 5 4 3 2 1						
E2 TFF	E2 TFE		RSVD							E2TFC					

位	名称	权限	复位值	描述
31	E2RFF	R	1'b0	RX FIFO full flag
30	E2RFE	R	1'b1	RX FIFO empty flag
29:23	RSVD			

BL702/704/706 参考手册 330/ 370 @2021 Bouffalo Lab



位	名称	权限	复位值	描述
22:16	E2RFC	R	7'd0	RX FIFO available count
15	E2TFF	R	1'b0	TX FIFO full flag
14	E2TFE	R	1'b1	TX FIFO empty flag
13:7	RSVD			
6:0	E2TFC	R	7'd64	TX FIFO available count

18.4.27 ep2_tx_fifo_wdata

地址: 0x4000d928

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
							RS	VD							
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	RSVD								E2TFW						

位	名称	权限	复位值	描述
31:8	RSVD			
7:0	E2TFW	W	Х	EP2 TX FIFO

18.4.28 ep2_rx_fifo_rdata

地址: 0x4000d92c

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
							RS	VD							
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	RSVD										E2F	RFR			

位	名称	权限	复位值	描述
31:8	RSVD			
7:0	E2RFR	R	8'h0	EP2 RX FIFO

BL702/704/706 参考手册 331/ 370 @2021 Bouffalo Lab



18.4.29 ep3_fifo_config

地址: 0x4000d930

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
							RS	VD							
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	RSVD									E3	E3	E3	E3	E3	E3
										TFU	TFO	RFC	TFC	DTEN	DTEN

位	名称	权限	复位值	描述
31:8	RSVD			
7	E3RFU	R	1'b0	Underflow flag of RX FIFO, can be cleared by rx_fifo_clr
6	E3RFO	R	1'b0	Overflow flag of RX FIFO, can be cleared by rx_fifo_clr
5	E3TFU	R	1'b0	Underflow flag of TX FIFO, can be cleared by tx_fifo_clr
4	E3TFO	R	1'b0	Overflow flag of TX FIFO, can be cleared by tx_fifo_clr
3	E3RFC	W1C	1'b0	Clear signal of RX FIFO
2	E3TFC	W1C	1'b0	Clear signal of TX FIFO
1	E3DTEN	R/W	1'b0	Enable signal of dma_rx_req/ack interface Set 1 when use DMA for rx FIFO data transfer
0	E3DTEN	R/W	1'b0	Enable signal of dma_tx_req/ack interface Set 1 when use DMA for tx FIFO data transfer

18.4.30 ep3_fifo_status

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	
E3 RFF	E3 RFE				RSVD				E3RFC							
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	
E3 TFF	E3 TFE				RSVD				E3TFC							

位	名称	权限	复位值	描述
31	E3RFF	R	1'b0	RX FIFO full flag
30	E3RFE	R	1'b1	RX FIFO empty flag
29:23	RSVD			



位	名称	权限	复位值	描述
22:16	E3RFC	R	7'd0	RX FIFO available count
15	E3TFF	R	1'b0	TX FIFO full flag
14	E3TFE	R	1'b1	TX FIFO empty flag
13:7	RSVD			
6:0	E3TFC	R	7'd64	TX FIFO available count

18.4.31 ep3_tx_fifo_wdata

地址: 0x4000d938

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
							RS	VD							
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	RSVD								E3TFW						

位	名称	权限	复位值	描述
31:8	RSVD			
7:0	E3TFW	W	Х	EP3 TX FIFO

18.4.32 ep3_rx_fifo_rdata

地址: 0x4000d93c

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
RSVD															
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
RSVD E3RFR															

位	名称	权限	复位值	描述
31:8	RSVD			
7:0	E3RFR	R	8'h0	EP3 RX FIFO

BL702/704/706 参考手册 333/ 370 @2021 Bouffalo Lab



18.4.33 ep4_fifo_config

地址: 0x4000d940

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
							RS	VD							
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
			RS	SVD				E4	E4	E4	E4	E4	E4	E4	E4
										TFU	TFO	RFC	TFC	DREN	DTEN

位	名称	权限	复位值	描述
31:8	RSVD			
7	E4RFU	R	1'b0	Underflow flag of RX FIFO, can be cleared by rx_fifo_clr
6	E4RFO	R	1'b0	Overflow flag of RX FIFO, can be cleared by rx_fifo_clr
5	E4TFU	R	1'b0	Underflow flag of TX FIFO, can be cleared by tx_fifo_clr
4	E4TFO	R	1'b0	Overflow flag of TX FIFO, can be cleared by tx_fifo_clr
3	E4RFC	W1C	1'b0	Clear signal of RX FIFO
2	E4TFC	W1C	1'b0	Clear signal of TX FIFO
1	E4DREN	R/W	1'b0	Enable signal of dma_rx_req/ack interface Set 1 when use DMA for rx FIFO data transfer
0	E4DTEN	R/W	1'b0	Enable signal of dma_tx_req/ack interface Set 1 when use DMA for tx FIFO data transfer

18.4.34 ep4_fifo_status

地址: 0x4000d944

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
E4 RFF	E4 RFE				RSVD							E4RFC			
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
E4 TFF	E4 TFE				RSVD							E4TFC			

位	名称	权限	复位值	描述
31	E4RFF	R	1'b0	RX FIFO full flag
30	E4RFE	R	1'b1	RX FIFO empty flag
29:23	RSVD			

BL702/704/706 参考手册 334/ 370 @2021 Bouffalo Lab



位	名称	权限	复位值	描述
22:16	E4RFC	R	7'd0	RX FIFO available count
15	E4TFF	R	1'b0	TX FIFO full flag
14	E4TFE	R	1'b1	TX FIFO empty flag
13:7	RSVD			
6:0	E4TFC	R	7'd64	TX FIFO available count

18.4.35 ep4_tx_fifo_wdata

地址: 0x4000d948

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
RSVD															
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
RSVD E4TFW															

位	名称	权限	复位值	描述
31:8	RSVD			
7:0	E4TFW	W	Х	EP4 TX FIFO

18.4.36 ep4_rx_fifo_rdata

地址: 0x4000d94c

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
RSVD															
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
RSVD E4RFR															

位	名称	权限	复位值	描述
31:8	RSVD			
7:0	E4RFR	R	8'h0	EP4 RX FIFO



18.4.37 ep5_fifo_config

地址: 0x4000d950

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
							RS	VD							
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
			RS	SVD				E5	E5	E5	E5	E5	E5	E5	E5
				RFU	RFO	TFU	TFO	RFC	TFC	DREN	DTEN				

位	名称	权限	复位值	描述
31:8	RSVD			
7	E5RFU	R	1'b0	Underflow flag of RX FIFO, can be cleared by rx_fifo_clr
6	E5RFO	R	1'b0	Overflow flag of RX FIFO, can be cleared by rx_fifo_clr
5	E5TFU	R	1'b0	Underflow flag of TX FIFO, can be cleared by tx_fifo_clr
4	E5TFO	R	1'b0	Overflow flag of TX FIFO, can be cleared by tx_fifo_clr
3	E5RFC	W1C	1'b0	Clear signal of RX FIFO
2	E5TFC	W1C	1'b0	Clear signal of TX FIFO
1	E5DREN	R/W	1'b0	Enable signal of dma_rx_req/ack interface Set 1 when use DMA for rx FIFO data transfer
0	E5DTEN	R/W	1'b0	Enable signal of dma_tx_req/ack interface Set 1 when use DMA for tx FIFO data transfer

18.4.38 ep5_fifo_status

地址: 0x4000d954

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
E5 RFF	E5 RFE				RSVD			E5RFC							
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
E5 TFF	E5 TFE		RSVD							E5TFC					

位	名称	权限	复位值	描述
31	E5RFF	R	1'b0	RX FIFO full flag
30	E5RFE	R	1'b1	RX FIFO empty flag
29:23	RSVD			

BL702/704/706 参考手册 336/ 370 @2021 Bouffalo Lab



位	名称	权限	复位值	描述
22:16	E5RFC	R	7'd0	RX FIFO available count
15	E5TFF	R	1'b0	TX FIFO full flag
14	E5TFE	R	1'b1	TX FIFO empty flag
13:7	RSVD			
6:0	E5TFC	R	7'd64	TX FIFO available count

18.4.39 ep5_tx_fifo_wdata

地址: 0x4000d958

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
							RS	VD							
15	15 14 13 12 11 10 9 8 7 6 5 4 3 2 1 0														
	RSVD										E51	FW			

位	名称	权限	复位值	描述
31:8	RSVD			
7:0	E5TFW	W	Х	EP5 TX FIFO

18.4.40 ep5_rx_fifo_rdata

地址: 0x4000d95c

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
							RS	VD							
15	15 14 13 12 11 10 9 8 7 6 5 4 3 2 1 0														
	RSVD								E5RFR						

位	名称	权限	复位值	描述
31:8	RSVD			
7:0	E5RFR	R	8'h0	EP5 RX FIFO

BL702/704/706 参考手册 337/ 370 @2021 Bouffalo Lab



18.4.41 ep6_fifo_config

地址: 0x4000d960

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
							RS	VD							
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	RSVD								E6	E6	E6	E6	E6	E6	E6
									RFO	TFU	TFO	RFC	TFC	DREN	DTEN

位	名称	权限	复位值	描述
31:8	RSVD			
7	E6RFU	R	1'b0	Underflow flag of RX FIFO, can be cleared by rx_fifo_clr
6	E6RFO	R	1'b0	Overflow flag of RX FIFO, can be cleared by rx_fifo_clr
5	E6TFU	R	1'b0	Underflow flag of TX FIFO, can be cleared by tx_fifo_clr
4	E6TFO	R	1'b0	Overflow flag of TX FIFO, can be cleared by tx_fifo_clr
3	E6RFC	W1C	1'b0	Clear signal of RX FIFO
2	E6TFC	W1C	1'b0	Clear signal of TX FIFO
1	E6DREN	R/W	1'b0	Enable signal of dma_rx_req/ack interface Set 1 when use DMA for rx FIFO data transfer
0	E6DTEN	R/W	1'b0	Enable signal of dma_tx_req/ack interface Set 1 when use DMA for tx FIFO data transfer

18.4.42 ep6_fifo_status

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
E6 RFF	E6 RFE				RSVD			E6RFC							
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
E6 TFF	E6 TFE		RSVD						E6TFC						

位	名称	权限	复位值	描述
31	E6RFF	R	1'b0	RX FIFO full flag
30	E6RFE	R	1'b1	RX FIFO empty flag
29:23	RSVD			



位	名称	权限	复位值	描述
22:16	E6RFC	R	7'd0	RX FIFO available count
15	E6TFF	R	1'b0	TX FIFO full flag
14	E6TFE	R	1'b1	TX FIFO empty flag
13:7	RSVD			
6:0	E6TFC	R	7'd64	TX FIFO available count

18.4.43 ep6_tx_fifo_wdata

地址: 0x4000d968

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
							RS	VD							
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	RSVD								E6TFW						

位	名称	权限	复位值	描述
31:8	RSVD			
7:0	E6TFW	W	Х	EP6 TX FIFO

18.4.44 ep6_rx_fifo_rdata

地址: 0x4000d96c

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
							RS	VD							
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	RSVD										E6F	RFR			

位	名称	权限	复位值	描述
31:8	RSVD			
7:0	E6RFR	R	8'h0	EP6 RX FIFO

BL702/704/706 参考手册 339/ 370 @2021 Bouffalo Lab



18.4.45 ep7_fifo_config

地址: 0x4000d970

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
							RS	VD							
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	RSVD									E7	E7	E7	E7	E7	E7
										TFU	TFO	RFC	TFC	DREN	DTEN

位	名称	权限	复位值	描述
31:8	RSVD			
7	E7RFU	R	1'b0	Underflow flag of RX FIFO, can be cleared by rx_fifo_clr
6	E7RFO	R	1'b0	Overflow flag of RX FIFO, can be cleared by rx_fifo_clr
5	E7TFU	R	1'b0	Underflow flag of TX FIFO, can be cleared by tx_fifo_clr
4	E7TFO	R	1'b0	Overflow flag of TX FIFO, can be cleared by tx_fifo_clr
3	E7RFC	W1C	1'b0	Clear signal of RX FIFO
2	E7TFC	W1C	1'b0	Clear signal of TX FIFO
1	E7DREN	R/W	1'b0	Enable signal of dma_rx_req/ack interface
				Set 1 when use DMA for rx FIFO data transfer
0	E7DTEN	R/W	1'b0	Enable signal of dma_tx_req/ack interface Set 1 when use DMA for tx FIFO data transfer

18.4.46 ep7_fifo_status

地址: 0x4000d974

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
E7 RFF	E7 RFE				RSVD				E7RFC						
15	14	13	12	11	10	9	8	7	7 6 5 4 3 2 1 0						0
E7 TFF	E7 TFE		RSVD							E7TFC					

位	名称	权限	复位值	描述
31	E7RFF	R	1'b0	RX FIFO full flag
30	E7RFE	R	1'b1	RX FIFO empty flag
29:23	RSVD			

BL702/704/706 参考手册 340/ 370 @2021 Bouffalo Lab



位	名称	权限	复位值	描述
22:16	E7RFC	R	7'd0	RX FIFO available count
15	E7TFF	R	1'b0	TX FIFO full flag
14	E7TFE	R	1'b1	TX FIFO empty flag
13:7	RSVD			
6:0	E7TFC	R	7'd64	TX FIFO available count

18.4.47 ep7_tx_fifo_wdata

地址: 0x4000d978

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
							RS	VD							
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	RSVD								E7TFW						

位	名称	权限	复位值	描述
31:8	RSVD			
7:0	E7TFW	W	х	EP7 TX FIFO

18.4.48 ep7_rx_fifo_rdata

地址: 0x4000d97c

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
							RS	VD							
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	RSVD										E7F	RFR			

位	名称	权限	复位值	描述
31:8	RSVD			
7:0	E7RFR	R	8'h0	EP7 RX FIFO

BL702/704/706 参考手册 341/ 370 @2021 Bouffalo Lab



18.4.49 xcvr_if_config

地址: 0x4000d9fc

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
SVD		RSVD													
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	RSVD														

位	名称	权限	复位值	描述
31	SVD	R	1'b0	
30:0	RSVD			

BL702/704/706 参考手册 342/ 370 @2021 Bouffalo Lab

19.1 概述

低功耗是物联网应用的一项重要指标。芯片的处理器包含 3 种功耗模式,包含工作模式、睡眠模式和休眠模式,可以根据当前应用场景选择合适的功耗模式,降低芯片功耗延长电池寿命。




图 19.1: 低功耗模式

19.2 主要特征

- 时钟控制:GLB 中对各外设的时钟控制, 小范围的省电, 响应速度较快
- 睡眠控制 (PDS): 包含 PDS0/1/2/3/4/5/6/7/31 这 9 个等级, 大范围省电, 响应速度中等
- 休眠控制 (HBN): 包含 HBN0/1/2 这 3 个等级,全局省电,响应时间长



19.3 功能描述

19.3.1 电源域

BL702 中有 9 个电源域,每个电源域的主要功能如下所示:

- PD_AON
 - HBN 状态机控制电源/隔离/复位/时钟
 - 保持内部电压输出选择
 - 引脚唤醒控制
- PD_AON_HBNRTC
 - 保留 RC32K/XTAL32K 控制寄存器
 - RTC 可以用于唤醒,也可用于 LED 闪烁
- PD_AON_HBNCORE
 - 部分电源控制寄存器
 - 4KB 的 HBN_RAM,用于在进入 PDS/HBN 模式前保存程序数据,进入 PDS/HBN 后数据不会消失
 - PIR 数字控制, PIR 是热释电红外传感器, HBN 区域内的一个外设, 可以用作 HBN 唤醒源
- PD_CORE
 - HBN 状态机控制电源/隔离/复位/时钟
 - 64KB 保留 RAM
 - Zigbee/BLE 计时器控制
- PD_CORE_MISC_DIG
 - 外设(数字部分)
- PD_CORE_MISC_ANA
 - 外设(模拟部分)
- PD_CPU
 - CPU/缓存控制器
 - ROM/高速 RAM
- PD_BZ
 - 蓝牙和 ZigBee



• PD_USB

- USB

每个电源域都由 9 个不同的电源模式控制,具体的控制方式如下表所示:

表 19.1: 电源模式

NO.	Scenario	AON	AON HBNRTC	AON_HB- NCORE	CORE	CORE MISC_DIG	CORE MISC_ANA	CPU	BZ	USB
1	Normal	ON	ON	ON	ON	ON	ON	ON	ON	ON
2	PDS0	ON	ON	ON	ON	ON	ON	ON	ON	ON
3	PDS1	ON	ON	ON	ON	ON	ON	ON	ON	OFF
4	PDS2	ON	ON	ON	ON	ON	ON	ON	OFF	ON
5	PDS3	ON	ON	ON	ON	ON	ON	ON	OFF	OFF
6	PDS4	ON	ON	ON	ON	ON	ON	OFF	ON	ON
7	PDS5	ON	ON	ON	ON	ON	ON	OFF	ON	OFF
8	PDS6	ON	ON	ON	ON	ON	ON	OFF	OFF	ON
9	PDS7	ON	ON	ON	ON	ON	ON	OFF	OFF	OFF
10	PDS31	ON	ON	ON	ON	OFF	OFF	OFF	OFF	OFF
11	HBN0	ON	ON	ON	OFF	OFF	OFF	OFF	OFF	OFF
12	HBN1	ON	ON	OFF	OFF	OFF	OFF	OFF	OFF	OFF
13	HBN2	ON	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF

19.3.2 唤醒源

芯片内部支持多种唤醒源,可从不同电源模式中唤醒。

PDS0/1/2/3 模式唤醒后 CPU 不会 reset, PDS4/5/6/7/31 及 HBN0/1/2 模式唤醒后 CPU 会 reset。当 CPU 唤醒并 reset 后,可以通过 event 寄存器获悉当前是因何种原因而 reset 的。

每个电源域都有自己的唤醒源,睡眠休眠状态下的唤醒源便是该模式下仍旧有电的电源域唤醒源的总和

PD_AON 有如下唤醒源:

• always on pin wakeup (GPIO10~13)

PD_AON_HBNRTC 有如下唤醒源:

· hbn rtc timer wakeup

PD_AON_HBNCORE 有如下唤醒源:



• pir 中断、bor 中断、acomp0 中断、acomp1 中断

PD_CORE 有如下唤醒源:

• ble sleep timer wakeup \(GPIO0~7 Pin Wakeup (select one) \) pds timer wakeup

PD_CORE_MISC_DIG 和 PD_CORE_MISC_ANA 有如下唤醒源:

• kys 中断、irrx 中断、GPIO0~8 GPIO Pin Wakeup、GPIO14~31 GPIO Pin Wakeup

PD_USB 有如下唤醒源:

• usb wakeup 中断

19.3.3 功耗模式

工作模式

芯片提供处理器与外设独立的时钟控制,在 GLB 和时钟的章节介绍对各模块的时钟控制,软件可以根据当前应用场景,对于不需要使用的处理器或外设进行时钟控制。时钟控制的反应是实时的,在此工作模式下,不需要担心响应时间。

睡眠模式 (PDS)

掉电模式相较于工作模式功耗较低。进入 PDS 模式后,将 RTC(Real Time Clock)之外的时钟进行管控,会切换为内部低速时钟,并将外部晶振与 PLL 关闭达到更加省电的状态,因此进入与离开此低功耗模式会有时间延迟。

1. 进入睡眠模式

软件可通过 PDS 配置让此模块进入掉电模式,等待处理,进入等待中断模式 (WFI) 后,PDS 模块会触发时钟控制模块进入 gate clock 操作,并通知模拟电路关闭 PLL 以及外部晶振

2. 离开睡眠模式

离开睡眠模式的方式有两种,第一是睡眠期间有特定的中断或事件打断空闲状态,第二是软件设定 PDS_TIM 的睡眠时间达到,两者均会触发 PDS 模块进入或离开低功耗模式。注意:因为打开晶振需要约 1ms 的时间,PDS 提供软件提前打开晶振的方式,这个做法可以加速 PDS 醒来,当 PDS 模块准备醒来时,此模块会通过中断通知处理器离开等待中断模式 (WFI)。

3. 数据保留

当进入睡眠模式时,OCRAM 区域的数据可以自动进入 retention 状态而保留下来,当唤醒后可以自行退出 retention 状态。并且在睡眠模式下,4K HBN_RAM 的数据会一直保留。

休眠模式 (HBN)

体眠模式在保留 AON(Always On) 电源的状态下,将大部分的芯片逻辑进行断电 (Vcore),直到收到外部事件才会将内部电路唤醒的。在休眠模式下可以达到极致的省电状态,但相对于前两者需要的响应时间也最长,适合长时间不需要工作的状态下,可以进入此状态,延长电池寿命。休眠时期会将大部分的电路断电,对应的寄存器值和内存的数据也会消失。因此 HBN 内部留有 4KB HBN_RAM,这个内存在休眠状态时不会断电,软件有需要保存的资料或状态可以在进入休眠前拷贝到这个内存,当从休眠恢复时,可以直接从 RAM 中存取数据,通常可以用作状态的纪录或是数据快

BL702/704/706 参考手册 346/ 370 @2021 Bouffalo Lab



速恢复(仅 HBN0 有效)。

19.4 PDS 寄存器描述

名称	描述			
PDS_CTL	PDS control register			
PDS_TIME1	PDS sleep time			
PDS_INT	PDS interrupt			
PDS_CTL2	PDS control register 2			
PDS_CTL3	PDS control register 3			
PDS_CTL4	PDS control register 4			
pds_stat	PDS state			
pds_ram1	PDS ram control			
pds_gpio_set_pu_pd PDS gpio set				
pds_gpio_int PDS gpio interrupt				

19.4.1 PDS_CTL

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
CTR	LPLL	CTR	LRF		IDOVOL				PD	NPW	RSVD	RLPW	IDO	RC32	RSEN
								CLK	ID11	MASK		CLK	VSEL	PC	
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
SEFO	PDXT	PWOF	WXRD	ISL	PUFS	MEM	GATE	CPFS	CIO	PD	PDDC	RSVD	XTFO	SLFE	PDSS
				EN		STBY	CLK			BGS					

位	名称	权限	复位值	描述
31:30	CTRLPLL	R/W	2'b00	00 : PDS don't Control PLL on/off 01 : PDS Control PLL on/off depend on gate_clock signal 10 : PDS Control PLL on/off depend on MISC isolation off/on 11 : PDS Control PLL on/off when pds at idle state Note. When PDS Control PLL, the real PU signal will still wait until "xtal_rdy"



位	名称	权限	复位值	描述
29:28	CTRLRF	R/W	2'b01	00 : PDS don't control RF on/off 01 : PDS control RF on/off depend on soc_en 10 : PDS control RF on/off depend on BLE power on/off 11 : PDS control RF on/off whe pds at idle state
27:24	IDOVOL	R/W	4'hA	LDO voltage value in PDS mode
23	FSRCLK	R/W	0	0 : Don't Force SRAM CLK Enable 1 : Force SRAM CLK Enable
22	PDID11	R/W	0	0 : power on Ido11 during PDS 1 : power down Ido11 during PDS
21	NPWMASK	R/W	0	pds start condition mask np_wfi
20	RSVD			
19	RLPWCLK	R/W	0	0 : Control SRAM Low Power without CLK (Async) 1 : Control SRAM Low Power with CLK (Sync)
18	IDOVSEL	R/W	0	PDS "SLEEP" control LDO voltage enable
17	RC32PC	R/W	0	1 : RC32M always on @any state 0 : RC32M on/off controlled by PDS state
16	RSEN	R/W	0	0 : no pds_reset 1: pds_rst controlled by PDS
15	SEFO	R/W	0	0 :pds_soc_enb controlled by PDS 1 :pds_soc_enb always active
14	PDXT	R/W	1	0 : don' t_touch xtal during PDS 1 : xtal power down during PDS
13	PWOF	R/W	1	0 : don' t_touch Power during PDS 1 : Power off during PDS (each power domain can has its own control)
12	WXRD	R/W	0	0 : Skip wait XTAL Ready before PDS Interrupt 1 : wait XTAL Ready during before PDS Interrupt
11	ISLEN	R/W	1	0 : don' t_touch Isolation during PDS (all power domain) 1 : Isolation during PDS (each power domain can has its own control)
10	PUFS	R/W	1	if cr_pds_ctrl_pu_flash =0 or not in PDS31 state 0 : SW Turn Off Flash 1: SW Turn on Flash
9	MEMSTBY	R/W	1	0 : don' t_touch mem_stby during PDS 1 : mem_stby during PDS (each power domain can has its own control)



位	名称	权限	复位值	描述
8	GATECLK	R/W	1	0 : don't_touch clock gating during PDS (all power domain) 1 : gate clock during PDS (each pwr domain has its own control)
7	CPFS	R/W	0	0 : don' 't touch Flash power during all PDS (Flash Power Always on) 1 : turn off Flash Power During PDS (same control with pds power off control)
6	CIO	R/W	0	1: allow PDS Control the GPIO IE/PU/PD at Sleep Mode
5	PDBGS	R/W	0	0 : don' t_touch bg_sys during PDS 1 : power down bg_sys during PDS
4	PDDC	R/W	0	0 : don' t_touch dcdc18 during PDS 1 : power down dcdc18 during PDS
3	RSVD			
2	XTFO	R/W	0	0 : don' t_touch xtal during PDS 1 : power down xtal during PDS
1	SLFE	R/W	0	0:can be awakened by pds_timer 1:can't be awakened by pds_timer
0	PDSS	W1P	0	Enter PDS

19.4.2 PDS_TIME1

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	SLTIM														
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	SLTIM														

位	名称	权限	复位值	描述
31:0	SLTIM	R/W	32'd3240	PDS Sleep Time (in units of 32K clock cycles)



19.4.3 PDS_INT

地址: 0x4000e00c

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	WUEV							WUSEN							
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
INCL	INCL RSVD PDMS RDMS RSVD WUMS						CRSE		RSEV		PDIT	RDIT	RSVD	WKIT	

位	名称	权限	复位值	描述
31:24	WUEV	R	0	Record Wakeup resason, and be clear by cr_pds_int_clr [31]: wakeup trigger by kys_int [30]: wakeup trigger by usb_wkup [29]: wakeup trigger by ble_slp_irq [28]: wakeup trigger by irrx_int [27]: wakeup trigger by gpio_irq [26]: wakeup trigger by hbn_irq_out[1] [25]: wakeup trigger by hbn_irq_out[0] [24]: wakeup trigger by pds_sleep_cnt=0
23:16	WUSEN	R/W	8'hFF	Mask PDS Wakeup Trigger [23]: enable wakeup trigger by kys_int [22]: enable wakeup trigger by usb_wkup [21]: enable wakeup trigger by ble_slp_irq [20]: enable wakeup trigger by irrx_int [19]: enable wakeup trigger by gpio_irq [17]: enable wakeup trigger by hbn_irq_out[1] [17]: enable wakeup trigger by hbn_irq_out[0] [16]: enable wakeup trigger by pds_sleep_cnt=0
15	INCL	R/W	0	pds interrupt & wakeup reason clear
14:12	RSVD			
11	PDMS	R/W	0	Mask pds pll done interrupt
10	RDMS	R/W	0	Mask pds rf done interrupt
9	RSVD			
8	WUMS	R/W	0	Mask pds wakeup interrupt
7	CRSE	W	0	clear pds reset event
6:4	RSEV	R	0	[2]: pds_rst_n (pds reset) [1]: pwr_rst_n (hbn power on reset) [0]: hreset_n (Bus Reset)
3	PDIT	R	0	pu_pll_done interrupt
2	RDIT	R	0	pu_rf_done interrupt



位	名称	权限	复位值	描述
1	RSVD			
0	WKIT	R	0	PDS Wakeup Interrupt

19.4.4 PDS_CTL2

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	RSVD											FUSB	FBZ	RSVD	FNP
												GCLK	GCLK		GCLK
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
FLIOD	JSB FBZ RSVD FNP FUSB FBZP RSVD FNP FUSB FBZ RSVD FNP									ENID	FUOD	ED7	DC) (D	ENID	
FUSB	FBZ	RSVD	FNP	FUSB	FBZP	RSVD	FNP	FUSB	FBZ	RSVD	FNP	FUSB	FBZ	RSVD	FNP

位	名称	权限	复位值	描述
31:20	RSVD			
19	FUSBGCLK	R/W	0	manual force USB clock gated
18	FBZGCLK	R/W	0	manual force BZ clock gated
17	RSVD			
16	FNPGCLK	R/W	0	manual force NP clock gated
15	FUSBMSLP	R/W	0	manual force USB memory sleep
14	FBZMSLP	R/W	0	manual force BZ memory sleep
13	RSVD			
12	FNPMSLP	R/W	0	manual force NP memory sleep
11	FUSBRST	R/W	0	manual force USB pds reset
10	FBZPRST	R/W	0	manual force BZ pds reset
9	RSVD			
8	FNPPRST	R/W	0	manual force NP pds reset
7	FUSBISEN	R/W	0	manual force USB isolation
6	FBZISEN	R/W	0	manual force BZ isolation
5	RSVD			
4	FNPISEN	R/W	0	manual force NP isolation
3	FUSBPWOF	R/W	0	manual force USB power off
2	FBZPWOF	R/W	0	manual force BZ power off



位	名称	权限	复位值	描述
1	RSVD			
0	FNPPWOF	R/W	0	manual force NP power off

19.4.5 PDS_CTL3

地址: 0x4000e014

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
RSVD	MSIS	USB	BLE	BZ	RS	RSVD		RSVD							
		ISO	ISO	ISO											
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
RSVD	FBLE	FMIS	RSVD	FBLE	FMIS	RSVD	FBLE	FMIS	RSVD	FBLE	RS	VD	FBLE	FMIS	RSVD
	GCLK	GCLK		MSTB	MSTB		PRST	PRST		ISO			PWOF	PWOF	

位	名称	权限	复位值	描述
31	RSVD			
30	MSIS	R/W	1	make misc isolated at PDS Sleep state make misc isolated at PDS Sleep state
29	USBISO	R/W	1	make usb isolated at PDS Sleep state make usb isolated at PDS Sleep state
28	BLEISO	R/W	1	1 : make bz_Ble isolated at PDS Sleep state 0 : make bz_Ble isolated at PDS Sleep state
27	BZISO	R/W	1	make BZ isolated at PDS Sleep state make BZ isolated at PDS Sleep state
26:25	RSVD			
24	NPISO	R/W	1	make NP isolated at PDS Sleep state make NP isolated at PDS Sleep state
23:15	RSVD			
14	FBLEGCLK	R/W	0	manual force BZ_BLE gate_clk
13	FMISGCLK	R/W	0	manual force MISC gate_clk
12	RSVD			
11	FBLEMSTB	R/W	0	manual force BZ_BLE mem_stby
10	FMISMSTB	R/W	0	manual force MISC mem_stby
9	RSVD			
8	FBLEPRST	R/W	0	manual force BZ_BLE pds_rst

BL702/704/706 参考手册 352/ 370 @2021 Bouffalo Lab



位	名称	权限	复位值	描述
7	FMISPRST	R/W	0	manual force MISC pds_rst
6	RSVD			
5	FBLEISO	R/W	0	manual force BZ_BLE iso_en
4:3	RSVD			
2	FBLEPWOF	R/W	0	manual force BZ_BLE pwr_off
1	FMISPWOF	R/W	0	manual force MISC pwr_off
0	RSVD			

19.4.6 PDS_CTL4

地址: 0x4000e018

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
MISC	MISC	RS	VD	MISC	MISC	MISC	MISC	USB	USB	USB	USB	BLE	BLE	BLE	BLE
DPOF	APOF			GCLK	MSTB	RST	PWOF	GCLK	MSTB	RST	PWOF	GCLK	MSTB	RST	PWOF
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
BZ	BZ	BZ	BZ		RSVD							NP	NP	NP	NP
GCLK	MSTB	RST	PWOF										MSTB	RST	PWOF

位	名称	权限	复位值	描述
31	MISCDPOF	R/W	1	Use with bit[27] cr_pds_misc_pwr_off , if cr_pds_misc pwr_off =1, this bit : 1: Power Off PD_CORE_MISC_DIG when pds_state run at Power OFF 0:Power On PD_CORE_MISC_DIG when pds_state run at Power OFF
30	MISCAPOF	R/W	1	Use with bit[27] cr_pds_misc_pwr_off , if cr_pds_misc pwr_off =1, this bit : 1: Power Off PD_CORE_MISC_ANA when pds_state run at Power OFF 0 :Power On PD_CORE_MISC_ANA when pds_state run at Power OFF
29:28	RSVD			
27	MISCGCLK	R/W	1	1 : make core_misc clock gated at PDS Sleep state 0 : make core_misc clocking at PDS Sleep state
26	MISCMSTB	R/W	1	1 : make core_misc RAM @Retention at PDS Sleep state 0 : make core_misc RAM @ Normal at PDS Sleep state

BL702/704/706 参考手册 353/ 370 @2021 Bouffalo Lab



位	名称	权限	复位值	描述
25	MISCRST	R/W	1	1 : make core_misc reset at PDS Sleep state 0 : make core_misc not reset at PDS Sleep state
24	MISCPWOF	R/W	1	1 : make core_misc Power off at PDS Sleep state 0 : make core_misc power on at PDS Sleep state
23	USBGCLK	R/W	1	1 : make usb clock gated at PDS Sleep state 0 : make usb clocking at PDS Sleep state
22	USBMSTB	R/W	1	1 : make usb RAM @Retention at PDS Sleep state 0 : make usb RAM @ Normal at PDS Sleep state
21	USBRST	R/W	1	1 : make usb reset at PDS Sleep state 0 : make usb not reset at PDS Sleep state
20	USBPWOF	R/W	1	1 : make usb Power off at PDS Sleep state 0 : make usb power on at PDS Sleep state
19	BLEGCLK	R/W	1	1 : make bz_ble clock gated at PDS Sleep state 0 : make bz_ble clocking at PDS Sleep state
18	BLEMSTB	R/W	1	1 : make bz_ble RAM @Retention at PDS Sleep state 0 : make bz_ble RAM @ Normal at PDS Sleep state
17	BLERST	R/W	1	1 : make bz_ble reset at PDS Sleep state 0 : make bz_ble not reset at PDS Sleep state
16	BLEPWOF	R/W	1	1 : make bz_ble Power off at PDS Sleep state 0 : make bz_ble power on at PDS Sleep state
15	BZGCLK	R/W	1	1 : make BZ clock gated at PDS Sleep state 0 : make BZ clocking at PDS Sleep state
14	BZMSTB	R/W	1	1 : make BZ RAM @Retention at PDS Sleep state 0 : make BZ RAM @ Normal at PDS Sleep state
13	BZRST	R/W	1	1 : make BZ reset at PDS Sleep state 0 : make BZ not reset at PDS Sleep state
12	BZPWOF	R/W	1	1 : make BZ Power off at PDS Sleep state 0 : make BZ power on at PDS Sleep state
11:4	RSVD			
3	NPGCLK	R/W	1	1 : make NP clock gated at PDS Sleep state 0 : make NP clocking at PDS Sleep state
2	NPMSTB	R/W	1	1 : make NP RAM @Retention at PDS Sleep state 0 : make NP RAM @ Normal at PDS Sleep state
1	NPRST	R/W	1	1 : make NP reset at PDS Sleep state 0 : make NP not reset at PDS Sleep state



位	名称	权限	复位值	描述
0	NPPWOF	R/W	1	1 : make NP Power off at PDS Sleep state 0 : make NP power on at PDS Sleep state

19.4.7 pds_stat

地址: 0x4000e01c

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
RSVD										PLL	STA				
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
RSVD RFSTA							RS	VD			S ⁻	ГА			

位	名称	权限	复位值	描述
31:18	RSVD			
17:16	PLLSTA	R	2'b00	ST_PDS_PLL_OFF = 2'b00; ST_PDS_PLL_SFREG = 2'b01; ST_PDS_PLL_PU = 2'b10; ST_PDS_PLL_RDY = 2'b11;
15:12	RSVD			
11:8	RFSTA	R	4'b0	ST_PDS_RF_OFF = 4'b0000; ST_PDS_PU_MBG = 4'b0001; ST_PDS_PU_LDO15RF = 4'b0011; ST_PDS_PU_SFREG = 4'b0111; ST_PDS_BZ_EN_AON = 4'b1111;
7:4	RSVD			

BL702/704/706 参考手册 355/ 370 @2021 Bouffalo Lab



位	名称	权限	复位值	描述
3:0	STA	R	4'b0	ST_IDLE = 4'b0000;
				ST_ECG = 4'b1000;
				ST_ERST = 4'b1100;
				ST_EISO = 4'b1111;
				ST_POFF = 4'b0111;
				ST_PRE_BGON = 4'b0011;
				ST_PRE_BGON1 = 4'b0001;
				ST_BGON = 4'b0101;
				ST_CLK_SW_32M = 4'b0100;
				ST_PON_DCDC = 4'b0110;
				ST_PON_LDO11_MISC = 4'b1110;
				ST_PON = 4'b1010;
				ST_DISO = 4'b0010;
				ST_DCG = 4'b1101;
				ST_DRST = 4'b1011;
				ST_WAIT_EFUSE = 4'b1001;

19.4.8 pds_ram1

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	RSVD														
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
RSVD RAMPGEN							RAMF	RET2N			RAMF	RET1N			

位	名称	权限	复位值	描述
31:12	RSVD			
11:8	RAMPGEN	R/W	4'h0	[3]: 48 64KB np_ram Low Power Enable [2]: 32 48KB np_ram Low Power Enable [1]: 16 32KB np_ram Low Power Enable [0]: 0 16KB np_ram Low Power Enable
7:4	RAMRET2N	R/W	4'h0	[3]: 48 64KB np_ram RET2N, 0: Active With cr_pds_rampgen[3]=1 and cr_pds_ram_ret1n[3]=1 [2]: 32 48KB np_ram RET 2N, 0: Active With cr_pds_rampgen[2]=1 and cr_pds_ram_ret1n[2]=1 [1]: 16 32KB np_ram RET 2N,0: Active With cr_pds_rampgen[1]=1 and cr_pds_ram_ret1n[1]=1 [0]: 0 16KB np_ram RET_2N, 0: Active With cr_pds_rampgen[0]=1 and cr_pds_ram_ret1n[0]=1



位	名称	权限	复位值	描述
3:0	RAMRET1N	R/W	4'hF	[3]: 48 64KB np_ram RET2N, 0: Active With cr_pds_rampgen[3]=1 [2]: 32 48KB np_ram RET 2N, 0: Active With cr_pds_rampgen[2]=1 [1]: 16 32KB np_ram RET 2N,0: Active With cr_pds_rampgen[1]=1 [0]: 0 16KB np_ram RET_2N, 0: Active With cr_pds_rampgen[0]=1

19.4.9 pds_gpio_set_pu_pd

地址: 0x4000e030

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	
RSVD IO2823PU						RS	RSVD IO2823PD									
15	14	13	13 12 11 10 9 8					7	6	5	5 4 3 2 1 0					
RS	SVD		IO2217PU						VD			IO22	17PD			

位	名称	权限	复位值	描述
31:30	RSVD			
29:24	IO2823PU	R/W	6'h0	pu, pd 00: no PD/PU/IE on PAD 01: Pulldown PAD 10: Pullup PAD 11: Active IE [0]: PAD_GPIO_23 [1]: PAD_GPIO_24 [5]: PAD_GPIO_28
23:22	RSVD			

BL702/704/706 参考手册 357/ 370 @2021 Bouffalo Lab



位		权限	复位值	描述
21:16	IO2823PD	R/W	6'h0	pu, pd 00: no PD/PU/IE on PAD 01: Pulldown PAD 10: Pullup PAD 11: Active IE [0]: PAD_GPIO_23 [1]: PAD_GPIO_24 [5]: PAD_GPIO_28
15:14	RSVD			
13:8	IO2217PU	R/W	6'h0	pu, pd 00: no PD/PU/IE on PAD 01: Pulldown PAD 10: Pullup PAD 11: Active IE [0]: PAD_GPIO_17 [1]: PAD_GPIO_18 [5]: PAD_GPIO_22
7:6	RSVD			
5:0	IO2217PD	R/W	6'h0	pu, pd 00: no PD/PU/IE on PAD 01: Pulldown PAD 10: Pullup PAD 11: Active IE [0]: PAD_GPIO_17 [1]: PAD_GPIO_18 [5]: PAD_GPIO_22



19.4.10 pds_gpio_int

地址: 0x4000e040

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	RSVD														
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	RSVD ITSEL						RSVD		ITMD	•	RSVD	ITCL	ITST	ITMS	

位	名称	权限	复位值	描述
31:11	RSVD			
10:8	ITSEL	R/W	3'd0	Select VDDCORE GPIO as PDS Interrupt Source (GPIO0 7)
7	RSVD			
6:4	ITMD	R/W	3'b0	PDS Interrupt Mode
3	RSVD			
2	ITCL	R/W	1'b0	Clear PDS Interrupt
1	ITST	R	1'b0	PDS Interrupt Status
0	ITMS	R/W	1'b1	Mask PDS Interrupt

19.5 HBN 寄存器描述

名称	描述
HBN_CTL	HBN control
HBN_TIME_L	RTC timer compare
HBN_TIME_H	RTC timer compare
RTC_TIME_L	RTC time latched value
RTC_TIME_H	RTC time latched value
HBN_IRQ_MODE	HBN irq mode
HBN_IRQ_STAT	HBN irq state
HBN_IRQ_CLR	HBN irq clear
HBN_PIR_CFG	HBN pir configuration
HBN_PIR_VTH	PIR compare threshold
HBN_PIR_INTERVAL	PIR interval

BL702/704/706 参考手册 359/ 370 @2021 Bouffalo Lab



名称	描述
HBN_MISC	HBN misc configuration
HBN_GLB	HBN glb configuration
HBN_SRAM	HBN ram control

19.5.1 HBN_CTL

地址: 0x4000f000

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16		
	HBN	STA		SRAM	SRS	PWON	RTCD	PODC	V11AONSL V11RTSL				L V11RTSL				
				SLP	OPT	OPT	OPT										
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0		
V11RT	SLPOFF	POFF	SRST	POFF	RSVD	POFF	TRPM	HBNM	RTCCTL								
	VRT	VCOR		HRTC		HCOR											

位	名称	权限	复位值	描述
31:28	HBNSTA	R	4'h0	SW polling until 0 (default 4'h3 @pwron)
27	SRAMSLP	R	1'b0	SW polling until 0 (default 1'b1 @pwron)
26	SRSOPT	R/W	0	
25	PWONOPT	R/W	0	
24	RTCDOPT	R/W	0	
23	PODC	R/W	1	Power On DCDC18 during Power On Sequence (require 400 800us)
22:19	V11AONSL	R/W	4'hA	VDD11_AON Voltage Out Select @ Enter hibernate
18:15	V11RTSL	R/W	4'hA	VDD11_RT Voltage Out Select @ Enter hibernate
14	POFFVRT	R/W	0	Set 1 to disable power off VDDCORE_RT at HBN mode (for low power)
13	POFFVCOR	R/W	0	Set 1 to disable power off VDDCORE at HBN mode (for debug)
12	SRST	R/W	0	soft reset
11	POFFHRTC	R/W	0	Power Off HBN RTC @ Enter hibernate
10	RSVD			
9	POFFHCOR	R/W	0	Power Off HBN Core @ Enter hibernate
8	TRPM	R	0	Boot Strap 0: Flash, 1: UART or SDIO

BL702/704/706 参考手册 360/ 370 @2021 Bouffalo Lab



位	名称	权限	复位值	描述
7	HBNM	W	0	Enter hibernate
6:0	RTCCTL	R/W	7'h0	[6:4] Slow LED, x/0.25/0.5/1/2/4/8/16 seconds [3] rtc long time 0 353days (bit 39 13 compare) [2] rtc short time 0 488s (bit 23 0 compare) [1] rtc time 0 353days (bit 39 0 compare) [0] rtc enable

19.5.2 HBN_TIME_L

地址: 0x4000f004

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	HBNTIML														
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	HBNTIML														

位	名称	权限	复位值	描述
31:0	HBNTIML	R/W	32'h0	RTC timer compare bit 31:0

19.5.3 HBN_TIME_H

地址: 0x4000f008

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	
	RSVD															
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	
	RSVD							НВИТІМН								

位	名称	权限	复位值	描述
31:8	RSVD			
7:0	HBNTIMH	R/W	8'h0	RTC timer compare bit 39:32

BL702/704/706 参考手册 361/ 370 @2021 Bouffalo Lab



19.5.4 RTC_TIME_L

地址: 0x4000f00c

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	RTCTIMLL														
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	RTCTIMLL														

位	名称	权限	复位值	描述
31:0	RTCTIMLL	R	32'h0	RTC time latched value bit 31:0

19.5.5 RTC_TIME_H

地址: 0x4000f010

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
RTC								RSVD							
TIML															
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	RSVD						RTCTIMLH								

位	名称	权限	复位值	描述
31	RTCTIML	W	0	RTC time latch for SW read
30:8	RSVD			
7:0	RTCTIMLH	R	8'h0	RTC time latched value bit 39:32

19.5.6 HBN_IRQ_MODE

地址: 0x4000f014

								1			1				
31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	RS	VD		PWU EN	PWUSEL			A1	EN	A0EN		RSVD	BOR EN	RSVD	HW PUPD
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	RSVD	RSVD AONPADIE			HPAM					HPWMODE					

BL702/704/706 参考手册 362/ 370 @2021 Bouffalo Lab



位	名称	权限	复位值	描述
31:28	RSVD			
27	PWUEN	R/W	0	Pin wakeup delay enable
26:24	PWUSEL	R/W	3'd3	Pin wakeup delay 1 7 sec
23:22	A1EN	R/W	0	enable acomp1 interrupt [20] posedge [21] negedge
21:20	A0EN	R/W	0	enable acomp0 interrupt [20] posedge [21] negedge
19	RSVD			
18	BOREN	R/W	0	enable brown-out interrupt
17	RSVD			
16	HWPUPD	R/W	1	1: Pull GPIO9 and GPIO17 @ pwr_on and pwr_rst 0 : no pull
15:13	RSVD			
12:8	AONPADIE	R/W	5'b11111	AON_PAD IE/SMT (GPIO13 GPIO9)
7:3	HPAM	R/W	5'b0	mask hbn_pin_wakeup_event
2:0	HPWMODE	R/W	3'b101	hbn_pin_wakeup mode 000 : sync falling edge trigger 001 : sync rising edge trigger 010 : sync low level trigger 011 : sync high level trigger 100 : async falling edge trigger 101 : async rising edge trigger 110 : async low level trigger 111 : async high level trigger

19.5.7 HBN_IRQ_STAT

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	IRQSTATE														
15	15 14 13 12 11 10 9 8 7 6 5 4 3 2 1 0														
	IRQSTATE														



位	名称	权限	复位值	描述
31:0	IRQSTATE	R	0	[22] acomp1 [20] acomp0 [18] brown-out [17] irq_pir state [16] irq_rtc state [4:0] hbn_pin_wakeup state (GPIO13 GPIO9)

19.5.8 HBN_IRQ_CLR

地址: 0x4000f01c

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	IRQCLR														
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	IRQCLR														

位	名称	权限	复位值	描述
31:0	IRQCLR	W	0	[22] irq_acomp1 clear [20] irq_acomp0 clear [18] irq_bor clear [17] irq_pir clear [16] irq_rtc clear [4:0] hbn_pin_wakeup clear (GPIO13 GPIO9)

19.5.9 HBN_PIR_CFG

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	RSVD														
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
		RS	VD	,		NO	CGEN	PIR	RSVD	PIR	DIS	RSVD	LPF	HPF	SEL
						SYNC		EN					SEL		

位	名称	权限	复位值	描述
31:10	RSVD			
9	NOSYNC	R/W	0	gpadc no sync



位	名称	权限	复位值	描述
8	CGEN	R/W	0	gpadc force cgen=1
7	PIREN	R/W	0	pir enable
6	RSVD			
5:4	PIRDIS	R/W	0	pir disable [4] low -> high won't trigger interrupt [5] high -> low won't trigger interrupt
3	RSVD			
2	LPFSEL	R/W	0	0: /1. 1:/2
1:0	HPFSEL	R/W	0	0: 1-z-1, 1: 1-z-2, 0: 2-z-3

19.5.10 HBN_PIR_VTH

地址: 0x4000f024

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	RSVD														
15	14	13	12 11 10 9 8 7 6 5 4 3 2 1 0												
RS	SVD	PIRVYH													

位	名称	权限	复位值	描述
31:14	RSVD			
13:0	PIRVYH	R/W	14'h3ff	PIR compare threshold

19.5.11 HBN_PIR_INTERVAL

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	·	·	·		·	·	RS	VD		·	·	·		·	
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	RS	VD							PIRIN	TERV					

位	名称	权限	复位值	描述
31:12	RSVD			



位	名称	权限	复位值	描述
11:0	PIRINTERV	R/W	12'd2621	pir_lpf_sel = 0: 32768 / (pir_interval+1) Hz, default 12.5Hz (80ms) pir_lpf_sel = 1: 32768 / (pir_interval*2+1) Hz, default 6.25Hz (160ms)

19.5.12 HBN_MISC

地址: 0x4000f02c

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
RS	SVD			PULLD	WAON			RS	VD			PULLU	JPAON		
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
		•			RS	VD					•	BOR	PU	BOR	BOR
												OUT	BOR	VTH	SEL

位	名称	权限	复位值	描述
31:30	RSVD			
29:24	PULLDWAON	R/W	6'h0	[5]: 1: Turn on Flash PAD PD (GPIO28), Only Set this bit when Flash @ Deep Power Down Mode [4]: 1: Turn on Flash PAD PD (GPIO27), Only Set this bit when Flash @ Deep Power Down Mode [3]: 1: Turn on Flash PAD PD (GPIO26), Only Set this bit when Flash @ Deep Power Down Mode [2]: 1: Turn on Flash PAD PD (GPIO25), Only Set this bit when Flash @ Deep Power Down Mode [1]: 1: Turn on Flash PAD PD (GPIO24), Only Set this bit when Flash @ Deep Power Down Mode [0]: 1: Turn on Flash PAD PD (GPIO23), Only Set this bit when Flash @ Deep Power Down Mode
23:22	RSVD			

BL702/704/706 参考手册 366/ 370 @2021 Bouffalo Lab



位	名称	权限	复位值	描述
21:16	PULLUPAON	R/W	6'h0	[5]: 1: Turn on Flash PAD PU (GPIO28), Only Set this bit when Flash @ Deep Power Down Mode [4]: 1: Turn on Flash PAD PU (GPIO27), Only Set this bit when Flash @ Deep Power Down Mode [3]: 1: Turn on Flash PAD PU (GPIO26), Only Set this bit when Flash @ Deep Power Down Mode [2]: 1: Turn on Flash PAD PU (GPIO25), Only Set this bit when Flash @ Deep Power Down Mode [1]: 1: Turn on Flash PAD PU (GPIO24), Only Set this bit when Flash @ Deep Power Down Mode [0]: 1: Turn on Flash PAD PU (GPIO23), Only Set this bit when Flash @ Deep Power Down Mode
15:4	RSVD			
3	BOROUT	R	1'h0	Brown Out Reset status
2	PUBOR	R/W	1'h0	Power up Brown Out Reset
1	BORVTH	R/W	1'h1	BOR threshold 0:2.0V, 1: 2.4V
0	BORSEL	R/W	1'h0	0: POR is independent of BOR, 1: POR is relevant to BOR

19.5.13 HBN_GLB

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
	AIDC	VEC			RTID	OVEC			RS	SVD			V11SC	VSEL	
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
RS	SVD	CRSE	CRSE HBNRSEV				PU F32 RC32				32SEL UART ROOTCLK CLK				

位	名称	权限	复位值	描述
31:28	AIDOVEC	R/W	4'ha	aon Ido output voltage external control: 0:0.60V, 1:0.65V, 2:0.70V, 3:0.75V, 4:0.80V, 5:0.85V, 6:0.9V, 7:0.95V 8:1.0V, 9:1.05V, 10:1.1V, 11:1.15V, 12:1.2V, 13:1.25V, 14:1.3V, 15:1.35V



位	名称	权限	复位值	描述
27:24	RTIDOVEC	R/W	4'ha	Ido output voltage external control: 0:0.60V, 1:0.65V, 2:0.70V, 3:0.75V, 4:0.80V, 5:0.85V, 6:0.9V, 7:0.95V 8:1.0V, 9:1.05V, 10:1.1V, 11:1.15V, 12:1.2V, 13:1.25V, 14:1.3V, 15:1.35V
23:20	RSVD			
19:16	V11SOVSEL	R/W	4'hA	vdd11soc output voltage selection
15:14	RSVD			
13	CRSE	R/W	1'b0	clear reset event
12:8	HBNRSEV	R	4'b0	[4]: bor_out_ event [3]: pwr_rst_n event [2]: sw_rst event [1]: ext_rst_n event [0]: por_out event
7:6		R/W	2'h1	Ido11_rt drive strength select
5	PURC32	R/W	1	0: Turn off rc32k during rtc power domain off, 1: Don't turn off rc32k
4:3	F32SEL	R/W	0	32KHz clock source selection (0: RC32K 1: XTAL 32K 3: DIG 32K)
2	UARTCLK	R/W	0	uart clock selection from HBN (0:fclk 1:96MHz)
1:0	ROOTCLK	R/W	0	root clock source selection (0: RC32M 1: XTAL 2/3: PLL)

19.5.14 HBN_SRAM

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
							RS	VD							
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	RSVD								RET			RS	VD		



位	名称	权限	复位值	描述
31:8	RSVD			
7	SLP	R/W	0	make HBN RAM Sleep
6	RET	R/W	0	make HBN RAM Retention
5:0	RSVD			

表 20.1: 修改记录

日期	版本	修改内容
2020/9/9	1.0	初版
2021/3/8	1.1	修改 DAC 对应的 GPIO 口