

SPM 장비의 설치조건 - 한글

전원 공급	3상 AC 220V $\pm 10\%$ 이내편차, 60Hz $\pm 1\text{Hz}$ 이내 편차, 전원 케이블 터미널 사이즈: 8-5, 정격 사용용량: 13KVA(다운트렌스 사용시 30KVA설치)
압축 공기	공기압력: 0.5-0.7 MPa, 분당 분사량: 100-110L/min 또는: 120L/min 0.1 mm 이하의 와이어 사용시 좀더 높은 압력이 요구될 수 있음: 압력 조정기에 부착하는 연결 커플링 나사 RC1/4
차폐 시설	Wire cut 방전가공기는 가공시 전자파로 인해 주변의 전자기기에 영향을 줄 수 있습니다. 이 같은 환경에서는 반드시 차폐시설을 설치해야 합니다.
설치 룸의 환경	일반적인 기계 구동 온도: 15-30°C, 초정밀 가공을 위한 온도 20 $\pm$ 1°C.(일일 편차)일반적으로 장비 주변에는 오일 유분이나 분진 발생 장치로 부터 분리 격리되어야 하고, 상시 유지 습도는 75% RH 이하로 유지해야 합니다.
전기 접지	전자기 간섭이나 누전으로 인한 손상을 방지하려면 장치를 접지해야 합니다. 접지 자체는 전기 설치 표준에 명시된대로 C 형 (접지 저항 최대 10 Ω) 이어야하며 다른 기계 (1개 접지)의 접지와 독립적으로 수행해야 합니다.
설치바닥 조건	기계를 설치하는 바닥은 평탄해야하고, 바닥의 강도는 공장조건을 충족해야 하며, 외부로 부터의 진동의 전달이 없어야 합니다. 바닥의 강도가 충족하지 않을 경우 기계의 정밀도에 영향을 줄 수 있으므로 충분히 보강하여야 합니다.

주의 : 설치 환경조건이 위와 같은 내용을 충족하지 않을 경우 기계정밀도를 보장할 수 없으며, 고장의 원인이 될 수 있음.

본사/공 장 : 경기도 안산시 단원구 엠티브이20로 10

전 화 : 031-499-8166 팩 스 : 031-499-8169

e-mail: spmedm@spmedm.com

Website: <https://www.spmedm.com>

Machine Installation Condition - English

Power Supply	AC 220V $\pm 10\%$ 3 phase 60Hz ± 1 Hz, connection cable terminal size:8-5, Power consumption: 13KVA
Air Supply	Air pressure 0.5-0.7 MPa, Flow rate: 100-110L/min or more: 120L/min or more(with a fine wire option) Regulator-side coupler mounting screw: Rc1/4
Shield room	FI discharge noise can interfere with surrounding radio, television and other sets, a shield room needs to be created
Environment	Ambient temperature: 15-30°C, Recommend 20 ± 1 °C for high precision machining. Install under the oil mist free and dust free environment. A place free from vibration. Humidity: 75% RH or less
Grounding	The unit must be grounded to avoid damage resulting from electro-magnetic interference or electrical leakage. The grounding itself should be of type C(grounding resistance of 10 Ω max.) as specified in the electrical installation standard and should be carried out independently of the grounding of any other piece of machinery(one piece grounding)
Installation floor	The floor on which the machine is installed must be flat, the strength of the floor must meet factory conditions, and there must be no transmission of vibration from the outside. If the strength of the floor is not sufficient, it may affect the precision of the machine, so it must be sufficiently reinforced.

Office/Factory : 경기도 안산시 단원구 엠티브이20로 10
 Tel : 031-499-8166 Fax : 031-499-8169
 e-mail: spmedm@spmedm.com
<https://www.spmedm.com>