

AE 319H

Symbol Equivalency chart

1. Zero-lift angle of attack $\rightarrow \alpha_{ZL} \equiv \alpha_{0l}$
2. Lift per unit span $\rightarrow L' \equiv l$
3. Drag per unit span $\rightarrow D' \equiv d$
4. Stagnation quantities for example, pressure and temperature $\rightarrow p_0 \equiv p_{t1}$ and $T_0 \equiv T_{t1}$ respectively.
5. Camberline $\rightarrow z_c \equiv z$
6. Internal energy $\rightarrow e \equiv u_e$
7. Moment coefficient about leading edge $\rightarrow c_{m_{LE}} \equiv c_{m0}$
8. Downwash velocity $\rightarrow w_d \equiv w$
9. Induced drag $\rightarrow D_i \equiv D_v$
10. Free-stream velocity $\rightarrow V_\infty \equiv U_\infty$
11. Induced angle of attack $\rightarrow \alpha_i \equiv \epsilon$