

Communication Protocol:

18 SSSS QXYZ GG CCC K

18 = Uniquely identifies this format to the receiver and

to an automation system, but not displayed on the

printer

SSSS = 4 digit Subscriber ID

Q = Event qualifier, which gives specific event

information

E = 1 New event or opening

R = 3 New restore or closing

P = 6 Previous event

YXZ = Event code (3 Hex digits)

GG = Group number (physical or logical, 2 Hex digits)

CCC = Zone or sensor number(3Hex digits, event

reports) or user number (Open/close report)

Note: The GG and CCC fields can contain 0 for a null (no information) field.



Contact ID Event Code Classification

| Medical Alarm - 100 | | General Alarms - 140 | | System Trouble - 300 | |
|----------------------|-------------------|----------------------|---------------------|----------------------|-------------------|
| 101 | Pendant | 141 | Polling Loop | and 3 | 10 |
| | Transmitter | | Open | 301 | AC Loss |
| 102 | Fail to report in | 142 | Polling Loop | 302 | Low System |
| | | | Short | | Battery |
| Fire A | larms - 110 | 143 | Expansion | 303 | RAM Checksum |
| 111 | Smoke | | Module Failure | | Bad |
| 112 | Combustion | 144 | Sensor Tamper | 304 | ROM Checksum |
| 113 | Water Flow | 145 | Expansion | | Bad |
| 114 | Heat | | Module Failure | 305 | System Reset |
| 115 | Pull Station | | | 306 | Panel Program |
| 116 | Duct | 24H N | lon-Burglary - | | Changed |
| 117 | Flame | 150 ar | nd 160 | 307 | Self-Test Failure |
| 118 | Near Alarm | 151 | Gas Detection | 308 | System |
| | | 152 | Refrigeration | | Shutdown |
| Panics | s Alarms - 120 | 153 | Loss of Heat | 309 | Battery Test |
| 121 | Duress | 154 | Water Leakage | | Failure |
| 122 | Silent | 155 | Foil Break | 310 | Ground Fault |
| 123 | Audible | 156 | Day Trouble | | |
| | | 157 | Low bottled Gas | Sound | ler/Relay |
| Burglar Alarms - 130 | | | Level | Troubles - 320 | |
| 131 | Perimeter | 158 | High Temp | 321 | Bell 1 |
| 132 | Interior | 159 | Low Temp | 322 | Bell 2 |
| 133 | 24 Hour | 161 | Loss of Air Flow | 323 | Alarm Relay |
| 134 | Entry/Exit | | | 324 | Trouble Relay |
| 135 | Day/Night | Fire S | upervisory - 200 | 325 | Reversing |
| 136 | Outdoor | and 2 | | | |
| 137 | Tamper | 201 | Low Water | | |
| 138 | Near Alarm | | Pressure | | |
| | | 202 | Low CO ₂ | | |
| | | 203 | Gate Valve | | |
| | | | Sensor | | |
| | | 204 | Low Water | | |
| | | | Level | | |
| | | 205 | Pump Activated | | |
| | | 206 | Pump Failure | | |
| | | | | | |



| System Peripheral | | Senso | Sensor Trouble - 380 | | Remote Access - 410 | |
|-------------------------------|------------------|--------|----------------------|-------|---------------------|--|
| Troubles - 330 and 340 | | 381 | Loss of | 411 | Call Request | |
| 331 | Polling Loop | | Supervisory- | | Made | |
| | Open | | RF | 412 | Success - | |
| 332 | Polling Loop | 382 | Loss of | | Download | |
| | Short | | Supervisory - | | Access | |
| 333 | Expansion | | RPM | 413 | Unsuccessful | |
| | Module Failure | 383 | Sensor Tamper | | Access | |
| 334 | Repeater Failure | 384 | RF Transmitter | 414 | System | |
| 335 | Local Printer | | Low Battery | | Shutdown | |
| | Paper Out | | | 415 | Dialer Shutdown | |
| 336 | Local Printer | Open | /Close - 400 | | | |
| | Failure | 401 | Open/Close by | Acces | ss Control - 420 | |
| | | | User | 421 | Access Denied | |
| Comn | nunication | 402 | Group | 422 | Access Report by | |
| Troubles - 350 and 360 | | | Open/Close | | User | |
| 351 | Telco 1 fault | 403 | Automatic | 441 | Stay Arming | |
| 352 | Telco 2 fault | | Open/Close | 451 | Early Opening | |
| 353 | Long Range | 404 | Late to | | /Closing | |
| | Radio | | Open/Close | 452 | Late Opening | |
| 354 | Fail to | 405 | Deferred | | /Closing | |
| | Communicate | | Open/Close | 453 | Late to Open | |
| 355 | Loss of Radio | 406 | Cancel | 454 | Late to Close | |
| | Supervision | 407 | Remote Arm | 455 | Auto-Arm | |
| 356 | Loss of Central | | /Disarm | | Failure | |
| | Polling | 408 | Quick Arm | | | |
| | | 409 | Keyswitch Open | Syste | m Disable | |
| Protection Loop | | /Close | - 500 | & 510 | | |
| Trouble - 370 | | | | | | |
| 371 | Protection Loop | | | | | |
| | Open | | | | | |
| 372 | Protection Loop | | | | | |
| | Short | | | | | |

373

Fire Trouble



| Sounder/Relay Disable | | Test/Misc 600 | | |
|-----------------------|------------------|---------------|------------------|--|
| - 520 | · | 601 | Manual Trigger | |
| 521 | Bell 1 Disable | | Test | |
| 522 | Bell 2 Disable | 602 | Periodic Test | |
| 523 | Alarm Relay | | Report | |
| | Disable | 603 | Periodic RF | |
| 524 | Trouble Relay | | Transmission | |
| | Disable | 604 | Fire Test | |
| 525 | Reversing Relay | 605 | Status Report to | |
| | Disable | | Follow | |
| | | 606 | Listen-in Follow | |
| Systen | n Peripheral | 607 | Walk Test Mode | |
| Disabl | e - 530 and 540 | 621 | Event Log Reset | |
| | | 622 | Event Log 50% | |
| Communication | | | Full | |
| Disable | | 623 | Event Log 90% | |
| - 550 and 560 | | | Full | |
| 551 | Dialer Disable | 624 | Event Log | |
| 552 | Radio | | Overflow | |
| | Transmitter | 625 | Time/Date Reset | |
| | Disable | 626 | Time/Date | |
| | | | Inaccurate | |
| Bypasses - 570 | | 627 | Program Mode | |
| 570 | Zone Bypass | | Entry | |
| 571 | Fire Zone Bypass | 628 | Program Mode | |
| 572 | 24 Hour Zone | | Exit | |
| | Bypass | 631 | Exception | |
| 573 | Burglary Zone | | Schedule | |
| | Bypass | | Change | |
| 574 | Group Bypass | | | |