

Y ENDSTOP MOUNTING WWW.VORONDESIGN.COM



The bottom of the drive module mid pieces have three locating tabs (shown here), while the top of the pieces only have two


LEFT DRIVE MODULE WWW.VORONDESIGN.COM

M3x20 SHCS





PULLEY ALIGNMENT

Verify top of Y pulley is flush with the top of the drive_module_lower component



LEFT DRIVE MODULE WWW.VORONDESIGN.COM






UPSIDE DOWN ASSEMBLY

For ease of assembly we recommend to assemble the A and B drives upside down.


LEFT DRIVE MODULE WWW.VORONDESIGN.COM



Route Y endstop wires through the drive module and fit in cutout shown


DON'T OVER TIGHTEN

The M5 bolts are threaded directly into plastic.



LEFT DRIVE MODULE WWW.VORONDESIGN.COM

M3x30 SHCS



MOTOR ORIENTATION

Install X motor so that wires face the back of the printer

ASSEMBLY TIP

Partially loosen these screws to make installation of drive module onto frame easier

