PA0 ADC0 PA1 XCK/TO PB1 PB1 T1 PB2 INT2/AIN0 PB3 OC0/AIN1 PB4 PB5 MOSI PB7 MISO PB7 SCK ADC7 XTAI XTAI PD0 RX PD1 TX PD2 INT0 PD3 INT1 PD4 TDI PC4 TD0 PC3 TMS PC2 TCK PC1 PD4 OC1A PD5 OC1B PD6 ICP1