



Home ▸ BFT Q.Bo Wireless Keypad Coding

 4.8 ★★★★★ based on 823 reviews

BFT Q.BO WIRELESS KEYPAD CODING

Step-by-step coding instructions, with the original manufacturer's download.

REQUEST A QUOTE

 (03) 8771 4824

REQUEST A QUOTE

 (03) 8771 4824

 sales@aggdoors.com

 Melbourne Vic 3000,



↓ DOWNLOAD ORIGINAL PDF

Genuine Q.Bo Wireless Keypad



Adding a code

1. Press ON button for 5 seconds or wait until the Red LED light flash once.
2. Enter default (1234) or existing password.
3. Press OK button. The Green LED light flashes and Red LED light turn on.
4. Enter the channel number to be activated 4x. (Ch 1: 1111 or Ch 2: 2222)
5. Press OK button. Green and Red LED light turn on at the same time.

6. Enter the new code. Enter 4 digit numbers and best to add the channel number at the end to remember which function it is. (e.g. New password: 56561 > Channel 1)
7. Press OK button. The Green LED light flashes and Red LED light turn on.
8. Repeat new code and Green LED light turns on. Code added!

WARNING: To add a code, you need to know the system password. T-BOX can handle up to 100 different codes. The new code will serve the same purpose as the existing code (activates the same channel).

Changing the password

1. Press ON button for 5 seconds or wait until the Red LED turn on.
2. Enter old password then press OK button. The Green LED flashes and Red LED turn on.
3. Enter new password then press OK button. Red and Green LED flash on at the same time.
4. Re-enter new password. Green light flash on. Password changed!

Memorizing on control unit / receiver

1. Press ON button for 5 seconds or wait until the Red LED turn on.
2. Enter the channel number that you will save the new code 4x. (Ch 1: 1111 or Ch 2: 2222 or Ch 3: 3333)
3. Press ON button again until Red LED flashes.
4. **For control units with display**

For receivers

5. Press ON button until Green LED flash 2x.

Deleting a code

1. Press ON button for 5 seconds or wait until the Red LED turn on.
2. Enter code to be deleted and press OK button. The Green LED flashes and Red LED turn on.
3. Re-enter code to be deleted and press OK button. Code deleted!

Repair all brands of garage doors & motors

Get in touch with us today using the form to get your garage door problem sorted.

REQUEST A QUOTE

 **(03) 8771 4824**

Our Services

Garage Door Repairs

Gate Repairs

Garage Door Spring Replacement

Emergency Garage Door Repairs

Roller Shutter Installations

Roller Shutter Repairs

Swing Gate Openers

Sliding Gate Openers

Quick Links

About Us

Contact Us

FAQs

Product Support

Brand

HTML Sitemap



 (03) 8771 4824

 sales@aggdoors.com.au

 Melbourne Vic 3000, Australia



© 2026 AGG DOORS. All Rights Reserved

[Terms & Conditions](#) [Privacy Policy](#) [AI Information](#)

We went with ClickClickMedia.