# **Smart Dog Access User Manual**

# **Table of Contents**

- 1. Introduction
  - Purpose
  - System Overview
- 2. Installation and Setup
  - Hardware Requirements
  - Assembly Instructions
  - Power Connection
- 3. Usage Guide
  - Enrolling RFID Tags
  - Access Control
  - Manual Override
- 4. User Interface (if applicable)
  - Configuration Settings
  - Access Log Viewing
  - Maintenance Tasks
- 5. Troubleshooting
  - Frequently Asked Questions
  - Known Issues and Solutions
- 6. Safety Instructions
  - Pet Safety
  - Electrical Safety
- 7. Maintenance and Care
  - Cleaning
  - Battery Replacement (if applicable)
- 8. Technical Specifications
  - Hardware Components
  - Dimensions and Weight

- Power Requirements
- 9. Warranty and Support
  - Warranty Coverage
  - Contact Information
- 10. Legal Information
  - License
  - Open Source Acknowledgements

## 1. Introduction

# **Purpose**

The Smart Dog Access system is designed to provide a secure and convenient access point for dogs, ensuring that only authorized pets can enter while preventing unauthorized access.

## **System Overview**

The system utilizes RFID technology and an ESP32 microcontroller to authenticate dogs wearing RFID-enabled collars. It features a robust design, manual override mechanism, and optional user interface for configuration, access log viewing, and maintenance tasks.

# 2. Installation and Setup

#### **Hardware Requirements**

Before installation, ensure you have all the necessary hardware components listed in the user manual or product documentation.

#### **Assembly Instructions**

Follow the step-by-step assembly instructions provided in the user manual or product documentation to set up the Smart Dog Access system.

#### **Power Connection**

Connect the power supply according to the provided instructions, ensuring proper voltage and polarity.

# 3. Usage Guide

## **Enrolling RFID Tags**

To grant access to your dogs, follow the instructions to enroll their RFID tags with the Smart Dog Access system.

## **Access Control**

When a dog wearing an authorized RFID collar approaches the Smart Dog Access door, the system will automatically unlock, granting access. Unauthorized dogs or intruders will be denied entry.

#### **Manual Override**

In case of emergencies or power outages, use the manual override mechanism to open the door manually from the inside or outside.

# 4. User Interface (if applicable)

If your system includes a user interface, refer to the user manual or product documentation for instructions on configuring settings, viewing access logs, and performing maintenance tasks.

## 5. Troubleshooting

Refer to the troubleshooting section for answers to frequently asked questions, known issues, and solutions to common problems.

# 6. Safety Instructions

Ensure the safety of your pets and follow the provided safety instructions. This includes guidelines for pet safety and electrical safety.

#### 7. Maintenance and Care

Learn how to properly clean and maintain the Smart Dog Access system. If applicable, find instructions for battery replacement.

## 8. Technical Specifications

Refer to the technical specifications section for detailed information about the hardware components, dimensions, weight, and power requirements of the Smart Dog Access system.

# 9. Warranty and Support

Understand the warranty coverage provided with the system and find contact information for customer support.

# 10. Legal Information

Review the license information and open source acknowledgements related to the Smart Dog Access system.

Please note that this is a sample template for a user manual. You can modify and expand it according to your specific product features, instructions, and requirements.