

Balanceè SmartPump

Everything the SmartPump V1 team needs — tracker, docs, and execution plan — in one place.

≡ Show menu

BALANCEÈ SMARTPUMP · ANDROID SCREEN SPEC

Every screen. *Every state. Every flow.*

Complete visual specification for Ekomobong. All 5 transaction flows, all pump display states, all attendant UI actions. Build exactly what you see here.

Idle + Mode Select

Flow 1 — Fixed Pre-pay

Flow 2 — Fill-up Cash

Flow 3 — Fill-up Digi

FLOW 4 · CASH — FIXED AMOUNT

Attendant enters naira. *System calculates litres.*

Customer states a cash amount. Attendant enters it on the pump screen. Android calculates the litre cutoff from the pushed price. Relay cuts at exactly that litre count.

SCREEN SEQUENCE — CASH FIXED FLOW

ATTENDANT ENTERS ₦

DISPENSING TO CUTOFF

COMPLETE — C

CASH ATT-0

ENTER CASH AMOUNT

₦5,000

CURRENT PRICE ₦870/L

LITRES CUTOFF 5.75 L

AUTHORISE CASH ₦5,000

Relay opens. Cuts at 5.75L exactly.

Attendant enters naira. System shows litre cutoff before authorising.

DISPENSING CASH

LITRES DISPENSED

3.18

of 5.75L target

₦2,767 used ₦5,000 cash

PRICE/L ₦870

CUTOFF AT 5.75 L

Gold = cash mode. Counting to 5.75L. Will cut automatically.

✓

Dor

CASH · F

LITRES

CASH

ATTENDANT

TXN

Operator sees: Attenda
5.75L against



