## Finding SOC for every data sample



- To compute OCV vs. SOC, must first compute SOC
- DOD (in Ah) at every point in time is calculated as

depth of discharge(t) = total Ah discharged until t

- $-\eta(25\,^{\circ}\text{C}) \times \text{total Ah charged at } 25\,^{\circ}\text{C} \text{ until } t$
- $-\eta(T) \times$  total Ah charged at temperature T until t
- Likewise, SOC corresponding to every data sample is then

state of charge(t) = 1 – depth of discharge(t)/Q

 $\blacksquare$  Check: SOC at end of step 4 must be 0 %, and SOC at end of step 8 must be 100 %


Dr. Gregory L. Plett University of Colorado Colorado Spri

Equivalent Circuit Cell Model Simulation | Identifying parameters of static model

### Challenge in finding OCV



- Figure plots discharge voltage from step 2 vs. SOC and charge voltage from step 6 vs. SOC
  - Same data as shown before, but now plotted vs. SOC rather than time
- Example illustrates that there is a challenge in determining OCV at all SOCs:
  - Missing discharge voltages at low SOC because test encountered cutoff voltage  $v_{\min}$ in step 2 before 0% SOC was reached;
  - Missing charge voltages at high SOC because test encountered cutoff voltage  $v_{
    m max}$ in step 6 before 100% SOC was reached.




Dr. Gregory L. Plett University of Colorado Colorado Spri

2.2.4: How do I determine a cell's temperature-dependent open-circuit voltage?

# Overcoming missing-data challenge (1)




- Estimate 100 % SOC discharge resistance  $R_0$  via instant voltage change when test moves from step 1 to step 2
- **E**stimate 0% SOC resistance  $R_0$  via voltage change at end of step 4
- Estimate 0% SOC charge resistance  $R_0$  via voltage change when moving from step 5 to 6
- Estimate 100 % SOC charge resistance  $R_0$  at end of step 8
- Assume R<sub>0</sub> changes linearly from 0 % SOC value to 100 % SOC value
- Adjust voltage curves by removing  $R_0i(t)$



## Overcoming missing-data challenge (2)



- Approximate mid-SOC steady-state resistance by considering voltage difference between adjusted curves at 50 % SOC
- Blend linearly between modified charge-voltage and discharge-voltage curves so that blend is halfway between curves at 50 % SOC
  - □ Follows charge curve for low SOC and discharge curve for high SOC
  - □ Overcomes "missing data" problem
- Figure shows OCV estimate as black dashed line



Dr. Gregory L. Plett University of Colorado Colorado Spri

Equivalent Circuit Cell Model Simulation | Identifying parameters of static model

### Modeling temperature dependence



- At any given SOC, OCV variation is nearly linear in *T*
- Combine individual approximate single-temperature OCV results to make a final model of the form

$$OCV(z(t), T(t)) = OCVO(z(t)) + T(t) \times OCVrel(z(t)),$$

where OCV0(z(t)) is the OCV relationship at 0 °C , and OCVrel(z(t)) (V/°C) is the linear temperature-correction factor at each SOC

■ Once OCVO(z(t)) and OCVrel(z(t)) are determined, OCV(z(t), T(t)) can be computed via two computationally efficient 1D table lookups

Dr. Gregory L. Plett University of Colorado Colorado Spring

Equivalent Circuit Cell Model Simulation | Identifying parameters of static model

2.2.4: How do I determine a cell's temperature-dependent open-circuit voltage?

# Computing OCV0 and OCVrel



■ To make OCV0(z(t)) and OCVrel(z(t)), note we can write

at m SOC values z for each of n temperatures (Y is  $n \times m$ ; A is  $n \times 2$ ; X is  $2 \times m$ )


- $\blacksquare$  One way to find X from A and Y is to use the least-squares solution, which is computed in Octave/MATLAB as X=A\Y;
  - □ We tend to use data only from tests above 0 °C because accuracy degrades at low temperatures due to high cell resistances




#### Sample results



■ The figures plot the outcome of this overall process for six different lithium-ion cells





Dr. Gregory L. Plett University of Colorado Colorado Spring

Equivalent Circuit Cell Model Simulation | Identifying parameters of static model 7 of 8

2.2.4: How do I determine a cell's temperature-dependent open-circuit voltage?

### Summary



- Encounter problem of "missing data" at high and low SOC
- First, extract dis/charge voltages at every available SOC
- Find R at 0 %, 50 %, and 100 % SOC—linearly interpolate for other SOCs
- Approximate OCV as *charge* voltage plus *charge* current times *R* at low SOCs and as discharge voltage plus discharge current times R at high SOCs
- $\blacksquare$  Assemble approximate OCVs at each temperature into matrix Y, put temperatures in matrix A, compute OCV0 and OCVrel as as  $X=A\setminus Y$ ;
- Two 1D table lookups used to compute OCV at any given SOC and temperature as

$$OCV(z(t), T(t)) = OCV0(z(t)) + T(t) \times OCVrel(z(t))$$

Dr. Gregory L. Plett University of Colorado Colorado Springs

Equivalent Circuit Cell Model Simulation | Identifying parameters of static model 8 of 8