SC//HyperCore Operations Guide

Chapter 1. Setup

This guide covers day-to-day operation of SC//HyperCore for cluster administrators.

Prerequisites include a supported browser, network access, and an administrator account.

Registration can be completed with or without an internet connection.

Single Sign-On supports Active Directory, Okta, and custom SSL certificates.

The web interface has panels for nodes, virtual machines, and storage.

Chapter 2. Users

Access is controlled through user accounts and role-based permissions. Administrators can create, edit, and delete users, and can reset passwords. Roles define which panels and actions a user can reach.

Chapter 3. Virtual Machines

Create a virtual machine by choosing CPU, memory, disks, and an optional ISO.

A virtual machine can be edited, cloned, imported, or exported.

Snapshots capture a virtual machine state and can be restored later.

vTPM support is available for guests that need a virtual trusted platform module.

Chapter 4. Support

For a node or disk failure, replace the hardware before opening a support case.

Include cluster logs, the node serial number, and the time of the failure.

System limits are listed in the appendix, including per-cluster and per-VM maximums.