Wineles Senson Networks

physical or environmental coud; hous.

Wetwon us of small, battery powered, while devices.

W5N veeds to adapt to Human IoT and machine IOT.

\rightarrow MAC

Seuson whomis arreplayed in ad-hoc where individual moder are juactive for a lay time MAC weeds to be different to thatitional winder MAC (every conservation and self-config).

L. Solutions:

- cannien sewsing
- RTS CTS only during high traffic loss
- Bacyoff

5- MAC (Sensor - MAC) is designed for WSN, wodes periodically sleep when others transmit.

Trades energy efficiency for latency and buren througher.

-> 802.15.4 and Zigbee

Designed for wineless controls and sevens
Openates in PANS and source in source amount

packet duices.

Low power, low cost, small packet, low through put, almost vous 905 services.

How Zigbee wonus?

Ston, Olusten tree on Mesh Network, noviens and end devices, active on sleep states of operation beacon and non-beacon modes of operation, different traffic-types

Li Traffic types:

- peulodic dota (sessons)
- intermittent data (stimulus didede nate)
- repetitive data (quantered time slot)

4) Traffic modes:

- Be acon mode (sent peniodically, low energy consumption, puecese timming, woordination and device can go to power save)
- Wou-beacou moole (no beacou seut, coondination (noutens have to stay awave, asymmetric power, heterogeneous vetwork).

- Coondina on (only one, initiates retwork,

stours info, all communicate with it, routing, bridge to other vetworks)

- novien (ZBR, optional, novies between noder, extends now coverage, manager local addumes)
- End Device (ZBE, Cow power, cheapent)

-> 802.15.4/Zig Bee Anchikehre

Ly 802,15.4 bonios

- -802.15.4 simple pachet dots puotocol for lightweight winds wellwords.
 - Channel access via Connien Seuse Muliple access with colision avoidance.
 - multi-level security
 - memage ac4 and optional beacons
 - Maximum battery life.

-> PHY frame shruchre

Packet fields: - Preamble (32 bits)

- Start of packet delimiter (8 bots)

- PHY neaden (8 bit)

- P5DU-> douba field (0-127 byte

L> 802, 15.4 HAC Design Onivers

- law cost - ease of implementation

- reliable data transer
- short rouge operation
- low power consumption

2 classes: FFD -> full function device

(tal4: to any device)

RFD -> reduced function device

(only tal4: to coordinate)

4 types of MAC frames:

- · data
- · beacon
- · acu
- . MAC command

is transmitted by the network coordinator to inform other devices about the existence and parameters of the network

is sent by the recipient of a Data Frame to confirm successful reception.

Divided who 2 pants:

- Inactive: all devices sleep (molidity itself)

- Active period divided into 16 slots (each has contention access period and contention fure period)

Beauties are used to stant seperframes;
sync with amociated arriver, amounce PAV.

In beauties enabled which y devices use slotted CSTAN/CA mechanism to contend for channels

Structure of superframe is controlled

by beacon order (30) and superframe order (50).

L, GTS concepts

A guaranteed time shot (673) allows or device to operate on the channel within a position of the superframe, only allocated by PAN coondinator, up to 7 675 at a time, based on reguments and analiability.

GTS can be deallocated and data frame transmitted in allocated GTS use only short adhering. Before GTS stants, now to be specified as either frammit on necesse, and each device must only request one transmit GTS and for one necesse GTS.

If it loses connection (sync), loses all GTS allocations

Ly Channel access mechanism (CSMAICA)

2 dypes:

- in won-beacon when only - unslotted CS4A/CA - in beacon enabled no -> slotted CSHA/CA

backoff periods weld

No be aligned with


superframe slot bornamics

PHY layer commences

all transmition on the


period.

La Association procedure





Lo Data transfer model

-> Device to coordinator



-> Condination to device





nou blacon - endeled.