
Topics for today

Mechanics of pointers, arrays, C-strings
Implementation of C function calls
Management of runtime stack, register use









The utility of pointers

"The fault, dear Brutus, is not in our stars But in ourselves, that we are underlings."

Julius Caesar (I, ii, 140-141)

Accessing data by address/location is ubiquitous and powerful!

You already know that pointers are useful

Sharing data instead of redundancy/copying

Construct linked structures (lists, trees, graphs)

Dynamic/runtime allocation

Now we learn how it works under the hood

Memory-mapped peripherals located at fixed address

Access to struct fields and array elements by relative location

ldr/str in assembly expressed in C as pointers — what do we gain?

Type system adds readability, some safety

Pointee and level of indirection now explicit in the type

Access contiguous data at offset/relative position using pointer arithmetic

Address arithmetic


Manipulate address numerically C pointer add/subtract is scaled by sizeof(pointee)

```
unsigned int *p = 0x20200000;
p = p + 1; // p is now 0x20200004
```

Fancy ARM addressing modes

```
ldr r0, [r1, #4]  // constant displacement
ldr r0, [r1, r2]  // variable displacement
ldr r0, [r1, r2, asl #3]  // scaled index
```

How do these relate to accessing data structures in C?



Q: How does type of pointee influence the generated assembly?

Arrays and pointers

Array is just a sequence of elements contiguous in memory
Sequence of memory locations can be treated an array and vice versa
No array "abstraction", no length tracking, no bounds checking

```
int n, arr[4], *p;
p = arr;
p = &arr[0]; // Same as prev line!
*p = 3;
p[0] = 3; // same as prev line!
n = *(arr + 1);
n = arr[1];  // same as prev line!
```

C-strings

No string "abstraction", just sequence of chars in memory, e.g. char array char * points to first char of sequence, terminated by null (zero byte)

64

6e

61

6c

65

```
char *s = "Leland";
char *t;

t = s;
s[0] = 'R';
t = s + 3;
t[1] = 'x';
```

```
loop:
  ldr r0, SET0
  str r1, [r0]
  mov r2, #DELAY
  wait1:
     subs r2, #1
     bne wait1
  ldr r0, CLR0
  str r1, [r0]
  mov r2, #DELAY
  wait2:
     subs r2, #1
     bne wait2
  b loop
```

Sure seems same code, would be nice to unify...

```
loop:
   ldr r0, SET0
   str r1, [r0]

   b delay

ldr r0, CLR0
```

str r1, [r0]

b delay

b loop

```
delay:
   mov r2, #DELAY
   wait:
      subs r2, #1
      bne wait

// but... where to go now?
```

```
loop:
    ldr r0, SET0
    str r1, [r0]
```

mov r14, pc b delay

ldr r0, CLR0
str r1, [r0]

mov r14, pc b delay

b loop

```
delay:
   mov r2, #DELAY
   wait:
       subs r2, #1
       bne wait
   mov pc, r14
```

We've just invented our own link register!

```
loop:
    ldr r0, SET0
    str r1, [r0]

mov r0, #DELAY
    mov r14, pc
    b delay

ldr r0, CLR0
```

str r1, [r0]

```
mov r0, #DELAY >> 2
mov r14, pc
b delay
```

```
b loop
```

```
delay:
wait:
subs r0, #1
bne wait
mov pc, r14
```

We've just invented our own parameter passing!

Anatomy of C function call

```
int factorial(int n)
  int result = 1;
  for (int i = n; i > 1; i--)
     result *= i;
                             Call and return
  return result;
                             Pass arguments
                             Local variables
                             Return value
                             Scratch/work space
```

Complication: nested function calls, recursion

Application binary interface

ABI specifies how code interoperates:

- Mechanism for call/return
- How parameters passed
- How return value communicated
- Use of registers (ownership/preservation)
- Stack management (up/down, alignment)

```
arm-none-eabi
ARM architecture
no hosting OS
embedded ABI
```

Mechanics of call/return

Caller puts up to 4 arguments in r0, r1, r2, r3 Call instruction is b1 (branch and link)

Callee puts return value in r0
Return instruction is bx (branch exchange)

```
add r0, r0, r1
bx lr // pc=lr
```

btw: 1r is alias for r14, pc is alias for r15

Caller and Callee

caller: function doing the calling

callee: function being called

main is <u>caller</u> of delta
delta is <u>callee</u> of main
delta is <u>caller</u> of abs

```
void main(void) {
    delta(10, 7);
}
int delta(int x, int y) {
    return abs(x-y);
}
int abs(int v) {
    return v < 0 ? -v : v;
}</pre>
```

Register Ownership

r0-r3 are callee-owned registers

- Callee can freely use/modify these registers
- Caller cedes to callee, has no expectation of register contents after call

r4-r13 are caller-owned registers

- Caller retains ownership, expects register contents to be same after call as it was before call
- Callee cannot use/modify these registers unless takes steps to preserve/restore values

Discuss...

- I. If callee needs scratch space for an intermediate result, which type of register should it choose?
- 2. What must a callee do when it wants to use a caller-owed register?
- 3. What is the advantage in having some registers callee-owned and others caller-owned? Wouldn't it be simpler if all treated the same?

The stack to the rescue!


Configure region in memory to store data for executing functions(s)

Stack frame per function, has local variables, scratch space, saved register values

- LIFO: push adds value on top of stack, pop removes lastmost value
- r13 (alias sp) points to lastmost value pushed
- stack grows down
 - newer values at lower addresses
 - push subtracts from sp
 - pop adds to sp
- push/pop aliases for load/store multiple with writeback

```
// start.s
mov sp, #0x8000000
bl main
```

```
void main(void)
   delta(10,7);
int delta(int x, y)
  return abs(x - y);
int abs(int v)
  return v < 0 : -v : v;
                           Diagram not to scale
```



Stack operations

```
// push to saved reg val on stack
// *--sp = r0
// decrement sp before store
// equivalent: str r0, [sp, #-4]!
push {r0}

// pop to restore reg val from stack
// r0 = *sp++
// increment sp after load
// equivalent: ldr r0, [sp], #4
pop {r0}
```

Gdb debugger

Debugger is incredibly useful!

Allows you to run your program in a monitored context Can set breakpoints, examine state, change values, reroute control, and more

Running bare metal on Pi, we have no such debugger (2)



But, gdb has simulation mode where it pretends to be an ARM processor, running on your laptop 🙌

Pretty good approximation (not perfect though, e.g. no peripherals)

Let's try it now!

Run under debugger and observe stack in action


```
$ arm-none-eabi-gdb program.elf
(gdb) target sim
(gdb) load
```

Read our guide to gdb simulation http://cs107e.github.io/guides/gdb/

sp in constant motion

Could access values on stack using **sp**-relative addressing, but

sp is constantly changing!




Add frame pointer

Dedicate **fp** register to be used as fixed anchor

Assign on entry to new function to point to top of stack frame

fp doesn't change, can access data at fixed offset relative to fp



APCS "full frame"

APCS = ARM Procedure Call Standard

Conventions for frame pointer and frame layout

Enable reliable stack introspection

CFLAGS to enable: -mapcs-frame

r11 used as fp

Adds a prolog/epilog to each function that sets up/tears down the standard frame and manages **fp**

Trace APCS full frame

Prolog

push fp, sp*, lr, pc
set fp to first word of stack frame

Body

fp stays anchored access data on stack fp-relative offsets won't vary even if sp changing

Epilog

pop fp, sp*, lr, pc*

I am fudging a bit about use of push and pop
 The sp register cannot be directly pushed/popped, instead moved through r12
 pc cannot be popped at end, is manually removed from stack

caller's frame

sp 🔫

ξβ

рс

lr

sp


fp

locals/ scratch/call other fns

sp →

Frame pointers form linked chain

Can start at currently executing call (abs) and back up to caller (delta), from there to its caller (main), who ends the chain



```
// start.s

// add init fp = NULL
// to terminate end of chain

mov sp, #0x8000000
mov fp, #0
bl main
```

APCS Pros/Cons

- + Anchored fp, offsets are constant
- + Standard frame layout enables runtime introspection
- + Backtrace for debugging
- + Unwind stack on exception

- Expensive, every function call affected
- Extra ~5 instructions to setup/tear down frame for each call
- 4 registers push/pop => extra 16 bytes per frame
- fp monopolizes use of one of our precious registers