**PWM** 

**Aurel GONTEAN** 

## Goal

- Configure the PWM module
- Program the PWM for a 10 kHz signal, 40% Duty Cycle
  - The crystal clock is 4 MHz and the PLL is enabled (HSPLL)
- Display the result using the Logic Analyzer