Aufgaben:

- **I. Basic questions** (30 minutes, 30 points)
 - 1. The Embedded Systems Model. Give an example of layers used by you.
 - 2. Define compiler, linker, interpreter
 - 3. Byte ordering. Use of bridges
- II. Advanced topics (15 minutes, 15 points)
 - 4. Explain the keyboard scan codes principle
- III. For the following code (45 minutes, 45 points). Some lines are already commented. After successful compilation, one observes that large memory areas (Data SRAM + Program Flash) are used. The code is used to debug an ADC conversion followed by an LCD write. Instead of LCD, the UART console is used. The ADC is 10 bit, referenced at 5 V.

```
☐ T Compiler Toolcha
                                                                  X20 (v2.00) [C:\Program Files (x06)\Microchip\x
      Instead of LCD, the UART console is used. The
                                                                  T Production Image: Optimization: +space
      ADC is 10 bit, referenced at 5 V.
                                                               Memory
    a. Comment the relevant instructions, the
                                                               □ □ Data 1.536 (0x600) bytes
                                                                             10%
        overall source code (10 points).
                                                                   Data Used: 158 (0x9E) Free: 1.378 (0x562)
    b. Explain why the program memory is 29%
                                                               Program 32.768 (0x8000) bytes
        used and explain how this number can be
                                                                            29%
                                                                   Program Used: 9.648 (0x25B0) Free: 23.12
        reduced (10 points).
                                                                Column Debug Tool
    c. Find ways to also reduce the data RAM
                                                                  Simulator

    Click to: Cimulated Periphe

        areas (10 points).
                                                             Debug Resources
                                                                 Program BP Used: 1 Free: 999
                                                                 Data BP Used: 1 Free: 999
#include "Definitions.h"
                                                                 Data Capture BP: No Support
#include <stdlib.h>
                                                                Unlimited BP (S/W): Simulator
#include <stdio.h>
                                                             <
                                                                                                         3
```

63

7

Convert_float_String - Dashboard ×

--- 🎥 Project Type: Application - Configuration: default

Checksum: Blank, no code loaded

12_Convert_float_String

PIC18F4520

Device

```
#include <stdarg.h>
void main(void) {
    unsigned int ADC Result = 100; //100 = 20.4 degrees Celsius
    float Temp;
    int Temp digits, Temp fractional;
    char buf2[3];
    char buf[2];
    Temp = (float)(((ADC_Result*16)/25)*8)/25;
    init uart();
                                // needed for the UART1 Output
                                // UART1 must be enabled in MPLAB X
                                // -> Simulator -> UART IO options
    Temp digits = (int)Temp;
    Temp fractional = (int)((Temp-(float)Temp digits)*10.0);
    itoa(buf,Temp_digits,10);
    itoa(buf2, Temp fractional, 10);
    printf("Temp = %2d",Temp digits);
    printf("%c",'.');
   printf("%1d\n",Temp fractional);
    return;
char *itoa(char *buf, int val, int base) {
      char *cp = buf;
```

```
if(val < 0) {
             *buf++ = '-';
             val = -val;
      utoa(buf, val, base);
      return cp;
}
char *utoa(char * buf, unsigned val, int base) {
      unsigned
                  v;
      char
                   c;
      v = val;
      do {
             v /= base;
             buf++:
      } while(v != 0);
      *buf-- = 0;
      do {
             c = val % base;
             val /= base;
             if(c >= 10)
                   c += 'A'-'0'-10;
             c += '0';
             *buf-- = c;
      } while(val != 0);
      return ++buf;
}
void putch(unsigned char data) {
                                    // needed for printf
    while( ! PIR1bits.TXIF)
                                     // wait until the transmitter is ready
       continue;
    TXREG = data;
                                     // send one character
}
void init uart(void) {
                                     // needed for printf
    TXSTAbits.TXEN = 1;
                                     // enable transmitter
    RCSTAbits.SPEN = 1;
                                     // enable serial port
The Definitions.h is as follows. You do not need to comment it.
#include <xc.h>
// PIC18F4520 Configuration
// CONFIG1H
#pragma config OSC = XT
                           // Oscillator Selection bits (XT oscillator)
#pragma config FCMEN = OFF
                           // (Fail-Safe Clock Monitor disabled)
                           // (Oscillator Switchover mode disabled)
#pragma config IESO = OFF
// CONFIG2L
#pragma config PWRT = OFF
                            // Power-up Timer Enable bit (PWRT disabled)
#pragma config BOREN = OFF
                            // (Brown-out Reset disabled in hardware and software)
                            // Brown Out Reset Voltage bits (Minimum setting)
#pragma config BORV = 3
// CONFIG2H
#pragma config WDT = OFF
                            // (WDT disabled (control is placed on the SWDTEN bit))
#pragma config WDTPS = 32768
                            // Watchdog Timer Postscale Select bits (1:32768)
// CONFIG3H
#pragma config PBADEN = OFF
                            // (PORTB<4:0> pins are configured as digital I/O on Reset)
#pragma config LPT1OSC = OFF // (Timer1 configured for higher power operation)
```

```
#pragma config MCLRE = ON
                               // (MCLR pin enabled; RE3 input pin disabled)
// CONFIG4L
#pragma config STVREN = ON
                               // (Stack full/underflow will cause Reset)
#pragma config LVP = ON
                               // (Single-Supply ICSP enabled)
#pragma config XINST = OFF
                               // (Instruction set extension and Indexed Addressing mode
                               // disabled (Legacy mode))
// CONFIG5L
#pragma config CP0 = OFF
                               // (Block 0 (000800-001FFFh) not code-protected)
#pragma config CP1 = OFF
                               // (Block 1 (002000-003FFFh) not code-protected)
                               // (Block 2 (004000-005FFFh) not code-protected)
#pragma config CP2 = OFF
#pragma config CP3 = OFF
                               // (Block 3 (006000-007FFFh) not code-protected)
// CONFIG5H
#pragma config CPB = OFF
                               // (Boot block (000000-0007FFh) not code-protected)
#pragma config CPD = OFF
                               // (Data EEPROM not code-protected)
// CONFIG6L
#pragma config WRT0 = OFF
                               // (Block 0 (000800-001FFFh) not write-protected)
#pragma config WRT1 = OFF
                               // (Block 1 (002000-003FFFh) not write-protected)
#pragma config WRT2 = OFF
                               // (Block 2 (004000-005FFFh) not write-protected)
#pragma config WRT3 = OFF
                               // (Block 3 (006000-007FFFh) not write-protected)
// CONFIG6H
#pragma config WRTC = OFF
                               // (Configuration registers (300000-3000FFh) not write-
protected)
#pragma config WRTB = OFF
                               // (Boot block (000000-0007FFh) not write-protected)
#pragma config WRTD = OFF
                                // (Data EEPROM not write-protected)
// CONFIG7L
#pragma config EBTR0 = OFF
                               // Block 0 not protected
                               // Block 1 not protected
#pragma config EBTR1 = OFF
#pragma config EBTR2 = OFF
                              // Block 2 not protected
#pragma config EBTR3 = OFF
                              // Block 3 not protected
// CONFIG7H
#pragma config EBTRB = OFF
                               // (Boot block not protected
// Prototypes AG
char *itoa(char *buf, int val, int base);
char *utoa(char *buf, unsigned val, int base);
void putch(unsigned char data);
void init uart(void);
//Defines
#define XTAL FREQ 4000000
```