



# Install a VMware Virtual Machine

(You can search online for the installation steps.)


Run the virtual machine as an administrator and create a new virtual machine.






Next




Next












For this step, you can select a higher specification if your computer has good hardware configuration. I set it to 2\*2.





Similarly, for this step, you can allocate more RAM if your computer has high configuration. Here I choose about 16GB.









## New Virtual Machine Wizard

X

### Ready to Create Virtual Machine

Click Finish to create the virtual machine. Then you can install Ubuntu 64-bit.


The virtual machine will be created with the following settings:

Name:	Ubuntu 64-bit
Location:	D:\Documents\Virtual Machines\Ubuntu 64-bit
Version:	Workstation 17.5.x
Operating System:	Ubuntu 64-bit
Hard Disk:	120 GB
Memory:	18820 MB
Network Adapter:	NAT
Other Devices:	4 CPU cores, CD/DVD, USB Controller, Sound Card

[Customize Hardware...](#)


Finish

Select the virtual machine we just created and click Edit





Select the downloaded ISO image file.

### Virtual Machine Settings




### Select the USB 3.1 port








Power on the virtual machine




Skip the installation for now. Due to the resolution issue, the installation button is not clickable. We will install the system after adjusting the resolution once we enter it.






After entering the system, right-click to adjust the resolution.








Double-click the installation program on the desktop to install the Ubuntu system.











Set up your personal information and login password.





Remember to press **Enter** when the system restarts; otherwise, it will stay in the waiting state indefinitely.