Introduction to Communication Protocols

Radhika Ghosal and Tushar Kataria

So, what are communication protocols?

- Ever used:
  - A USB drive?
  - An Ethernet cable?
  - An SD Card?
- All of these use some communication protocol or the other!

So, what are communication protocols?

- Whenever you need to talk to a piece of hardware, you'll need to use a communication protocol both your devices understand.
- For today, we'll be restricting ourselves to simple protocols used in embedded systems, for talking to devices like LCD screens and sensors.

The Language of Communication

1. Serial Communication
2. Parallel Communication
3. Bit Rate vs Baud Rate vs Throughput
4. Clock Skew
5. Serial vs Parallel
6. Simplex Communication
7. Half Duplex Communication
8. Full Duplex Communication

Let’s play a game!

SPI Protocol

- What we just demonstrated, is the SPI (Serial Peripheral Interface) protocol.
- Summary:
  - SPI is a full-duplex synchronous serial data transfer protocol.
  - Data transfer takes place in between Master and Slave devices.
  - Each Master/Slave device has an internal 8 bit shift register, which is connected to other devices so as to form a circular/ring buffer.
  - At each clock pulse, data gets right shifted in the circular/ring buffer.
  - After 8 clock pulses, data is completely exchanged in between devices.
  - SPI bus consists of four wires/signals – MOSI, MISO, SCK and SS'.
  - When we connect more than one Slave devices, then we choose them using the SS' signal.
  - CPOL and CPHA must be set so that Master and Slave devices sync properly.
  - AVR ISP uses SPI to program the microcontroller.

4 modes of SPI

Table 59. CPOL and CPHA Functionality

	Leading Edge	Trailing Edge	SPI Mode
CPOL = 0, CPHA = 0	Sample (Rising)	Setup (Falling)	0
CPOL = 0, CPHA = 1	Setup (Rising)	Sample (Falling)	1
CPOL = 1, CPHA = 0	Sample (Falling)	Setup (Rising)	2
CPOL = 1, CPHA = 1	Setup (Falling)	Sample (Rising)	3

Source-Atmega32 Datasheet

Talk is cheap, show me the code.

SPI Protocol




POWER JACK
USB JACK
RESET Button
7-12V Depending on current drawn
GND
VIN
2.1mm
Cut to disable the auto-reset
Absolute max per pin 40mA reccomended 20mA
Absolute max 200mA for entire package
R3 Only
Not Connected
IOREF
RESET
3V3
5V
GND
GND
VIN
PCINT14
1 PC6
ADC0 PCINT8 14 A0 23 PC0
ADC1 PCINT9 15 A1 24 PC1
ADC2 PCINT10 16 A2 25 PC2
ADC3 PCINT11 17 A3 26 PC3
SDA ADC4 PCINT12 18 A4 27 PC4
SCL ADC5 PCINT13 19 A5 28 PC5
28 PC5 19 A5 PCINT13 ADC5 SCL
27 PC4 18 A4 PCINT12 ADC4 SDA
21 AREF AREF
19 PB5 13 PCINT5 SCK
18 PB4 12 PCINT4 MISO
17 PB3 11 OC2A PCINT3 PWM MOSI
16 PB2 10 OC1B PCINT2 PWM SS
15 PB1 9 OC1A PCINT1 PWM
14 PB0 8 CLKO PCINT0 ICP1
13 PD7 7 AIN1 PCINT23
12 PD6 6 AIN0 PCINT22 PWM OC0A
11 PD5 5 T1 PCINT21 PWM
6 PD4 4 T0 PCINT20 XCK
5 PD3 3 INT1 PCINT19 PWM OC2B
4 PD2 2 INT0 PCINT18
3 PD1 1 TXD PCINT17 TX
2 PD0 0 RXD PCINT16 RX
R3 Only
Connected to the ATMega and used for USB program and communicating with it
ARDUINO UNO
GND
Power
Control
Physical Pin
Port Pin
Pin Function
Digital Pin
Analog Related Pin
PWM Pin
Serial Pin
IDE
Source Total 150mA
www.pighixxx.com
18 FEB 2013
ver 2 rev 2 - 05.03.2013

SPI Protocol

SPCR = 0x50:

bit 7	bit 6	bit 5	bit 4	bit 3	bit 2	bit 1	bit 0
SPIE	**SPE**	DORD	**MSTR**	CPOL	CPHA	SPR1	SPR0
0	**1**	0	**1**	0	0	0	0

- Bit 7: SPIE - SPI Interrupt Enable - We don’t need no interrupts, so **0**
- Bit 6: SPE - SPI Enable - Yes, so **1**
- Bit 5: DORD - Data Order - **0** when MSB sent & received first
- Bit 4: MSTR - Master/Slave Select - Master, so **1**
- Bit 3: CPOL - Clock Polarity - **0**, clock starts LOW
- Bit 2: CPHA - Clock Phase - **0**, read on posedge
- Bit 1, Bit 0: SPR1, SPR0 - SPI Clock Rate Select - **00**, osc/4 = 16MHz/4 = 4MHz

Yes, we really like games.

I^2C Protocol

- Two-wire protocol, uses only 2 lines, SDA (Serial Data Line) and SCL (Serial Clock Line)
- Synchronous, half-duplex protocol, adheres to clock signal
- Best of both worlds: fewer wires, maintains speed

I²C Protocol



I^2C Protocol



Arduino Version

```
// Master writer
#include <Wire.h>

void setup() {
  Wire.begin(); // join i2c bus (address optional for master)
}

byte x = 0;

void loop() {
  Wire.beginTransmission(8); // transmit to device #8
  Wire.write("x is ");        // sends five bytes
  Wire.write(x);              // sends one byte
  Wire.endTransmission();    // stop transmitting

  x++;
  delay(500);
}
```

Arduino Version

```
#include <Wire.h>

void setup() {
  Wire.begin(8);                // join i2c bus with address #8
  Wire.onReceive(receiveEvent); // register event
  Serial.begin(9600);           // start serial for output
}

void loop() {
  delay(100);
}
void receiveEvent(int howMany) {
  while (1 < Wire.available()) { // loop through all but the last
    char c = Wire.read(); // receive byte as a character
    Serial.print(c);         // print the character
  }
  int x = Wire.read();    // receive byte as an integer
  Serial.println(x);         // print the integer
}
```

Today’s Task

- Write your name onto the given LCD display in AVR C
  - No libraries allowed! (except basic AVR libraries)
  - Hint: Use the SPI Protocol
  - Tip: Check the datasheet

  https://www.sparkfun.com/datasheets/LCD/HD44780.pdf