









production programming when chip is blank After programming, the firmware can pull the PS_HOLD low to shutdown the LDO

Battery voltage monitoring circuit SSM6L61NU N-Mosfet GND - BM_EN P-Mosfet ≶100k VBATT > **-**VVV-R13 100k GND - Vout = (Vin*R15)/(R14+R15) - BM = 1.8V @ VBATT = 4.2V -ВМ C11 R15
75K GND GND





