ContiConnect (Fleet Analytics Portal) - PW Test Case #14424

PW Test Case # 14305 (New): Basic Functional Test for BAT

PW Epic # 14407 (New): BAT R11/17 Business Tests

Show / No-Show vehicle in Portal - Admin Check

11/10/2017 05:09 PM - Alexandros Efthymiadis

Status:	Passed	**% Done:**	0%
Priority:	Normal	**Spent time:**	0.00 hour
Assignee:			
Test_ID:		**Business_Process:**	
Module:		**Business_Area:**	

Description

Prerequisite:
Steps:

1. Log into System using the user: cku_user1 pw: cku_user1
2. Go to "Administration" part.
3. Open the Vehicles page
4. Click Create
5. Click in the Fleet Name text box part.
6. Search for the Fleet ID : "07301794"
7. Select the Account with the Depot ID 0003244771
8. Set Data:
   Status = Active
   Vehicle type = Bus
   Axle configuration = S2-S2
   Internal Customer Vehicle ID = NOSHOW-BUS
   Pressure Unit = Bar
   Temperature Unit = Fahrenheit
   Make = "any"
   Billing for vehicle = No show & No Pay
   Target Pressure (Bird View)= 2 Bar
   LPN: NO-SHOW-BUS-0X (Change last Number!)
9. Click Save
10. Release the pressure from the wheels so there should in normal case be issue.

Expect
Administration:
Search for Vehicle in Administration Vehicle Search, Search for Depot ID "3244771": User should now see the Vehicle in the List.
Open the Vehicle and check that every attribute fits according to the values used for creation.

Connti Connect
Go to Conti Connect - My Fleet. Search for your vehicle. Vehicle should not appear!

Related issues:

Copied to BAT4 - PW Test Case #15435: Show / No-Show vehicle in Portal - Adm...	**New**

History

#1 - 11/14/2017 12:40 PM - Vigneshwar Kalyanasundaram

- Status changed from New to Accepted

#2 - 11/14/2017 01:59 PM - Vigneshwar Kalyanasundaram

- Status changed from Accepted to Ready for Test

#3 - 11/14/2017 02:00 PM - Vigneshwar Kalyanasundaram

- Status changed from Ready for Test to Passed

#4 - 01/05/2018 07:37 AM - Vigneshwar Kalyanasundaram

- Copied to PW Test Case #15435: Show / No-Show vehicle in Portal - Admin Check added