


# 02 - Electronics Installation.

Written By: Dan Rock



### Step 1 — To Begin.



 Position the Motion System so that the back is facing you.


#### Step 2 — Rear Panel.





Remove the Rear Panel.

#### Step 3 — Position.



 Rotate the frame so that the front is resting on the table and the top is facing you.

#### **Step 4** — **Gather Parts.**



- 8 x M4 Nylon Washers.
- 8 x M4 8mm Button Head Screws.
- 8 x M4 6mm Button Head Screws.
- 8 x 12mm Standoffs
- 8 x M4 Washers.

### Step 5 — Washer.



 To each 8mm M4 screw fit a washer.

# Step 6 — Fit.








- Fit the Standoffs to the Electronics Panel as shown.
- Do not fully tighten the screws.

#### Step 7 — Duet.





- Unpack the Duet2 and Duex5.
- Fit the supplied ribbon cable to the boards.

### Step 8 — Duet.





- Place the Duet WiFi/ Ethernet and DueX on the standoffs.
- Please note the position of the boards in relation to the stepper motors.

#### Step 9 — Duet.





- Place the Nylon washers over the remaining button head screws.
- Apply thread lock to the button head screws.

### Step 10 — Tighten.







- Fasten the board to the standoffs.
- Fully tighten all the screws.

#### Step 11 — PSU.





Unbox and unpack the PSU.

↑ Check the input voltage selector on the side of the PSU.


### Step 12 — Duet.





Apply the Duet Sticker to the PSU.

### Step 13 — Parts.




- 4 x M4 12mm Button Head Screws.
- 4 x M4 Washers.
- 4 x M4 Nylon spacers.


## Step 14 — Washers.



 Place the M4 washers over the button head screws.

#### Step 15 — PSU.








- Place the nylon spacers over the holes.
- Use a poker to line the hole of the spacer to the hole in the panel.
- Place the power supply on the spacers.
- Make sure to line up the holes on the power supply with the holes in the spacer/ panel.
- Do this gently to avoid moving the spacers out of place.

#### Step 16 — PSU.









Screw in the button head screws.

#### **Step 17 — Gather Optional Parts.**



- 2 x M4 16mm Button Head Screws.
- 2 x M4 Washers.
- 2 x M4 Hex Half Nuts.
- 1 x SSR.


#### Step 18 — SSR.



 Place the washers on the M4 button head screws.

### Step 19 — Check Orientation.





Position the SSR as shown.

### Step 20 — SSR.








Fix the SSR in place.

# Step 21 — Orientation.





Check the orientation of the SSR and other electronics.