


# 02a - Bowden Titan Installation.

Written By: Dan Rock



#### Step 1 — Titans.






- 2 x Standard Titans with Motors and Bowden adaptesr.
- 2 x Mirroed Titans with Motors and Bowden adapters.

## Step 2 — Panel.








Pop-out the four holes in the Electronics panel for the extruder motors.

## Step 3 — Titan.




- Take note of the Bowden Titan

  Assembly Guide.
- The back of the gear needs to be 3mm from the motor as shown in the image.

#### Step 4 — Titan.





- Fit an M3 10mm Socket Cap Screw (in the Motion System Fixings Kit and not supplied with the Titans) through the Titan Housing.
- Poistion as shown on the Electronics Panel.
- ↑ T0 & T1 use Standard Titans.
- ↑ T2 & T3 use Mirrored Titans.

#### Step 5 — Motor.








- Affix a motor as shown.
- (i) You may wish to use the small Alan keys to align the holes when fastening the initial screws.

## Step 6 — Gather.





Titan Parts.


## Step 7 — Nut.





Screw the nut to the thumb screw.

## Step 8 — Assembly.







Build the parts into the Titan.

## Step 9 — Assemble.







Build Up.


#### Step 10 — Screw.





- Secure the titan using the three 35mm screws from the Motion System fixings kit and a shorter screw for the Titan fixing kit.
- Refer to the <u>Titan Assembly Guide</u> when installing the extruders.

#### Step 11 — Check.




Check the gear turns freely.

## Step 12 — Titans.








• Fit the remaining Titans to the Electronics Panel.

## Step 13



Done!