


06 - HT Heated Bed.

Written By: Greg Holloway




PARTS:

- 300 x 200 HT Bed (1)
- M3 12mm Button Head Screw (4)
- M3 Washer (4)
- Bed Fixings Kit (1)

Step 1 — Parts.





Gather the required Pats.

You may choose to fit the bed at at a later stage as the bed must be removed again during the Wiring Installation.

Step 2 — Screws.








- Place a washer onto each of the four M3 12mm Button Head Screws.
- Apply Thread Lock to one of the screws.
- Pass one of the screws into the corner of the bed plate from the underside.

Step 3 — Standoff.








- Screw on a standoff.
- Do not fully tighten the screws.
- Repeat for each corner, remembering to apply Thread Lock as in the previous step.
- Place the bed on top of the four standoffs.

Step 4 — Washer.







Slide a washer onto a standoff.

Step 5 — Affix.







- Into each corner fit a Screw and washer.
- Tighten down the bed.

not over tighten the screws, the bed must be able to expand during heating.