ESI
Xjam

BITWIG

Overview

Encoders:
Bank A: Encoders control the first six Remote Controls of the currently selected device
Bank B/C: Encoders are freely assignable

CTRL Bank:
Toggles Encoder Banks between A (green), B (yellow) and C (red)

Pad Bank:
Toggles Pad Banks between A (green), B (yellow) and C (red)

Pads:
Bank A: Pads send MIDI note data, starting from C1.
Bank B/C: Same note values as Bank A, just different MIDI channels (2 and 3)

*Please reset the Xjam to factory defaults first. Custom configurations may result in non-working assignments.