
## Drum Pad Mode


Pads are used as Note Input for currently armed Tracks.



PADS 1-8: SET NOTE REPEAT RATE (IF ENABLED)

## Step Sequencer

The Step Sequencer lets you edit 16 steps of note data at a time for a single selected drum pad. It will edit the currently selected note clip inside Bitwig Studio.



Pads represents the 16 steps of the current time window

SET SELECTED PAD