
Drum Pad Mode



Step Sequencer

The Step Sequencer will let you edit 16 steps of note data at a time for a single selected drum pad. It will edit the currently selected note clip inside Bitwig Studio.

