
FaderPort 8 / 16

This Controller Extension uses the native Studio One mode of the FaderPort 8/16.

By default it is configured in this mode. If it is not, see <u>Chapter 2.1 in the FaderPort Owner's Manual</u> for how to change it.







Automation Controls

LATCH/TOUCH/WRITE: Set mode and Enable Automation Write

OFF: Disable Automation Write



TRACK: Faders control channel level

EDIT PLUG-INS: Faders control device parameters

SENDS: Faders control send level

Pan: Faders control channel pan


Sends

Track

Timecode

Edit Plugins

Pan



Session Navigator

These buttons alter the functions of the pushbutton encoder and the \leftarrow and \rightarrow buttons

CHANNEL: Encoder and navigation buttons control channel scrolling

Zoom: Encoder controls horizontal zooming. Navigation buttons selects items left/right. Pressing the Encoder toggles between zoomto-fit and zoom-to-selected

Scroll: Encoder and navigation buttons move the Play Start Position. Press the encoder to jump there. BANK: Encoder and navigation buttons scroll through channels in banks of sixteen

Master: Assign the rightmost channel to the Master track

СLICK: Toggle metronome

MARKER: Hold to launch Cue Markers using the Channel Select buttons.