
FaderPort 8 / 16

This Controller Extension uses the native Studio One mode of the FaderPort 8/16.

By default it is configured in this mode. If it is not, see <u>Chapter 2.1 in the FaderPort Owner's Manual</u> for how to change it.









LATCH/TOUCH/WRITE: Set mode and Enable **Automation Write**

OFF: Disable Automation Write





Session Navigator

These buttons alter the functions of the pushbutton encoder and the \leftarrow and \rightarrow buttons

CHANNEL: Encoder and navigation buttons control channel scrolling

ZOOM: Encoder controls horizontal zooming. Navigation buttons control vertical zooming.

Scroll: Encoder and navigation buttons control timeline scrolling

BANK: Encoder and navigation buttons scroll through channels in banks of sixteen

MASTER: Assign the rightmost channel to the Master track

СLICK: Toggle metronome

Fader Modes

Marker: Encoder and navigation buttons scroll through markers. Push Encoder to drop a marker.