# LinnStrument

When connected, Bitwig Studio will automatically detect and setup your LinnStrument for MPE operation. This will allow you to play, record, and edit notes in a polyphonic fashion, which each note having continuous control over the Pitch, Timbre and Pressure expressions within Bitwig Studio.

SETTINGS

By default, Bitwig Studio will send MIDI messages to initialize the Linnstrument in MPE mode with a known Pitch Bend Range. If you for some reason want to be in control of the settings yourself set *Send initialization messages* to *No*.

The Pitch Bend Range settings is both use to initialize the Linnstrument and to translate incoming MPE notes into absolute pitch values. This must match the setting on the Linnstrument otherwise per-note pitch expressions won't play and be recorded correctly.