






**DEHNgard modular DG M TNC 275 (FM)**

**DE** Einbauranleitung  
**GB** Installation instructions  
**IT** Istruzioni di montaggio  
**FR** Instructions de montage  
**NL** Montagehandleiding  
**ES** Instrucciones de montaje  
**PT** Instruções de montagem  
**DK** Monteringsvejledning  
**SE** Monteringsanvisning  
**FI** Asennusohje  
**GR** Οδηγίες συναρμολόγησης  
**PL** Instrukcja montażu  
**CZ** Montážní návod  
**TR** Kurulum Talimatları  
**RU** Инструкция по монтажу  
**CN** 安装说明  
**HU** Szerelési útmutató  
**JP** 設置説明書

**DG M TNS 275 (FM) DG M TT 275 (FM)**



DG M TNC 275 (FM)	DG M TNS 275 (FM)	DG M TT 275 (FM)
U <sub>N</sub> /Tol.: ±10%	230 / 400 V;	255 V
U <sub>C</sub>	275 V~	
f <sub>N</sub>	50 / 60 Hz	
max.	125 A gG	---
I <sub>SCCR</sub>	50 kAmps	---
I <sub>H</sub>	---	100 Arms
I <sub>max</sub>	40 kA	
g°	-40°C ... +80°C	
φ	5% ... 95%	
I <sub>PE</sub>	< 0,15 mA	< 5 µA
IP 1)	20	
L x W x H	90 mm x 54 mm x 73 mm	90 mm x 72 mm x 73 mm
min. □ L, N, PE(N),	1.5 mm <sup>2</sup>	
max. □ L, N, PE(N),	25 mm <sup>2</sup>	35 mm <sup>2</sup>
□	16 mm <sup>2</sup> Cu	≥15.5 mm

**TN-C DG M TNC 275 (FM)****TN (-C) -S DG M TNS 275 (FM)****TT DG M TT 275 (FM)****DEHNgard modular DG M TNC 275 (FM), DG M TNS 275 (FM), DG M TT 275 (FM)**

	F1 ≤ 125 A gG
	F1 > 125 A gG F2 ≤ 125 A gG

**DEHNgard modular DG M TNC 275 (FM), DG M TNS 275 (FM), DG M TT 275 (FM)**

	S <sub>2</sub> / mm <sup>2</sup>	S <sub>3</sub> / mm <sup>2</sup>	S <sub>4</sub> / mm <sup>2</sup>	
25	4	6	6	...
35	4	6	6	...
40	4	6	6	...
50	6	6	6	...
63	10	10	10	...
80	10	10	10	...
100	16	16	16	...
125	16	16	16	...
> 125	16	16	16	125

**DEHNgard modular DG M TNC 275 FM, DG M TNS 275 FM, DG M TT 275 FM**

U <sub>N</sub> / I <sub>N</sub>	AC: 250 V / 0.5 A
DC:	250 V / 0.1 A 125 V / 0.2 A 75 V / 0.5 A
	max. 1.5 mm <sup>2</sup>

