### FROM LAST TIME...

### **Analysis of Feedback Systems**

- · Feedback controller structure
- Nominal sensitivity functions
- · Stability of nominal feedback system
- Root locus



$$T(s) = \frac{G(s)C(s)}{1 + G(s)C(s)}$$

$$S(s) = \frac{1}{1 + G(s)C(s)}$$

$$S_i(s) = \frac{G(s)}{1 + G(s)C(s)}$$

$$S_u(s) = \frac{C(s)}{1 + G(s)C(s)}$$

James A. Mynderse

MRE 5323 – More Stability

Controller

 $1 + KC_a(s)G(s) = 0$ 

# $D_{I}(s)$ $D_{O}(s)$ $\downarrow \qquad \qquad \downarrow \qquad \qquad \qquad \downarrow \qquad \qquad \qquad \downarrow \qquad \qquad \qquad \downarrow \qquad \qquad \qquad \qquad \qquad \downarrow \qquad \qquad \qquad \qquad \qquad \downarrow \qquad \qquad \qquad \qquad \downarrow \qquad \qquad \qquad \qquad \qquad \downarrow \qquad \qquad \qquad \qquad \qquad \downarrow \qquad \qquad \qquad \qquad \qquad \qquad \downarrow \qquad \qquad \qquad \qquad \qquad \downarrow \qquad \qquad \qquad \qquad \qquad$

1

### **MORE STABILITY**

### **Topics**

- · Nyquist test for stability
- Relative stability
- Robust stability

### At the end of this section, students should be able to:

- Apply the Nyquist stability theorem.
- Quantify relative stability using gain and phase margins.
- · Apply the robust stability theorem.

James A. Mynderse

MRE 5323 - More Stability

,


### **MORE STABILITY**

# NYQUIST STABILITY

James A. Mynderse

MRE 5323 - More Stability

3



Recall the open-loop transfer function

$$L(s) = C(s)G(s) = \frac{N_L(s)}{D_L(s)}$$

The closed-loop characteristic equation is given by


$$F(s) = 1 + L(s) = 0$$

James A. Mynderse

### **STABILITY IN FREQUENCY DOMAIN**

We want to know where the zeros of F(s) are.

- Use a MAPPING between the s-plane (where the roots are) and the F(s)-plane.
- Since we want stability, isolate the RHP with a geometrically simple directed contour  $\Gamma_{\!\scriptscriptstyle S}.$




James A. Mynderse

MRE 5323 - More Stability

## **EFFECT OF ZEROS OF** F(s)


1. Zero outside contour F(s) = s + a, a > 0



James A. Mynderse

## **EFFECT OF ZEROS OF** F(s)

1. Zero inside contour F(s) = s - a,



James A. Mynderse

MRE 5323 - More Stability

# PRINCIPLE OF THE ARGUMENT (CAUCHY)

Let F(s) be a single-valued function that has a finite number of poles in the s-plane. Choose a closed path  $\Gamma_s$  in the s-plane such that it avoids any poles or zeros of F(s). Then the corresponding contour  $\Gamma_F$  mapped in the F(s)-plane will encircle the origin  $N_{CW}$  times in a clockwise direction.


$$N_{CW} = N_Z - N_P$$

 $N_Z = \#$  of zeros of F(s) encircled by  $\Gamma_S$  $N_P = \#$  of poles of F(s) encircled by  $\Gamma_S$ 

James A. Mynderse

### **APPLICATION TO STABILITY**

#### Recall:



$$F(s) = 1 + L(s) = 0 = 1 + \frac{N_L(s)}{D_L(s)} = \frac{D_L(s) + N_L(s)}{D_L(s)}$$

**zeros of** F(s): roots of characteristic equation (closed-loop poles)

poles of F(s): open-loop poles


James A. Mynderse

MRE 5323 - More Stability

9

## WE STILL NEED TO RELATE F(s) TO L(s)

$$F(s) = 1 + L(s)$$
  $L(s) = F(s) - 1$ 



James A. Mynderse

### **NYQUIST STABILITY CRITERION**

$$N_{CW} = N_Z - N_P$$

$$\begin{split} N_{CW} &= \text{\# of CW encirclements of } -1 \text{ by } \Gamma_L \\ N_Z &= \text{\# of closed-loop poles encircled by } \Gamma_S \\ N_P &= \text{\# of open-loop poles encircled by } \Gamma_S \end{split}$$

A feedback system having  $N_P$  open-loop poles in the RHP is stable if and only if the Nyquist plot of L(s) encircles -1  $N_P$  times in a counterclockwise direction.

James A. Mynderse

MRE 5323 - More Stability

11

# STEPS IN SKETCHING A NYQUIST PLOT


- 1. Plot poles of L(s) in the s-plane.
- 2. Draw the Nyquist contour  $\Gamma_s$ , indenting to the right of any poles of L(s) on the imaginary axis.
- 3. Map contour  $\Gamma_s$  to L(s)-plane.
- 4. Apply encirclement condition.

James A. Mynderse

MRE 5323 - More Stability

### **NYQUIST EXAMPLE**

$$L(s) = \frac{2K}{(2s+1)(s+1)(\frac{s}{2}+1)}$$



James A. Mynderse

MRE 5323 - More Stability

## **NYQUIST PLOT**

**Curve 1:** 
$$s = j\omega$$
  $L(j\omega) = \frac{1}{2}$ 

$$L(j\omega) = \frac{2}{(1+j2\omega)(1+j\omega)\left(1+j\frac{\omega}{2}\right)}$$

$$|L(j\omega)| = \frac{2}{\sqrt{1 + (2\omega)^2}\sqrt{1 + \omega^2}\sqrt{1 + \left(\frac{\omega}{2}\right)^2}}$$

$$\angle L(j\omega) = -\tan^{-1}(2\omega) - \tan^{-1}\omega - \tan^{-1}\left(\frac{\omega}{2}\right)$$

ω	$ L(j\omega) $	$\angle L(j\omega)$
0		
1		
2		
$\omega \to \infty$		

Curve 3:  $s = -j\omega$ : Complex conjugate of Curve 1

James A. Mynderse

MRE 5323 - More Stability

## **NYQUIST PLOT**

Curve 2:  $s = Re^{j\phi}$ 

$$L(Re^{j\phi}) = \frac{2}{(1 + 2Re^{j\phi})(1 + Re^{j\phi})\left(1 + \frac{1}{2}Re^{j\phi}\right)}$$

Let  $R \to \infty$ 

$$L(Re^{j\phi}) \approx \frac{2}{2Re^{j\phi}Re^{j\phi}\frac{1}{2}Re^{j\phi}}$$

$$L(Re^{j\phi}) \approx \frac{2}{R^2} e^{-3j\phi}$$

$$\lim_{R\to\infty}|L(s)|\to 0$$

James A. Mynderse


MRE 5323 - More Stability

15

## **NYQUIST STABILITY CRITERION**

James A. Mynderse

MRE 5323 - More Stability



**MORE STABILITY** 

# RELATIVE STABILITY

James A. Mynderse

MRE 5323 - More Stability

# SO FAR WE'VE ONLY DISCUSSED STABILITY AS A BINARY CONDITION

Poles in LHP Passed Routh-Hurwitz test Passed Nyquist test

Poles in RHP Failed Routh-Hurwitz test Failed Nyquist test


- For a given system, how far apart are these regions?
- Could we give it a little push from stability to instability?
- Relative stability measures how far from instability a system is currently
- Relative stability is measured in magnitude and phase

James A. Mynderse

MRE 5323 - More Stability

19

# PROXIMITY TO ENCIRCLEMENT OF -1 IS A RELATIVE STABILITY.




- Gain Margin the factor by which the open-loop gain can be increased at a phase of −180° before the system goes unstable.
- Phase Margin the amount by which open-loop phase can be decreased at unity magnitude before system goes unstable

James A. Mynderse

MRE 5323 - More Stability

# THE CLOSEST APPROACH OF THE NYQUIST PATH TO -1 GIVES US THE SENSITIVITY PEAK



$$M_{s} = \frac{1}{\eta} = \max |S_{o}(j\omega)|$$
$$= \max \left| \frac{1}{1 + G_{o}(j\omega)C(j\omega)} \right|$$


- ullet  $M_{s}$  is the nominal sensitivity peak
- Larger  $M_s$  means closer to instability

James A. Mynderse

MRE 5323 - More Stability

21


### **EXAMPLE:**





$$L_o(s) = \frac{3}{(s+1)^3}$$

James A. Mynderse

MRE 5323 - More Stability







### **SUMMARY OF MARGINS**

For stability, we want no encirclement of  $\neg 1$  (for minimum-phase systems):

- GM > 1 or  $GM_{dB} > 0$
- $PM > 0^{\circ}$

As measures of relative stability, more positive GM & PM imply farther away from instability:

- GM indicates allowable extra gain
- PM indicates allowable extra phase lag (time delay)

James A. Mynderse

MRE 5323 - More Stability

### **MORE STABILITY**


# ROBUST STABILITY

James A. Mynderse

MRE 5323 - More Stability

27

# THAT'S ALL WELL AND GOOD, BUT WHAT HAPPENS WHEN ACTUAL SYSTEM ISN'T NOMINAL?




$$L_o(s) = \frac{3}{(s+1)^3}$$

$$L(s) = \frac{3}{(s+1)^3}e^{-0.5s}$$

James A. Mynderse

MRE 5323 - More Stability

# COMPARE THE MODEL ERROR TO THE SENSITIVITY PEAK



If the difference between nominal and actual is less than the inverse of nominal sensitivity peak, the system is still stable!

$$|L(j\omega) - L_o(j\omega)| < |1 + L_o(j\omega)|$$

James A. Mynderse

MRE 5323 - More Stability

29

# WE CAN DO SOME MANIPULATION TO MAKE THIS MORE USEFUL

$$|L(j\omega) - L_o(j\omega)| < |1 + L_o(j\omega)|$$

$$|C(j\omega)G(j\omega) - C(j\omega)G_o(j\omega)| < |1 + L_o(j\omega)|$$

$$|\mathcal{C}(j\omega)G_o(j\omega)|\cdot \left|\frac{G(j\omega)-G_o(j\omega)}{G_o(j\omega)}\right|<|1+L_o(j\omega)|$$

$$\frac{|L_o(j\omega)|}{|1+L_o(j\omega)|} \cdot \left| \frac{G(j\omega) - G_o(j\omega)}{G_o(j\omega)} \right| < 1$$

 $|T_o(j\omega)||G_{\Lambda}(j\omega)|<1$ 

James A. Mynderse

MRE 5323 - More Stability

)

### **ROBUST STABILITY THEOREM**

Consider a plant with a nominal TF of  $G_0(s)$  and a true TF of G(s).

- Assume that a controller C(s) has been designed to achieve nominal internal stability (i.e., no unstable pole/zero cancellation and  $L_o(s) = G_o(s)C(s)$  is stable).
- Also assume that  $L_o(s) = G_o(s)C(s)$  and L(s) = G(s)C(s) have the same number of unstable poles.

Then, a sufficient condition for stability of the actual feedback loop obtained by applying the controller to the true plant is that

$$|T_o(j\omega)||G_{\Delta}(j\omega)| = \left|\frac{L_o(j\omega)}{1 + L_o(j\omega)}\right||G_{\Delta}(j\omega)| < 1$$

where  $G_{\Delta}(j\omega)$  is the frequency response of the multiplicative modeling error.

James A. Mynderse

MRE 5323 - More Stability

31

### **ROBUST STABILITY EXAMPLE**

#### **Problem Formulation**


Nominal System	Actual System	MME
$L_o(s) = \frac{3}{(s+1)^3}$	$L(s) = \frac{3}{(s+1)^3} e^{-T_d s}$	$G_{\Delta}(s) = e^{-T_{d}s} - 1$

Find exact value of time delay that leads to instability.

$$\left|e^{-T_{d}j\omega}\right| = 1$$
  $\angle e^{-T_{d}j\omega} = -T_{d}\omega$  [rad]

James A. Mynderse

MRE 5323 - More Stability



## **ROBUST STABILITY EXAMPLE (CONT.)**


Estimate the critical time delay using Robust Stability

$$T_o(s) = \frac{L_o(s)}{1 + L_o(s)} = \frac{\frac{3}{(s+1)^3}}{1 + \frac{3}{(s+1)^3}} = \frac{3}{(s+1)^3 + 3}$$

$$G_{\Delta}(s) = e^{-T_d s} - 1$$

James A. Mynderse

MRE 5323 - More Stability



## ROBUST STABILITY EXAMPLE

Comment on any differences in the two values for time delay

James A. Mynderse MRE 5323 – More Stability

### **ACTUAL AND NOMINAL SENSITIVITY**

### **Actual Achieved Sensitivity Functions**

$$S(s) = S_o(s)S_{\Delta}(s)$$

$$T(s) = T_o(s)(1 + G_{\Delta}(s))S_{\Delta}(s)$$

$$S_i(s) = S_{io}(s)(1 + G_{\Delta}(s))S_{\Delta}(s)$$

$$S_u(s) = S_{uo}(s)S_{\Delta}(s)$$

where

$$S_{\Delta}(s) = \frac{1}{1 + T_o(s)G_{\Delta}(s)},$$
 Error Sensitivity  $G_{\Delta}(s) = \frac{G(s) - G_o(s)}{G_o(s)},$  MME

James A. Mynderse

MRE 5323 - More Stability

37

### **HOW DID YOU DO THAT?**

Sensitivity functions all have the same term in the denominator

$$\frac{1}{1+GC}$$

We can rewrite this term to include a comparison of the nominal plant model and true plant

But it would be more useful if we could connect this to the MME

$$G_{\Delta}(s) = \frac{G(s) - G_0(s)}{G_0(s)}$$

James A. Mynderse

MRE 5323 - More Stability

### **HOW DID YOU DO THAT?**

$$\frac{1+G_oC}{1+GC} = \frac{1}{\left(\frac{1+GC}{1+G_oC}\right)}$$

$$=\frac{1}{1+T_oG_{\Delta}}$$

James A. Mynderse

MRE 5323 - More Stability

-

### **PERFORMANCE ROBUSTNESS**

To ensure that achieved performance is close to nominal performance, we need

$$S_{\Delta}(j\omega)\approx 1$$

$$S_{\Delta}(s) = \frac{1}{1 + T_o(s)G_{\Delta}(s)}$$

James A. Mynderse

MRE 5323 - More Stability

## **COMING UP...**

### **Pole Placement Controller Design**

- Pole placement design
- Controller with integration
- PID via pole placement

#### **PID Control via Pole Placement**

- P, PD, PI, PID controllers
- Smith predictor

James A. Mynderse

MRE 5323 - More Stability