

Guide Book

- Forward and backward
- High and low speed
- Volume adjustment
- Power display
- 2.4G R/C
- Wireless connection
- Music

Audi TT RS Roadster Ride On



IMPORTED AND MADE FOR ATAA CARS
ATAA INTERACTIVE SL
CIF B73966277
WWW.ATAACARS.COM



Spare parts list


      													
A B C D E F G													
      													
H I J K L M N													
Name	A	B	C	D	E	F	G	H	I	J	K	L	M
	Car	Rearview	Steering	Rear	Windshield	Rear	Front	Wheel	Seat	Charger	Remote	Seat	Screw
	body	mirror	wheel	spoiler		wheel	wheel	cover			control	lock	
Qty	1	2	1	1	1	2	2	4	2	1	1	2	3
N													
Name	Spanner												
Qty	2												



Product specification

Name	Specification
Battery	12V
Suitable age	37-95 months
Loading capacity	30kg
Product size	102*60*44cm
Speed	2.5-3.5km/h
Charge/use time	charge 8-10h, use 1-2h
Charger	12V
Remote control	AAA1.5V (not included)


Funciones



- | | |
|-------------------------|------------------------|
| ① Power display | ⑦ High and low speed |
| ② Music switch/Volume - | ⑧ Forward and backward |
| ③ Stop/play | ⑨ Music button |
| ④ Music switch/Volume + | ⑩ Horn button |
| ⑤ Mode | ⑪ Pedal switch |
| ⑥ Power switch | |

Remote control function and explanation

- Do not swift forward/backward button when car is driving, or will damage the motor.
- Remote control can be used normallySpeed when battery assembled.
- Remote control should be used under adults' supervision.
- Remote control is prior to man control.



How to adjust R/C frequency:
Long press forward and backward button for 3 seconds, and the speed indicator flashes. Then turn on the power, the speed indicator goes to long bright, means the connection successfully, If the speed indicator no response, means the connection failed. Replace the batteries and retry.

- Take off the battery cover. Put two AAA1.5V remote control battery in with right polarity.
- New and used batteries can not be used mixed.
- Do not insert batteries into wrong polarity, or will be short-circuited.
- Non-rechargeable batteries can not be recharged. Exhausted batteries should be replaced by adults.
- The exhausted battery must be handled and operated properly by adults only. Do not be played by children.

Installation procedure

1. Front wheel assembly

Turn over car body, add 1pcs front wheel, 1pcs washer to direction bracket, then use nut to tighten. At last, insert wheel cover into the holes on the wheel. The same assembly step for the other side.



2. Rear wheel assembly

Turn over car body, add 1pcs rear wheel, 1pcs washer to rear axle, then use nut to tighten. At last, insert wheel cover into the holes on the wheel. The same assembly step for the other side.



3. Steering wheel and windshield assembly

Connect the line of steering wheel and the line in the hole of platform. Insert steering wheel into steering lever, use screw and nut to tighten them. At last, insert windshield into the reserved place on the platform.



4. Rearview mirror and battery line assembly

Insert rearview mirror into the reserved place on the car. Connect two red connectors like picture.



5. Seat assembly

Connect seat together, use 3pcs to tighten, then insert seat into reserved place on the car.



6. Seat and rear spoiler assembly

Use 2pcs seat lock to tighten seat. Insert rear spoiler into reserved place on the car.



Warnings

For children's safety, please read these carefully. Assembly and adjustment must be done by adults, keep children away. Keep children under 36 months away from small parts. Safe belt is a must when children playing. Do not be closeto fire. Adult must teach how to play it and never leave children alone for playing. Do not stand up or play when children are stepping on foot pedal. Battery must be charged by adults only. Please charge it first before use. Keep children away from plastic bag, or suffocation may occur. Only use spare parts which provided by manufacturer. Charger is not a toy for playing. Maximum loading capacity is 30KG. Do not overload. Suitable age: 37-95 months.

Safety use

Do not play in the street, road, slope or ditch. Do not change the line or add electric device to the car. Play the car in the dry area, not wet. Keep away from fire, or may damage the line. One rider one time only. Do not overload. Maximum capacity is 30KG. Turn power off if no use. If long time no use, unplug battery line. Check battery, charger and other spare parts regularly. If any problem, please fix it before playing.

Charging notification

For the first use, please charge 8-12 hours, or will damage the battery. Plug charger DC line into charge hole first, then plug charger into socket. Car can not be played when it charging. Every time it charged, do not charge more than 20 hours. It is normal that charger and battery warm (under 60°) during charging. Do not charge if plug is wet, or will occur short-circuited. Only use charger provided by manufacturer, or will damage charger and battery or occur short-circuited. If long time no use, please charge 1 time per month at least.

Charging steps are as follows:

- Step 1: The charging hole is under the seat.
- Step 2: Put the charger plug into the plug hole.
- Step 3: Connect the charger to the power socket.



Warning: Car must be charged by adults only. Car is useless during charging

Problem solution

Problem	Analysis	Solution
Car can not move	Battery low power	Charge battery
	Fuse protect	Reuse a few minutes later
	Power not turn on	I urn on it again
	Battery line loose	Reconnect
	Battery damaged	Replace a new one
	Electric device damaged	Replace a new one
	Motor damaged	Replace a new one
Battery can not be recharged	Battery connector loose	Reconnect
	Charger not plug in	Replug
	Chager damages	Replace a new one
Car does not run very long	Battery power low	Recharge
	Battery is old	Replace a new one
Charger feels warm when charging	Chemical reaction	Normal
Speed slow	Battery is old	Replace a new one
	Battery power low	Recharge
	Overloaded	Reduce weight under 30KG
	Road is not even	Play in a smooth area

Maintenance and Service

- Check battery, charger and other spare parts regularly. If any problem, please fix it before playing.
- Use lubricating oil to care iron parts. Keep car away from fire and sunshine. Park it on the even place, not reversal or gradient.
- Park it indoor and cover it with waterproof cloth.
- Keep car away from fire, like stove or heater, or plastic may melt.
- Keep away from flammable things, or may occur fire accident.
- Charge it after use and must be done by adults only. If long time no use, please charge it 1 time per month, in order to maintain battery.
- Clean the vehicle with a dry cloth only. Do not use chemical solvent to wipe plastic parts. Do not wash it with water or play it when raining or snowing. Water will damage motor, electric system or battery.
- Please turn power off after each use.
- Only use charger provided by manufacturer.
- Do not change car's structure or electric line. Check job request some skills or under specialist's guidance.

"Trademarks, design patents and copyrights are used with the approval of the owner AUDI AG." Licensee: Pinghu XH Children Products Co., Ltd