ADD: NO.5, HUIJING ROAD, HUIMEI XINCUN,XINTANG TOWN, ZENGCHENG, GUANGZHOU,PRC TEL: 0086-20-320=911533 FAX: 0086-20-32916033 WWW.DIRTMAX.COM E-MAIL:SALES@DIRTMAX.COM

# DTE150 (150cc)




ADD: NO.5, HUIJING ROAD, HUIMEI XINCUN, XINTANG TOWN, ZENGCHENG, GUANGZHOU, PRC TEL: 0086-20-320=911533 FAX: 0086-20-32916033 WWW. DIRTMAX. COM E-MAIL: SALES@DIRTMAX. COM

|            |                                 | 目 | 录 | (INDEX TO ENGINE GROUP) |       |
|------------|---------------------------------|---|---|-------------------------|-------|
| E-1        | 气缸组件                            |   |   |                         | 1     |
|            | CYLINDER ASSY                   |   |   |                         |       |
| E-2        | 气缸头                             |   |   |                         | 2-3   |
|            | Cylinder Head                   |   |   |                         |       |
| E-3        | 凸轮轴总成                           |   |   |                         | 4     |
|            | CAMSHAFT ASSY                   |   |   |                         | _     |
| E-4        | 时规链                             |   |   |                         | 5     |
| B 5        | TIME CHAIN                      |   |   |                         | ć     |
| E-5        | 左、右箱体                           |   |   |                         | 6     |
| E-6        | CRANKCASE<br>曲轴总成               |   |   |                         | 7     |
| E-0        | 四和志及<br>CRANKSHAFT              |   |   |                         | 1     |
| E-7        | 右边盖                             |   |   |                         | 8     |
| <b>L</b> ' | CRANKCASE COVER                 |   |   |                         | Ü     |
| E-8        | 左曲轴箱盖 磁电机                       |   |   |                         | 9     |
|            | Left Crankcase Cover & Magnetio |   |   |                         |       |
| E-9        | 离合器组件                           |   |   |                         | 10    |
|            | CLUTCH COMPONENT PART           |   |   |                         |       |
| E-10       | 变速鼓组件                           |   |   |                         | 11-12 |
|            | SHIFTING MOTIVATOR              |   |   |                         |       |
| E-11       | 起动轴组合                           |   |   |                         | 13    |
|            | START ASSY                      |   |   |                         |       |
| E-12       | 主、副轴组件                          |   |   |                         | 14–15 |
| L          | SLOWING DOWN SUBASSEMBLY        |   |   |                         | 1.0   |
| E-13       | 油泵总成                            |   |   |                         | 16    |
| D 14       | PUMP ASSY                       |   |   |                         | 1.7   |
| E-14       | 平衡轮组件                           |   |   |                         | 17    |
|            | BALANCE WHEEL ASSY              |   |   |                         |       |

ADD: NO.5, HUIJING ROAD, HUIMEI XINCUN, XINTANG TOWN, ZENGCHENG, GUANGZHOU, PRC TEL: 0086-20-320=911533 FAX: 0086-20-32916033 WWW. DIRTMAX. COM E-MAIL: SALES@DIRTMAX. COM


E-1 气缸组件 CYLINDER ASSY



| 序号<br>Ref. No. | 零部件编码<br>Part No. | 零部件名称           | Description                | 数量<br>Quantiyy | 备注<br>Remark |
|----------------|-------------------|-----------------|----------------------------|----------------|--------------|
| 1              | 210A038           | 4 11            | CYLINDER BODY              | 1              |              |
| 2              | 2101B010          | 气缸体密封垫          | CYLINDER BODY SEAL PACKING | 1              |              |
| 3              | 210A000           | 气缸头组件           | CYLINDER HEAD ASSY         | 1              |              |
| 4              | D00A001           | 进气门导管           | SUCTION-VALVE PIPE         | 2              |              |
| 5              | D00A002           | 排气门导管           | EXHAUST VALVE PIPE         | 1              |              |
| 6              | 210B008           | 气缸头密封垫组件        | CYLINDER HEAD SEAL GASKET  | 1              |              |
| 7              | 97008012          | 定位销 8×12        | ASSEMBLING PIN 8×12        | 4              |              |
| 8              | GB5787            | 2 42 4 74 1 III | BOLT M8×38                 | 2              |              |
| 9              | GB5783            | 螺栓              | BOLT                       | 2              |              |
| 10             | 208-1-14          | 0 型密封圈          | O SHAPED SEAL RING         | 3              |              |
| 11             | 210E030           | 油道管             | OIL PIPE                   | 1              |              |

ADD: NO.5, HUIJING ROAD, HUIMEI XINCUN, XINTANG TOWN, ZENGCHENG, GUANGZHOU, PRC TEL: 0086-20-320=911533 FAX: 0086-20-32916033 WWW. DIRTMAX. COM E-MAIL: SALES@DIRTMAX. COM

E-2 气缸头 CYLINDER HEAD



| 序号<br>Ref. No. | 零部件编码<br>Part No. | 零部件名称    | Description                           | 数量<br>Quantiyy | 备注<br>Remark |
|----------------|-------------------|----------|---------------------------------------|----------------|--------------|
| 1              | 210A033           | 气缸头左盖    | CYLINDER HEAD LEFT COVER              | 1              |              |
| 2              | 2101B006          | 气缸头左盖密封圈 | CYLINDER HEAD LEFT COVER SEAL PACKING | 1              |              |
| 3              | 210A032           | 气门盖      | VALVA COVER                           | 2              |              |
| 4              | 210C074           | 气门盖密封圈   | SEAL FOR INTAKE VALVE                 | 2              |              |
| 5              | D001D021          | NGK 火花塞  | NGK SPARKING PLUG                     | 1              |              |
| 6              |                   | 双头螺栓     | DOUBLE -HEAD SCREW                    | 4              |              |
| 7              |                   | 盖形螺母     | NUT                                   | 4              |              |
| 8              | GB5787            | 带盘螺栓     | PLATE BOLT                            | 4              |              |
| 9              | 208B030           | 进气管密封垫   | SEAL PACKING FOR THE INTAKE           | 1              |              |
| 10             | L00JQ214          | 进气管      | INTAKE                                | 1              |              |
| 11             | F001B014          | 密封垫      | SEAL PACKING                          | 1              |              |
| 12             | F00C039           | 隔热垫      | CARBURETOR SEAL PACKING               | 1              |              |
| 13             | GB5787            | 带盘螺栓     | PLATE BOLT                            | 1              |              |
| 14             | GB5787            | 带盘螺栓     | PLATE BOLT                            | 1              |              |


ADD: NO.5, HUIJING ROAD, HUIMEI XINCUN, XINTANG TOWN, ZENGCHENG, GUANGZHOU, PRC TEL: 0086-20-320=911533 FAX: 0086-20-32916033 WWW. DIRTMAX. COM E-MAIL: SALES@DIRTMAX. COM

| 5轮轴总成 | CAMSHAFT ASSY |                        |
|-------|---------------|------------------------|
|       | 8700          |                        |
|       | 8 0 0         | 10 9                   |
| 5-4   | <del>-5</del> | 9 11 12                |
| 2—63  |               | 10 50 mm 00000 p 16 15 |
|       | 8-0-7         |                        |

| 序号       | 零部件编码    | 零部件名称   | Description               | 数量       | 备注     |
|----------|----------|---------|---------------------------|----------|--------|
| Ref. No. | Part No. |         |                           | Quantiyy | Remark |
| 1        | 210L050  | 摇臂轴挡板   | ROCKERARM SHAFT FENDER    | 1        |        |
| 2        | 210F020  | 凸轮轴组件   | CAMSHAFT SUBASSEMBLY      | 1        |        |
| 3        | 210F015  | 摇臂轴     | ROCKERARM SHAFT           | 2        |        |
| 5        | GB5783   | 螺栓      | BOLT                      | 2        |        |
| 6        | 210F000  | 气门摇臂    | ROCKER ARM, VALVE         | 2        |        |
| 7        | A00F001  | 气门调节螺钉  | AIR VALVE ADJUSTING SCREW | 2        |        |
| 8        | A00F002  | 气门调节螺母  | AIR VALVE ADJUSTINF NUT   | 2        |        |
| 9        | F03F034  | 气门内外弹簧座 | UP SPRING SEAT            | 2        |        |
| 10       | F03F033  | 气门锁夹    | AIR VALVE LOCKER          | 2        |        |
| 11       | 210H004  | 气门内弹簧   | INNER SPRING, VALVE       | 2        |        |
| 12       | 210Н003  | 气门外弹簧   | OUTER SPRING, VALVE       | 2        |        |
| 14       | 210F045  | 进气门     | INDUCTION VALVE           | 2        |        |
| 15       | 210F039  | 排气门     | EXHAUST VALVE             | 1        |        |
| 16       | F00C043  | 油封      | VALVE STEM SEAL           | 2        |        |

ADD: NO.5, HUIJING ROAD, HUIMEI XINCUN, XINTANG TOWN, ZENGCHENG, GUANGZHOU, PRC TEL: 0086-20-320=911533 FAX: 0086-20-32916033 WWW. DIRTMAX.COM E-MAIL:SALES@DIRTMAX.COM


E-4 时规链 TIME CHAIN



| 序号<br>Ref. No. | 零部件编码<br>Part No. | 零部件名称     | Description            | 数量<br>Quantiyy | 备注<br>Remark |
|----------------|-------------------|-----------|------------------------|----------------|--------------|
| 1              | 210F011           | 正时从动链轮    | TIMING DRIVEN SPROCKET | Qualitiyy      | кешатк       |
| 2              | 210F012           | 正时链条      | TIMING CHAIN           | 1              |              |
| 3              | 210C006           | 链条张紧板     | TENSION PLATE          | 1              |              |
| 4              | 210C007           | 链条导向板     | GUIDE                  | 1              |              |
| 5              | 578305012         | 六角螺栓M5×12 | BOLT M5×12             | 2              |              |
| 6              | 210F014           | 张紧器       | CHAIN TENSIONER ASSY   | 1              |              |
| 7              | 210L010           | 张紧板螺栓     | BOLT, TENSION PLATE    | 1              |              |
| 8              |                   | 垫圈8       | WASHER 8               | 1              |              |
| 9              |                   | 螺栓M6×20   | BOLT M6×20             | 2              |              |
| 10             | 2101B004          | 张紧器密封垫    | GASKET, TENSIONER      | 1              |              |
| 11             |                   | 0型圏       | O-RING                 | 1              |              |
| 12             |                   | 调节螺钉      | BOLT,ADJUST            | 1              |              |
| 13             |                   | 垫圈8       | WASHER 8               | 1              |              |
| 14             |                   | 螺母M8      | Nut M8                 | 1              |              |

ADD: NO.5, HUIJING ROAD, HUIMEI XINCUN, XINTANG TOWN, ZENGCHENG, GUANGZHOU, PRC TEL: 0086-20-320=911533 FAX: 0086-20-32916033 WWW. DIRTMAX. COM E-MAIL: SALES@DIRTMAX. COM


E-5 左、右箱体 **CRANKCASE** 



| 序号       | 零部件编码      | 零部件名称        | Description                | 数量       | 备注     |
|----------|------------|--------------|----------------------------|----------|--------|
| Ref. No. | Part No.   |              |                            | Quantiyy | Remark |
| 1        | 210A020    | 右曲轴箱体        | RIGHT CRANKCASE BODY       | 1        |        |
| 2        | 2101B005   | 曲轴箱密封垫       | CRANKCASE SEALED PACKING   | 1        |        |
| 3        | 210A010    | 左曲轴箱体        | LEFT CRANKCASE BOGY        | 1        |        |
| 4        | F00C024    | 通气管          | BREATHING PIPE             | 1        |        |
| 5        | D00L014    | 溢流管夹         | OVERFLOW PIPE CLIP         | 1        |        |
| 6        | D00L039BCR | <b>高</b> 丛线夹 | PIPE CLAMPING              | 1        |        |
| 7        | F08M001    | 汽缸双头螺栓 A     | CYLINDER TRAPPED STUD(A)   | 2        |        |
| 8        | F03M002    | 汽缸双头螺栓 B     | CYLINDER TRAPPED STUD (B)  | 2        |        |
| 9        | D00L021    | 垫圈           | WASHER                     | 1        |        |
| 10       | 97010014   | 定位销          | ASTEMBLING PIN             | 2        |        |
| 11       | D00E026BX  | 放油螺栓         | DISCHARGING OIL PLUG SCREW | 1        |        |
| 12       | GB5787     | 螺栓           | BOLT                       | 2        |        |
| 13       | GB5787     | 螺栓           | BOLT                       | 1        |        |
| 14       | GB5787     | 螺栓           | BOLT                       | 4        |        |
| 15       | D001C008   | 油封           | WASHER                     | 1        |        |
| 16       | D00C026    | 油封           | WASHER                     | 1        |        |


ADD: NO.5, HUIJING ROAD, HUIMEI XINCUN, XINTANG TOWN, ZENGCHENG, GUANGZHOU, PRC TEL: 0086-20-320=911533 FAX: 0086-20-32916033 WWW. DIRTMAX. COM E-MAIL: SALES@DIRTMAX. COM

E-6 曲轴总成 CRANKSHAFT



| 序号       | 零部件编码    | 零部件名称  | Description            | 数量       | 备注     |
|----------|----------|--------|------------------------|----------|--------|
| Ref. No. | Part No. |        |                        | Quantiyy | Remark |
| 1        | 210Ј000  | 曲柄连杆组件 | CRANK CONNECTING ROD   | 1        |        |
| 2        | 210Ј013  | 活塞环组合  | PISTON RING SET        | 1        |        |
| 3        | 210Ј014  | 活塞     | PISTON                 | 1        |        |
| 4        | 210Ј012  | 活塞销    | PISTON PIN             | 1        |        |
| 5        | D00J011  | 活塞销挡圈  | PISTON PIN SHIELD RING | 2        |        |
| 6        | 210Ј025  | 连杆     | CONNECTING ROD LEVEL   | 1        |        |
| 7        | 210Ј005  | 右曲柄    | RIGHT-HAND CRANKSHAFT  | 1        |        |
| 8        | 210Ј006  | 左曲柄    | LEFT-HAND CRANK SHAFT  | 1        |        |
| 9        | 208J007  | 曲柄销    | CRANK PIN              | 1        |        |
| 10       | 208Ј001  | 半圆链    | SEMICIRCULAR KEY       | 1        |        |
| 11       | E13E023  | 油泵驱动齿轮 | OIL PUMP DRIVER GEAR   | 1        |        |
| 12       | 63/22    | 轴承     | BEARING                | 2        |        |
| 13       | 210Ј008  | 连杆大头轴承 | BEARING                | 1        |        |
| 14       | D04K015  | 主动齿轮   | PRIMARY DRIVER GEAR    | 1        |        |


ADD: NO.5, HUIJING ROAD, HUIMEI XINCUN, XINTANG TOWN, ZENGCHENG, GUANGZHOU, PRC EL: 0086-20-320-911533 FAX: 0086-20-32916033 WWW. DIRTMAX. COM E-MAIL: SALES@DIRTMAX. COM



| 序号       | 零部件编码      | 零部件名称     | Description                 | 数量       | 备注     |
|----------|------------|-----------|-----------------------------|----------|--------|
| Ref. No. | Part No.   |           |                             | Quantiyy | Remark |
| 1        | 210A034    | 右曲轴箱盖     | RIGHT CRANKCASE COVER       | 1        |        |
| 2        | 2101B002   | 右曲轴箱盖密封垫  | RIGHT CRANKCASE SEALED      | 1        |        |
| 3        | 97108012   | 定位销       | PITCHED PIN                 | 2        |        |
| 4        | GB5787     | 螺栓        | BOLT                        | 5        |        |
| 5        | GB5787     | 螺栓        | BOLT                        | 1        |        |
| 6        | GB5787     | 螺栓        | BOLT                        | 2        |        |
| 7        | D00C038    | 机油标尺组合    | OIL SCALE ASSEMBLY          | 1        |        |
| 8        | D00C060    | O型密封圈     | O-SHAPED SEALED RING        | 1        |        |
| 9        | D00C016    | 油封        | OIL SEAL                    | 1        |        |
| 10       | E13L031    | 离合器拉索定位支架 | CLUTCH CABLE CLIP           | 1        |        |
| 11       | E13G010BCR | 离合器操纵杆    | CLUTCH CONTROL LEVER        | 1        |        |
| 12       | E13H007    | 操纵杆复位弹簧   | CONTROL LEVER RETURN SPRING | 1        |        |
| 13       | F04C030    | 油封        | OIL SEAL                    | 1        |        |
| 14       | 208-7-14   | 增油导管      | OIL PIPE                    | 1        |        |

ADD: NO.5, HUIJING ROAD, HUIMEI XINCUN, XINTANG TOWN, ZENGCHENG, GUANGZHOU, PRC EL: 0086-20-320=911533 FAX: 0086-20-32916033 WWW.DIRTMAX.COM E-MAIL:SALES@DIRTMAX.COM


#### E-8 左曲轴箱盖 磁电机 Left Crankcase Cover & Magnetio



| 序号       | 零部件编码          | 零部件名称  | Description          | 数量       | 备注     |
|----------|----------------|--------|----------------------|----------|--------|
| Ref. No. | Part No.       |        |                      | Quantiyy | Remark |
| 1        | A019A070       | 左箱盖    | LEFT CRANKCASE COVER | 1        |        |
| 2        | 208D050        | 磁电机总成  | MAGNETON             | 1        |        |
| 3        | 208D060        | 磁电机转子  | FLYWHEEL             | 1        |        |
| 4        | 208D070        | 磁电机定子  | STATOR MODULE        | 1        |        |
| 5        | 617710000BCR-1 | 六角螺母   | HEX NUT              | 1        |        |
| 6        | D00C028        | 油封     | OILE SEAL            | 1        |        |
| 7        | D001C062       | O 型密封圈 | O-SHAPED SEAL        | 1        |        |
| 8        | F002C048       | O 型密封圈 | O-SHAPED SEAL        | 1        |        |
| 9        | GB818          | 螺钉     | BOLT                 | 2        |        |
| 10       | GB5787         | 螺栓     | BOLT                 | 1        |        |
| 11       | GB5787         | 螺栓     | BOLT                 | 2        |        |

ADD: NO.5, HUIJING ROAD, HUIMEI XINCUN, XINTANG TOWN, ZENGCHENG, GUANGZHOU, PRC TEL: 0086-20-320=911533 FAX: 0086-20-32916033 WWW. DIRTMAX.COM E-MAIL:SALES@DIRTMAX.COM


E-9 离合器组件 CLUTCH COMPONENT PART



| 序号<br>Ref. No. | 零部件编码<br>Part No. | 零部件名称          | Description            | 数量<br>Quantivy | 备注<br>Remark |
|----------------|-------------------|----------------|------------------------|----------------|--------------|
| 1              | 208-9-1           | <b>离合器外罩组合</b> | CLUTCH EXTERNAL ASSY   | 1              |              |
| 2              | 208-9-2           | 定位环            | HOLDING RING           | 1              |              |
| 3              | 208-9-3           | 离合器中心套         | CENTRE OF CLUTCH COVER | 1              |              |
| 4              | 208-9-4           |                | CLUTCH FRICTION DISK   | 5              |              |
| 5              | 208-9-5           |                | CLUTCH BOARD           | 4              |              |
| 6              | 208-9-6           |                | CLUTCH PRESSURE PLATE  | 1              |              |
| 7              | 208-9-7           |                | CLUTCH LIFT SLAB       | 1              |              |
| 8              | 208-9-8           | <b>轴</b> 承     | BEARING                | 1              |              |
| 9              | 208-9-9           |                | CLUTCH SPRING          | 4              |              |
| 10             | 208-9-10          |                | CLUTCH PUSH ROD        | 1              |              |
| 11             | 208-9-11          | 螺栓             | BOLT                   | 4              |              |
| 12             | 208-9-12          | 圆螺母            | ROUND NUT              | 1              |              |
| 13             | 208-9-13          | 碟型垫圏           | DISK SHAPED WASHER     | 1              |              |
| 14             | 208-9-14          | 花键垫圏           | SPLINE SHAFT WASHER    | 1              |              |
| 15             | 206G000           |                | CLUTCH ASSEMBLY        | 1              |              |


ADD: NO.5, HUIJING ROAD, HUIMEI XINCUN, XINTANG TOWN, ZENGCHENG, GUANGZHOU, PRC EL: 0086-20-320=911533 FAX: 0086-20-32916033 WWW. DIRTMAX. COM E-MAIL:SALES@DIRTMAX. COM

E-10 变速鼓组件 SHIFTING MOTIVATOR




| 序号       | 零部件编码     | 零部件名称    | Description                            | 数量       | 备注     |
|----------|-----------|----------|--|----------|--------|
| Ref. No. | Part No.  |          |  | Quantiyy | Remark |
| 1        | 208-10-1  | 齿轮拨叉     | GEAR SHIFT FORK                        | 2        |        |
| 2        | 208-10-2  | 导向销      | GUIDE PIN                              | 1        |        |
| 3        | 208-10-3  | 弹簧夹      | SPRING CLIP                            | 1        |        |
| 4        | 210K066   | 变速鼓      | SHIFTING DRUM                          | 1        |        |
| 5        | A00D010   | 空档开关接触片  | NEUTRAL GEAR SWITCH CONTACT            | 1        |        |
| 6        | A00K023   | 五星板      | SPEED VARIATOR STRONGBACSTRONGBACK PIN | 1        |        |
| 7        | 208-10-7  | 定位板销钉    | STRONGBACK PIN BOLT                    | 5        |        |
| 8        | 2101K070  | 变速鼓定位板组件 | SPEED VARIATOR STRONGBACK SUBASSEMBLY  | 1        |        |
| 9        | D00H009   | 定位板弹簧    | STRONGBACK SPRING                      | 1        |        |
| 10       | A00K062   | 垫圈       | WASHER                                 | 1        |        |
| 11       | 208-10-11 | 变档轴      | SHIFTING SUBASSEMBLY                   | 1        |        |
| 12       | 208-10-12 | 弹簧       | SPRING                                 | 1        |        |
| 13       | 208-10-13 | 复位弹簧     | RETURN SPRING                          | 1        |        |
| 14       | D00K024   | 定位螺栓     | ASSEMBLING SPING                       | 1        |        |
| 15       | GB5787    | 带盘螺栓     | BOLT WITH SALVER                       | 1        |        |
| 16       | 208-10-16 | 定位销      | ASSEMBLING PIN                         | 2        |        |

ADD: NO.5, HUIJING ROAD, HUIMEI XINCUN, XINTANG TOWN, ZENGCHENG, GUANGZHOU, PRC EL: 0086-20-320=911533 FAX: 0086-20-32916033 WWW.DIRTMAX.COM E-MAIL:SALES@DIRTMAX.COM



| 序号<br>Ref. No. | 零部件编码<br>Part No. | 零部件名称 | Description                | 数量<br>Quantiyy | 备注<br>Remark |
|----------------|-------------------|-------|----------------------------|----------------|--------------|
| 17             | A00L033           | 开关压板  | SWITCH PRESSBOARD          | 1              |              |
| 18             | A00K082           | 动触头组合 | MOVING CONTACT SUBASSEMBLY | 1              |              |
| 19             | 208-10-19         | 内六角螺栓 | SOCKET HEAD CAP SCREW      | 1              |              |
| 20             | 210K060           | 变速鼓组合 | SHIFTING YOKE VARIATOR     | 1              |              |
| 21             | C03K000           | 换档臂组件 | SHIFTING SUBASSEMBLY       | 1              |              |


ADD: NO.5, HUIJING ROAD, HUIMEI XINCUN, XINTANG TOWN, ZENGCHENG, GUANGZHOU, PRC TEL: 0086-20-320=911533 FAX: 0086-20-32916033 WWW. DIRTMAX. COM E-MAIL: SALES@DIRTMAX. COM



| 序号       | 零部件编码      | 零部件名称                                   | Description                      | 数量       | 备注     |
|----------|------------|---|----------------------------------|----------|--------|
| Ref. No. | Part No.   |   |                                  | Quantiyy | Remark |
| 1        | 208K025    | 起动齿轮                                    | START GEAR                       | 1        |        |
| 2        | 208-11-2   | 起动棘轮                                    | STARTING RATCHET WHEEL           | 1        |        |
| 3        | 208-11-3   | 起动轴                                     | STARTING SHAFT                   | 1        |        |
| 4        | 208-11-4   | 弹簧                                      | SPRING                           | 1        |        |
| 5        | 208-11-5   | 棘轮弹簧座                                   | RATCHET WHEEL SPRINGS SUPPORTING | 1        |        |
| 6        | 208-11-6   | 棘轮导向板                                   | RATCHET WHEEL GUIDE RUNNER       | 1        |        |
| 7        | 208-11-7   | 起动轴复位弹簧                                 | STARTING SHAFT RETURN SPRING     | 1        |        |
| 8        | 208-11-8   | 起动轴弹簧座                                  | STARTING SHAFT SPRING SUPPORTING | 1        |        |
| 9        | GB5783     | 螺栓                                      | BOLT                             | 2        |        |
| 10       | 208-11-10  | 垫圈                                      | WASHER                           | 1        |        |
| 11       | 208-11-11  | 垫圈                                      | WASHER                           | 2        |        |
| 12       | 208-11-12  | 垫圈                                      | WASHER                           | 3        |        |
| 13       | 208-11-13  | 护挡圈                                     | SHIELD RING                      | 1        |        |
| 14       | 2081000    | 起动轴组合                                   | STARTING SHAFT ASSEMBLY          | 1        |        |
| 15       | 208-11-15  | 弹簧盖                                     | SPRING COVER                     | 1        |        |
| 16       | 208-11-16  | 垫圈 ———————————————————————————————————— | WASHER                           | 2        |        |
| GUANGZ   | HUU DIRTMA | X MOTORSPORTS CO., LTD.                 |                                  |          | - 14 - |

ADD: NO.5, HUIJING ROAD, HUIMEI XINCUN, XINTANG TOWN, ZENGCHENG, GUANGZHOU, PRC TEL: 0086-20-320=911533 FAX: 0086-20-32916033 WWW. DIRTMAX. COM E-MAIL: SALES@DIRTMAX. COM


E-12 主、副轴组件 SLOWING DOWN SUBASSEMBLY



| 序号       | 零部件编码     | 零部件名称       | Description                   | 数量       | 备注     |
|----------|-----------|-------------|-------------------------------|----------|--------|
| Ref. No. | Part No.  |             |                               | Quantiyy | Remark |
| 1        | E13K030   | 传动主轴 (不含轴承) | TRANSMISSION MMAIN SHAFT      | 1        |        |
| 2        | E13K040   | 传动副轴 (不含轴承) | TRANSMISSION COUNTENSHAFT     | 1        |        |
| 3        | 208-12-3  | 齿轮          | GEAR WHEEL                    | 1        |        |
| 4        | 208-12-4  | 齿轮套         | GEARED SLEEVE                 | 1        |        |
| 5        | 208-12-5  | 齿轮          | GEAR WHEEL                    | 1        |        |
| 6        | 208-12-6  | 花键从动齿轮      | SPLINE SHAFT DRIVER GEAR      | 1        |        |
| 7        | 208-12-7  | 花键主动齿轮      | SPLINE SHAFT MAIN DRIVEN GEAR | 1        |        |
| 8        | 208-12-8  | 齿轮          | GEAR WHEEL                    | 1        |        |
| 9        | 208-12-9  | 齿轮          | GEAR WHEEL                    | 1        |        |
| 10       | 208-12-10 | 花键齿轮        | SPLINE SHAFT GEAR WHEEL       | 1        |        |
| 11       | A001K014  | 主动链轮        | DRIVE SPROCKET                | 1        |        |
| 12       | 208-12-12 | 主动链轮卡圈      | SRIVE SPROCKET CLOSING RING   | 1        |        |
| 13       | 27666001  | 轴承          | BEARING                       | 1        |        |
| 14       | 2766202X3 | 轴承          | BEARING                       | 1        |        |
| 15       | 2766303X3 | 轴承          | BEARING                       | 2        |        |
| 16       | 208-12-16 | 推力垫圈        | THRUST WASHER                 | 1        |        |

ADD: NO.5, HUIJING ROAD, HUIMEI XINCUN, XINTANG TOWN, ZENGCHENG, GUANGZHOU, PRC EL: 0086-20-320=911533 FAX: 0086-20-32916033 WWW. DIRTMAX. COM E-MAIL: SALES@DIRTMAX. COM


E-12 主、副轴组件 SLOWING DOWN SUBASSEMBLY



| 序号       | 零部件编码     | 零部件名称  | Description         | 数量       | 备注     |
|----------|-----------|--------|---------------------|----------|--------|
| Ref. No. | Part No.  |        |                     | Quantiyy | Remark |
| 17       | 208-12-17 | 花键垫圈   | SPLINE SHAFT WASHER | 1        |        |
| 18       | 208-12-18 | 花键垫圈   | SPLING SHAFT WASHER | 3        |        |
| 19       | 208-12-19 | 花键垫圈   | SPLING SHAFT WASHER | 2        |        |
| 20       | 208-12-20 | 螺栓     | BOLT                | 2        |        |
| 21       | 208-12-21 | 推力垫圈   | SPLING SHAFT WASHER | 1        |        |
| 22       | 208-12-22 | 挡圈     | SHIELD RING         | 5        |        |
| 23       | 208-12-23 | 起动过桥齿轮 | STAR ROLLING GEAR   | 1        |        |
| 24       | 208-12-24 | 挡圈 15  | SHIELD RING         | 1        |        |
| 25       | 208-12-25 | 离合器齿轮套 | CLITCH GEAR SLEEVE  | 1        |        |
|          |           |        |                     |          |        |

ADD: NO.5, HUIJING ROAD, HUIMEI XINCUN, XINTANG TOWN, ZENGCHENG, GUANGZHOU, PRC TEL: 0086-20-320=911533 FAX: 0086-20-32916033 WWW. DIRTMAX.COM E-MAIL:SALES@DIRTMAX.COM


E-13 油泵总成 PUMP ASSY



| 序号       | 零部件编码    | 零部件名称   | Description            | 数量       | 备注     |
|----------|----------|---------|------------------------|----------|--------|
| Ref. No. | Part No. |         |                        | Quantiyy | Remark |
| 1        | 210E000  | 机油泵部件   | OIL PUMP COMPONENTS    | 1        |        |
| 2        |          | 油泵从动齿轮  | OIL PUMP DRIVER GEAR   | 1        |        |
| 3        |          | 油泵内转子   | OIL PUMP INNER ROTOR   | 1        |        |
| 4        |          | 油泵外转子   | OIL PUMP OUTER ROTOR   | 1        |        |
| 5        | D00C037  | 机油过滤网组件 | OIL FILTER SUBASSEMBLY | 1        |        |
| 6        |          | 带盘螺栓    | PLATE BOLT             | 1        |        |
| 7        |          | 挡圈      | SHIELD RING            | 1        |        |
| 8        | GB5783   | 带盘螺栓    | BOLT WITH SALVER       | 1        |        |
| 9        | GB5783   | 带盘螺栓    | BOLT WITH SALVER       | 2        |        |
| 10       |          | 销轴      | PIN BEARING            | 1        |        |
| 11       |          | 销轴      | PIN BEARING            | 1        |        |
| 12       |          | 油泵盖     | OIL PUMP COVER         | 1        |        |
| 13       |          | 油泵轴     | OIL PUMP AXIS          | 1        |        |
| 14       |          | 定位销     | ASSEMBLING PIN         | 2        |        |
| 15       |          | 油泉体     | OIL PUMP BODY          | 1        |        |

ADD: NO.5, HUIJING ROAD, HUIMEI XINCUN, XINTANG TOWN, ZENGCHENG, GUANGZHOU, PRC TEL: 0086-20-320=911533 FAX: 0086-20-32916033 WWW. DIRTMAX. COM E-MAIL: SALES@DIRTMAX. COM

E-14 平衡轮组件 BALANCE WHEEL ASSY



| 序号<br>Ref. No. | 零部件编码<br>Part No. | 零部件名称 | Description         | 数量<br>Quantiyy | 备注<br>Remark |
|----------------|-------------------|-------|---------------------|----------------|--------------|
| 1              | 208G082           | 平衡轮   | BALANCE WHEEL       | 1              |              |
| 2              | 208-14-2          | 碟形垫圈  | WASHER              | 1              |              |
| 3              | 208-14-3          | 锁紧螺母  | LOCK NUT            | 1              |              |
| 4              | 208-14-4          | 纸垫    | PAPER WASHER        | 1              |              |
| 5              | 208-14-5          | 平衡轮盖  | BALANCE WHEEL COVER | 1              |              |
| 6              | 208-14-6          | 螺钉M5  | BOLT M5             | 4              |              |