#### Back to search page

# Click to download printable version of this guide.

<u>AWR Microwave Office Element Catalog</u> > <u>Lumped Element</u> > Inductor With Q (Closed Form): INDQ2

<u>Prev</u>


<u>Next</u>

# Inductor With Q (Closed Form): INDQ2

# **Symbol**



# **Topology**



### **Parameters**

| Name  | Description                       | Unit Type  | Default  |
|-------|-----------------------------------|------------|----------|
| ID    | Name                              | Text       | L1       |
| L     | Inductance                        | Inductance | 1 nH     |
| Q     | Q                                 |            | 50       |
| FQ    | Frequency at which Q is evaluated | Frequency  | 0 .1 GHz |
| *MODE | Loss mode                         |            | Constant |
| RDC   | DC resistance                     |            | 0        |

<sup>\*</sup> indicates a secondary parameter

#### **Parameter Details**

**MODE.** Defines how R behaves as a function of frequency. Choose "Constant", "Proportional to sqrt(freq)", "Proportional to freq", or "Proportional to sqrt(freq), constant L".

**RDC.** The DC resistance (the value of R at 0 Hz). It is used only for the three frequency-dependent modes, not for "Constant" mode.

# **Implementation Details**

Implements an inductor with frequency-dependent Q.

## Layout

This element does not have an assigned layout cell. You can assign artwork cells to any element. See "Assigning Artwork Cells to Layout of Schematic Elements" for details.

#### Restrictions

FQ must be greater than or equal to zero.

Prev Up Next Home

Please send email to <a href="mailto:awr.support@cadence.com">awr.support@cadence.com</a> if you would like to provide feedback on this article. Please make sure to include the article link in the email.

Legal and Trademark Notice