Cleaning Robot



Category: **Hospitality & Housekeeping** Type: **Full SOP** Priority: **High** 20 labs

Covers these lab items: Cleaning Robots

What it is used for

A cleaning robot moves across suitable floors to collect dust or perform programmed cleaning tasks. Correct setup, obstacle removal, and supervision help prevent collisions, falls, and equipment damage.

Main parts

- Main body contains the drive system and control electronics.
- Cleaning brushes sweep dirt toward the suction inlet or collection area.
- Wheels and sensors help the robot move and detect obstacles.
- Dust bin or collection container stores collected debris.
- Battery supplies power to the robot.
- Charging contacts or dock recharge the battery on supported models.
- Control buttons or an app start cleaning and set operating modes.

Before you start

1. Read the user instructions and confirm the robot suits the floor and cleaning area.
2. Inspect the body, wheels, brushes, sensors, dust bin, battery, and charging dock.
3. Remove loose cables, small objects, liquids, and other hazards from the floor.
4. Keep stairs, raised edges, and drop-offs protected according to the manufacturer's instructions.
5. Empty the dust bin and check that brushes and filters are fitted correctly.
6. Ensure the charging dock is stable, dry, and connected to a suitable power outlet.

How to use

1. Place the robot on the floor or charging dock as instructed by the manufacturer.
2. Charge the battery sufficiently before starting the cleaning cycle.
3. Select the cleaning mode using the control buttons or supported app.
4. Move people, pets, loose cables, and small objects away from the cleaning path.
5. Start the robot and observe its initial movement to confirm normal operation.
6. Allow the robot to clean within the prepared area and monitor it where necessary.
7. Pause or stop the robot if it becomes trapped, collides repeatedly, or behaves unusually.
8. Switch off the robot before removing tangled hair, threads, or other obstructions.
9. Empty the dust bin and clean the brushes and sensors according to instructions.
10. Return the robot to its dock or storage location after cleaning.

⚠ Safety

- Do not operate the robot on wet floors unless the model is designed for that task.
- Keep fingers, hair, loose clothing, and hands away from moving brushes and wheels.
- Keep the robot and charging dock away from water and wet electrical connections.
- Protect stairs and open edges; do not rely only on sensors to prevent falls.
- Do not use a damaged battery, charging cable, dock, or robot housing.
- Supervise operation around young children, pets, and crowded areas.

Care & storage

- Empty the dust bin and clean brushes and filters at the recommended intervals.
- Wipe sensors and charging contacts gently with a dry, suitable cloth.
- Check wheels, brushes, battery, and dock for wear or damage regularly.
- Store the robot in a dry place and follow the manufacturer's battery care instructions.

Common mistakes to avoid

- Starting cleaning before removing loose cables and small objects from the floor.
- Allowing the robot to approach unprotected stairs or open edges.
- Cleaning moving brushes while the robot is powered on.
- Using water or cleaning chemicals on sensors or electrical contacts without approval.

Disclaimer: This SOP is prepared from general information available on the internet. For detailed instructions, refer to the manufacturer's original manual / file.

Prepared by - Subodh Kumar