Mixer Grinder



Category: **Food Processing & Kitchen** Type: **Full SOP** Priority: **High** 6 labs

Covers these lab items: Mixer and grinder; Mixer Grinder; Mixer (Mixture- Grinder)

What it is used for

A mixer grinder blends, mixes, and grinds suitable food ingredients using rotating blades. Correct jar selection, secure locking, and safe cleaning help prevent cuts, spills, and motor damage.

Main parts

- Motor unit provides the power to rotate the blades.
- Jar or container holds ingredients during mixing or grinding.
- Blade assembly cuts, blends, or grinds the ingredients.
- Lid and lid lock help prevent spills during operation.
- Jar handle supports safe holding and pouring.
- Speed control or pulse switch regulates operation.
- Power cord and plug supply electricity to the appliance.

Before you start

1. Read the manufacturer's instructions and choose the correct jar for the task.
2. Inspect the motor unit, jar, lid, blade assembly, plug, and cord for damage.
3. Place the mixer grinder on a stable, dry surface near a suitable outlet.
4. Ensure the jar, lid, and blade assembly are clean and correctly fitted.
5. Cut large ingredients into suitable pieces and check that they are permitted for the jar.
6. Keep hands, utensils, and loose objects away from the blade assembly.

How to use

1. Switch off the appliance before fitting or removing a jar.
2. Place the ingredients inside the jar without exceeding its marked capacity.
3. Add the required liquid if the recipe and appliance instructions permit it.
4. Fit the lid securely and lock the jar onto the motor unit.
5. Connect the plug with dry hands and select an appropriate speed.
6. Use short pulse intervals when suitable and avoid running the motor longer than recommended.
7. Switch off and wait until the blades stop completely before opening the lid.
8. Disconnect power before scraping ingredients or removing the jar.
9. Pour the contents carefully and handle the blade assembly without touching its sharp edges.
10. Unplug the appliance and clean the jar, lid, and blade parts according to instructions.

⚠ Safety

- Never operate the appliance without a properly secured jar and lid.
- Never insert fingers or utensils into a jar while the motor is running.
- Do not exceed the jar's capacity or operate it with unsuitable ingredients.
- Keep the motor unit, plug, and cord away from water.
- Do not open a hot jar or touch blades immediately after operation.
- Stop using the appliance if it vibrates excessively, leaks, or produces a burning smell.

Care & storage

- Unplug the appliance before cleaning or removing blade assemblies.
- Wash compatible jars and lids according to the manufacturer's instructions and dry them fully.
- Wipe the motor unit with a slightly damp cloth without immersing it in water.
- Inspect the cord, jar, seals, and blades regularly and replace damaged parts.

Common mistakes to avoid

- Running the mixer grinder with a loose lid or incorrectly fitted jar.
- Filling the jar beyond its maximum mark.
- Opening the jar before the blades stop completely.
- Immersing the motor unit or touching sharp blades carelessly during cleaning.

Disclaimer: This SOP is prepared from general information available on the internet. For detailed instructions, refer to the manufacturer's original manual / file.

Prepared by - Subodh Kumar