Hair Curler (Electric)



Category: **Beauty, Wellness & Fitness** Type: **Full SOP** Priority: **High** 4 labs

Covers these lab items: Electric Curler

What it is used for

An electric hair curler uses controlled heat to shape hair into curls or waves. Correct temperature selection, careful handling, and safe cooling help achieve consistent styling while reducing burns and hair damage.

Main parts

- Heated barrel or curling surface transfers heat to the hair.
- Clamp or curling attachment holds hair on applicable models.
- Handle provides a grip away from the heated surface.
- Temperature control adjusts the heating level.
- Power cord and plug supply electrical power.
- Indicator light or display shows heating status on equipped models.
- Heat-resistant stand supports the tool during use.
- Cool tip provides a designated gripping area on applicable models.

Before you start

1. Read the manufacturer's instructions and identify the available temperature settings.
2. Inspect the cord, plug, handle, barrel, and controls for damage.
3. Ensure hair is dry unless the device is specifically designed for damp hair.
4. Remove tangles and divide hair into manageable sections.
5. Place the curler on a stable, heat-resistant surface near a suitable outlet.
6. Keep the tool away from water, flammable materials, and loose fabrics.

How to use

1. Place the curler on its heat-resistant stand before switching it on.
2. Connect it to a suitable power outlet and select an appropriate temperature.
3. Wait until the tool reaches the selected temperature according to its indicator or manual.
4. Take a small section of hair and position it carefully near the barrel.
5. Wrap or clamp the hair according to the device design, keeping the hot surface away from skin.
6. Hold the hair for the recommended time and release it gently.
7. Repeat for other sections without repeatedly heating the same section.
8. Switch off and unplug the curler after styling.
9. Place the tool on a heat-resistant surface and allow it to cool completely.
10. Clean the cooled tool according to the manual and store it safely.

⚠ Safety

- Never touch the heated barrel or leave the hot tool unattended.
- Do not use the curler near water or with wet hands.
- Stop using the device if the cord, plug, or casing is damaged.
- Keep the heated surface away from the scalp, ears, neck, and fingers.
- Use the lowest effective temperature suitable for the hair type and condition.
- Unplug the tool before cleaning and allow it to cool before storage.

Care & storage

- Remove styling product residue from the cooled barrel using approved materials.
- Inspect the cord, plug, handle, and temperature controls regularly.
- Avoid wrapping the power cord tightly around the tool.
- Store the fully cooled curler in a dry, safe place.

Common mistakes to avoid

- Selecting excessive heat for the hair type or condition.
- Holding hair against the heated surface longer than recommended.
- Using the device near water or with wet hands.
- Storing the curler before it has cooled completely.

Disclaimer: This SOP is prepared from general information available on the internet. For detailed instructions, refer to the manufacturer's original manual / file.

Prepared by - Subodh Kumar