Hair Clipper



Category: **Beauty, Wellness & Fitness** Type: **Full SOP** Priority: **High** 2 labs

Covers these lab items: Clippers

What it is used for

A hair clipper trims or cuts hair using powered moving blades and interchangeable guards. Use clean, intact blades and the correct guard setting to achieve an even cut while preventing skin injury.

Main parts

- Clipper body and power switch
- Moving and stationary blade set
- Interchangeable cutting guards or combs
- Battery or power cord and charging connection
- Blade adjustment lever, if fitted
- Cleaning brush and blade lubricant

Before you start

1. Inspect the clipper body, blades, guard, and power connection for damage.
2. Confirm the battery is charged or the power supply is suitable.
3. Clean and disinfect the clipper and compatible guards between clients.
4. Check the blade alignment and ensure the blade set is securely fitted.
5. Ask about scalp sensitivity, skin irritation, and areas requiring special care.
6. Wash hands and prepare a clean workstation and required PPE.

How to use

1. Choose a guard length suitable for the requested haircut.
2. Switch off the clipper before attaching or changing the guard.
3. Fit the guard securely and check that the blade moves freely.
4. Switch on the clipper and verify normal operation and sound.
5. Hold the clipper with a firm, comfortable grip.
6. Trim in controlled strokes, following the hair growth pattern as appropriate.
7. Use shorter, gentle strokes around ears, neckline, and sensitive areas.
8. Remove loose hair from the blade area as needed, with the clipper switched off.
9. Check the cut for evenness and adjust the guard only after switching off.
10. Switch off the clipper when the haircut is complete.
11. Remove hair clippings and clean and disinfect reusable accessories.
12. Apply blade lubricant only as specified by the manufacturer.
13. Store the clipper and guards in a clean, dry place.

⚠ Safety

- Only trained users should operate the clipper professionally.
- Do not use a clipper with damaged blades, guards, or electrical insulation.
- Keep fingers, loose clothing, and cords away from moving blades.
- Do not press blades hard against the skin or use them on irritated skin.
- Switch off and disconnect the clipper before cleaning or blade changes.
- Use a new or properly disinfected compatible attachment for each client.

Care & storage

- Brush away hair after each use.
- Clean and disinfect compatible guards and contact surfaces between clients.
- Lubricate blades according to the manufacturer's instructions.
- Inspect blades, battery, cord, and charging port regularly.
- Replace dull or damaged blades with approved parts.

Common mistakes to avoid

- Using the wrong guard length for the requested cut.
- Applying excessive pressure and irritating or cutting the skin.
- Sharing guards without proper cleaning and disinfection.
- Cleaning or adjusting the blades while the clipper is running.

Disclaimer: This SOP is prepared from general information available on the internet. For detailed instructions, refer to the manufacturer's original manual / file.

Prepared by - Subodh Kumar