Induction Cooktop



Category: **Food Processing & Kitchen** Type: **Full SOP** Priority: **High** 2 labs

Covers these lab items: Induction cooker; Induction Cooktop

What it is used for

An induction cooktop heats compatible cookware using an electromagnetic field for cooking or warming food. Use suitable cookware, keep the cooking surface clear and dry, and follow the manufacturer's operating instructions.

Main parts

- Glass-ceramic cooking surface
- Induction coil and internal electronics
- Power control and display panel
- Temperature or power-level controls
- Timer and safety lock, if fitted
- Power cord and plug

Before you start

1. Place the cooktop on a flat, stable, heat-resistant surface.
2. Inspect the cooking surface, power cord, plug, and controls for damage.
3. Confirm the cookware is induction-compatible and has a flat base.
4. Ensure the air inlet and outlet are clear and the surrounding area is dry.
5. Keep paper, cloth, plastic, and other combustible items away from the cooking zone.
6. Check the required power supply and review the manufacturer's instructions.

How to use

1. Place compatible cookware centrally on the designated cooking zone.
2. Add the food or liquid to the cookware before heating as appropriate.
3. Connect the cooktop to the recommended power supply.
4. Switch on the unit and select the required cooking zone, if applicable.
5. Set a suitable power level or temperature using the controls.
6. Monitor the cooking process and adjust settings as needed.
7. Use suitable utensils and avoid touching the hot cookware or cooking surface.
8. Use the timer or safety lock when appropriate and available.
9. Switch off the cooking zone when cooking is complete.
10. Remove cookware carefully using suitable heat protection.
11. Switch off and unplug the unit if required before cleaning or storage.
12. Allow the surface to cool, then clean it using an approved method.
13. Check that the cooking area is dry and store the unit safely.

⚠ Safety

- Use only cookware compatible with induction cooking.
- Do not operate the cooktop with cracked glass or damaged wiring.
- Keep water away from electrical connections and do not immerse the unit.
- The cooking surface and cookware may remain hot after switching off.
- Do not place metal objects, foil, or unsuitable containers on the cooking zone.
- Keep ventilation openings clear and follow the specified electrical load requirements.

Care & storage

- Clean spills after the surface has cooled sufficiently.
- Use cleaning products approved for the glass-ceramic surface.
- Keep ventilation openings free from dust and grease.
- Inspect the cord, plug, and surface regularly for damage.
- Disconnect power before cleaning areas near electrical components.

Common mistakes to avoid

- Using cookware that is not induction-compatible.
- Blocking the ventilation openings or placing the unit on an unstable surface.
- Touching the cooking surface immediately after use.
- Cleaning with abrasive tools or pouring water over the electrical unit.

Disclaimer: This SOP is prepared from general information available on the internet. For detailed instructions, refer to the manufacturer's original manual / file.

Prepared by - Subodh Kumar